



AVALANCHE® DOUBLE AUGER GRAIN CART MODEL 2096

Serial Number B40680100 & Higher

Part No. 294486

Foreword

This symbol identifies important safety messages. When you see it, read the message that follows and be alert to the possibility of personal injury.

Remember, safety instructions stated in this manual are for your protection. Read them carefully and follow them closely when working around or using this machine.

Read and study this manual completely before attempting to operate this implement. Take this manual to the field for handy reference when operating, adjusting, or servicing your machine.

When referenced, "Right-Hand" (RH) and "Left-Hand" (LH) side of the machine are determined by standing behind the machine and facing in the direction of travel.



Product Information

When ordering parts or when requesting further information or assistance, always give the following information:

- Machine name
- Model number
- Serial number

All products manufactured by Unverferth Mfg. Co., Inc. are warranted to be free from material and workmanship defects for one full year from time of consumer delivery. Your local dealer will gladly assist you with any warranty questions.

Please fill out and retain this portion for your records. The serial number decal is located at the left-front corner of your grain cart.

| Purchase Date | Model | Serial No |
|----------------|------------------------|-----------|
| Dealer | City | |
| Dealer Contact | P | Phone |
| | SERIAL NUMBER DECAL LO | |

IMPORTANT

• The information, specifications, and illustrations in the manual are based on information available at the time it was written. Due to continuing improvements in the design and manufacture of Unverferth products, all specifications and information contained herein are subject to change without notice.

Section I Safety

| General Hazard Information | 1-2 |
|-------------------------------|------|
| Safety Decals | |
| Following Safety Instructions | 1-7 |
| Before Operating | 1-7 |
| Before Servicing | |
| During Operation | 1-9 |
| Before Transporting | 1-9 |
| During Transport | 1-9 |
| Driveline Safety | |
| Pressurized Oil | |
| Preparing for Emergencies | |
| Wearing Protective Equipment | 1-12 |
| | |

Section II Set Up

| Set Up Checklist | |
|--|-----|
| Basic Cart Set Up | 2-3 |
| Hydraulic System | |
| Wheel/Tire Set Up | |
| Tire Pressure | 2-4 |
| Wheel Nuts | 2-4 |
| PTO Brackets Removal | 2-5 |
| SMV Emblem & SIS Decal | 2-5 |
| Video System (Optional) | 2-5 |
| Driveline Set Up | |
| Coupling the Cut-Out Clutch | |
| Upper Ladder Extension to Operating Position | 2-7 |
| Jack | 2-8 |
| Optional Hydraulic Jack | |
| Horizontal Cleanout Door Inspection | |
| Steering Tandem Switch Box Connection | |
| Steering Tandem Set Up | |
| Axle Suspension System Set Up | |
| Belt Engagement | |
| Operational Check | |
| | |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Section III Operation

| Operating Checklist | . 3-2 |
|---|--------|
| Preparing Tractor | . 3-2 |
| Preparing Cart | . 3-3 |
| Lubrication | . 3-4 |
| Video System (Optional) | . 3-4 |
| Hitching to Tractor | |
| Drawbar Connection | . 3-5 |
| Jack Usage | . 3-6 |
| Optional Hydraulic Jack Usage | . 3-7 |
| Transport Chain Connection | . 3-8 |
| Hydraulic Connections | . 3-9 |
| Towing | . 3-11 |
| Electrical Connections | . 3-12 |
| Optional Implement Brake Connection | . 3-12 |
| Optional Electric Over Hydraulic Operation (EOH) 5 Function | . 3-13 |
| Manual Override for Optional Electric Over Hydraulic System | . 3-16 |
| Electric Over Hydraulic 5 Function Troubleshooting | . 3-18 |
| Vertical & Horizontal Cleanout Door Operation | |
| Vertical Cleanout Door | . 3-20 |
| Horizontal Cleanout Door | . 3-22 |
| Auger Operation | |
| PTO Driven Auger | . 3-24 |
| Auger Overload Procedure | . 3-25 |
| Vertical Auger Fold | . 3-26 |
| Steering Tandem | . 3-27 |
| Ladder Operation | . 3-28 |
| Weather Guard Tarp | . 3-32 |
| | |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Section IV Maintenance

| Lubrication |
|---|
| Hydraulic System - Purge Hydraulic System |
| Hydraulic System - Relieving Hydraulic Pressure 4-6 |
| Bleeding Procedure for Braking System 4-7 |
| Steering Tandem Maintenance |
| Steering Tandem Linkage Adjustment Procedures 4-10 |
| Center Linkage Adjustment 4-10 |
| Side Linkage Adjustment 4-11 |
| Steering Indicator Adjustment Procedures 4-13 |
| Steering Tandem Rockshaft Replacement 4-14 |
| Auger Driveline Bearings |
| Gearbox with Sight Glass |
| Driveline Removal 4-19 |
| Clamping Cone Assembly 4-19 |
| Seasonal Storage |
| Auger System |
| Vertical Auger 4-21 |
| Vertical Auger Timing 4-22 |
| Horizontal Auger |
| Horizontal Auger Height Measurement 4-23 |
| Hanger Bearing Height Adjustment 4-24 |
| Baffle Adjustment |
| 5-Pin Driver Replacement |
| Belt Tightener Adjustment 4-34 |
| V-Belt Alignment 4-35 |
| Split Tapered Bushings 4-35 |
| Verify Telescoping PTO Shaft Length |
| PTO Shaft & Clutch 4-38 |
| PTO Quick Disconnect |
| Tarp Troubleshooting Inspection & Maintenance |
| Electrical System Schematic |
| Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 |
| Braking System Schematic |
| Wheels & Tires |
| Wheel Nut Torque Requirements 4-47 |
| Tire Pressure |
| Tire Warranty |
| Torque Chart - Hardware Grade 5 4-51 |
| Torque Chart - Hardware Grade 8 4-52 |
| Hydraulic Fittings - Torque and Installation |
| |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. |
| FOR LILLARVERT INFORMATION. DEFARE REFER TO VOUR LILLARVERT MANUAL |

FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Section V Parts

| Please visit www.unverferth.com/parts/ for the most current pa | rts listing. |
|---|--------------|
| Decals | |
| Touch-Up Paint | 5-7 |
| Vertical Auger Flighting Components | 5-8 |
| Horizontal Auger Components | 5-10 |
| Hopper Flow Door Components | |
| Flow Door Components | 5-14 |
| Indicator Assembly | 5-16 |
| Steering Tandem Indicator Components | 5-18 |
| Clean Out Door Components | 5-20 |
| Ladder Components | |
| Hitch & Tongue Components | |
| Suspension Link Components | |
| Suspension Link To Hub Components | |
| Suspension Linkage Components | |
| Suspension Link Grease Bank Components | |
| Steering Tandem Internal Bracing Components | |
| Track Internal Bracing Components | |
| Sideboard Components | |
| Steering Tandem Wheels & Tires | |
| Optional Brake Components | |
| Steering Tandem Hydraulic Suspension Components | |
| Steering Hydraulic Plumbing Components | |
| Steering Tandem Hub Components | |
| Track Axle Mounting Components | 5-47 |
| EOH Valve Functions & Wire Locations 5 Spool | |
| EOH Valve Assembly Components 5 Spool (Optional) | |
| EOH Tractor Circuit Hydraulic Components (Optional) | |
| Flow Door Circuit Hydraulic Components | |
| Auger Tilt Hydraulic Components | |
| Auger Fold Hydraulic Components | |
| EOH Spout Rotate & Tilt Hydraulic Components (Optional) | |
| Cylinders | |
| Gearbox Components Electrical Components - 5 Function Control Grip | |
| Cut Out Clutch PTO Assembly | |
| Cut Out Clutch Components | |
| Lower Auger Linkage Components | |
| Lower Auger Door & Cover Components | |
| Auger Tube Components | |
| Auger Grease Bank Components | |
| Switch Assembly Components for Rotating Spout Option | |
| Downspout Components | |
| Weather Guard Tarp Components | |
| Hydraulic Jack (Optional) - Kit #294143B | |
| Video System Option | |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. | |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | |
| FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUA | |
| FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP M | |
| FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER D | ELIVERY |
| SYSTEM MANUAL. | |

Notes

Section I Safety

| General Hazard Information | 1-2 |
|-------------------------------|-------|
| Safety Decals | 1-3 |
| Following Safety Instructions | 1-7 |
| Before Operating | 1-7 |
| Before Servicing | 1-8 |
| During Operation | 1-9 |
| Before Transporting | 1-9 |
| During Transport | 1-9 |
| Driveline Safety | .1-10 |
| Pressurized Oil | .1-11 |
| Preparing for Emergencies | .1-12 |
| Wearing Protective Equipment | |
| | |

General Hazard Information

No accident-prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

A large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the field, or in the industrial plant, can be safer than the person who is at the controls. If accidents are to be prevented--and they can be prevented--it will be done by the operators who accept the full measure of their responsibility.

It is true that the designer, the manufacturer, and the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that, "the best kind of a safety device is a careful operator." We, at Unverferth Mfg. Co., Inc. ask that you be that kind of operator.

REMEMBER: THINK SAFETY A CAREFUL OPERATOR IS THE BEST INSURANCE AGAINST AN ACCIDENT!



SIGNAL WORDS



INDICATES AN EXTREMELY HAZARDOUS SITUATION OR ACTION THAT WILL RESULT IN SERIOUS INJURY OR DEATH.



INDICATES A HAZARDOUS SITUATION OR ACTION THAT COULD RESULT IN SERIOUS INJURY OR DEATH.

A CAUTION

INDICATES AN UNSAFE SITUATION OR ACTION THAT MAY RESULT IN PERSONAL INJURY.

IMPORTANT

Is used for instruction on operating, adjusting, or servicing a machine.

Safety Decals



 REPLACE LOST, DAMAGED, PAINTED, OR UNREADABLE DECALS IMMEDIATELY. IF PARTS THAT HAVE DECALS ARE REPLACED, ALSO MAKE SURE TO INSTALL NEW DECALS. THESE DECALS INFORM AND REMIND THE OPERATOR WITH OPERATIONAL INFORMATION AND SAFETY MESSAGES.









1-7

Brent 2096 — Safety

Following Safety Instructions

- Read and understand this operator's manual before operating.
- All machinery should be operated only by trained and authorized personnel.
- To prevent machine damage, use only attachments and service parts approved by the manufacturer.
- Always shut tractor engine off and remove key before servicing.
- Avoid personal attire such as loose fitting clothing, shoestrings, drawstrings, pants cuffs, long hair, etc., that may become entangled in moving parts.
- Do not allow anyone to ride on the implement. Make sure everyone is clear before operating machine or towing vehicle.
- Never attempt to operate implement unless you are in the driver's seat.
- Never enter a cart containing grain. Flowing grain traps and suffocates victims in seconds.
- This unit may be equipped with a hydraulic brake system. Pull only with a power source equipped with an ISO:5676 compatible hydraulic brake coupler. Failure to use correct coupler may result in brake lockup. Damage due to brake lockup is not covered under warranty.

Before Operating

- Do not stand between towing vehicle and implement during hitching.
- Always make certain everyone and everything is clear of the machine before beginning operation.
- Verify that all safety shields are in place and properly secured.
- Ensure that all applicable safety decals are installed and legible.
- When working around the implement, be careful not to be cut by sharp edges.
- Secure drawbar pin with safety latch and lock tractor drawbar in fixed position.
- Add sufficient ballast to tractor to maintain steering and braking control at all times. Do not exceed tractor's lift capacity or ballast capacity.











Before Servicing

Avoid working under an implement; however, if it becomes absolutely unavoidable, • make sure the implement is safely blocked.



- Ensure that all applicable safety decals are installed and legible. •
- When working around the implement, be careful not to be cut by sharp edges.
- To prevent personal injury or death, always ensure that there are people who remain • outside the cart to assist the person working inside, and that all safe workplace practices are followed. There are restricted mobility and limited exit paths when working inside the implement.
- Secure drawbar pin with safety lock and lock tractor drawbar in fixed position. •
- Explosive separation of a tire and rim can cause serious injury or death. Only properly trained personnel should attempt to service a tire and wheel assembly.

During Operation

- Regulate speed to field conditions. Maintain complete control at all times.
- Never service or lubricate equipment when in operation.
- Keep away from overhead power lines. Electrical shock can cause serious injury or death.



- Use extreme care when operating close to ditches, fences, or on hillsides.
- Do not leave towing vehicle unattended with engine running.

Before Transporting

- Secure transport chain to towing vehicle before transporting. DO NOT transport without chain.
- Check for proper function of all available transport lights. Make sure that all reflectors are clean and in place on machine. Make sure the SMV emblem and SIS decals are visible to approaching traffic.
- This implement may not be equipped with brakes. Ensure that the towing vehicle has adequate weight and braking capacity to tow this unit.

During Transport

- Comply with all laws governing highway safety when moving machinery.
- Use transport lights as required by all laws to adequately warn operators of other vehicles.
- Use good judgment when transporting equipment on highways. Regulate speed to road conditions and maintain complete control.
- Maximum transport speed of this implement should never exceed 20 m.p.h. as indicated on the machine. Maximum transport speed of any combination of implements must not exceed the lowest specified speed of the implements in combination. Do not exceed 10 m.p.h. during off-highway travel.
- Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.
- Do not transport grain cart on roads while loaded.
- It is probable that this implement is taller, wider and longer than the towing vehicle. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Driveline Safety

• Do not allow children near equipment that is running or engaged.



- Do not exceed 1000 r.p.m. PTO speed.
- Disengage the PTO, stop the tractor engine, and remove key from ignition before making inspections, or performing maintenance and repairs.
- Inspect the driveline, quick disconnect, overload shear-bolt limiter or clutch, and shielding often. Repair immediately. Use replacement parts and attaching hardware equivalent to the original equipment. Only alterations described in this manual for overall length adjustment are allowed. Any other alteration is prohibited.
- Avoid excessively long hardware or exposed and protruding parts which can snag and cause entanglement.
- Lubricate the driveline as recommended in the MAINTENANCE section.
- Keep hoses, wiring, ropes, etc. from dangling too close to the driveline.
- Install driveline and shields according to recommended lengths and attaching methods with recommended hardware. The driveline shield should rotate independently a full rotation and telescope freely. The retaining chain must be secured to the implement safety shield.
- Adjust drawbar to height and length recommended in OPERATION section.
- Use caution when turning to avoid contact between tractor tires and driveline.
- Check the length of the telescoping members to insure the driveline will not bottom out or separate when turning and/or going over rough terrain.
- Proper extended and collapsed lengths of the telescoping PTO shaft must be verified before first
 operation with each and every tractor. If the extended length of the PTO shaft is insufficient, it may
 become uncoupled during operation and cause serious injury or death from contact with uncontrolled flailing of PTO shaft assembly components.

Pressurized Oil

- Relieve the hydraulic system of all pressure before adjusting or servicing. See hydraulic power unit manual for procedure to relieve pressure.
- High-pressure fluids can penetrate the skin and cause serious injury or death. Use cardboard or wood to detect leaks in the hydraulic system. Seek medical treatment immediately if injured by high-pressure fluids.



- Accumulators used in this hydraulic system can retain fluid under pressure even after tractor hydraulic valve is placed in FLOAT. See tractor operators manual for procedure to relieve pressure.
- Hydraulic system must be purged of air before operating to prevent serious injury or death.
- Do not bend or strike high-pressure lines. Do not install bent or damaged tubes or hoses.
- Repair all oil leaks. Leaks can cause fires, personal injury, and environmental damage.
- Route hoses and lines carefully to prevent premature failure due to kinking and rubbing against other parts. Make sure that all clamps, guards and shields are installed correctly.
- Check hydraulic hoses and tubes carefully. Replace components as necessary if any of the following conditions are found:
 - o End fittings damaged, displaced, or leaking.
 - o Outer covering chafed/cut or wire reinforcing exposed.
 - o Outer covering ballooning locally.
 - o Evidence of kinking or crushing of the flexible part of a hose.

Preparing for Emergencies Keep a first aid kit and properly rated fire extinguisher nearby. Keep emergency numbers for fire, rescue, and poison control personnel near the phone.





Section II Set Up

| Set Up Checklist | |
|--|------|
| Basic Cart Set Up | .2-3 |
| Hydraulic System | |
| Wheel/Tire Set Up | .2-4 |
| Tire Pressure | .2-4 |
| Wheel Nuts | .2-4 |
| PTO Brackets Removal | .2-5 |
| SMV Emblem & SIS Decal | .2-5 |
| Video System (Optional) | .2-5 |
| Driveline Set Up | .2-6 |
| Coupling the Cut-Out Clutch | .2-6 |
| Upper Ladder Extension to Operating Position | |
| Jack | |
| Optional Hydraulic Jack | .2-8 |
| Horizontal Cleanout Door Inspection | 2-10 |
| Steering Tandem Switch Box Connection | |
| Steering Tandem Set Up | 2-14 |
| Axle Suspension System Set Up | |
| Belt Engagement | |
| Operational Check | |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Set Up Checklist

After the cart has been completely assembled, use the following checklist and inspect the cart. Check off each item as it is found satisfactory or after proper adjustment is made.

- □ Set or Calibrate tractor PTO control engagement to MINIMUM setting. Refer to tractor operator's manual for setting information.
- □ Remove auger spout cylinder stop.
- □ Remove PTO brackets.
- □ Torque wheel nuts and check tire pressure as specified in MAINTENANCE section.
- □ Verify track has been aligned and is properly conditioned. (If applicable)
- □ Inflate tires to specified air pressure. (if applicable)
- Lubricate all grease fittings and check gearbox oil level.
- □ Inspect cleanout door assembly for play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section.
- □ Verify all safety decals are correctly located and legible. Replace if damaged.
- □ Verify all reflective decals are correctly located.
- □ Check SMV decal and SIS decals are in place, clean and visible.
- □ Verify transport lights are working properly.
- □ Verify PTO length, see "Verify Telescoping PTO Shaft Length" in MAINTENANCE section.
- □ Align and properly tension belts/chains. See "Belt Tightener Adjustment" and "V-Belt Alignment" in MAINTENANCE section.
- □ Ensure safety screens over horizontal auger are in place and properly secured.
- □ Install transport chains and torque hardware to specification. See "Transport Chain Connection" in OPERATION section.
- □ Paint all parts scratched in shipment.
- □ Test run the augers. See "Auger Operation" in OPERATION section.

Basic Cart Set Up

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERI-OUS INJURY OR DEATH.
- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO THE TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRAC-TOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUP-PORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 200 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

Due to shipping requirements and various dealerinstalled options, some initial cart setup will be required after it arrives from the factory. Use the following procedures as needed for initial cart setup.



Hydraulic System

Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.

Wheel/Tire Set Up

Tire Pressure

Tire pressure must be verified before first use and adjusted as necessary. Refer to MAINTENANCE section of this manual for information on tire pressure.

Wheel Nuts

A CAUTION

• IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CON-TROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGULARLY. SEE TORQUE PAGE IN THE "MAINTENANCE" SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

Installing wheels without the proper inset/offset could result in hub or spindle failure. This
will cause substantial damage to cart and is not covered by warranty. Inset/offset will vary
depending on tire size. Consult dealer for proper inset/offset.

Brent 2096 — Set Up

Basic Set Up (continued)

PTO Brackets Removal

Remove the PTO assembly and PTO brackets on the tongue, before operating the auger tilt or when connecting the driveline assembly to the tractor. Keep PTO brackets for seasonal storage. Refer to "Seasonal Storage" in MAINTENANCE section.

IMPORTANT

• PTO assembly and PTO brackets must be removed before operating the auger tilt or when connecting the driveline assembly to the tractor. Failure to remove PTO assembly and PTO brackets will result in damage to the PTO assembly, tongue, auger and tractor.





Remove SMV emblem and reattach

with reflective side facing outward.

SMV Emblem & SIS Decal

The reflective surface of the SMV must face rearward. This may require removal of film protecting the reflective surface or removing and reinstallation of the SMV.

When reinstalling the SMV make sure that it is mounted with the wide part of the SMV at the bottom.

For the SIS decals (one on the front and one on the rear of the cart) make sure both decals are clean and visible.



Video System (Optional)

The video system includes its own installation instruction sheet. Reference the provided instruction sheet.

Driveline Set Up

Clean and grease the Implement Gearbox splined shaft. Gearbox shaft guard has access doors for installing and removing of driveline.

A DANGER

• ENTANGLEMENT WITH THE DRIVELINE WILL CAUSE SERIOUS INJURY OR DEATH. KEEP ALL GUARDS AND SHIELDS IN GOOD CONDITION AND PROPERLY INSTALLED AT ALL TIMES. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOE STRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC. THAT CAN BECOME EN-TANGLED IN A ROTATING DRIVELINE.

Coupling The Cut-Out Clutch

Engage PTO drive shaft onto implement PTO shaft until retaining groove of implement PTO shaft aligns with clamping cone hole. Insert clamping cone into threaded hole, hand tighten. Torque cone to 75 ft.-lb. (Fig. 2-1)

<u>NOTE</u>: See MAINTENANCE section - PTO Quick Disconnect - for disassembly instructions.



Upper Ladder Extension to Operating Position



- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFOCATES VICTIMS IN SECONDS.
- <u>NOTE</u>: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.
- <u>NOTE</u>: To change ladder assembly positions, refer to "Ladder Operation" in the OPERATION section.
- 1. Move the upper ladder extension (289707B) from shipping position by removing the 5/16"-18UNC x 3/4" carriage bolts (9388-024), 5/16" flat washers (9405-064) and 5/16"-18UNC lock nuts (9008441). Keep hardware for next step. (FIG. 2-2)



- 2. Using hardware from step 1, attach upper ladder extension to the higher set of holes to be in operating position. (FIG. 2-2 & FIG. 2-3)
- 3. Torque hardware to 17 ft.-lbs.



Jack

A WARNING

 UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. AL-WAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTEND-ED TO SUPPORT AN EMPTY CART ONLY.

Attach jack to left-inside frame using pin and hair pin. Pivot the jack 90 degrees and reinstall pin for field use.



Optional Hydraulic Jack

1. Assemble hoses (9006068) and fittings to cylinder (9006422) as shown in figure 2-4. The valve needs to be assembled to the hose on the base end of the cylinder. Assemble the fittings on the cylinder so they face each other, then store the hydraulic hoses on the hose caddy.



Brent 2096 — Set Up

Basic Cart Set Up (continued)

Optional Hydraulic Jack (continued)

- Assemble the cylinder (9006422) and jack foot (271723B) to the jack weldment (271712B) as shown in figure 2-5 using capscrew (9390-197) and locknut (92199).
- 3. Torque hardware to 25 ft.-lbs.

- Mounting bracket (273808B) must be attached to the jack weldment (271712B) using 1"-8UNC x 7" capscrew (9390-197) and 1"-8UNC locknut (92199), before mounting to the tongue of the cart. Then attach the mounting bracket (273808B) to the back side of the front hitch plate with two 7/8"-9UNC x 2 1/4" capscrews (9390-165). See figure 2-6.
- 5. Torque hardware to 25 ft.-lbs.

- 6. Line up the base end of the cylinder with the lug on the top of the tongue and assemble the cylinder pin (272587) and snap rings (91192) shown in figure 2-7.
- 7. Cycle the hydraulic cylinder several times to ensure that the air is purged from the cylinder.







Horizontal Cleanout Door Inspection

A WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.
- <u>NOTE</u>: For cleanout door assembly operation, refer to "Vertical & Horizontal Cleanout Door Operation" in the OPERATION section.
- <u>NOTE</u>: This procedure is a **two-person** process. One person operates the tensioner handle while the second person inspects the horizontal cleanout doors.
- Park the unit on a firm, level surface. Block the wheels/tracks on the machine to keep the unit from moving. Set the vehicle parking brake, shut off the engine and remove the ignition key.
- 2. Use the tensioner handle, located on the lefthand side of the grain cart, behind the first panel to open and close the horizontal cleanout doors.
- 3. Insert tensioner handle into cleanout door receiver coupler on the rear panel, and remove lynch pin from rockshaft. Keep lynch pin.
- 4. Rotate tensioner handle clockwise to open the doors. (Fig. 2-8 & 2-9)
- 5. Clean the door area of debris that may prevent the door from shutting completely. (Fig. 2-8 & 2-9)
- Inspect the cleanout door and rockshaft for loose hardware. Do not torque hardware. (Fig. 2-8 & 2-9)

(Continued on next page.)



Horizontal Cleanout Door Inspection

- 7. If plate insert needs adjustment, loosen the two flat head machine screws holding the plate in position. (Fig. 2-10)
- 8. Ensure the plate inserts are aligned and fit into the belly pan cut-outs. (Fig. 2-10)
- <u>NOTE</u>: As the tensioner handle is rotated counterclockwise near the end of the close position, the coiled springs will extend to apply pressure to cleanout doors. If the doors do not close or visual door perimeter gaps are present, adjust the front to rear rockshaft starting at step 9. If doors close, go to step 13.
- 9. Loosen all the hardware in the slotted brackets connecting the cleanout door rockshaft to the grain cart tube. (Fig. 2-11)
- 10. Starting at the front of the cart, using a jack, push the rockshaft up and toward the runner tube. (Fig. 2-11)
- <u>NOTE</u>: Ideal distance between the runner tube and rockshaft is 3 1/4".
- 11. When the rockshaft is in position, torque the hardware previously loosened to 28 ft.-lbs.
- 12. Continue repositioning the rockshaft moving toward the back of the cart.





Brent 2096 — Set Up

Basic Cart Set Up (continued)

Horizontal Cleanout Door Inspection

- Rotate the tensioner handle counter-clockwise to close the doors allowing the plate to fit and seal into the belly pan opening. (Fig. 2-12 & 2-13)
- 14. Open the doors and torque plate hardware to 17 ft.-lbs. (Fig. 2-13)
- 15. Close the doors and ensure all doors seal. (Fig. 2-13)
- 16. Insert lynch pin into rockshaft and return handle to storage location.



Brent 2096 — Set Up



Steering Tandem Set Up

The unit may have been shipped with axle suspension lowered to decrease shipping height. The unit will need to have hydraulic fluid added to raise the unit to operating height. Measure suspension to set cart height. If using tractor for filling or removing fluid from the suspension, always monitor supply fluid level before, at intervals during and after the procedure. Only adjust or service suspension system with empty cart.

Axle Suspension System Set Up

IMPORTANT

- The following procedure is only to be performed when the cart is empty.
- 1. With cart on a level surface, secure tongue by hooking to tractor or by securing to the floor.
- 2. Make sure the auger is folded in the transport position and the grain cart is empty.
- Attach the tensioner hose assembly to the tractor couplers. Next, attach the single end to the valve on top of the left hand front suspension cylinder. (Fig. 2-15)
- 4. Open valve atop of the front suspension cylinders. (Fig. 2-15)

NOTE: Handle 90° to valve is closed.

- 5. Use the tractor valve to raise the left front and left rear cylinders. Cycle through to remove air out of the system.
- Adjust stroke until the average distance between the front and back cylinders is 7 9/16 inches. Measuring from gland of cylinder body to rod end plate edge. (Fig. 2-16)
- 7. Close valve on left, front cylinder by turning the handle 90° to the valve.
- 8. Move single end of hose assembly from left front cylinder valve to right front cylinder valve.
- 9. Repeat steps 4 through 7 for right side of axle suspension.



Belt Engagement



• MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

The unit is shipped without the tension applied to the belts. To engage the tensioner, use the belt tensioner handle located on the left-hand side of the grain cart, behind the first panel. Verify the belts are correctly aligned and are seated in both sheaves. If belt hangs over edge of sheave, detention idler, adjust and retention idler. (Fig. 2-17 and 2-18)

<u>NOTE</u>: See MAINTENANCE section - V-Belt Alignment - for more details.



Operational Check

A WARNING

• MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SE-CURELY FASTENED BEFORE OPERATING UNIT.

IMPORTANT

 Before running the auger pivot, the vertical auger clean-out door must be closed to prevent machine damage.

Once set-up has been completed, run the cart to check for operation and functionality:

- 1. Lights Work, Turn, Brake
- 2. Flow Door
- 3. Flow Door Indicator
- 4. Auger Fold
- 5. Auger Pivot
- 6. Spout Rotate & Pivot (if applicable)
- 7. Auger Startup & Shut-down
- 8. Steering (if applicable)
- 9. Brakes (if applicable)




Section III Operation

| Operating Checklist | .3-2 |
|---|-------|
| Preparing Tractor | .3-2 |
| Preparing Cart | .3-3 |
| Lubrication | |
| Video System (Optional) | .3-4 |
| Hitching to Tractor | |
| Drawbar Connection | .3-5 |
| Jack Usage | .3-6 |
| Optional Hydraulic Jack Usage | .3-7 |
| Transport Chain Connection | .3-8 |
| Hydraulic Connections | .3-9 |
| Towing | .3-11 |
| Electrical Connections | .3-12 |
| Optional Implement Brake Connection | .3-12 |
| Optional Electric Over Hydraulic Operation (EOH) 5 Function | .3-13 |
| Manual Override for Optional Electric Over Hydraulic System | .3-16 |
| Electric Over Hydraulic 5 Function Troubleshooting | .3-18 |
| Vertical & Horizontal Cleanout Door Operation | |
| Vertical Cleanout Door | .3-20 |
| Horizontal Cleanout Door | .3-22 |
| Auger Operation | |
| PTO Driven Auger | .3-24 |
| Auger Overload Procedure | .3-25 |
| Vertical Auger Fold | .3-26 |
| Steering Tandem | .3-27 |
| Ladder Operation | .3-28 |
| Weather Guard Tarp | .3-32 |
| | |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Operating Checklist

- Read and understand all safety precautions before operating cart.
- R.V. antifreeze needs to be completely flushed from the Water Delivery System and disposed of properly. Make certain the Water Delivery System only contains water before placing the Water Delivery System in service. (If applicable)
- Set or Calibrate tractor PTO control engagement to MINIMUM setting. Refer to tractor operator's manual for setting information.
- □ Torque wheel nuts and check tire pressure as specified in MAINTENANCE section.
- □ Verify track has been aligned and is properly conditioned. (If applicable)
- □ Inflate tires to specified air pressure. (if applicable)
- Lubricate all grease fittings and check gearbox oil level.
- □ Inspect cleanout door assembly for play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section.
- Test operation and functionality of flow door indicator, auger fold, auger pivot, spout rotate, and spout tilt.
- □ Verify all reflective decals are correctly located.
- Check SMV sign and SIS decals are clearly visible with the cart attached to the tractor.
- Verify transport lights are working properly. Check and follow all regulations before towing on a road or highway.
- Verify that hitch height and length when attached to the tractor are sufficient to prevent severe bends in PTO U-joint angles.
- □ Verify PTO length, see "Verify Telescoping PTO Shaft Length" in MAINTENANCE section.
- Align and properly tension belts/chains. See "Belt Tightener Adjustment" and "V-Belt Alignment" in MAINTENANCE section.
- □ Ensure safety screens over horizontal auger are in place and properly secured.
- Install transport chains and torque hardware to specification. See "Transport Chain Connection" in OPERATION section.
- □ Test run the augers. See "Auger Operation" in OPERATION section.

Preparing Tractor

Before operating cart, read the tractor Operator's Manual and gain an understanding of its safe methods of operation.

Check the tractor brakes and transport lights. Make sure they are in proper working order.

On carts equipped with optional hydraulic brake system, make sure the tractor is equipped with the components necessary for operating the cart's hydraulic brakes. Consult your tractors Operator's Manual or your tractor dealer for the appropriate brake control system.

Check if the tractor has multiple PTO engagement modulation settings and has the latest PTO engagement software from the OEM. If unsure, contact your local dealer for tractor capabilities and recommended setting for grain cart operation.

Check the tractor hydraulic oil reservoir and add oil if needed.

Verify that the tractor is adequately ballasted for drawbar operation at the anticipated draft load. See tractor manual for ballasting instructions.

If possible, adjust the tractor drawbar vertically so the topside of the drawbar is approximately 17-22 inches from the ground. Ensure that the drawbar is locked in the center position.

Preparing Tractor (continued)

<u>NOTE</u>: The grain cart hitch and tractor drawbar must be of the same Category. The cart comes standard with a Category 5 hitch. A Category 4 tongue is available. Contact your dealer for a CAT 4 tongue if required. Check that the drawbar is in the required 20" position and will adequately support loads.



• USE OF NON-MATCHING CATEGORY HITCH AND TRACTOR DRAWBAR CONNECTION WILL RESULT IN POOR HITCH PERFORMANCE AS WELL AS DAMAGE TO TRACTOR, IMPLEMENT OR BOTH.

Hitch pin sizes for each Category to help identify which Category drawbar you have.
Category 4 1-3/4" Dia. (50 mm)
Category 5 2-3/4 Dia. (70 mm)

On tractors equipped with a 3-point hitch, raise and secure the linkage to prevent interference with the cart tongue, hydraulic hoses and the hydraulic drive option during turning. It may be necessary to remove tractor 3-point quick attach to avoid damage during turning.

Preparing Cart

Perform the service checks below. Repair or replace any damaged or worn parts before operating.

Hardware

Check for loose bolts and nuts, and tighten as needed. Check again after the first half-day of operation.

Pivot Pins

Check that all pins are in place and in good condition. Replace any worn, damaged or missing pins.

Hitch

Check hitch wear plates for damage and wear. Be aware of the size of hitch adapter bushing that is being used. Select correct size for the hitch pin/draw bar you are using.

Auger

Inspect auger for damage and wear.

(Continued on next page)

Preparing Cart (continued)

Hydraulic System

Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.

Optional Hydraulic Brake System

On carts equipped with the optional hydraulic brake system, ensure hose is properly connected to the tractor's hydraulic trailer brake coupler. Consult your tractors Operator's Manual or your tractor dealer for more information.

Tires/Wheels

Check tire pressures and maintain at recommended values listed in the MAINTENANCE section of this manual.



 IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGU-LARLY. SEE TORQUE PAGE IN THE "MAINTENANCE" SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

Installing wheels without the proper inset/offset could result in hub or spindle failure. This will
cause substantial damage to cart and is not covered by warranty. Inset/offset will vary depending on tire size. Consult dealer for proper inset/offset.

For questions regarding new tire warranty, please contact your local original equipment tire dealer. **USED TIRES CARRY NO WARRANTY**. Tire manufacturers' phone numbers and web sites are listed in the MAINTENANCE section of this manual for your convenience.

Lubrication

Lubricate the cart as outlined in the MAINTENANCE section of this manual.

Video System (Optional)

IMPORTANT

Do not operate video system below 15°F. Damage to video system can occur.

The video system includes its own operation instruction sheet.

Hitching to Tractor

Drawbar Connection

This cart is intended to be hitched to a tractor drawbar. Do not attempt to hitch to any other location on the tractor other than the drawbar.

The cart comes with a CAT 4 hitch for use with a 1 1/2" pin and designed for a clevistype tractor drawbar. If a 1 1/2" or 1 3/4" diameter hitch pin is used, a corresponding bushing must be inserted into the hitch tang and held in place with o-rings. If a bushing is already in the hitch, use a punch and hammer to remove and replace with the correctly sized bushing. (Figure 3-1)

<u>NOTE</u>: Use of the proper hitch pin/bushing will prevent excessive wear and tear on both the cart and tractor.

<u>NOTE</u>: Bushings and o-rings are stored in the toolbox on the right-hand side of the cart.

Lock tractor drawbar in center position.

Set tractor drawbar length to 20" from the end of the tractor PTO shaft to center of hitch tang pinhole.



• DO NOT STAND BETWEEN TOWING VEHI-CLE AND IMPLEMENT WHEN HITCHING. ALWAYS ENGAGE PARKING BRAKE AND STOP ENGINE BEFORE INSERTING HITCH PIN OR SECURING LATCHES.

Place wear shoe (281663-CAT 3; 281898-CAT 4; 281899-CAT 5) between tractor hitch and grain cart hitch. (Figure 3-2)

After inserting drawbar pin, secure drawbar pin with a locking device to prevent uncoupling during use.

<u>NOTE:</u> Hitch tang can be flipped providing a drawbar connection height difference of 2 7/8" (Figure 3-3). Position the hitch tang to help assure a level cart when loaded, or the rear of the hopper slightly higher than the front, to maintain rear slope cleanout. Whenever the hitch tang is flipped, the driveline clearances need to be reviewed.





2 7/8" Higher Than The Standard Position



A WARNING

• UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRAC-TOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.

Jack Usage

Use jack to support an empty grain cart, never a loaded grain cart. Always have a loaded grain cart hooked to tractor. Attach jack to left inside frame using pin and hair pin. Pivot the jack 90 degrees and reinstall pin for field use. (Fig. 3-4)

IMPORTANT

• After cart is hitched to tractor, pivot jack to storage location. (Fig. 3-4 and 3-5)



Hitching to Tractor (continued)

Optional Hydraulic Jack Usage

A WARNING

• HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.

IMPORTANT

• After cart is hitched to tractor, attach hydraulic hoses to tractor and retract hydraulic cylinder to store hydraulic jack between the frame rails.

Use hydraulic jack to support an empty grain cart, never a loaded grain cart. Always have a loaded grain cart hooked to tractor.

Always close the manual valve for the hydraulic jack for in-field use and when unhitched from the tractor.

- 1. Remove hoses from storage slots.
- 2. Attach jack cylinder hose couplers to tractor.
- 3. Open valve to allow hydraulic flow.
- 4. Use tractor hydraulic valve to extend cylinder and lift tongue.
- 5. Once attached to tractor drawbar, retract cylinder to lower tongue and to raise jack into storage position.
- 6. Close valve and then disconnect hose couplers from tractor.



- 7. Place hose couplers into storage caddy. Be sure to route hoses to clear PTO driveline during operation.
- 8. Check for leaks.

Transport Chain Connection

CAUTION

- ALWAYS USE TRANSPORT CHAIN WHEN TRANSPORTING IMPLEMENTS. FAILURE TO USE A TRANSPORT CHAIN COULD CAUSE PERSONAL INJURY IF CART BECOMES DISENGAGED.
- REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED OR DAMAGED. DO NOT WELD TRANSPORT CHAIN.

Tractor must be equipped with a transport chain support. Always use intermediate support when connecting cart directly to a tractor. DO NOT use the intermediate chain support as the chain attaching point. Fig. 3-7 shows how the transport chain must be installed between cart and tractor.

The chain is rated for towing the grain cart empty on public roads. Never tow a loaded grain cart on public roads. Use only ASABE approved chains. Allow no more slack in chain than necessary to permit turning.



Hydraulic Connections

Clean hydraulic hose couplers before connecting to the tractor. For convenience, this unit is equipped with color hose grips attached to the hydraulic hoses. This will help in identifying the hose function and correct hook up. (FIG. 3-8)

For steering tandem, attach hydraulic hoses labeled "TURN LEFT" and "TURN RIGHT" into tractor hydraulic remote. Connect hydraulic hose "TURN LEFT" to extend port, and "TURN RIGHT" to retract port.

| Color | Function | |
|----------|-------------------------------|--|
| Red | Flow Door Open and Close | |
| Yellow | Spout Tilt In and Out | |
| Tan | Joystick or Spout Rotate | |
| Green | Auger Fold and Unfold | |
| Blue | Auger Pivot Up and Down | |
| Black | Jack Raise and Lower | |
| Orange | Water Pump | |
| Optional | Hydraulic Pressure and Return | |
| Optional | Steering Tandem | |
| Optional | Brakes | |

After initial set-up or replacement of any hydraulic component on the cart, air must be removed from the cart's hydraulic system. Reference "Hydraulic System - Purge Hydraulic System" section in the MAINTENANCE section.

Route hoses away from areas that may cause abrasion or kinking of hoses during operation.

(Continued on next page)

Hydraulic Connections

Before disconnecting hoses from tractor, place tractor in Park and shut PTO off, operate auger fold and tilt to the lowest positions. Where possible, remove hydraulic pressure loads and avoid potential pressure buildup in the lines from long storage periods such as upper auger not in rest position. If equipped with hydraulic jack, extend jack to desired position, turn valve to closed position. See tractor operator's manual for proper procedure to relieve pressure from the lines. After SCV pressures have been relieved and tractor engine is off, disconnect hoses from tractor. Install couplers into storage slots provided. (FIG. 3-8)



Towing

Even if the cart is equipped with brakes, ensure that the towing vehicle has adequate weight and braking capacity to tow this implement. See the towing vehicle manual for towing capacity. Never tow a loaded grain cart over public roads.

IMPORTANT

• To prevent damage to the cart brake system, manually release pressure from the cart hydraulic brakes if towing without a hydraulic brake equipped vehicle.

Maximum speed of cart should never exceed 20 m.p.h. Do not exceed 10 m.p.h. during off-highway travel. Do not exceed 8 m.p.h. when cart is fully loaded.

Secure drawbar pin with a locking device and lock tractor drawbar in centered position.

The PTO drive shaft needs to be placed in the storage position on the tongue or properly attached to the tractor. See "Coupling The Cut-Out Clutch" in SET UP section and "PTO Shaft and Clutch" in MAINTENANCE section before connecting the PTO drive shaft to the tractor.

Secure transport chain to tractor chain support before towing.

Tractor is required to be equipped with rear port to connect the grain cart brake hose which allows the cart brakes to engage when tractor brake pedals are depressed. If tractor doesn't have rear port, please contact your tractor dealer to purchase the OEM rear port option.

Verify brake operation/release before towing.



• THE STANDARD TRANSPORT CHAIN PROVIDED IS FOR THE BASIC CART WHEN TOWED EMPTY FOR ROAD TRAVEL.

Regulate speed to road conditions and maintain complete control.

It is probable that this cart is taller, wider and longer than the towing tractor. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.

Always have auger folded back into storage position when auger is not in use. (Fig. 3-9)



Electrical Connections

This cart is equipped with a seven-pin SAE connector plug which will connect with the receptacle found on most newer tractors. If your tractor does not have this type of receptacle, an SAE J-560 seven-point socket can be purchased from your Unverferth, dealer (Part number 92824).

<u>NOTE:</u> 7-pin connector must be plugged into the tractor in order for the spout system to operate.

The wiring schematic for this cart, shown in the MAINTENANCE section, complies with AS-ABE Standards. Always verify correct electrical function before using this cart.



This unit is equipped with Side Marker lights for enhanced visibility. These lights will have different functionality depending upon the tractor lighting selection.

If the tractor field lights switch is on; the Side Marker lights and the amber turn signal lights are on solid and will not flash.

If the flashers and/or turn signal is on; the Side Marker lights flash in unison with their respective side's amber turn lamp.

Compliance with all lighting and marking laws is the responsibility of the operator at the time of travel.

See federal regulation 49 CFR 562; available at www.govinfo.gov for US federal law requirements.

See your Unverferth dealer for additional brackets, reflectors, or lights to meet your requirements.

Optional Implement Brake Connection

Connector should comply with ISO:5676 standards. Brake hydraulic hose is designated with blue color band. See tractor's operators manual for connection location.

Optional Electric Over Hydraulic Operation 5 Function

Before operating cart, familarize yourself with the functions associated with the joystick controller by operating with an empty cart.

The joystick comes with a mounting pin allowing storage inside the tractor cab when not in use.

- 1. Connect the red wire from power harness (9008251) to a key-switched +12VDC power supply. (Fig. 3-11)
- NOTE: Consult the tractor's FIG. 3-11 RED Wire to +12VDC WHITE Wire operators manual for Key Switch to Ground proper connection to the Auxiliary Power Outlet in the tractor cab. 9008251 L-Series Control Grip 5 Function NOTE: 7-pin connector must be plugged into the tractor in order for the spout system to operate. 9008252 Kit #291491B 9007290 9007266
- 2. Connect the white wire from power harness (9008251) to ground. (Fig. 3-11)

Optional Electric Over Hydraulic Operation 5 Function (continued)

- 3. Connect the Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.
- 4. Place the remote in continuous detent so that the Hydraulic Pressure hose is pressurized and set the hydraulic flow to a maximum 6 gal/min to minimum 4 gal/min.
- To fold auger out from transport to operating position, push down the auger unfold button on joystick face until the upper and lower auger are engaged and fold linkage is over center. See Fig. 3-12.

<u>NOTE</u>: Joystick has a double tap feature, which allows the operator to quickly double tap a function in order to operate it for a set time. If the auger fold or auger unfold buttons are double tapped, the function will stay on for 60 seconds to complete the full cycle without holding the buttons down. Pressing either of those buttons during these timed cycles will CANCEL the cycle. This double tap feature only applies to auger fold and unfold functions.

- 6. To pivot spout OUT away from cart, push hat switch toward OUT. Hold the switch until desired position is achieved. See Fig. 3-12.
- 7. To pivot spout IN toward cart, push hat switch toward IN. Hold the switch until desired position is achieved. See Fig. 3-12.
- 8. To pivot the entire auger UP, press and hold the auger pivot UP button until the desired height is achieved. See Fig. 3-12.
- 9. To pivot the entire auger DOWN, press and hold the auger pivot DOWN button until the desired height is achieved. See Fig. 3-12.





Spout Centered Position

3-15

Manual Override for Optional Electric Over Hydraulic System

A WARNING

- MOVING OR ROTATING AUGER COMPONENTS CAN CAUSE SERIOUS INJURY OR MA-CHINE DAMAGE. BEFORE OPERATING MANUAL OVERRIDE(S), ENSURE EVERYONE IS AWAY FROM THE SPOUT AND THAT THE SPOUT WILL NOT CONTACT ANY OTHER PARTS OF THE GRAIN CART. ALL CONTROL SWITCHES ARE DEACTIVATED WHILE UTILIZING MANUAL OVERRIDE(S).
- MOVING OR ROTATING PTO COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT OPERATE PTO WHILE UTILIZING MANUAL OVERRIDE(S).
- <u>NOTE</u>: Manual override operation is intended for emergency use **ONLY** and is not intended for continuous operation.

<u>NOTE:</u> 7-pin connector must be plugged into the tractor in order for the spout system to operate.

- 1. Park the empty grain cart on a firm and level surface. Block the tires/tracks on the machine to keep it from moving. Set the tractor's parking brake.
- 2. Connect the Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.
- <u>NOTE</u>: Center rotating spout before activating auger fold.
- 3. To operate the manual override functions, place the tractor SCV remote in continuous detent so that the Hydraulic Pressure hose is pressurized.
- 4. Remove cover plate (272606B) from the bottom of the lower auger housing to access the EOH block assembly.
- 5. Push and hold the manual override button on valve (9008438). (FIG. 3-16)



Manual Override for Optional Electric Over Hydraulic System (continued)

- While holding the manual override button, operate the desired function on valve (9008416) & (9008463) by rotating the manual override knurled knob from the locked neutral position. (FIG. 3-17 & 3-18)
- 7. Push or pull the knob to operate the valve function in the desired direction. (FIG. 3-18)
- 8. Once the desired position is reached, release manual override button on valve (9008438).
- <u>NOTE</u>: Cartridge valve (9008416) & (9008463) must be locked in the middle detent position to function properly. (FIG 3-17 & 3-18)
- Return knurled knob to center and lock valve (9008416) & (9008463) in position. (FIG. 3-17 & 3-18)
- <u>NOTE</u>: Refer to "Troubleshooting" for EOH, vertical auger and/or rotating spout issues in the OPERATION section.
- 10. Turn off hydraulic circuit when done. Correct electric/hydraulic system before continued use. Consult your dealer for service and parts.



Electric Over Hydraulic 5 Function Troubleshooting

Problem

Possible Cause

Corrective Action

| No Electric Over Hydraulic (EOH) Functions work | Not getting 12 Volt power supply to the power harness in the tractor | Check the connections to the main power harness in the tractor cab, and check the 5 AMP fuse in the fuse holder of the main power harness. Replace fuse if necessary. | |
|--|--|---|--|
| | Not getting good connection at Deutch connectors in the harnesses | Unplug the Deutsch connectors at the hitch point and in the ex- tension harness (if used). Clean up the connectors with electrical contact cleaner. Make sure the connectors are aligned correctly and re-connect them. | |
| | Not pressurizing the correct hydraulic hose | Make sure the quick couplers are properly connected to the tractor SCV and the Hydraulic Pressure line is being pressurized when engaging the tractor SCV. | |
| Auger unfolds, but won't fold back in to transport position | Rotating Spout is not in the folding position | Rotate the spout so it is positioned straight down or forward in order to fold the auger into transport position. | |
| | Rotating spout switch is faulty or out of adjustment | Make sure the spout is in the centered position. Press and hold the manual overide button on the electric over hydraulic (EOH) valve on the auger fold cylinder while someone operates the hydraulic remote to fold the auger back to the transport position. Inspect the switch assembly near the rotating spout cylinder. The clearance between the end of the proximity switch and the barrel of the rotating spout cylinder must not exceed 1/4". | |
| Auger unfolds part way and stops | Debris in the EOH block on the auger fold cylinder | Fold auger, remove the Coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil. | |
| | Rotating Spout switch is out of ad- justment or has been activated. | With the auger folded in to the lower transport rest, have some- one depress and hold the switch at the vertical auger hinge plate. Use any means necessary to depress the switch without placing your hands or other body parts near the pinch points. With the switch depressed, rotate the spout to the folding postion. | |

Electric Over Hydraulic 5 Function Troubleshooting (continued)

Possible Cause

Problem

Corrective Action

| | 7 pin connector is not plugged into tractor. | Plug in 7 pin connector to same power source as the 5 function controller. | |
|--|--|---|--|
| Spout rotate does not operate | Proximity Switch at the auger hinge is not getting Power or Ground. | Check power and ground to the proximity switch harness on the vertical auger. | |
| | Proximity switch located at the hinge plate is not adjusted correctly. | This proximity switch has a 1/4" effective operating range. The upper auger hinge plate needs to be within that range when it is unfolded in to the operating position. Adjust the proximity switch in or out in order for the sensor to activate when it is in the operating position. | |
| Rotating spout will not function | Switch located at the hinge plate of the vertical auger is not getting power, ground or is defective | Check the ground wire on the top plate of the lower vertical auger and on the left hand standard just behind the front plate of the harness. Unplug the 3 pin connector on the hinge plate proximity switch. With a multi-meter or test light, confirm that the pin in socket B has +12V constant power and socket A has +12V when the sensor is activated. | |
| One single function will not work | Defective coil on the EOH valve for that function | Loosen the cap for the coils associated with that function on the EOH valve. Depress the button on the remote, and determine if the coils are getting magnetized. Inspect the wiring connectors to these coils, and replace the coil if necessary. | |
| | Defective valve on the EOH valve for that function | Remove the coil and the cartridge valve on the EOH valve block for that function. Replace the valve if it doesn't operate when the coil is magnetized. | |
| | Debris in the EOH block at the base of the vertical auger | Remove the coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil. | |
| Functions continue to operate after the button on the remote is released | Tractor hydraulic flow is set too high | Turn tractor hydraulic flow down so that flow doesn't exceed 6 gallons per minute. | |
| | Defective valve on the EOH valve for that function | Remove the Coil and the cartridge valve on the EOH valve block for that function, and replace the cartridge. | |

Vertical & Horizontal Cleanout Door Operation

A WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

Vertical Cleanout Door

- 1. Park the empty grain cart on a firm and level surface. Block the tires/tracks on the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
- 2. To completely close cleanout door, ensure the vertical auger cleanout door top edge clears the vertical position stop (key stop). (FIG. 3-19)
- 3. Attach eye bolt ends of over center latches to the hooks on the vertical auger. (FIG. 3-19)
- 4. Clasp the over center latch handles to lock the door in the closed position. (FIG. 3-19)



- 5. Inspect and verify cleanout door perimeter for gaps. Ensure all grain dust and filings are removed that may prevent the door from shutting completely.
- 6. If gaps are present, unclasp the over center latch and tighten eye bolt to improve door seal contact on the vertical auger.
- 7. Rehook eye bolt to vertical auger and clasp the over center latch.

NOTE: Repeat closing the door and inspection, as necessary.

Vertical & Horizontal Cleanout Door Operation (continued)

Vertical Cleanout Door

- <u>NOTE</u>: Remove the vertical auger cleanout door to improve vertical auger cleaning.
- 8. To open and remove the vertical auger cleanout door, unclasp the over center latch. (FIG. 3-20)
- 9. Unhook the eye bolt from the vertical auger and open the cleanout door. (FIG. 3-20)

- 10. The hinge on the vertical auger cleanout door is set on a pin. Lift and remove the cleanout door from the vertical auger. Keep vertical auger cleanout door. (FIG. 3-21)
- 11. Inspect and verify all debris is removed from inside the vertical auger housing.
- 12. Reattach the vertical cleanout door to the vertical auger.



Vertical & Horizontal Cleanout Door Operation (continued)

Horizontal Cleanout Door

Use the tensioner handle, located on the left-hand side of the grain cart, behind the first panel to open and close the horizontal cleanout doors.

- 1. Insert tensioner handle into the cleanout door receiver coupler on the rear panel, and remove lynch pin from rockshaft. Keep lynch pin. (FIG. 3-22)
- 2. Rotate the tensioner handle clockwise to open the cleanout doors. (FIG. 3-23)
- 3. Insert and lock lynch pin into rockshaft. (FIG. 3-23)

- 4. Inspect and verify all debris is removed that may prevent the doors from shutting completely. (FIG. 3-24)
- <u>NOTE</u>: If cleanout doors do not function properly, refer to "Horizontal Cleanout Door Inspection" in SET UP section for more information.
- 5. Remove lynch pin from rockshaft and rotate handle counter-clockwise and clockwise to check for smooth door operation.



Vertical & Horizontal Cleanout Door Operation (continued)

Horizontal Cleanout Door

6. Rotate handle counter-clockwise to close doors and ensure all doors seal. (FIG. 3-25)

7. Insert and lock lynch pin into rockshaft and return handle to storage location. (FIG. 3-26)





Auger Operation

PTO Driven Auger

▲ DANGER

• ELECTROCUTION WILL CAUSE SERIOUS INJURY OR DEATH. THE GRAIN CART IS NOT INSULATED. KEEP AWAY FROM ALL ELECTRI-CAL LINES AND DEVICES. ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT.



A WARNING

- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL IN-JURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- TO PREVENT PERSONAL INJURY OR DEATH ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS LIMITED MOBILITY AND EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- 1. Before loading cart or operating auger, verify that the flow control door is closed.
- <u>NOTE</u>: If spout rotate moves out of center, the auger will not unfold to unloading position. The spout must be manually rotated to center position. See "Manual Override for Optional Electric Over Hydraulic System" in the OPERATION section.
- Choose an area free from obstructions and unfold auger into unloading position. Allow sufficient time for the cylinder to fully engage the two augers and over-center latch to fully engage.
- 3. Engage PTO at low engine RPM, then increase engine RPM until 1000 PTO RPM is reached.



- 4. Open flow control door to desired unloading rate. Numbers on the auger tube provide a point of reference for operator convenience. (Fig. 3-27)
- 5. To slow or stop grain flow, close flow door, rather than reducing tractor RPM. Close flow door fully when unloading is complete.

NOTE: If an overload occurs, see "Auger Overload Procedure."

<u>NOTE</u>: It is not recommended to disengage auger with flow control door open. Auger system will require substantially more torque to start, placing extra stress on both cart and tractor driveline.

Cart is equipped with baffles that can be adjusted to accommodate the flow of different materials and/or the torque demands associated with different materials. See the SET UP section for the procedure.

Auger Operation (continued)

- 6. When auger is empty, reduce PTO rpm to idle, and stop PTO.
- 7. After PTO has come to a complete stop, align the checker flag decals to center spout as shown in FIG. 3-28.
- 8. Once spout is centered, fold auger to the transport position or field position.
- <u>NOTE:</u> Spout can be TILTED to any position, but must be ROTATED to center for auger to fold.



Auger Overload Procedure

- 1. Close flow door.
- 2. With the PTO off and driveline stopped, disengage the belt tensioner using the belt tensioner handle, this disengages the horizontal auger from the drivetrain. (FIG. 3-29)
- 3. Restart the tractor PTO with the engine RPM set to produce 850 to 1,000 PTO RPM and engage the tractor PTO to empty the vertical auger.
- 4. Once vertical auger is empty, stop PTO.
- With the tractor PTO off and driveline stopped, reengage the belt tensioner using the belt tensioner handle. Return handle to storage. (FIG. 3-30)
- Restart the tractor PTO with the engine RPM set to produce 850 to 1,000 PTO RPM and engage the tractor PTO to empty the drag auger.

<u>NOTE</u>: If the grain cannot be relieved by above method, open bottom clean out doors (see "Vertical & Horizontal Clean-Out Door Operation" in this section) to remove grain from auger before repeating these steps to clean out auger.



Auger Operation (continued)

Vertical Auger Fold



 DO NOT STAND ON LADDER OR FRAME UNLESS TRACTOR ENGINE IS TURNED OFF AND KEYS ARE REMOVED FROM THE IGNITION.

Actuate hydraulic auger fold circuit to pivot vertical auger between transport and operating positions. When unfolding auger, allow sufficient time for cylinder to rotate the outside fold link into an over-center position. (Fig. 3-31)

<u>NOTE</u>: Auger spout will not rotate until auger is fully extended and auger will not fold until the spout is centered. Transport Position Shown



Steering Tandem

Steering Tandem Indicator

Steering Tandem Tire position can be determined by observing indicator arrow located on the lower right portion of front panel.

NOTE: Indicator is best observed when auger is in field transport position.

Steering Tandem Operation

The steerable tandem has three different settings: Auto-Steer, Lock and Manual.

The defaulted function of the steering tandem is **Auto-Steer**. **Auto-Steer** is achieved when switch is in "OFF" position. (Regardless of tractor hydraulic lever position) This function allows grain cart tires to steer freely and to trail tractor.

To lock current steering position of tandem: Turn "ON/OFF" switch to "ON" and have tractor hydraulic remote lever in neutral position. This function may be used to hold steering position when moving back and forth along side of semi trailer.



To Manual steer tandem:

Turn "ON/OFF" switch to "ON" and move tractor hydraulic remote lever to extend or retract depending on steering direction and hydraulic connections noted earlier. This function may be used when backing unit into shed, or to make a reverse travel turn in opposite direction of forward turn.

<u>NOTE</u>: It is important to keep cylinders correctly phased. See "Steering Cylinder Rephasing" in the MAINTENANCE section.

<u>NOTE</u>: It is recommended to take scale readings with the wheels inline and vehicle stopped for maximum accuracy. See scale manual for more information.

Optional Implement Brake System for Steering Tandem

This system is for tractors with hydraulic trailer brake option. Once connected and properly bled, this system sends pressure to the implement's brakes when the brake pedal is used. After the brake pedal is released, pressure is removed from the implement calipers. Always check brake operation with an empty cart and familiarize the effectiveness as the load increases in the cart.

Ladder Operation

A WARNING

- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFO-CATES VICTIMS IN SECONDS.

<u>NOTE</u>: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.

<u>NOTE</u>: Ensure upper ladder extension is attached to higher holes on the ladder. Reference "Upper Ladder Extension to Operating Position" section in the SET UP section.

<u>NOTE</u>: Always use lock pin in the working and storage position to lock the ladder extension. The lock pin can be inserted in either left-hand or right-hand ladder hole. (FIGS. 3-32 & 3-33)





Ladder Operation (continued)

Storage to Working Position

- 1. Standing in front of ladder, place hands on outside ladder handles.
- 2. Keep one hand on ladder handle and with opposite hand, remove lock pin from ladder extension. Retain for future use. (FIG. 3-34)



3. With hands back on ladder handles, push ladder towards hopper bin and lift ladder extension to unseat ladder extension rod from the cradle. (FIG. 3-35)



THE LADDER IS NOW FREE TO PIVOT.

- FIG. 3-35 Bottom View
- 4. Slowly swing ladder outward until hinge is fully extended and locks in the working position. (FIG. 3-36)



Ladder Operation (continued)

Storage to Working Position

- 5. Lift and seat ladder extension into shorter leg of "J slot". (FIG. 3-37)
- 6. Using lock pin from step 2, insert lock pin into ladder extension and ladder. (FIG. 3-37)



 FALLING FROM AN UNSECURED LADDER MAY CAUSE SERIOUS INJURY OR DEATH. ALWAYS INSERT LOCK PIN BEFORE CLIMBING.

Working to Storage Position

- 7. Standing in front of ladder, place hands on outside ladder handles.
- 8. Keep one hand on ladder handle and with opposite hand, remove lock pin from ladder extension. Retain for future use. (FIG. 3-38)
- With hands back on ladder handles, lift and unseat ladder extension from shorter leg of "J slot". (FIG. 3-37)
- 10. Lower ladder extension until fully seated in longer leg of "J slot". (FIG. 3-38)





- 11. Keep one hand on ladder handle and with opposite hand, reach between ladder rungs and grab the ladder hinge hole. (FIG. 3-39)
- 12. Slowly lift ladder hinge until the ladder starts folding.
- 13. Remove hand from ladder hinge hole and place onto ladder handle.
- 14. Slowly push ladder towards hopper bin.



Ladder Operation (continued)

Working to Storage Position

15. Lower ladder extension and seat ladder extension rod onto the cradle. (FIG. 3-40)



16. Using lock pin from step 8, insert lock pin into ladder extension and ladder. (FIG. 3-41)



Weather Guard Tarp

WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.

IMPORTANT

- Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.
- Tarp should not be used if it is torn or the bungee cords are frayed or show damage. If water pools on the tarp, adjust tension of tarp cables and/or arm springs as required.

Always use adequate caution when operating tarp.

Make sure tarp is open before unloading or loading.

Make sure nobody is near the tarp system before and during operating.

Do not operate tarp with cart hoisted in an elevated position.

If tarp is covered with snow, it is important to remove snow before operating.

End caps must be free from grain that may be piled on them. Grain should not be heaped higher than the end caps or tarp bows.

Tarp may be fully opened or completely closed while in transit. However, the closed position is recommended.

Ensure everyone who operates the tarp is familiar with the correct procedures outlined in this manual.

Weather Guard Tarp (continued)

Procedure

- 1. Using both hands, carefully remove crank from holder. (Fig. 3-42)
- 2. Roll tarp to the desired location, choosing either a fully open or fully closed position.
- 3. To close the tarp, roll the main tarp tube clockwise up under the latch plate. Next, bring the crank handle down perpendicular to the ground. Continue by lifting it up into the crank retainer.

NOTE: Crank U-joint may need to be re-indexed on tarp tube to achieve correct tension.

- 4. Place crank in holder.
- 5. To open tarp, turn the main tarp tube counter clockwise until the tarp is fully open. Place crank in crank holder.



Notes

Section IV Maintenance

| Hydraulic System - Purge Hydraulic System. 4-5 Hydraulic System - Relieving Hydraulic Pressure 4-6 Bleeding Procedure for Braking System 4-7 Steering Tandem Linkage Adjustment Procedures 4-10 Side Linkage Adjustment 4-11 Steering Tandem Rockshaft Replacement 4-13 Steering Tandem Rockshaft Replacement 4-14 Auger Driveline Bearings 4-14 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-22 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-34 V-Picical Auger Timing 4-24 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-24 Split Tapered Bushings 4-36 PTO Quick Disconnect 4-36 | Lubric | ation | 4-2 |
|--|---------|---|---------|
| Bieeding Procedure for Braking System 4-7 Steering Tandem Maintenance 4-8 Steering Tandem Linkage Adjustment Procedures 4-10 O Center Linkage Adjustment 4-11 Steering Tandem Rockshaft Replacement 4-11 Steering Tandem Rockshaft Replacement 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-25 5-Pin Driver Replacement 4-35 Split Tapered Bushings 4-35 Split Tapered Bushings 4-36 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Tarp Troubleshooting Inspection & Maintenance 4-44 Brit Agener Sustem 4-45 Taro Troubleshooting Inspection & Maintenance </td <td>Hydrau</td> <td>ulic System - Purge Hydraulic System</td> <td>4-5</td> | Hydrau | ulic System - Purge Hydraulic System | 4-5 |
| Bieeding Procedure for Braking System 4-7 Steering Tandem Maintenance 4-8 Steering Tandem Linkage Adjustment Procedures 4-10 O Center Linkage Adjustment 4-11 Steering Tandem Rockshaft Replacement 4-11 Steering Tandem Rockshaft Replacement 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-25 5-Pin Driver Replacement 4-35 Split Tapered Bushings 4-35 Split Tapered Bushings 4-36 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Tarp Troubleshooting Inspection & Maintenance 4-44 Brit Agener Sustem 4-45 Taro Troubleshooting Inspection & Maintenance </td <td>Hydra</td> <td>ulic System - Relieving Hydraulic Pressure</td> <td>4-6</td> | Hydra | ulic System - Relieving Hydraulic Pressure | 4-6 |
| Steering Tandem Maintenance 4-8 Steering Tandem Linkage Adjustment Procedures 4-10 Center Linkage Adjustment 4-11 Steering Indicator Adjustment Procedures 4-11 Steering Tandem Rockshaft Replacement 4-11 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Steering Tandem Rockshaft Replacement 4-14 Auger System 4-19 Vertical Auger Timing 4-22 Horizontal Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-35 Split Tapered Bushings 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Toubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical System Schematic 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-46 < | | | |
| Center Linkage Adjustment 4-10 Side Linkage Adjustment 4-11 Steering Indicator Adjustment Procedures 4-13 Steering Tandem Rockshaft Replacement 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Suick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-47 Herek Nut Torque Requirements 4-46 Wheel Nut Torque | | | |
| Center Linkage Adjustment 4-10 Side Linkage Adjustment 4-11 Steering Indicator Adjustment Procedures 4-13 Steering Tandem Rockshaft Replacement 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Suick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-47 Herek Nut Torque Requirements 4-46 Wheel Nut Torque | Steerir | ng Tandem Linkage Adjustment Procedures | |
| Side Linkage Adjustment 4-11 Steering Indicator Adjustment Procedures 4-13 Steering Tandem Rockshaft Replacement 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger 4-22 Horizontal Auger 4-23 Horizontal Auger 4-23 Horizontal Auger 4-24 Bearing Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement. 4-27 Split Tapered Bushings 4-33 V-Belt Alignment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-36 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheels & Tires 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-4 | | | |
| Steering Indicator Adjustment Procedures 4-13 Steering Tandem Rockshaft Replacement. 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger 4-22 Horizontal Auger 4-22 Horizontal Auger 4-23 Hanger Bearing Height Measurement. 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement. 4-25 Split Tapered Bushings 4-35 Split Tapered Bushings 4-36 PTO Quick Disconnect. 4-40 Tarp Troubleshooting Inspection & Maintenance. 4-41 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic. 4-47 Wheel Nut Torque Requirements 4-450 Tire Pressure 4-44 Tire Warranty 4-50 Torque Chart - Hardware Grade 5. 4-51 <td< td=""><td></td><td></td><td></td></td<> | | | |
| Steering Tandem Rockshaft Replacement. 4-14 Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Harger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-36 Verity Tapered Bushings 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-44 Tarp Troubleshooting Inspection & Maintenance 4-42 Electrical System Schematic 4-44 Braking System Schematic 4-44 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-44 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-50 Torque Chart - Hardware Grade 5 4-52 Horizontal Auger Prove Replacements | | | |
| Auger Driveline Bearings 4-18 Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-22 Vertical Auger 4-21 Vertical Auger Timing 4-22 Horizontal Auger 4-23 Hanger Bearing Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-24 Baffle Adjustment 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Quick Disconnect 4-40 Tar Troubleshooting Inspection & Maintenance 4-41 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Vorque Chart - Hardware Grade 5 | | | |
| Gearbox with Sight Glass 4-19 Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheels & Tires 4-47 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittting | | | |
| Driveline Removal 4-19 Clamping Cone Assembly 4-19 Seasonal Storage 4-20 Auger System 4-21 Vertical Auger 4-21 Vertical Auger Timing 4-22 Horizontal Auger 4-23 Horizontal Auger Height Measurement. 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 S-Pin Driver Replacement. 4-25 S-Pin Driver Replacement 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Braking System Schematic 4-44 Braking System Schematic 4-46 Wheel Nut Torque Requirements 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-53 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLE | • | | |
| Clamping Cone Assembly | | | |
| Seasonal Storage 4-20 Auger System 4-21 Vertical Auger Timing 4-21 Vertical Auger Timing 4-22 Horizontal Auger Height Measurement. 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement. 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Split Tapered Bushings 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect. 4-40 Tap Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Braking System Schematic 4-46 Wheels & Tires 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-51 Torque Chart - Hardware Grade 5. 4-51 Torque Chart - Hardware Grade 5. 4-51 Horizonde Aster INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | | |
| Auger System 4-21 Vertical Auger Timing 4-22 Vortical Auger Timing 4-22 Horizontal Auger 4-23 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-47 Tire Pressure 4-48 Tire Varranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 5 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TR | | | |
| Vertical Auger 4-21 Vertical Auger Timing 4-22 Horizontal Auger 4-23 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-45 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-50 Torque Chart - Hardware Grade 5. 4-51 Torque Chart - Hardware Grade 5. 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. | | • | |
| Vertical Auger Timing 4-22 Horizontal Auger. 4-23 Horizontal Auger Height Measurement. 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement. 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheels & Tires 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | - | | |
| Horizontal Auger 4-23 Horizontal Auger Height Measurement 4-23 Hanger Bearing Height Adjustment 4-24 Baffle Adjustment 4-25 5-Pin Driver Replacement 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | • | |
| Horizontal Auger Height Measurement4-23Hanger Bearing Height Adjustment4-24Baffle Adjustment4-255-Pin Driver Replacement4-27Belt Tightener Adjustment4-34V-Belt Alignment4-35Split Tapered Bushings4-35Verify Telescoping PTO Shaft Length4-36PTO Shaft & Clutch4-38PTO Quick Disconnect4-40Tarp Troubleshooting Inspection & Maintenance4-41Electrical System Schematic4-42Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional)4-44Wheel Nut Torque Requirements4-47Tire Pressure4-48Tire Warranty4-50Torque Chart - Hardware Grade 54-51Torque Chart - Hardware Grade 84-52Hydraulic Fittings - Torque and Installation4-53FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | 0 0 | |
| Hanger Bearing Height Adjustment4-24Baffle Adjustment4-255-Pin Driver Replacement.4-27Belt Tightener Adjustment4-34V-Belt Alignment4-35Split Tapered Bushings4-35Verify Telescoping PTO Shaft Length4-36PTO Shaft & Clutch4-38PTO Quick Disconnect.4-40Tarp Troubleshooting Inspection & Maintenance4-41Electrical System Schematic4-42Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional)4-44Braking System Schematic4-47Tire Pressure4-48Tire Warranty4-50Torque Chart - Hardware Grade 54-51Torque Chart - Hardware Grade 84-52Hydraulic Fittings - Torque and Installation4-53FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | | |
| Baffle Adjustment 4-25 5-Pin Driver Replacement. 4-27 Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect. 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | | |
| 5-Pin Driver Replacement | | | |
| Belt Tightener Adjustment 4-34 V-Belt Alignment 4-35 Split Tapered Bushings 4-35 Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheels & Tires 4-47 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | | |
| V-Belt Alignment | | • | |
| Split Tapered Bushings4-35Verify Telescoping PTO Shaft Length4-36PTO Shaft & Clutch4-38PTO Quick Disconnect4-40Tarp Troubleshooting Inspection & Maintenance4-41Electrical System Schematic4-42Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional)4-44Braking System Schematic4-46Wheels & Tires4-47Tire Pressure4-48Tire Varranty4-50Torque Chart - Hardware Grade 5.4-51Torque Chart - Hardware Grade 8.4-52Hydraulic Fittings - Torque and Installation.4-53FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | • • | |
| Verify Telescoping PTO Shaft Length 4-36 PTO Shaft & Clutch 4-38 PTO Quick Disconnect. 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic. 4-46 Wheels & Tires 4-47 Mheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5. 4-51 Torque Chart - Hardware Grade 8. 4-52 Hydraulic Fittings - Torque and Installation. 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | • | |
| PTO Shaft & Clutch 4-38 PTO Quick Disconnect. 4-40 Tarp Troubleshooting Inspection & Maintenance 4-41 Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic. 4-46 Wheels & Tires 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5. 4-51 Torque Chart - Hardware Grade 8. 4-52 Hydraulic Fittings - Torque and Installation. 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | - | | |
| Tarp Troubleshooting Inspection & Maintenance4-41Electrical System Schematic4-42Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional)4-44Braking System Schematic4-46Wheels & Tires4-47Wheel Nut Torque Requirements4-47Tire Pressure4-48Tire Warranty4-50Torque Chart - Hardware Grade 54-51Torque Chart - Hardware Grade 84-52Hydraulic Fittings - Torque and Installation4-53FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | - | | |
| Electrical System Schematic 4-42 Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional) 4-44 Braking System Schematic 4-46 Wheels & Tires 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | PTO C | Quick Disconnect | 4-40 |
| Electrical Over Hydraulic (EOH) System Schematic 5 Function (Optional)4-44 Braking System Schematic | Tarp T | Froubleshooting Inspection & Maintenance | 4-41 |
| Braking System Schematic. 4-46 Wheels & Tires 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5. 4-51 Torque Chart - Hardware Grade 8. 4-52 Hydraulic Fittings - Torque and Installation. 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | Electri | cal System Schematic | 4-42 |
| Wheels & Tires 4-47 Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | Electri | cal Over Hydraulic (EOH) System Schematic 5 Function (Optiona | al)4-44 |
| Wheel Nut Torque Requirements 4-47 Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5. 4-51 Torque Chart - Hardware Grade 8. 4-52 Hydraulic Fittings - Torque and Installation. 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | Brakin | g System Schematic | |
| Tire Pressure 4-48 Tire Warranty 4-50 Torque Chart - Hardware Grade 5 4-51 Torque Chart - Hardware Grade 8 4-52 Hydraulic Fittings - Torque and Installation 4-53 FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. 4-53 FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. 4-53 | Wheel | s & Tires | |
| Tire Warranty4-50Torque Chart - Hardware Grade 5 | Wh | eel Nut Torque Requirements | 4-47 |
| Torque Chart - Hardware Grade 5 | Tire | e Pressure | 4-48 |
| Torque Chart - Hardware Grade 8 | Tire | e Warranty | 4-50 |
| Hydraulic Fittings - Torque and Installation | Torque | e Chart - Hardware Grade 5 | 4-51 |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | Torque | e Chart - Hardware Grade 8 | 4-52 |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | Hydrau | ulic Fittings - Torque and Installation | 4-53 |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | | FOR SCALE INFORMATION. PLEASE REFER TO YOUR SCALE MANUAL | |
| | | | |
| TOR ORANVEOLINI ORIVIATION, LEADE HELER TO TOOR ORANVEOLINIANOAE. | FO | R UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MAN | |
| FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. | | | |

FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Lubrication

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.




Lubrication

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.

The lubrication locations and recommended schedule are as follows:

| ITEM | DESCRIPTION | POINT | LUBRICANT | QTY. | HOURS |
|------|---|---------------------|-----------|------------------|-------------------------------|
| A | PTO Driveshaft | 3 | EP-2 | 1 Shot | See Previous Page |
| В | Gearbox Remove Cover - Check oil level every 2 weeks. Re- place oil every season. Refer to Gear- box in MAINTENANCE section. | 1 | EP80W90 | Approx 85 oz. | Once Every Season |
| С | Auger Pivot Rings - Front & Rear Auger Hinge | 7 | EP-2 | 2 Shots | Daily |
| D* | Hanger Bearing - Vertical Lower Auger *See note below. | 1 | EP-2 | 2 Shots* | Monthly |
| E | Top Bearing - Vertical Upper Auger | 1 | EP-2 | 1 Shot | Each Season |
| F | Horizontal Auger End & Center Bearings | 2 | EP-2 | 2 Shots | Monthly |
| G | Auger Pivot Pin - Vertical Upper Auger Hinge | 2 | EP-2 | 2 Shots | Daily |
| Н | Grease Slide Plate | 1 | EP-2 | 1 Shot | Each Season |
| I | Tongue Pivot Bushing | 2 (one per side) | EP-2 | 2 Shots | Daily |
| J | Front Horizontal Auger Bearing & Gear- box Support Bearing | 2 | EP-2 | 1 Shot | Weekly |
| к | Grease Bank for Parallel Linkage Pins | 4 (per wheel) | EP-2 | 6 Shots | Daily |
| L | Grease Bank for Steering Kingpin | 1 (per wheel) | EP-2 | 6 Shots | Daily |
| м | Grease Bank for Clevis Pivot Pins | 2 (per wheel) | EP-2 | 6 Shots | Daily |
| N | Tie Rod End on Steering Linkage | 4 | EP-2 | 2 Shots | Every 40 hours of usage |
| 0 | Grease Bank for Suspension Cylinder Both Ends | 2 | EP-2 | 6 Shots | Daily |
| Р | Hubs | 4 | EP-2 | Repack | Annually |

*<u>NOTE</u>: Hanger bearing contains hydraulic shut-off grease zerk (9005240) with pressure relief to prevent over-greasing and could push bearing seals out. If grease is coming out of the relief on the zerk this is normal and the bearing contains enough grease.

| GREASE BANK HOSE # | SUSPENSION LINK FUNCTION |
|-----------------------|--------------------------|
| 1 | Upper Clevis Pin |
| 2 | Lower Cylinder Pin |
| 3 | - |
| 4 | King Pin |
| 5 | Lower Clevis Pin |
| 6 | Upper Cylinder Pin |
| 7 | Upper Link Arm Pin |
| 8 | Upper Link Arm Pin |
| 9 | Lower Link Arm Pin |
| 10 | Lower Link Arm Pin |

Hydraulic System

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the grain cart requires little maintenance.

Replacing Hoses/Fittings/Cylinders:

- 1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3000 psi.
- 2. Do not use hoses, fittings and cylinders that have pipe threads.
- 3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings according to "Torque Chart" in this section.
- 4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
- 5. Always purge the hydraulic system after servicing.

Purge Hydraulic System



- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCE-DURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SE-RIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.



• KEEP CLEAR OF PINCH POINT AREAS.

Purge air from system as follows:

- A. Disconnect the rod end of all cylinders in a circuit and block up cylinders so the rod can completely extend and retract without contacting any other component.
- B. Pressurize the system and maintain system at full pressure for at least 5 seconds after cylinder rods stop moving. Check that all cylinders have fully extended or retracted.
- C. Check oil reservoir in hydraulic power source and refill as needed.
- D. Pressurize system again to reverse the motion of step B. Maintain pressure on system for at least 5 seconds after cylinder rods stop moving. Check that cylinders have fully extended or retracted.
- E. Check for hydraulic leaks using cardboard or wood. Tighten connections according to directions in Torque Chart.
- F. Repeat steps B, C, D, and E 3-4 times.
- G. Depressurize hydraulic system and connect cylinder rod clevises to their mating lugs.

IMPORTANT

• Machine damage will occur if the cylinder is incorrectly installed.

Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.

Hydraulic System (continued)

Relieving Hydraulic Pressure

To relieve hydraulic pressure in the system, be sure hydraulic motor is disengaged and/or hydraulic cylinder is not exerting force on the system. Next, consult tractor operators manual for procedure to relieve pressure.



| Bleed | ling Procedure For Braking System |
|-----------|--|
| Λ | WARNING |
| • | RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES. |
| • | HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS. |
| • | EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT. |
| | System is intended for tractors with hydraulic trailer brakes. If your tractor does not hydraulic trailer brakes, contact your dealer for support. |
| | This procedure is a two-person process. One person operates the brake pedal while second person loosens the bleeder screw on the brake caliper. |
| the | using a tractor, set the tractor parking brake, but leave tractor engine on throughout e procedure. Attach hydraulic brake coupler on the cart to the implement brake port the rear of the tractor. |
| 2. Ap | ply and hold pressure to brake pedal. |
| at cir | tach 1/4" hose to fitting. Put hose in an approved container. Loosen the bleeder screw the top of the caliper, on the brake caliper of the closest wheel located in the hydraulic cuit. If necessary, pump the brake pedal to extract all air from the system. Once ai bbles are no longer present, tighten the bleeder screw. (Fig. 4-1) |
| | peat steps 2 and 3 to the next closest brake caliper in the brake circuit. Repeat untibrakes are bled. |
| 5. Ch | eck that all brakes actuate and release properly with tractor brake pedal. |
| | Fig. 4-1 BLEEDER SCREW |

Steering Tandem Maintenance

Periodically check tire alignment and linkages for damage. Remove trash and/or dirt that may have accumulated and possibly interfere with steering performance.

Alignment of tires can be changed by adjustment of linkage(s). See "Steering Tandem Linkage Adjustment Procedures".

Steering Tandem Troubleshooting

NOTE: Always perform the following steps with an empty cart.

Tire Misalignment:

- 1. Steer the left set of tires until all tire edges are inline and straight forward. Check the opposite side. If both tire edges are equally out of alignment, then the center link-age needs adjustment. See "Steering Tandem Center Linkage Adjustment Procedure" in this section.
- 2. If only one tire on the opposite side is not straight, then that tire linkage needs to be adjusted. See "Steering Tandem Side Linkage Adjustment Procedure" in this section.

Failure to Auto-Steer:

- If grease zerks are present, heavily grease the 4 steering kingpins and 8 clevis pivot pins. For grease zerk locations, see "Lubrication" in this section. After long periods of inactivity, the pins can seize in the bushing. Once the pins are greased, manual steer the wheels in both directions. If wheel assemblies to not rotate freely, grease again and repeat manually steering the wheels.
- Make sure the steering axle control switch is in the OFF/Auto-Steer position. (Fig. 4-2)
- 3. Check for debris that may be obstructing tie-rod movement.

(Continued on next page)

| C STE | ERING AX | (LE CONTR | 80L (C) |
|---------------------|----------|-----------|-------------------|
| ON Look / Manual | | | OFF Auto-Stoor |
| | | 8 | 005054 |
| IG. 4-2 | | | |

Steering Tandem Maintenance (continued)

Steering Tandem Troubleshooting

NOTE: Always perform the below steps with an empty cart.

Failure to Manual-Steer:

- 1. Make sure the steering axle control switch is in the ON position. (Fig. 4-3)
- 2. Make sure the hydraulic hoses are attached properly.
- 3. Make sure hydraulic circuit is on.



4. Check the harness connection on the steering valve located on the cross axle, make sure there is 12-Volt to the solenoid on the valve attached to the cross axle. (Fig. 4-4)



Steering Indicator Misalignment:

1. Straighten the wheels, if the steering indicator is not centered, follow "Steering Indicator Adjustment Procedure" in this section.

Steering Tandem Linkage Adjustment Procedures

WARNING

- UNEXPECTED IMPLEMENT MOVEMENT CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT SERVICE OR MAKE ADJUSTMENTS TO IMPLEMENT WHILE THE TOWING VEHICLE IS RUNNING.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 7,500 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.



NOTE: Do not block tires since they are being manually steered.

Center Linkage Adjustment:

Use this procedure if:

- * Both tires on both sides are equally out of alignment.
- * Or both tires on one side are out of alignment.
- 1. Park the empty unit on a firm, level surface. Set the towing vehicle's parking brake. Tractor hydraulics are required for some steps, shut off engine and remove ignition key when hydraulic functions are complete. Turn the Steering Tandem switch to the "ON" position, and ensure the hydraulic lever is in float.
- Manually steer until equal stroke is measured on both ends of cylinder. Measuring from the center of the cylinder pin to the edge of the mount bracket, it should be around 8 3/4" on both sides. Check tire alignment. Verify suspension height is correct. (Fig. 4-5)



Steering Tandem Linkage Adjustment Procedures (continued)

- With the center of the cylinder pin to the edge of the mount bracket around 8 3/4", adjust the short tie-rod only on the side of the cylinder that needs adjustment. Loosen the jam nuts on each end of the short tie-rod. (Fig. 4-6)
- Extend or shorten tie-rod by turning jam nuts with 1/2" turn increments while checking wheel alignment between adjustments. Recenter the steering cylinder and check tire alignment. Continue to make adjustments until wheels are straight. (Fig. 4-6)
- 5. If the tires are removed, use the hub face to align.
- 6. If the tires are assembled, check alignment across the outside center of the tires. Due to variation in rubber tire profile, adjust the alignment until the front and rear of both tires are within 1/2" of being inline.
- Once wheels are aligned, tighten jam nuts located on the ends of the tie-rod. (Fig. 4-7)
- 8. Check alignment of the indicator, if it is misaligned follow "Steering Indicator Adjustment Procedures" in this section.

Side Linkage Adjustment:

Use this procedure if:

- * One or both front tires are out of alignment.
- * Or one or both back tires are out of alignment.
- 1. Remove the weight from the tire by using a safe lifting device rated for a minimum of 7,500 lbs., and support the lower para-link arm of the tandem. (Fig. 4-8)









Steering Tandem Linkage Adjustment Procedures (continued)

- 2. Loosen the jam nut on the rod end, and loosen the clamp and hardware on the tie-rod end. (Fig. 4-9 & 4-10)
- 3. Adjust rod end jam nut with 1/4" to 1/2" turn increments while checking wheel alignment between adjustments. (Fig. 4-9)



- <u>NOTE</u>: Make sure the capscrew on the clamp is facing away from the clevis and spindle to prevent interference when steering. (Fig. 4-10)
- 4. Once wheels are aligned, tighten the jam nut and the tie-rod clamp. (Fig. 4-9 & 4-10)
- 5. Lower tire to ground and check alignment.



Steering Indicator Adjustment Procedures

Use this procedure if:

- * To center indicator when tires are straight forward.
- 1. Straighten the wheels, and loosen the hex nuts (97189) on the u-bolt (9001114). (Fig. 4-11)



 Adjust the u-bolt (9001114) to center the red indicator (283749R) on the front of the cart, and retighten the hex nuts (97189). (Fig. 4-11 & 4-12)



Steering Tandem Rockshaft Replacement

WARNING

- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 7,500 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.



NOTE: Removing and assembling rockshaft takes two people: one at the front and rear.

- 1. Park the empty grain cart on a firm, level surface. Block the tires to keep the machine from moving. Relieve hydraulic pressure, see tractor operator's manual. Set the tractor's parking brake, shut-off the engine, and remove the ignition key. Completely disconnect the tractor from the grain cart.
- 2. Remove the weight from the tire by using a safe lifting device rated for a minimum of 7,500 lbs., and support the lower para-link arm of the tandem. (Fig. 4-13)



Steering Tandem Rockshaft Replacement (continued)

 Disconnect the lower tie-rod only on the side of the cylinder that needs rockshaft replacement. (Fig. 4-14)

4. Remove the pin on the end of the short tierod as shown. Keep pin. (Fig. 4-15)





- 5. At the rear of the rockshaft, remove the retaining ring on the end of the pin. Keep retaining ring. (Fig. 4-16)
- 6. Slide the pin from the rockshaft, spacer bushings and tie-rod. Keep pin and spacer bushings. (Fig. 4-16).
- 7. Repeat steps 5 and 6 for the front of the rockshaft.
- Remove the 3/4" capscrews, 3/4" flat washers and 3/4" lock nuts (all hardware qty. 2) attached to the bearing retainer and grain cart as shown. Keep 3/4" hardware. (Fig. 4-17)





Steering Tandem Rockshaft Replacement (continued)

- <u>NOTE</u>: Removing and assembling rockshaft takes two people: one at the front and rear.
- 9. Slide the rockshaft forward to remove from the rear pivot bushing. (Fig. 4-18)
- 10. Slide the rockshaft rearward to remove from the front pivot bushing.
- 11. Lower the rear end of the rockshaft, and slide the rockshaft rearward to remove from grain cart. Discard rockshaft.
- 12. Remove and discard self lubricating bushings and washers from the front and rear of the rockshaft. (Fig. 4-19)



FIG. 4-19

- 13. Slide new washer and self lubricating bushing to the front end of the new rockshaft.
- 14. Assemble rockshaft by raising the front end and inserting into the front pivot bushing.
- 15. Slide new washer and self lubricating bushing to the rear end of the rockshaft.
- 16. Insert rockshaft into the rear pivot bushing.
- 17. Reusing 3/4" hardware from step 8, reattach the hardware to the bearing retainer and grain cart. Loosely tighten hardware. (FIG. 4-20)



Steering Tandem Rockshaft Replacement (continued)

- 18. At the rear of the rockshaft and using parts from step 6, insert the pin into the rockshaft, spacer bushings and tie-rod.
- 19. Reusing retaining ring, attach to the end of the pin.
- 20. Repeat steps 18 and 19 for the front of the rockshaft.
- 21. Reusing pin from step 4, attach to the end of the short tie-rod and rockshaft bracket.
- 22. Tighten all hardware.
- 23. Lower tire to ground, remove safe lifting devices and check alignment of the tires.
- Tighten the jam nuts located on the ends of the short tie-rods. Check the alignment of the indicator, if it is misaligned "Steering Indicator Misalignment" in the previous section. (Fig. 4-21)



Auger Driveline Bearings

IMPORTANT

• Periodically check set screws in all bearings at either end of the driveline for tightness. (Fig. 4-22 & 4-23)





Gearbox with Sight Glass

When checking the oil level of the gearbox, the vertical auger should be tilted all the way down.

For adequate lubrication, the oil should be visible in the sight glass. Fill with oil to the sight glass only. (Fig. 4-24)

Maximum gearbox life: Check oil level every 2 weeks.

Replace oil every season with approximately 85 oz. 80W90 EP lubricant.



Driveline Removal



• MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING. ENSURE SERVICE COV-ERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

Gearbox shaft guard has access doors for installing and removing of driveline.

Clamping Cone Assembly

Use a hammer and punch and moderately hit the end of clamping cone, as shown. Back off the clamping cone 1/2 turn. Continue alternating punch and unscrewing clamping cone until clamping cone can be removed by hand. (FIG. 4-25)



Seasonal Storage

Always open flow door, horizontal and vertical auger cleanout doors to remove any remaining grain and to allow moisture to dry.

Wash machine inside and out before storing to remove dirt and debris that can draw and collect moisture. When using pressure washers maintain an adequate distance so not to force water into bearings.

Reattach PTO brackets (291974G or 291974R) to the inside right hand side of the tongue and place PTO assembly on brackets.

Lubricate machine at all points outlined.

Repaint all areas where paint has been removed to keep from rust developing. Rust will affect grain flow.

Coat exposed cylinder piston rods with rust preventative material if applicable.

Inspect machine for parts that may need to be replaced so they may be ordered in the off season.



If unit is equipped with a scale indicator, electric hydraulic controls or steering controls, store these indoors in a dry location.

Close the tarp to keep debris out of the hopper.

Auger System

Vertical Auger

Annually check all bolts, nuts, and set screws. Perform lubrication as specified.

Before servicing the vertical auger, park the unit on a firm, level surface. Block the wheels/ tracks to keep the machine from moving. Raise vertical auger to discharge position and close horizontal auger flow door. Set the tractor parking brake, turn off tractor engine, remove ignition key, and disconnect PTO shaft and hydraulic lines from tractor.

<u>NOTE</u>: The lower auger position is indexed from the drive dog / tube flange hinge surface as shown. (Fig. 4-28)

<u>NOTE</u>: Hanger bearing contains zerk (9005240) with pressure relief to prevent over-greasing that could push bearing seals out. If grease comes out of the relief on the zerk, this is normal and the bearing has enough grease. (Fig. 4-29)



Auger System (continued)

Vertical Auger Timing

1. For the lower vertical auger, use the top edge of the flighting as a 12 o'clock reference. Position the drive dog so the driving edge is at the 7 o'clock position.

<u>NOTE</u>: Looking down at the lower flighting (FIG. 4-31) the auger rotation will be counterclockwise. When looking up at the upper flighting (FIG. 4-32) the auger rotation will be clockwise.



- 2. For the upper auger, use the staring edge of the flighting as a 12 o'clock reference. Postion the driven edge of the drive pin at the 8 o'clock position. See Fig. 4-32.
- 3. When engaged, the upper flighting should immediately follow the lower flighting.

Auger System (continued)

Horizontal Auger

Annually check all bolts, nuts, and set screws. Perform lubrication as specified.

Horizontal Auger Height Measurement

- 4. Run a string from the front of the cart to the back, above the cleanout doors and linkages as shown in FIG. 4-33.
- 5. Attach the string to the bottom of the belly pan in the front side of the front opening. Place a 3/8"-1/2" spacer under the belly pan and clamp the string to the center of the opening as shown in FIG. 4-34.
- Attach the opposite end of the string to the back side of the rear belly pan opening. Place the same thickness of spacer as was used on the front in between the string and the belly pan. Pull the string tight and clamp to the center of the opening. (FIG. 4-35)
- 7. Measure the distance from the string to the bottom of the flighting center pipe in between the flighting pitch. Take a measurement through the front opening and the rear opening. If the measurement in the front and rear is different, add a shim under the smaller dimensioned end between the string and the belly pan so the measurements are the same.
- Measure the string to the auger tube either in front or behind the hanger bearing. If this dimension is 1/8" greater than the measurement taken in the front and rear, shims are required on top of the center hanger bearing. (FIG. 4-36)

<u>NOTE</u>: The shims are 1/8" thick each. Add as needed. Shims are available from your Brent dealer.









Auger System (continued)

Hanger Bearing Height Adjustment

- 9. Remove the center screens inside the hopper by removing the 3/8" hardware holding them in place. (FIG. 4-37)
- Remove the restrictor weldment on the auger tent at the opening above the hanger bearing. (FIG. 4-38)
- 11. Loosen the two 5/8"x2" capscrews. It is not necessary to remove this hardware if two or fewer shims are being installed. Install the shims from the backside between the bearing and the bracket as shown in FIG. 4-38.





- 12. If more than two shims are necessary to set the bearing height, replace the 5/8"x1 3/4" capscrews with the 5/8"x2" capscrews supplied in the kit.
- 13. Re-measure the distance from the flighting tube to the string making sure the string is pulled tight. If the measurements are all within 1/8", the string can be removed.
- 14. Reassemble the restrictor weldment and screens on the inside of the cart.
- 15. Reassemble the cleanout door linkages on the front and rear doors.
- 16. Close cleanout doors and reassemble the cleanout door lock pin.
- 17. Ensure all personnel and tools are removed from the cart and reconnect the cart to the tractor.
- 18. Run the auger starting at a low RPM and increase speed to max RPM to make sure the auger flighting does not make contact with the belly pan or flow doors.

Baffle Adjustment

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE THE CART, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE CART.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL IN-JURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.

Refer to the following reasons for baffle adjustment:

<u>NOTE</u>: To unload the cart evenly from front to back the openings should increase in height from back to front.

- 1. If higher flow is desired and torque is not the limiting factor, raise each baffle to an incremental amount and rerun.
- 2. If more material remains at the back of the cart towards the end of the unloading cycle, the back baffles should be adjusted upward in incremental amounts and rerun.
- 3. If more material remains at the front of the cart towards the end of the unloading cycle, the back baffles should be adjusted downward in incremental amounts and rerun.
- 4. If the cart requires more torque than what is available at times during the unloading cycle, then all baffles should be adjusted downward in incremental amounts.

Baffle Adjustment (continued)

The horizontal auger baffles are factory-set at the lowest position. This position results in the lowest power requirements and longest flighting life. Once grain has been run through the unit, adjustments can be made to achieve the ideal unloading performance.

Before making any baffle adjustments, close horizontal auger flow door. Securely block the grain cart, set the tractor parking brake, turn off tractor engine and remove ignition key.

If a higher flow is desired and torque is not a factor, loosen the (2) flange nuts on each baffle, see figure 4-39. Use the lift handle to raise each baffle to the desired position, retighten both flange nuts, see figures 4-39 & 4-40.

<u>NOTE</u>: DO NOT REMOVE ANY SCREEN PAN-ELS. The flange nuts are best accessed using an extended socket wrench and 9/16" socket through the screen panel openings.

<u>NOTE</u>: Screen removed in figure 4-40 for illustration only.





5. Remove capscrews and lock washers holding bearing onto the hanger bearing plate.

Washers & Capscrews

5-Pin Driver Replacement (continued)

6. Remove the hanger bearing bracket to allow access to work on the bearing and shaft. Remove two center tube connecting capscrews in the horizontal auger. (Figure 4-43)

- 7. Remove the SMV bracket located on the rear auger cover. (Figure 4-44)
- 8. Remove the capscrews from the auger cover. (Figure 4-44)

9. Pry the auger from the auger tube. (Figure 4-45)

10. Using a safe lifting device rated for a minimum 1,000 lbs., pull the rear auger out 3 feet using a strap. (Figure 4-46)





FIG. 4-50

 Install front capscrews, spacer bushings and locknuts 180 degrees from each other and assemble spacer bushings on threaded side of capscrews. Hand tighten hardware. (Figure 4-50)



5-Pin Driver Replacement (continued)

- Install hanger bracket. Leave the capscrews loose attaching hanger bracket to the cart. Attach hanger bracket to the bearing. (Figure 4-51)
- 19. Reattach grease line components. (Figure 4-51)
- <u>NOTE</u>: Rear auger flighting should lead the front auger flighting.
- 20. Slide the rear auger forward. Align the pins and holes with the rear auger pipe. (Figure 4-52)

21. Extend a string tightly from front to rear to check horizontal auger alignment. Measure the string to the auger tube either in front or behind the hanger bearing. If this dimension is 1/8" greater than the measurement taken in the front and rear, shims (8GA - 286419B or 12GA - 286424B) are required on top of the center hanger bearing. Ideally the center measurement should be equal to or 1/8" lower than the measurements on the ends of the augers. (Figure 4-53)

<u>NOTE</u>: The shims are 1/8" thick each. Add as needed. See "Auger System - Horizontal Auger Height Measurement" in MAINTENANCE section for more details.

- 22. Torque hanger bracket capscrews to 130 ft.lbs. See Figure 4-51.
- 23. Torque front auger capscrews to 200 ft.-lbs. (Figure 4-54)









5-Pin Driver Replacement (continued)

- 24. Reattach the rear auger cover and SMV bracket back onto the cart. (Figure 4-55)
- 25. Reinstall ALL the grates.



Belt Tightener Adjustment

IMPORTANT

- Do not use belt dressing.
- Keep grease and oil off of belt and pulleys.

NOTE: Pulleys do not need to be removed to remove/replace belt.

Due to prolonged use, belt wear may be evident causing slack. To correct this, follow these steps.

1. Park the unit on firm, level surface. Block the wheels to keep the machine from moving. Set the vehicle parking brake, shut-off the engine, and remove the ignition key from the towing vehicle.





- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING. EN-SURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FAS-TENED BEFORE OPERATING MACHINE.
- 2. Remove PTO assembly from gearbox input shaft.
- Detension the belt as outlined in OPERATION section. Open the cover guard access door and check if the belt tensioner handle is engaged or disengaged. If required, engage belt tensioner handle to seat belt into the pulleys.





Belt Tightener Adjustment (continued)

4. Remove cover, disengage belt tensioner handle and inspect belts for misalignment, loose parts and cracks. Replace if necessary with a matched set. (Fig. 4-26)



Belt Tightener Adjustment (continued)

- Belt tension is adjusted with hex nuts below the spring. All belt tension MUST be released from linkage. Loosen outer hex nut and adjust inner nut to establish a 3 1/16" pre-load dimension between the heavy washers. Tighten the outer hex nut against inner nut to lock position. (Fig. 4-59)
- Check the lower belt pulley to ensure belt is aligned in their grooves and with the belt tensioner handle, engage the roller/idler linkage against the belt and over-center stop. The compressed spring should now be approximately 1 3/4" between the washers and generating a force of approximately 480 lbs. against the belt. (Fig. 4-60)
- 7. Release and tighten belt multiple times to confirm positions and final adjustments. See Fig. 4-60 and Fig. 4-61.
- Tighten belt to retain them into the lower pulley for cover guard assembly. Reinstall the cover guard and the PTO shaft to the gearbox input shaft. Clear work area and test run drivetrain for 3 minutes at no greater than 1000 RPM.

A WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- 9. Disengage PTO and turn off tractor. Through the cover access door, check the compressed spring length is approximately 1 3/4" between the washers and check each belt for uniform tension. If more adjustment is needed, refer to Steps 5 through 7. If no additional spring adjustment is available, then both belts must be replaced with a new matched set.

NOTE: Always replace belts in matched sets.



V-Belt Alignment

- 1. Pulleys must be aligned with the fixed idler. Belts should be centered on idler for longest belt life. (Fig. 4-62)
- 2. After tightening taper-lock bushing hardware, lay a straight edge across face of the drive and driven belt pulleys to ensure alignment between the grooves on the pulleys.

Split Tapered Bushings

Check annually for tight engagement to driveshaft. Torque three bolts progressively to values shown:

1 3/4" Bore (Gearbox) - 30 ft-lbs.

2 1/4" Bore (Horizontal Auger) - 75 ft.-lbs.

Some gap must remain between flange & hub when bushing is properly tightened.

To remove from shaft, remove capscrews and insert them in tapped holes in bushing flange. Tighten progressively until bushing disengages.



Verify Telescoping PTO Shaft Length

WARNING

• PROPER EXTENDED AND COLLAPSED LENGTHS OF THE TELESCOPING PTO SHAFT MUST BE VERIFIED BEFORE FIRST OPERATION WITH EACH AND EVERY TRACTOR. IF THE EXTENDED LENGTH OF THE PTO SHAFT IS NOT SUFFICIENT, IT MAY BECOME UNCOUPLED IN OPERATION AND CAUSE SERIOUS INJURY OR DEATH FROM CONTACT WITH UNCONTROLLED FLAILING OF PTO SHAFT ASSEMBLY COMPONENTS.

IMPORTANT

• Check the length of the telescoping members to insure the driveline will not bottom out or separate when turning and/or going over rough terrain.

Consult your OEM dealer for recommended drawbar and PTO set up.

An excessive collapsed length can result in damage to the PTO driveline and attached components. This is most likely to occur during extreme turning angles and/or travel over rough terrain. Conditions are amplified on tractors with tracks operating in uneven terrain, particularly rice levies. Damaged driveline components can result in unsafe operation and severely reduced driveline component life.

Check the length of the telescoping members to ensure the driveline will not bottom out or separate when turning and/or going over rough terrain.

<u>NOTE</u>: Do not exceed 10 degrees beyond a straight pull line while operating the PTO. To verify proper extended and collapsed lengths, use the following procedure:

1. Fully collapse PTO shaft and measure length "L" (Fig. 4-63).

Enter here:____(1)

(Verify that outer tube does not bottom out on surrounding plastic shield components).

2. Pull apart PTO telescoping shaft ends and measure lengths "T" & "C" (Fig. 4-64)

Add "T" + "C" measurments together Enter total here:____(2)

- 3. Calculate maximum recommended extended length:
 - a. Subtract line 1 from line 2 Enter here:____(a)
 - b. Divide line (a) by 2 Enter here:____(b)
 - c. Add line (b) to line 1. Enter here:____(c)
 - d. Subtract 3 inches from line (c) Enter here:____(d)

This is the maximum recommended extended length.



Verify Telescoping PTO Shaft Length (continued)

- 4. Hitch tractor drawbar to cart, ensuring that tractor and cart are on level ground and coupled as straight as practical.
- 5. Connect PTO shaft to tractor, and measure length "L" from same points as used in step 1. Ensure that this measurement does not exceed the maximum recommended extended length calculated in step 3 above. If necessary, choose a shorter drawbar position, or obtain a longer PTO shaft assembly before operating cart.
- 6. Position the tractor to obtain the tightest turning angle, relative to the cart. (Fig. 4-65)
- 7. Measure the length "L" from the same points as used in step 1. This distance must be at least 1.5 inches greater than the distance measured in step 1. If necessary, adjust the length of the PTO shaft by cutting the inner and outer plastic guard tubes and inner and outer sliding profiles by the same length. Round off all sharp edges and remove burrs before greasing and reassembling shaft halves. (Fig. 4-66)



PTO Shaft and Clutch

Length Adjustment (Figs. F1 - F4)

<u>NOTE</u>: Maximum operating length, see step 3d on page 4-36.

- 1. To adjust length, hold the half-shafts next to each other in the shortest working position and mark them.
- 2. Shorten inner and outer guard tubes equally.
- 3. Shorten inner and outer sliding profiles by the same length as the guard tubes.
- 4. Round off all sharp edges and remove burrs. Grease sliding profiles.

A WARNING



F4

• CHECK THE LENGTH OF THE TELESCOPING MEMBERS TO INSURE THE DRIVELINE WILL NOT BOTTOM OUT OR SEPARATE WHEN TURNING AND/OR GOING OVER ROUGH TERRAIN.

F3

To Dismantle Guard (Figs. J1 - J4)

- 1. Remove locking screw.
- 2. Align bearing tabs with cone pockets.
- 3. Remove half-guard.
- 4. Remove bearing ring.


PTO Shaft and Clutch (continued)

To Assemble Guard (Figs. K1 - K5)

- 1. Grease yoke groove and inner profile tube.
- 2. Fit bearing ring in groove with recesses facing profile tube.
- 3. Slip on half-guard.
- 4. Turn cone until it engages correctly.
- 5. Install locking screw.











To Assemble Cone (Figs. L1 - L3)

- Dismantle guard (Figs. J1 J3). Remove old cone (e.g. cut open with knife). Take off chain. Place neck of new cone in hot water (approx 800 C / 1800 F) and pull onto bearing housing (Fig. L1).
- Turn guard cone into assembly position (Fig. L2). Further assembly instructions for guard (Figs. K1 K5).
- 3. Reconnect chain if required (Fig. L3).



PTO Quick Disconnect

Coupling

Slide clamp yoke or cut-out clutch onto connecting shaft. Make sure the location hole for the clamping cone is positioned above the annular groove of the connecting shaft. Screw appropriate clamping cone into the location hole. Slightly moving the clamp yoke or clutch to and from in the axial direction will help drive in the clamping cone. Check the clamp yoke or clutch for a tight and safe fit and continue to check at regular intervals. Retighten the clamping cone as necessary. Torque clamping cone to 75 ft.-lbs.

When over loading occurs, the clutch disengages and will repeatedly attempt to reset. The clutch will create a repeated "clicking" noise when resetting. Torque demand must decrease for clutch to reset.



Tarp Troubleshooting Inspection & Maintenance

| PROBLEM | SOLUTION | |
|---------------------------|---|--|
| TARP SAGS IN MIDDLE AREAS | 1. BOWS MAY BE BENT OR ADJUSTED TOO LOW | |
| | 2. MISSING OR LOOSE RIDGE STRAP REPLACE OR RETIGHTEN | |
| | 3. TENSION MAY BE TOO LOOSE. U-JOINT MAY NEED TO BE ADJUSTED ON SPLINED SHAFT TO PROVIDE MORE TENSION | |
| HOLES OR TEARS IN TARP | 1. CONSULT YOUR LOCAL DEALER FOR REPAIRS | |
| | 2. ORDER TARP REPAIR KIT FROM DEALER | |
| | 3. WHEN NEW TARP OR PARTS ARE NEEDED ALWAYS REPLACE WITH ORIGINAL PARTS | |

Inspection and Maintenance

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.

IMPORTANT

- Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.
- Tarp should not be used if it is torn or the bungee cords are frayed or show damage. If water pools on the tarp adjust tension of tarp cables and/or arm springs as required.

Periodic preventive maintenance should be practiced. Inspect tarp and hardware often for abrasions or loosened bolts that may need adjustment and/or repair. Check bungee cords for wear and adjust tension at the beginning of the season and again half way through the season.

Tears in tarp should addressed before further tarp operation. If water pools on tarp, adjust tension of tarp cables and/or arm springs.

If installed correctly, tarp should always operate as well as when first installed. If tarp does not pass this simple inspection, make all appropriate repairs or adjustments immediately before serious damage occurs.











**LOCATE/REPLACE IN LOWEST BLEEDER PORT OF EACH CALIPER.

Wheels and Tires

Wheel Nut Torque Requirements

A CAUTION

• IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagram 1.

| WHEEL HARDWARE | | |
|----------------|-------------|--|
| SIZE | FOOT-POUNDS | |
| 7/8-14 (UNF) | 440 ftIbs. | |
| M22x1.5 | 475 ftlbs. | |

| NOTE: Do not use anti-seize on wheel hardware. |
|--|
|--|



Wheels and Tires (continued)

Tire Pressure

The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. It is important that tires are inspected after unit is loaded. Start with minimum pressure. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. Do not exceed maximum recommended tire pressure. Each tire must be inflated to 35 PSI max to seat the beads, deflated to 5-10 PSI, then reinflated to the tire's max PSI when mounting. Tire Pressure for Grain Carts

| | Pressure for Grain Carts | Load Index / Ply | |
|-----------|---------------------------|------------------|----------|
| Tire Make | Tire Size | Rating | Max. PSI |
| Firestone | 23.1x26 R-3 | 12 | 32 |
| | 23.1x26 R-1 | 12 | 32 |
| | 28Lx26 R-3 | 12 | 26 |
| | 24.5x32 R-3 | 12 | 32 |
| | 24.5x32 R-1 | 12 | 32 |
| | 30.5x32 R-1 | 14 | 28 |
| | 30.5x32 R-3 | 14 | 28 |
| | 30.5x32 R-3 | 16 | 34 |
| | 30.5x32 R-1 | 16 | 26 |
| | 35.5x32 R-3 | 20 | 36 |
| | 76x50.00x32 HF-3 | 16 | 40 |
| | 76x50.00x32 HF-3 | 20 | 50 |
| | 800/65R32 R-1W | 172A8 | 44 |
| | 800/60R32 R-3 | 181B | 46 |
| | 900/65R32 R-3 | 191B | 46 |
| | 900/60R32 R-1 | 176A8 | 44 |
| | 1250/50R32F IF/CFO R-1WNP | 201D | 46 |
| | 1250/50R32F IF/CFO R-1W | 188B | 30 |
| | 520/85R38 R-1 | 155A8 | 29 |
| | 520/85R38 R-1 | 173A8 | 64 |
| | 480/80R42 R-1 | 151A8 | 36 |
| | 520/85R42 R-1 | 157A8 | 29 |
| | 520/85R42 R-1 | 165A8 | 51 |
| | 520/85R42 IF/CFO R-1 | 169A8/B | 35 |
| | 520/85R42 R-1W | 169B | 35 |
| | 420/80R46 R-1 | 151A8 | 44 |
| | 480/80R46 R-1 | 158A8 | 44 |
| | 380/90R46 R-1 | 152B | 51 |

Wheels and Tires (continued)

Tire Pressure (continued)

| Tire Make | Tire Size | Load Index / Ply Rating | Max. PSI |
|----------------|-----------------------------|----------------------------|----------|
| Titan/Goodyear | 23.1x26 R-3 | 10 | 26 |
| | 23.1x26 R-1 | 10 | 26 |
| | 24.5R32 R-1 | 169A8/B (5-Star) | 48 |
| | 24.5x32 R-3 | 12 | 32 |
| | 24.5x32 R-1 | 12 | 32 |
| | 30.5x32 R-3 | 16 | 26 |
| | 30.5x32 R-3 | 14 | 22 |
| | 30.5x32 R-1 | 14 | 22 |
| | 480/80x42 R-1 | 166A8 | 23 |
| | 1100/45R46 F-1W | 195D | 35 |
| Mitas | 650/75R32 R-1W | 172A8 | 58 |
| | 900/60x32 R-1W | 176A8 | 41 |
| | 900/70R32 R-1W | 188A8 | 53 |
| | 1050/50x32 R-1W | 178A8 | 41 |
| | 1250/50R32 R-1W | 188A8 | 41 |
| | 900/60x38 R-1W | 181A8 | 44 |
| | 520/85x42 R-1W | 162A8 | 44 |
| | 650/65x42 R-1W | 168A8 | 44 |
| Alliance | 35.5LR32 | 193A8 | 44 |
| | 900/60R32 R-1W | 192D | 46 |
| | 1050/50R32 R-1W | 185A8 | 63 |
| | 1250/50R32 R-1W | 201B | 46 |
| Trelleborg | VF1050/50R32 R-1 | 198D | 52 |
| | 900/50R32 R-1W 900/60x32 | 181A8 176LI | 55 44 |
| | 850/55R42 R-1W | 161A8 | 44 32 |

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. **USED TIRES CARRY NO WARRANTY.** Following are phone numbers and Websites for your convenience:

| <u>Firestone</u> | www.firestoneag.com Phone 800-847-3364 |
|---------------------------------------|---|
| <u>Titan</u> or <u>Goodyear</u> | www.titan-intl.com Phone 800-USA-BEAR Fax 515-265-9301 |
| Trelleborg | www.trelleborg.com Phone 866-633-8473 |
| <u>Continental/Mitas</u> | www.mitas-tires.com Phone 704-542-3422 Fax 704-542-3474 |
| Alliance | www.atgtire.com Phone 781-325-3801 |

Complete Torque Chart

Capscrews - Grade 5

NOTE:

- Grade 5 capscrews can be identified by three radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

| SIZE | FOOT POUNDS | NEWTON METERS |
|----------|----------------|------------------|
| 1/4-20 | 8-10 | 11-13 |
| 1/4-28 | 9-11 | 12-15 |
| 5/16-18 | 15-17 | 20-23 |
| 5/16-24 | 17-19 | 23-26 |
| 3/8-16 | 25-28 | 34-38 |
| 3/8-24 | 28-31 | 38-42 |
| 7/16-14 | 40-45 | 54-61 |
| 7/16-20 | 45-50 | 61-68 |
| 1/2-13 | 62-68 | 84-92 |
| 1/2-20 | 68-75 | 92-102 |
| 9/16-12 | 90-98 | 122-133 |
| 9/16-18 | 100-110 | 134-148 |
| 5/8-11 | 120-135 | 162-183 |
| 5/8-18 | 124-137 | 168-186 |
| 3/4-10 | 200-220 | 270-300 |
| 3/4-16 | 210-230 | 285-310 |
| 7/8-9 | 330-350 | 425-475 |
| 7/8-14 | 360-380 | 460-515 |
| 1-8 | 500-525 | 675-710 |
| 1-14 | 540-560 | 730-760 |
| 1 1/8-7 | 600-635 | 815-860 |
| 1 1/8-12 | 665-700 | 920-950 |
| 1 1/4-7 | 850-895 | 1150-1215 |
| 1 1/4-12 | 940-990 | 1275-1340 |
| 1 3/8-6 | 1125-1175 | 1525-1590 |
| 1 3/8-12 | 1280-1335 | 1735-1810 |
| 1 1/2-6 | 1500-1560 | 2035-2115 |
| 1 1/2-12 | 1685-1755 | 2285-2380 |

IMPORTANT

• Follow these torque recommendations except when specified in text.

Complete Torque Chart

Capscrews - Grade 8

NOTE:

- Grade 8 capscrews can be identified by six radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

| SIZE | FOOT POUNDS | NEWTON METERS |
|----------|----------------|------------------|
| 5/16-18 | 20-22 | 27-30 |
| 5/16-24 | 21-23 | 28-31 |
| 3/8-16 | 35-39 | 47-53 |
| 3/8-24 | 36-41 | 49-55 |
| 7/16-14 | 54-58 | 73-78 |
| 7/16-20 | 55-60 | 75-80 |
| 1/2-13 | 82-88 | 110-120 |
| 1/2-20 | 94-99 | 125-135 |
| 9/16-12 | 127-134 | 170-180 |
| 9/16-18 | 147-155 | 199-210 |
| 5/8-11 | 160-170 | 215-230 |
| 5/8-18 | 165-175 | 225-235 |
| 3/4-10 | 280-295 | 380-400 |
| 3/4-16 | 330-365 | 445-495 |
| 7/8-9 | 410-430 | 555-580 |
| 7/8-14 | 420-440 | 570-595 |
| 1-8 | 630-650 | 850-880 |
| 1-14 | 680-700 | 920-950 |
| 1 1/8-7 | 900-930 | 1220-1260 |
| 1 1/8-12 | 930-950 | 1260-1290 |
| 1 1/4-7 | 1250-1300 | 1695-1760 |
| 1 1/4-12 | 1280-1320 | 1735-1790 |

IMPORTANT

• Follow these torque recommendations except when specified in text.

Hydraulic Fittings - Torque and Installation

SAE Flare Connection (J. I. C.)

- 1. Tighten nut with finger until it bottoms the seat.
- 2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



SAE Straight Thread O-Ring Seal

- 1. Insure jam nut and washer are backed up to the back side of smooth portion of elbow adapter.
- 2. Lubricate o-ring.
- 3. Thread into port until washer bottoms onto spot face.
- 4. Position elbows by backing up adapter.
- 5. Tighten jam nut.



Notes

Section V Parts

Please visit www.unverferth.com/parts/ for the most current parts listing.

| Decals | |
|---|------|
| Touch-Up Paint | |
| Vertical Auger Flighting Components | 5-8 |
| Horizontal Auger Components | |
| Hopper Flow Door Components | 5-12 |
| Flow Door Components | 5-14 |
| Indicator Assembly | 5-16 |
| Steering Tandem Indicator Components | 5-18 |
| Clean Out Door Components | 5-20 |
| Ladder Components | 5-22 |
| Hitch & Tongue Components | |
| Suspension Link Components | |
| Suspension Link To Hub Components | |
| Suspension Linkage Components | 5-30 |
| Suspension Link Grease Bank Components | |
| Steering Tandem Internal Bracing Components | |
| Track Internal Bracing Components | 5-36 |
| Sideboard Components | |
| Steering Tandem Wheels & Tires | 5-39 |
| Optional Brake Components | |
| Steering Tandem Hydraulic Suspension Components | |
| Steering Hydraulic Plumbing Components | |
| Steering Tandem Hub Components | 5-46 |
| Track Axle Mounting Components | |
| EOH Valve Functions & Wire Locations 5 Spool | |
| EOH Valve Assembly Components 5 Spool (Optional) | |
| EOH Tractor Circuit Hydraulic Components (Optional) | 5-52 |
| Flow Door Circuit Hydraulic Components | |
| Auger Tilt Hydraulic Components | |
| Auger Fold Hydraulic Components | |
| EOH Spout Rotate & Tilt Hydraulic Components (Optional) | |
| Cylinders | |
| Gearbox Components | |
| Electrical Components - 5 Function Control Grip | |
| Cut Out Clutch PTO Assembly | |
| Cut Out Clutch Components | |
| Lower Auger Linkage Components | |
| Lower Auger Door & Cover Components | |
| Auger Tube Components | |
| Auger Grease Bank Components | |
| Switch Assembly Components for Rotating Spout Option | |
| Downspout Components | |
| Weather Guard Tarp Components | |
| Hydraulic Jack (Optional) - Kit #294143B | |
| Video System Option | 5-86 |
| | |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Brent 2096 — Parts

Decals



Decals (continued)



Brent 2096 — Parts

Decals (continued)



Decals (continued)



Decals (continued)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|--------------|---|-----|-------|
| 1 | 9004271 | Decal, Avalanche | 2 | |
| 2 | 900024 | Decal, WARNING (High Pressure Oil) | 1 | |
| 3 | 97961 | Decal, WARNING (Read Manual) | 1 | |
| 4 | 9003474 | Decal, DANGER (Electrical Lines) | 1 | |
| 5 | 9004864 | Decal, Steering Indicator | 1 | |
| 6 | 91605 | Decal, FEMA | 1 | |
| 7 | 94094 | Decal, WARNING (Tongue Rise) | 1 | |
| 8 | 95046 | Decal, DANGER (Entanglement) | 2 | |
| 9 | 97575 | Decal, CAUTION (Transport Chains) | 1 | |
| 10 | 9003475 | Decal, WARNING (Cut & Crush) | 4 | |
| 11 | 95839 | Decal, WARNING (Pinch Point) | 4 | |
| 12 | 95445 | Decal, DANGER (High Pressure Fluid) | 1 | |
| 13 | 9008151 | Decal, IMPORTANT (PTO Engagement) | 1 | |
| 14 | 9003476 | Decal, WARNING (No Riders) | 2 | |
| 15 | TA1-906109-0 | Decal, WARNING (Moving Parts Crush/Cut) | 1 | |
| 16 | 98229 | Decal, WARNING (Falling Equipment) | 1 | |
| 17 | 9003478 | Decal, DANGER (Never Play) | 1 | |
| 18 | 9008947 | Decal, Grease | 5 | |
| 19 | 9005971 | Decal, WARNING (Suspension) | 1 | |
| 20 | 9003477 | Decal, IMPORTANT (Operation) | 1 | |
| 21 | 9004966 | Decal, IMPORTANT (Cart Loading) | 1 | |
| 22 | 9003127 | Reflector 2x9 =AMBER= | 7 | |
| 23 | 9003126 | Reflector 2x9 =RED= | 2 | |
| 24 | 9003125 | Reflector 2x9 =FLUORESCENT= | 2 | |
| 25 | 9006589 | Decal, Stripe | 18 | |
| 26 | 94754 | Decal, UM Wheel Systems | 1 | |
| 27 | 9006588 | Decal, Brent Logo | 4 | |
| 28 | 9006788 | Decal, 2096 | 4 | |
| 29 | TA510514 | SMV Emblem | 1 | |
| 30 | 9006601 | Decal, Flow Control Indicator | 1 | |
| 31 | 9007162 | Information Tag Brakes Option | 1 | |
| 32 | 95008 | Decal, CAUTION (Slippery Surface) | 1 | |
| 33 | 9008543 | Decal, IMPORTANT (Spout Rotate) | 1 | |
| 34 | 9008715 | Decal, Front SIS 20 MPH | 1 | |
| 35 | 9008721 | Decal, Front SIS 30 KPH | 1 | |
| 36 | 9008714 | Decal, Rear SIS 20 MPH | 1 | |
| 37 | 9008720 | Decal, Rear SIS 30 KPH | 1 | |
| 38 | 9008594 | Decal, Hose Legend | 1 | |
| 39 | 9009168 | Decal, WARNING (Ladder Lock Pin) | 1 | |
| 40 | 9008925 | Decal, Grease Bank | 1 | |

Touch-Up Paint

| PAINT | SPRAY |
|--------------|---------|
| Black | 97013 |
| Green | 97015 |
| Red | 97301 |
| Primer, Gray | 9500082 |
| Off White | 97016 |
| Silver Mist | 97012 |

Vertical Auger Flighting Components



Vertical Auger Flighting Components

| | | | | nost current parts iisting. |
|------|------------|---|-----|--|
| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
| 1 | 281283 | Soft Start Assembly | 1 | |
| 2 | 9003230 | Split Bushing 2 3/4 OD x 2 1/2 ID x 2 | | |
| 3 | 289932B | Bearing Bracket Weldment =Black= | 1 | |
| 4 | 276548B | Upper Auger Weldment =Black= | 1 | |
| 5 | 9004877 | Split Bushing 4.25 OD x 4.011 ID | 1 | |
| 6 | 287826B | Lower Auger Replacement Kit =Black= | 1 | Fits 2 1/4"-20 Spline Gearbox Shaft |
| 7 | 283515 | Auger Tube Adapter | 1 | |
| 8 | 287802 | Drive Plate Assembly (5-Pin) | 1 | |
| 9 | 288813 | Drive Dog Casting | 1 | |
| 10 | 284986 | Hood Pivot Pin Weldment | 1 | |
| 11 | 407699 | Washer Plate, 2 1/2" Dia. | 1 | |
| 12 | 9001529 | Flange Screws 1/2-13UNC x 1 | 4 | |
| 13 | 9002492 | Bearing 2" Dia. Flanged | 1 | |
| 14 | 9003949 | Pipe Coupling, 1/8 NPT Female | 2 | |
| 15 | 9004731 | Pillow Block Bearing, 2 1/2" Bore | 1 | |
| 16 | 9004878 | Self Lubricating Washer | 1 | |
| 17 | 9004899 | Spring - 10 Coils | 4 | |
| 18 | 9000875 | Grease Zerk | 1 | |
| 19 | 9005793 | Grease Pipe | 1 | |
| 20 | 9007366 | Gearbox 1 3/4-20 Spline Input Shaft 2 1/4-17 Spline Output Shaft | 1 | See "Gearbox" in this section for parts. |
| 21 | 9007377B | Dust Cover =Black= | 1 | |
| 22 | 91178 | Retaining Ring | 1 | |
| 23 | 9390-100 | Capscrew, 1/2-13UNC x 1 1/4 Grade 5 | 5 | |
| 24 | 9390-119 | Capscrew, 1/2-13UNC x 8 Grade 5 | 1 | |
| 25 | 9390-122 | Capscrew, 5/8-11UNC x 1 1/2 Grade 5 | 20 | |
| 26 | 9390-135 | Capscrew, 5/8-11UNC x 5 1/2 Grade 5 | 4 | |
| 27 | 9390-159 | Capscrew, 3/4-10UNC x 7 Grade 5 | 2 | |
| 28 | 93974 | Flat Washer 2" | | |
| 29 | 9404-025 | Lock Washer, 1/2 Grade 5 | 5 | |
| 30 | 9404-030 | Lock Washer, 5/8" | 10 | |
| 31 | 9800 | Locknut, 1/2-13UNC Grade 5 | 1 | |
| 32 | 9801 | Locknut, 5/8-11UNC Grade 5 | 4 | |
| 33 | 9802 | Locknut, 3/4-10UNC Grade 5 | 2 | |
| 37 | 903161-063 | Flange Screw, 5/8-11 x 1 1/4 Grade 5 | 2 | |
| 38 | 410511 | Spacer Bushing | 1 | |
| | · | | | <u>.</u> |

Horizontal Auger Components



Horizontal Auger Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|---|-----|-----------------------------|
| 1 | 273779 | Auger Shaft 2 1/2 Dia. x 18 | 1 | |
| 2 | 286424 | Bearing Shim Plate | A/R | |
| 3 | 294631B | Rear Drag Auger Weldment =Black= | 1 | |
| 4 | 286382B | Bearing Mount Bar =Black= | 1 | |
| 5 | 295033B | Front Drag Auger Replacement Kit (Black) | 1 | |
| 6 | 283097G | Cover Plate =Green= | 1 | |
| 0 | 283097R | Cover Plate =Red= | | |
| 7 | 293957 | Auger Coupler Shaft Weldment | 1 | |
| 8 | 9002492 | Bearing 2" Dia. Flanged | 1 | |
| 9 | 9003735 | Cable Tie 11" Long | 1 | |
| 10 | 9004731 | Bearing - Pillow Block | 1 | |
| 11 | 9004764 | 90° Elbow Pipe | 1 | |
| 12 | 9006964 | Hex Pipe Nipple | 1 | |
| 10 | 9004932 | Grease Hose 1/8 x 36 | 1 | For Track Models |
| 13 | 9003830 | Grease Hose 24" | 1 | For Steerable Tandem Models |
| 14 | 9006965 | Grease Hose 1/8 x 15 (3000 PSI) | 1 | |
| 15 | 91262 | Large Flange Screw 3/8-16UNC x 1 | 9 | Grade 5 |
| 16 | 91299-161 | Capscrew, 3/4-10UNC x 8 | 2 | Grade 8 |
| 17 | 9390-123 | Capscrew 5/8-11UNC x 1 3/4 | 2 | Grade 5 |
| 18 | 9390-124 | Capscrew 5/8-11UNC x 2 | 8 | Grade 5 |
| 19 | 9390-125 | Capscrew 5/8-11UNC x 2 1/4 | 2 | Grade 5 |
| 20 | 9394-014 | Hex Nut, 5/8-11UNC | 10 | Grade 5 |
| 21 | 9404-029 | Lock Washer 5/8" | 12 | |
| 22 | 9405-098 | Flat Washer 5/8" SAE | 4 | |
| 23 | 9802 | Lock Nut/Top, 3/4-10UNC | 2 | Grade B |
| 24 | 9002562 | Key 1/2 x 1/2 x 2 1/2 | 1 | |
| 25 | 9003949 | Pipe Coupling | 1 | |
| 26 | 9005073 | Quicklinc Fitting 1/4" Tube x 1/8NPT Straight | 2 | |
| 27 | 9005074 | Nylon Tube 1/4" OD | 1 | |
| 28 | 9005565 | Flange Bearing 4-Bolt, 2 1/4" ID | 1 | |
| 29 | 91141 | Locknut 7/8-9UNC | 2 | |
| 30 | 91299-178 | Capscrew 7/8-9UNC x 7 | 2 | Grade 8 |
| 31 | 93426 | Grease Zerk | 1 | |
| 32 | 9405-076 | Flat Washer 3/8" USS | 1 | |
| 33 | 286283 | Auger Tube Adapter 4 3/4" Dia. x 6 5/8 | 1 | |
| 34 | 283895B | Spacer Bushing | 2 | |

Hopper Flow Door Components



Hopper Flow Door Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES | | |
|------|----------|--|-----|--|--|--|
| 1 | 266285 | ldler Pin 1 x 4 1/2 | 1 | | | |
| 2 | 271054* | Cylinder Mount Plate | - | *Not for individual sale, see Item 6 | | |
| 3 | 250104 | ldler Pin 1 Dia. x 4 | 2 | | | |
| 4 | 271331B* | Seal Plate =Black= | - | *Not for individual sale, see Items 20, 21 | | |
| 5 | 272141B | Cover Plate =Black= | 2 | | | |
| 6 | 294483B | Front Tent Service Kit =Black= | 1 | Includes Items 2, 9, 10 | | |
| 7 | 294484B | Rear Tent Service Kit =Black= | 1 | Includes Items 11, 12 | | |
| 8 | 294485B | Middle Tent Service Kit =Black= | 1 | Includes Items 5 | | |
| 9 | 273259B | Front LH Baffle =Black= | 1 | | | |
| 10 | 273260B | Front RH Baffle =Black= | 1 | | | |
| 11 | 273261B | Rear LH Baffle =Black= | 1 | | | |
| 12 | 273262B | Rear RH Baffle =Black= | 1 | | | |
| 13 | 294240B | Front Flow Door Linkage Weld't =Black= | 1 | | | |
| 14 | 273314B | Rear Flow Door Linkage Weld't =Black= | 1 | | | |
| 15 | 294286B | Screen Weldment =Black= | 6 | For All Track Screens | | |
| 16 | 294449B | Rear RH Screen Weldment =Black= | 1 | For Steerable Tandem | | |
| 17 | 294448B | Rear LH Screen Weldment =Black= | 1 | For Steerable Tandem | | |
| 18 | 273718B | Middle RH Screen Weldment =Black= | 2 | For Steerable Tandem | | |
| 19 | 273717B | Middle LH Screen Weldment =Black= | 2 | For Steerable Tandem | | |
| 20 | 273510B | Front Flow Door Linkage Kit =Black= | 1 | Includes Items 4, 13, 22 | | |
| 21 | 273511B | Rear Flow Door Linkage Kit =Black= | 1 | Includes Items 4, 14, 22 | | |
| 22 | 282187B | Tent Hole Cover Plate =Black= | 3 | | | |
| 23 | 294286B | Front LH Screen Weldment =Black= | 1 | For Steerable Tandem | | |
| 24 | 294286B | Front RH Screen Weldement =Black= | 1 | For Steerable Tandem | | |
| 25 | 284721B | Restrictor Weldment =Black= | 12 | | | |
| 26 | 804572 | Axle Lift Pin 1" Dia. x 3 1/2 | 1 | | | |
| 27 | 9002575 | Hydraulic Cylinder 3 x 16 (3000PSI) | 1 | 3/4-16 SAE O-Ring Ports | | |
| 28 | 91262 | Large Flange Screw 3/8-16 UNC x 1 | 16 | Grade 5 | | |
| 29 | 91263 | Locknut, 3/8-16UNC | 56 | Grade 5 | | |
| 30 | 9390-103 | Capscrew 1/2-13 UNC x 2 | 4 | Grade 5 | | |
| 31 | 9391-046 | Cotter Pin 3/16 Dia. x 2 | 6 | | | |
| 32 | 9394-010 | Hex Nut 1/2-13 UNC | 4 | Grade 5 | | |
| 33 | 9404-025 | Lock Washer 1/2 | 4 | | | |
| 34 | 95585 | Large Flange Screw 3/8-16 UNC x 3/4 | 12 | Grade 5 | | |
| 35 | 294449B | Center RH Screen Weldment =Black= | 1 | For Steerable Tandem | | |
| 36 | 294448B | Center LH Screen Weldment =Black= | 1 | For Steerable Tandem | | |

Flow Door Components - Front Flow Door

Please visit www.unverferth.com/parts/ for the most current parts listing.



| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-----------|-------------------------------------|-----|
| 1 | 294283B | Front Tent Weldment | 1 |
| 2 | 273157B | Front LH Door Weldment | 1 |
| 3 | 273158B | Front RH Door Weldment | 1 |
| 4 | 284168 | Bushing 2 1/4 0D x 49/64 ID x 0.500 | 8 |
| 5 | 284169 | Bushing 3/4 0D x 7/16 ID x 0.531 | 8 |
| 6 | 9005471 | Flat Washer 3/8 (Hardened) | 8 |
| 7 | 9003396 | Flange Lock Nut 3/8-16 UNC Gr.5 | 8 |
| 8 | 91299-057 | Capscrew 3/8-16UNC x 1 1/2 Gr.8 | 8 |

Flow Door Components - Middle Flow Door





| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-----------|-------------------------------------|-----|
| 1 | 294284B | Middle Tent Weldment | 1 |
| 2 | 273246B | Middle RH Door Weldment | 1 |
| 3 | 273247B | Middle LH Door Weldment | 1 |
| 4 | 284168 | Bushing 2 1/4 OD x 49/64 ID x 0.500 | 6 |
| 5 | 284169 | Bushing 3/4 OD x 7/16 ID x 0.531 | 6 |
| 6 | 9005471 | Flat Washer 3/8 (Hardened) | 6 |
| 7 | 9003396 | Flange Lock Nut 3/8-16 UNC Gr.5 | 6 |
| 8 | 91299-057 | Capscrew 3/8-16UNC x 1 1/2 Gr.8 | 6 |

Flow Door Components - Rear Flow Door



| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-----------|-------------------------------------|-----|
| 1 | 294285B | Rear Tent Weldment | 1 |
| 2 | 273165B | Rear LH Door Weldment | 1 |
| 3 | 273166B | Rear RH Door Weldment | 1 |
| 4 | 284168 | Bushing 2 1/4 0D x 49/64 ID x 0.500 | 4 |
| 5 | 284169 | Bushing 3/4 OD x 7/16 ID x 0.531 | 4 |
| 6 | 9005471 | Flat Washer 3/8 (Hardened) | 4 |
| 7 | 9003396 | Flange Lock Nut 3/8-16 UNC Gr.5 | 4 |
| 8 | 91299-057 | Capscrew 3/8-16UNC x 1 1/2 G8 | 4 |

Indicator Assembly



Indicator Assembly

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|------------------------------|-----|-----------------------------|
| | 271584 | Complete Indicator Assembly | 1 | Includes Items 1 through 17 |
| 1 | 271582 | Push Rod Indicator | 1 | |
| 2 | 271585 | Bushing - Coupler | 1 | |
| 3 | 271589 | Cable Tube (Push Rod) | 1 | |
| 4 | 271593 | Reducer Bushing | 1 | |
| 5 | 271595R | Flow Door Indicator =Red= | 1 | |
| 6 | 9006610 | Seal (Wiper) | 1 | |
| 7 | 9006611 | Inner Cable (Conduit) - 3/16 | 1 | |
| 8 | 9008612 | Seal (Shaft) | 1 | |
| 9 | 9006630 | Rod End, 3/8" | 1 | |
| 10 | 9006634 | Connector Fitting | 1 | |
| 11 | 9006635 | Quad Ring | 1 | |
| 12 | 9006636 | Wear Ring | 1 | |
| 13 | 271597 | Wire Stop | 1 | |
| 14 | 9006640 | Hose Fitting | 1 | |
| 15 | 9006641 | Snap Ring | 1 | |
| 16 | 9006644 | Retaining Ring - Internal | 1 | |
| 17 | 271586 | Plastic Tubing - 81" | 1 | |

Steering Tandem Indicator Components



Steering Tandem Indicator Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|------------------------------------|-----|------------------|
| 1 | 273524B | Indicator Clamp Weldment =Black= | 1 | |
| 2 | 273525B | Indicator Bolt =Black= | 2 | |
| 3 | 283749R | Indicator Weldment =Red= | 1 | |
| 4 | 9001114 | U-Bolt 1/4-20 UNC | 1 | |
| 5 | 9005109 | Rod End #10-32 | 1 | |
| 6 | 9005127 | Push/Pull Cable 204" with Rod Ends | 1 | Includes Item #5 |
| 7 | 9006037 | Cable Clamp 3/8" | 1 | |
| 8 | 91262 | Flange Screw/Lrg 3/8-16 UNC x 1 | 1 | Grade 5 |
| 9 | 9405-076 | Flat Washer 3/8 USS | 1 | |
| 10 | 97189 | Hex Nut/Large Flange 1/4-20 UNC | 6 | Grade 5 |
| 11 | 97420 | Flange Screw 1/4-20 UNC x 3/4 | 6 | Grade 5 |
| 12 | 9830-016 | Hex Nut #10-32 | 3 | Grade 2 |

Clean Out Door Components


Clean Out Door Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|----------------------|
| 1 | 9390-056 | Capscrew 3/8-16UNC x 1 1/4 | 24 | Grade 5 |
| 2 | 9928 | Locknut 3/8-16UNC | 24 | |
| 3 | 97189 | Large Flange Hex Nut 1/4-20UNC | 12 | |
| 4 | 273748B | Cleanout Door Weldment =Black= | 3 | |
| 5 | 273741B | Door Pivot Plate =Black= | 6 | |
| 6 | 9006351 | Clamp Pair | 6 | |
| 7 | 9006352 | Top Plate | 6 | |
| 8 | 273739B | Front Link Arm Weldment =Black= | 1 | For Tracks |
| ° | 273827B | Front Link Arm Weldment =Black= | 1 | For Steerable Tandem |
| | 273743B | Rear Link Arm Weldment =Black= | 1 | For Tracks |
| 9 | 273828B | Rear Link Arm Weldment =Black= | 1 | For Steerable Tandem |
| 10 | 273730B | Cleanout Door Weldment =Black= | 3 | |
| 11 | 273734B | Door Linkage =Black= | 12 | |
| 12 | 9390-015 | Capscrew 1/4-20UNC x 3 1/2 | 12 | Grade 5 |
| 13 | 91266 | Flange Screw 1/2-13UNC x 1 1/4 | 12 | Grade 5 |
| 14 | 91267 | Flange Nut 1/2-13UNC | 12 | |
| 15 | 273753B | Door Latch Weldment =Black= | 1 | |
| 16 | 9000938 | Lynch Pin 3/8" Dia. x 2 1/4 | 1 | |
| 17 | 271566B | Stop Bushing =Black= | 1 | |
| 18 | 9390-108 | Capscrew 1/2-13UNC x 3 1/4 | 1 | Grade 5 |
| 19 | 94981 | Locknut 1/2-13UNC | 1 | |
| 20 | 9007108 | Gasket w/Adhesive Backing for Clean-Out Door | AR | Specify in Feet |

Ladder Components



Ladder Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|-------|
| 1 | 2003029 | Nylon Bushing, .625" OD x .406" ID x .380" | 6 | |
| 2 | 289294B | Plate-Bracket, Ladder | 1 | |
| 3 | 2003030 | Nylon Bushing, .875" OD x .531" ID x .563" | 4 | |
| 4 | 9405-088 | Flat Washer, 1/2" USS | 6 | |
| 5 | 9390-107 | Capscrew, 1/2"-13UNC x 3" G5 | 4 | |
| 6 | 9003397 | Lock Nut/Top, 1/2"-13UNC | 4 | |
| 7 | TA620384 | Plastic Stop, 1" Dia. x .250" | 8 | |
| 8 | 9005305 | Lynch Pin 3/8" Dia. x 3" | 1 | |
| 9 | 99985 | Button Head Socket, 3/8"-16UNC x 1 1/4" | 2 | |
| 10 | 9008159 | Lock Nut/Top, 3/8"-16UNC | 6 | |
| 11 | 9003503 | Rivet 3/16 X 1/4 | 8 | |
| 12 | 289717B | Ladder Link Weldment | 1 | |
| 13 | 9390-057 | Capscrew, 3/8"-16UNC x 1 1/2" G5 | 4 | |
| 14 | 289328B | Ladder Extension Weldment | 1 | |
| 15 | 289326B | Ladder Weldment | 1 | |
| 16 | 289280B | Step Weldment | 1 | |
| 17 | 289707B | Ladder Extension Weldment | 1 | |
| 18 | 9004998 | Rivet Burr 3/16" | 4 | |
| 19 | 289844B | Ladder Weldment | 1 | |
| 20 | 9388-029 | Carriage Bolt, 5/16"-18UNC x 2" G5 | 4 | |
| 21 | 9405-064 | Flat Washer, 5/16" ID (1/4" Nominal) USS | 8 | |
| 22 | 901527 | Lock Nut/Center, 5/16"-18UNC | 8 | |
| 23 | 9388-024 | Carriage Bolt, 5/16"-18UNC x 3/4" G5 | 4 | |
| 24 | 9388-102 | Carriage Bolt, 1/2"-13UNC x 1" | 2 | |
| 25 | 91267 | Flange Nut, 1/2"-13UNC | 2 | |

Hitch & Tongue Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|--|-----|-------------------|
| 1 | 9004898 | Transport Chain 41,000# | 1 | |
| 2 | 91299-191 | Capscrew 1-8UNC x 4 | 1 | Grade 8 |
| 3 | 92199 | Locknut 1-8UNC | 2 | |
| 4 | 9008857 | Front Window & Trim Assembly 14 15/32" x 19 21/32" | 1 | |
| 5 | 9008680 | Rear Window & Trim Assembly 17 7/32" x 19 21/32" | 2 | |
| 6 | 9390-005 | Capscrew 1/4-20UNC x 1 | 4 | Grade 5 |
| 7 | 294121B | Window Bracket | 2 | (Rear Slope Only) |
| 8 | 9008933 | Pan Head Screw 8-18UNC x 1/2 | 36 | |
| 9 | 9405-064 | Flat Washer 1/4" | 4 | |

Hitch & Tongue Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|----------|----------------------|--|----------|--|
| 10 | 9936 | Locknut 1/4-20UNC | 6 | |
| 13 | 9390-006 | Capscrew 1/4-20UNC x 1 1/4 | 2 | Grade 5 |
| 14 | 94763 | Fender Washer | 2 | |
| 15 | 9008634 | Toolbox | 1 | |
| 16 | 9001968 | Trailer Connector Holder | 1 | |
| 17 | 97420 | Flange Screw 1/4-20UNC x 3/4 | 6 | Grade 5 |
| 18 | 97189 | Large Flange Hex Nut 1/4-20UNC | 6 | |
| 19 | 273368 | Tongue Pin 2 Dia. x 7 3/4 | 2 | |
| | 9005011 | Jack 7,000# Capacity with Pin | 1 | |
| 20 | 9007632 | Jack Pin, 7/8 Dia. w/Chain | 1 | NOT SHOWN |
| 21 | 9005230 | PTO Assembly Complete | 1 | 1 3/4-20 Spline, W2500 |
| 22 | 294128B | Hose Caddy Replacement Kit =Black= | 1 | Includes Items 22A - 22F, 25 and 52 |
| 22A | 294083B | Hose Caddy Weldment =Black= | 1 | |
| 22B | 294085B | Hose Caddy Cover =Black= | 1 | |
| 220 | 294086 | Hose Retainer | 1 | |
| 22D | 9000787 | Trim - Edge | 1/2 | Specify in Feet |
| 22E | 9003848 | Hose Wrap | 3 | Specify in Feet |
| 22E | 91256 | Large Flange Capscrew 5/16-18UNC x 3/4 Grade 5 | 6 | |
| 23 | 9390-130 | Capscrew 5/8-11UNC x 3 1/2 | 2 | Grade 5 |
| 24 | 95905 | Lock Nut/Ctr 5/8-11UNC | 2 | |
| 25 | 9000104 | Cable Tie, 21 1/2" Lg | 2 | |
| 26 | 9005473 | Split Tension Bushing 2 3/8 OD x 2 ID x 1 | 4 | |
| 27 | 91299-195 | Capscrew 1-8UNC x 6 | 1 | Grade 8 |
| 28 | 282329B | Cast Hitch 3.75" Load Bar =Black= CAT 5 | 1 | Standard |
| 29 | 91192 | Retaining Ring 1" | 2 | Standard |
| 29 | 273780G | Tongue Weldment =Green= | 1 | |
| 30 | 273780G 273780R | Tongue Weldment =Red= | 1 | |
| 31 | 273760R 271687B | Spring Retainer Plate | 2 | l |
| 32 | | | | |
| | 9006456 | Polyurethane Spring 4 3/4" Thick | 2 | |
| 33 | 9006457 | Polyurethane Spring 2 1/2" Thick | 2 | Crodo E |
| 34 | 9390-464 | Capscrew 1-8UNC x 10 | | Grade 5 |
| 35 36 | 273237 903171-663 | Nylon Wear Pad Screw Flat Countersunk Head Phillips 5/16"-18UNC x 1 | 2 | |
| 07 | | | | |
| 37 | 91257 | Flange Nut 5/16"-18UNC | 14 | <u> </u> |
| 38 | 281691 | Hitch Pin 1 Dia. x 7 3/8" CAT 5 | 1 | l |
| 39 | 281899 | Wearshoe - Hitch, CAT 5 | 1 | <u> </u> |
| 40 | 281898 | Wearshoe - Hitch, CAT 4 | 1 | Ontional |
| 41 | 282875B | Cast Hitch 3.75" Load Bar =Black= CAT 4 | 1 | Optional |
| 42 | 282876 | Hitch Pin 1" Dia. x 5 1/2" CAT 4 | | Fan Otaan Aula |
| 43 | 9004913 | Load Bar 3 3/4" Dia. with 16 ft. Cable CAT 4 | 1 | For Steer Axle |
| | 9004910 | | 1 | For Tracks |
| 44 | 9008135 | Load Bar 3 3/4" Dia. with 16 ft. Cable CAT 5 | 1 | For Steer Axle |
| | 9008119 | | 1 | For Tracks |
| 45 | 294143B | Optional Hydraulic Jack Kit | 1 | l |
| 48 | 271891B | Shield Tube =Black= | 1 | ļ |
| 49 | 9005376 | U-Nut | 3 | ļ |
| 50 | 9390-053 | Capscrew, 3/8-16UNC x 3/4 Grade 5 | 3 | ļ |
| 51 | 291974G | PTO Bracket =Green= | 1 | ļ |
| | 291974R | PTO Bracket =Red= | 1 | ļ |
| 52 | 91267 | Flange Nut, 1/2-13UNC Grade 5 | 8 | ļ |
| 53 | 289382B | GCM Mounting Bracket =Black= | <u> </u> | |

Suspension Link Components



Suspension Link Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|--------------------|---|-----|--------------------------|
| 1 | 268542 | Flat Washer 2" (3 1/2 OD) | 12 | |
| 2 | 273407B | Suspension Frame Weld =Black= | 1 | |
| 3 | 286103 | Pin Weldment | 1 | |
| 4 | 286139 | Pin Weldment | 1 | |
| 5 | 286140B | Upper Arm Weldment =Black= | 1 | |
| 6 | 286148B | Lower Arm Weldment =Black= | 1 | |
| 7 | 286167 | Pin 2 x 8 3/4 | 4 | |
| 8 | 286168B | Flat Washer 3/4" (3 1/4 OD) =Black= | 2 | |
| 9 | 9006785 | Adapter, 90 Degree 1/8 NPTM x 1/8 NPTF | 4 | |
| 10 | 9005886 | Cylinder 6 x 12 (3000 PSI) | 1 | 3/4-16 & 1 1/16-12 Ports |
| 11 | 92199 | Locknut/Ctr 1-8 UNC | 11 | |
| 12 | 9390-109 | Capscrew 1/2-13 UNC x 3 1/2 | 4 | Grade 5 |
| 13 | 9390-143 | Capscrew 3/4-10 UNC x 1 1/2 | 3 | Grade 5 |
| 14 | 9390-145 | Capscrew 3/4-10 UNC x 2 | 1 | Grade 5 |
| 15 | 9390-187 | Capscrew 1-8 UNC x 3 | 11 | Grade 5 |
| 16 | 9404-033 | Lock Washer 3/4 #10 | 3 | |
| 17 | 9405-104 | Flat Washer 3/4 | 1 | |
| 18 | 94981 | Locknut/Ctr 1/2-13 UNC | 4 | |
| 19 | 95123 | Tension Bushing 2 3/8 OD x 2 ID x 2 Lg. | 4 | |
| 20 | 96732 | Locknut/Ctr 3/4-10 UNC | 1 | |
| 21 | 9405-118 | Flat Washer 1" (2 1/2 OD) USS | 4 | |

Suspension Link To Hub Components



Suspension Link To Hub Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|---|
| 1 | 92199 | Locknut/Ctr 1-8 UNC | 6 | |
| 2 | 9390-187 | Capscrew 1-8 UNC x 3 | 6 | Grade 5 |
| 3 | 92470 | Castle Nut 2-12 UNF | 3 | Grade 5 |
| 4 | 286120 | Suspension Pin Weldment 3" OD | 2 | |
| 5 | 9005474 | Tension Bushing 3 1/2 OD x 3 ID x 3 Lg. | 4 | |
| 6 | 282377 | Flat Washer 3" (4 1/2" OD) | 4 | |
| 7 | 9404-033 | Lock Washer 3/4 | 4 | |
| 8 | 9405-104 | Flat Washer 3/4 | 6 | |
| 9 | 9390-065 | Capscrew, 3/8-16UNC x 3 1/2 | 3 | Grade 5 |
| 10 | 9005934 | Tapered Thrust Bearing 2.51 OD x 4.375 ID x 1.063 Lg. | 1 | |
| 11 | 95905 | Locknut/Ctr 5/8-11 UNC | 1 | Grade 5 |
| 12 | 9390-137 | Capscrew 5/8-11 UNC x 6 1/2 | 1 | Grade 5 |
| 13 | 96732 | Locknut 3/4-10UNC | 2 | Grade 5 |
| 4.4 | 286109B | Clevis Weldment-RH =Black= | 1 | |
| 14 | 286115B | Clevis Weldment-LH =Black= | 1 | |
| 15 | 9006785 | Adapter, 90 Degree 1/8 NPTM x 1/8 NPTF | 3 | |
| 16 | 286216 | King Pin Weldment 2 1/2" OD | 1 | |
| 17 | 9390-143 | Capscrew 3/4-10 UNC x 1 1/2 | 6 | Grade 5 |
| 10 | 267283G | Hub & Spindle Assembly Replacement Kit - M22 Hardware =Green= | _ | Refer to "Steering Tandem Hub |
| 18 | 267283R | Hub & Spindle Assembly Replacement Kit - M22 Hardware =Red= | 1 | Components" Section |
| 19 | 9006046 | Self Lube Bushing 3 OD x 2 1/2 ID x 3 Lg. | 2 | |
| 20 | 286194B | Spindle Retainer Casting =Black= | 1 | |
| 21 | 286233B | Washer 3 7/8" OD x 2.060" ID =Black= | 3 | |
| 22 | 286100 | Brake Kit | 1 | Refer to "Optional Brake Components" Section |
| | 267288 | Stud & Nut Kit M22 x 1.5 | 1 | Refer to "Steering Tandem Hub |
| 23 | 9007001 | Stud Bolt, M22 x 1.5 x 4 | 10 | Components" Section |
| | 97319 | Flanged Cap Nut, M22 x 1.5 | 10 | |
| 24 | 902875 | Locknut, 3/8-16UNC | 3 | |

Suspension Linkage Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---------------------------|-----|-------|
| 1 | 283725 | Pin Weldment | 2 | |
| 2 | 286131B | Link - Rocker, RH Painted | 1 | |
| 3 | 286150B | Tie - Rod Assembly | 4 | |
| 4 | 286174B | Pivot Bushing, LH | 2 | |
| 4 | 286175B | Pivot Bushing, RH | 2 | |

Suspension Linkage Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|----------------------------|-----|---------------------------|
| 5 | 286181B | Link Weldment, Rocker | 1 | |
| 6 | 286182 | Washer | 4 | |
| 7 | 286183B | Bar - Spacer | 2 | |
| 8 | 286185 | Bushing - Spacer | 8 | |
| 9 | 286204B | Tie - Rod, Steering Link | 2 | Includes Items 44, 45, 46 |
| 10 | 286238 | Pin Replacement Kit | 4 | |
| 11 | 286223B | Cylinder Clamp | 2 | |
| 12 | 286228B | Bearing Retainer | 2 | |
| 13 | 286229B | Bearing Retainer | 2 | |
| 14 | 286235 | Pin - Cylinder | 2 | |
| 15 | 9004613 | Bushing - Self Lubricating | 4 | |
| 16 | 9006055 | Bushing - Self Lubricating | 2 | |
| 17 | 91177 | Retaining Ring | 10 | |
| 18 | 9390-007 | HCS 1/4 x 1 1/2 UNC | 16 | Grade 5 |
| 19 | 9390-105 | HCS 1/2 x 2 /12 UNC | 4 | Grade 5 |
| 20 | 9390-124 | HCS 5/8 x 2 UNC | 8 | Grade 5 |
| 21 | 9390-147 | HCS 3/4 x 2 1/2 UNC | 4 | Grade 5 |
| 22 | 9390-185 | HCS 1 x 2 1/2 UNC | 44 | Grade 5 |
| 23 | 9390-189 | HCS 1 x 3 1/2 UNC | 4 | Grade 5 |
| 24 | 9394-020 | Hex Nut 1-8 UNC | 8 | Grade 5 |
| 25 | 9404-025 | Lock Washer 1/2 | 4 | |
| 26 | 9404-042 | Lock Washer 1 EXTRA | 8 | |
| 27 | 9405-064 | Flat Washer 1/4 USS | 8 | |
| 28 | 9405-086 | Flat Washer 1/2 SAE | 4 | |
| 29 | 9405-104 | Flat Washer 3/4 SAE | 4 | |
| 30 | 95905 | Locknut/CTR 5/8-11 UNC | 8 | |
| 31 | 96732 | Locknut/CTR 3/4-10 | 4 | |
| 32 | 9936 | Locknut 1/4-20 | 4 | |
| 34 | 286152B | Tube - Tie Rod | 1 | |
| 35 | 9004744 | Male Rod End, 1 1/4-12 LH | 1 | |
| 36 | 9004827 | Hex Jam Nut 1 1/2-12 LH | 1 | |
| 37 | 9004928 | Tie Rod Clamp - 2" | 1 | Includes Items 38 & 39 |
| 38 | 9801 | Locknut/Top 5/8-11 UNC | 1 | |
| 39 | 9390-128 | HCS, 5/8 x 3 UNC | 1 | Grade 5 |
| 40 | 9005945 | RH Thread Tie Rod End | 1 | Includes Items 41 & 42 |
| 41 | 9000875 | Zerk 90° | 1 | |
| 42 | 9393-018 | Slotted Nut 7/8 UNF G2 | 1 | |
| 44 | 286203B | Tie Rod Tube | 1 | |
| 45 | 9004827 | Hex Jam Nut 1 1/2-12 LH | 1 | |
| 46 | 9395-023 | Hex Jam Nut 1 1/4 UNF G5 | 1 | |

Suspension Link Grease Bank Components



Suspension Link Grease Bank Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|--|
| 1 | 282696B | GREASE HOSE BRACKET =Black= | 1 | |
| 2 | 9000106 | CABLE TIE 7 1/2 | 6 | |
| 3 | 9004764 | ELBOW 90 DEG 1/8 NPTF x 1/8 NPTF | 9 | |
| 4 | 9006753 | HOSE COUPLING 1/8 NPTM SWIVEL (2 PIECE) | 18 | |
| 5 | 9006785 | ADAPTER-90 DEG 1/8 NPTM X 1/8 NPTF | 9 | |
| 6 | 9006876 | HIGH PRESSURE GREASE HOSE 61" | 1 | Upper Clevis Pin |
| 7 | 9006877 | HIGH PRESSURE GREASE HOSE 68" | 1 | King Pin |
| 8 | 9006878 | HIGH PRESSURE GREASE HOSE 46" | 3 | Lower Cylinder Pin Lower Clevis Pin Upper Cylinder Pin |
| 9 | 9006879 | HIGH PRESSURE GREASE HOSE 36" | 1 | Upper Link Arm Pin |
| 10 | 9006880 | HIGH PRESSURE GREASE HOSE 26" | 3 | Upper Link Arm Pin (2 Places) Lower Link Arm Pin |
| 11 | 93426 | GREASE ZERK | 9 | |
| 12 | 9390-184 | CAPSCREW 1-8UNC X 2 1/4 GR5 | 1 | |
| 13 | 9394-020 | HEX NUT 1-8UNC GR5 | 1 | |
| 14 | 9404-041 | LOCK WASHER 1 | 1 | |

<u>NOTE</u>: For more suspension link grease bank details, refer to "Lubrication" in the MAINTENANCE section.

Steering Tandem Internal Bracing Components



Steering Tandem Internal Bracing Components

PART NO. DESCRIPTION NOTES ITEM QTY 1 294409B Cross Tube Weldment =Black= 3 Axle Truss Weldment =Black= 2 273415B 2 3 273491B Wheel Well Brace =Black= 2 4 91267 Locking Flange Nut 1/2-13UNC 36 Grade 5 5 9005705 Flange Screw 1/2-13UNC x 1 1/2 36 Grade 5 91262 Screw/Large Flange 3/8-16UNC x 1 6 32 Grade 5 7 91263 Nut/Large Flange 3/8-16UNC 32 Grade 5 92199 Locknut 1-8UNC 16 8 Grade 5 9 9390-185 Capscrew 1-8UNC x 3 16 Grade 5 Flat Washer 1" USS 10 9405-118 16

Track Internal Bracing Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--------------------------------|-----|---------|
| 1 | 294409B | Cross Tube Weldment =Black= | 3 | |
| 2 | 91267 | Flange Nut 1/2-13UNC | 36 | Grade 5 |
| 3 | 9005705 | Flange Screw 1/2-13UNC x 1 1/2 | 36 | Grade 5 |

Notes

Sideboard Components



Sideboard Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--|------|---------|
| 1 | 294429B | Front Board Weldment =Black= | 1 | |
| 2 | 294434B | Rear Board Weldment =Black= | 1 | |
| 3 | 294419B | Front LH Board Weldment =Black= SHOWN | 1 | |
| 4 | 294421B | 2nd LH Board Weldment =Black= | 1 | |
| 5 | 294423B | 3rd LH Board Weldment =Black= | 1 | |
| 6 | 294425B | Rear LH Board Weldment =Black= SHOWN | 1 | |
| 7 | 294411B | Front RH Board Weldment =Black= SHOWN | 1 | |
| 8 | 294413B | 2nd RH Board Weldment =Black= | 1 | |
| 9 | 294415B | 3rd RH Board Weldment =Black= | 1 | |
| 10 | 294417B | Rear RH Board Weldment =Black= SHOWN | 1 | |
| 11 | 294441B | Sideboard Brace Weldment =Black= | 3 | |
| 12 | 294439B | Plate - Side Board Brace =Black= | 2 | |
| 13 | 294440B | Plate - Side Board Brace =Black= | 2 | |
| 14 | 9008680 | Window and Trim Assembly | 2 | |
| 15 | 9008933 | Pan Head Phillips Screw 8-18UNC x 1/2" | 24 | |
| 16 | 9004626 | Hinge | 12 | |
| 17 | 91256 | Screw/Large Flange, 5/16-18 UNC x 3/4 | 48 | Grade 5 |
| 18 | 91257 | Hex Nut/Large Flange, 5/16-18 UNC | 48 | Grade 5 |
| 19 | 91262 | Screw/Large Flange, 3/8-16 UNC x 1 | 38 | Grade 5 |
| 20 | 91263 | Hex Nut/Large Flange, 3/8-16 UNC | 63 | Grade 5 |
| 21 | 95585 | Capscrew/Large Flange 3/8-16 UNC x 3/4 | 14 | Grade 5 |
| 22 | 294437B | Plate - Sideboard Corner =Black= | 2 | |
| 23 | 294438B | Plate - Sideboard Corner =Black= | 2 | |
| 24 | 9003259 | Flange Screw 3/8"-16UNC x 1 1/4" | 11 | Grade 5 |

Steering Tandem Wheels & Tires

Please visit www.unverferth.com/parts/ for the most current parts listing.



TIRES

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Tire manufacturers' phone numbers and websites are listed in the Maintenance Section for your convenience.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|-----------------------|-----|---------------------------------------|
| | 18009 | Wheel & Tire Accomply | 4 | 30 x 38 / 900/60R38 R1W (Off-White) |
| | 18009SM | Vheel & Tire Assembly | 4 | 30 x 38 / 900/60R38 R1W (Silver Mist) |
| 1 | 9500845 | Wheel Only | 4 | 30 x 38 (Off-White) |
| | 9500845SM | Wheel Only | 4 | 30 x 38 (Silver Mist) |
| | 99497 | Tire Only | 4 | TL900/60R38C R-1W |
| 2 | 93300 | Valve Stem | 4 | |
| 2 | 95365 | Plug | 4 | |

Optional Brake Components



Optional Brake Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|--|
| 1 | 283711 | Brake Rotor Plate | 4 | |
| 2 | 9002273 | Cross, 9/16-18 JIC M | 1 | |
| 3 | 9003735 | Cable Tie, 11" Long | 24 | |
| 4 | 9004762 | Brake Assembly | 1 | Includes Items 4A, 4B, 4C |
| 4A | 9007135 | Brake Pad - Outer | 1 | |
| 4B | 9007136 | Brake Pad - Inner | 1 | |
| 4C | 9007137 | Brake Assembly Seal Kit | 1 | Not Shown |
| 5 | 9005173 | Quick Coupler | 1 | |
| 6 | 9006005 | Adapter, 9/16-18 JIC M to M18x1.5 | 1 | |
| 7 | 9005970 | Hydraulic Fitting, 7/16-20 UNF ORB x 45° 9/16 UNF JIC | 4 | Locate/Replace in lowest bleeder port of each caliper. |
| 8 | 9004886 | Hose, 1/4 x 408 (3000 PSI) | 1 | |
| 9 | 9005974 | Hose, 1/4 x 97 (3000 PSI) | 1 | |
| 10 | 9005975 | Hose, 1/4 x 70 (3000 PSI) | 2 | |
| 11 | 9005976 | Hose, 1/4 x 99 (3000 PSI) | 2 | |
| 12 | 9390-147 | Capscrew, 3/4-10 UNC x 2 1/2 | 24 | Grade 5 - Torque @ 200 to 220 FtLbs. |
| 13 | 9390-348 | Capscrew, 5/8-18 UNF x 2 | 40 | Grade 5 - Torque @ 124 to 137 FtLbs. |
| 14 | 9404-029 | Lock Washer, 5/8 | 40 | |
| 15 | 9404-033 | Lock Washer, 3/4 | 24 | |
| 16 | 9875 | Tee, 9/16-18 JIC M | 1 | |
| 17 | 9876 | Elbow, 90° 9/16-18 JIC M x 9/16-18 JIC FM | 2 | |
| 18 | 286237 | Shim - Brake Caliper | 16 | Use As Needed |
| 19 | 9007162 | Brakes Information Tag | 1 | |

Steering Tandem Hydraulic Suspension Components



Steering Tandem Hydraulic Suspension Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|--------------------|---|-----|---|
| 1 | 9000299 | Hydraulic Adapter Fitting | 2 | 9/16-18 JIC Female Swivel Nut x 3/8-18 NPTF Female |
| 2 | 9501684 | Hydraulic Hose 3/8 x 68 | 4 | (3000 PSI) 9/16-18 JIC Female Swivel Nut Both Ends |
| 3 | 9003736 | Breather 3/8 NPT | 2 | |
| 4 | 9003813 | Top Plate | 6 | |
| 5 | 9003818 | Top Plate | 6 | |
| 6 | 9003819 | Single Clamp Pair (1.05) | 6 | |
| 7 | 9004652 | Single Clamp Pair (0.67) | 6 | |
| 8 | 9005426 | Ball Valve (7250 PSI) | 2 | 3/4-16 O-R Female Ports |
| 9 | 9005428 | Hydraulic Fitting | 2 | 3/4-16 Male ORB x 13/16-16 Female ORFS |
| 10 | 9005886 | Hydraulic Cylinder 6 x 12 | 4 | (3000 PSI) 3/4-16 and 1 1/16-12 Ports |
| 11 | 9005947 | Hyd. Fitting - Branch Tee | 2 | 1 3/16-12 ORFS x 1 3/16-12 ORFS Run x 1 1/16-12 ORB |
| 12 | 9005948 | Hyd. Fitting - 90deg Elbow | 2 | 1 1/16-12 ORB x 1 3/16-12 ORFS |
| 13 | 9005949 | Hydraulic Fitting | 2 | 1 3/16-12 ORFS Female x 13/16-16 ORFS Male |
| 14 | 9005987 | Hydraulic Hose 3/4 x 116 | 2 | (3000 PSI) 1 3/16-12 Swivel 45deg FmI ORFS Both Ends |
| 15 | 91383 | Male Tip Coupling | 3 | 3/4-16 Female O-Ring (3000PSI) |
| 16 | 91511 | Dust Cap/Iso Coupler | 2 | |
| 17 | 9390-007 | Hex Capscrew | 12 | 1/4-20 UNC x 1 1/2 Grade 5 |
| 18 | 9390-009 | Hex Capscrew | 12 | 1/4-20 UNC x 2 Grade 5 |
| 19 | 98508 | Hydraulic Fitting - Union | 2 | 3/4-16 O-R Male x 3/4-16 O-R Male |
| 20 | 9874 | Hyd. Fitting - 90deg Elbow | 4 | 9/16-18 JIC Male x 3/4-16 O-R Male |
| 21 | 9875 | Hydraulic Tee Fitting | 2 | 9/16-18 JIC Male All 3 Branches |
| 22 | 9005564 | Hydraulic Hose 1/4 x 305 - Suspension Charge | 1 | (3000 PSI) 3/4-16 UNF-1A x O-R Male Solid Straight Both Ends |
| 23 | 97286 | Pioneer Coupler | 1 | SAE 3/4-16 O-R Female 2-Way Sleeve |

Steering Hydraulic Plumbing Components



Steering Hydraulic Plumbing Components

| ITE | Μ | PART NO. | DESCRIPTION | QTY | NOTES |
|-----|----|----------|-------------------------------|-----|--|
| 1 | | 286223B | Cylinder Clamp =Black= | 2 | |
| 2 |) | 9003814 | Top Plate | 6 | |
| 3 | } | 9003816 | Poly Clamp Pair (0.54) | 6 | |
| 4 | ŀ | 9004637 | Hydraulic Hose 1/4 x 430 | 2 | (3000 PSI) 9/16-18 JIC Female Swivel x 3/4-16 Male 0-R |
| 5 | 5 | 9004831 | Hose Marker Sleeve | 1 | 1"Dia. x 1 1/2 (Turn Left) |
| 6 | 5 | 9004832 | Hose Marker Sleeve | 1 | 1"Dia. x 1 1/2 (Turn Right) |
| 7 | , | 9008730 | Steering Valve - Directional | 1 | 2800 PSI Relief Setting |
| | 8 | 9008731 | Solenoid Valve Cartridge | 1 | 2 Position, 2 Way w/ Coil |
| | 9 | 9005664 | Valve - Directional | 2 | 3/4 Dia. x 3 11/32 (2800 PSI), 12 GPM |
| | 10 | 9005665 | Valve Block | 1 | |
| 1 | 2 | 9005991 | Cylinder-Welded, Dbl Ended | 1 | 3 x 10 w/ 3/4 ORB Ports (3000 PSI) |
| 1 | 3 | 9005992 | Hydraulic Hose 1/2 x 15 | 2 | (3000 PSI) 3/4-16 JIC Swivel Female Both Ends |
| 1 | 4 | 91383 | Male Tip Coupling | 2 | 3/4-16 Female 0-Ring (3000PSI) |
| 1 | 5 | 9863 | Hyd. Fitting - 90° Elbow | 2 | 3/4-16 JIC Male x 3/4-16 ORB Male |
| 1 | 6 | 9390-009 | Hex Capscrew | 2 | 1/4-20 UNC x 2 Grade 5 |
| 1 | 7 | 9390-032 | Hex Capscrew | 6 | 5/16-18 UNC x 1 1/2 Grade 5 |
| 1 | 8 | 9390-124 | Hex Capscrew | 8 | 5/8-11 UNC x 2 Grade 5 |
| 1 | 9 | 9936 | Locknut/Ctr 1/4-20 UNC | 2 | |
| 2 | 0 | 95905 | Locknut/Ctr 5/8-11 UNC | 8 | |
| 2 | 1 | 96842 | Hyd. Fitting - 45° Elbow | 2 | 9/16-18 JIC Male x 9/16-18 ORB Male |
| 2 | 2 | 93586 | Hydraulic Fitting - 45° Elbow | 2 | 3/4-16 JIC Male x 3/4-16 ORB Male |

Steering Tandem Hub Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|-----------------|
| -1 | 267283G | Hub & Spindle Assembly with M22 x 1.5 Hdw =Green= | 1 | |
| 1 | 267283R | Hub & Spindle Assembly with M22 x 1.5 Hdw =Red= | | |
| 2 | 283739G | Hub Sub-Asy with M22 x 1.5 Hdw =Green= | 1 | |
| | 283739R | Hub Sub-Asy with M22 x 1.5 Hdw =Red= | I | |
| 3 | 92462 | Outer Bearing Cup | 1 | |
| 4 | 92476 | Inner Bearing Cup | 1 | |
| 5 | 9007001 | Stud Bolt, M22 x 1.5 x 4 | 10 | |
| 6 | 9006348 | Scale Spindle 4 1/2" Dia. with 21 Ft. Cable | 1 | With Scales |
| 7 | 92455 | Seal | 1 | |
| 8 | 92464 | Outer Bearing Cone | 1 | |
| 9 | 286171G | Hub Cap "Bolt-On Type" =Green= | 1 | |
| 9 | 286171R | Hub Cap "Bolt-On Type" =Red= | I | |
| 10 | 284230 | Gasket | 1 | |
| 11 | 92470 | Castle Nut, 2-12UNF | 1 | Grade 5 |
| 12 | 92472 | Spindle Washer (Hardened) | 1 | |
| 13 | 92545 | Inner Bearing Cone | 1 | |
| 14 | 9390-026 | Capscrew, 5/16-18UNC x 1/2 | 4 | Grade 5 |
| 15 | 9390-064 | Capscrew, 3/8-16UNC x 3 1/4 | 1 | Grade 5 |
| 15A | 902875 | Locknut, 3/8-16UNC | 1 | |
| 16 | 91160 | Grease Zerk | 1 | |
| 17 | 267275 | Wheel Nut Kit | 1 | Use with Item 5 |
| 18 | 97319 | Flanged Cap Nut, M22 x 1.5 | 10 | |

Track Axle Mounting Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|--------------------------------------|-----|---------------|
| 1 | 282690 | Washer 8 1/2" OD | 4 | |
| 2 | 282102 | Track Pivot Shaft 7" Dia. | 2 | |
| 3 | 9404-041 | Lock Washer 1" | 8 | |
| 4 | 282689B | Cover Plate | 2 | |
| 5 | 9390-184 | Capscrew 1"-8UNC x 2 1/4" | 8 | Grade 5 |
| 6 | 93426 | Grease Zerk | 2 | |
| 7 | 9006816 | Adapter 1/8"NPT | 2 | |
| 8 | 9006785 | 90° Adapter | 2 | |
| 9 | 91192 | Retaining Ring 1" | 8 | |
| 10 | 9005811 | Load Bar 3 1/2" Dia. w/ 30 Ft. Cable | 4 | |
| 11 | 282876 | Pin 1" Dia. x 5 1/2" | 4 | |
| 12 | 804685 | Flat Washer 2" | 16 | |
| 13 | 9008441 | Elastic Locknut 1"-14UNS Grade 8 | 16 | |
| 14 | 91299-1458 | Capscrew 1"-14UNS x 3 1/2" Grade 8 | 16 | |
| 15 | 804685 | Flat Washer 2" | 16 | |
| 16 | 9390-464 | Capscrew 1"-8UNC x 10" | 2 | Grade 5 |
| 17 | 92199 | Lock Nut 1-8UNC | 2 | |
| 10 | 282069B | Avia Waldmant Black | 4 | Standard Axle |
| 18 | 267797B | Axle Weldment =Black= | | 50" Axle |
| 19 | 268838B | Axle Mount Casting =Black= | 4 | |

Electric Over Hydraulic (EOH) Valve Functions and Wire Locations 5 Spool (Optional)



| PORT | END OF CYLINDER | FUNCTION |
|------|-----------------|--------------------|
| A | BUTT END | Flow Door |
| В | RAM END | Flow Door |
| С | RAM END | Auger Fold |
| D | BUTT END | Auger Fold |
| E | RAM END | Spout Tilt Out |
| F | BUTT END | Spout Tilt In |
| G | RAM END | Spout Rotate Back |
| Н | BUTT END | Spout Rotate Front |
| I | BUTT END | Auger Tilt Down |
| J | RAM END | Auger Tilt Up |
| Р | | Tractor Pressure |
| Т | | Tractor Return |

Notes

Electric Over Hydraulic (EOH) Valve Assembly Components 5 Spool (Optional)



Electric Over Hydraulic (EOH) Valve Assembly Components 5 Spool (Optional)

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|--|
| 1 | 293416 | EOH Block Assembly - 5 Spool Replacement Kit | 1 | Includes Items 2-7 and Instruction Sheet |
| 2 | 9003856 | Pilot Check Valve | 4 | |
| 3 | 9005769 | Coil - 12 VDC DN-40 | 11 | |
| 4 | 9008667 | Manifold Block - 5 Spool | 1 | |
| 5 | 9008416 | Cartridge Valve - 4 Way, 3 Position - Closed Center w/Detented Manual Override | 3 | Includes Retaining Cap |
| | 9003906 | Seal Kit | - | |
| 6 | 9008463 | Cartridge Valve - 4 Way, 3 Position - Open Center w/Detented Manual Override | 2 | Includes Retaining Cap |
| | 9003906 | Seal Kit | - | |
| 7 | 9008438 | Cartridge Valve - 2 Way, 2 Position w/Push Type Manual Overide | 1 | |
| | 9003904 | Seal Kit | - | |

EOH Tractor Circuit Hydraulic Components (Optional)



| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|---|
| 1 | 95802 | Hydraulic Hose, 1/2 x 205" - 3000 PSI | 1 | |
| 2 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 1 | |
| 3 | 9008601 | Hose Grips - Tan (Pair) - Hydraulic Pressure | 1 | Solid Tan - Cylinder Extended |
| 4 | 9008601 | Hose Grips - Tan (Pair) - Hydraulic Return | 1 | Half Tan/Half Gray - Cylinder Retracted |
| 5 | 9006527 | JIC Tube Reducer 9/16-18 UNF Male x 9/16-UNF Female | 1 | |
| 6 | 901568 | Elbow, 90° Extra Long 3/4-16 JIC x 3/4-16 Male O-Ring | 1 | |
| 7 | 91257 | Large Flange Hex Nut, 5/16-18UNC Gr.5 | 3 | |
| 8 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 9 | 98508 | Adapter 3/4-16 O-Ring Male x 3/4-16 O-Ring Male | 1 | |
| 10 | 9006994 | Check Line Valve 145 PSI | 1 | |
| 11 | 9390-042 | Capscrew, 5/16-18UNC x 4 Gr.5 | 3 | |
| 12 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 1 | |
| 13 | 272606B | Valve Cover Plate | 1 | Also Order Item #21 |
| 20 | 9005403 | 120 Micron Hydraulic Filter | 1 | |
| 21 | 9008564 | Decal, CAUTION (Valve Block) | 1 | Add To Inside Cover Plate #13 |

Brent 2096 - Parts

Flow Door Circuit Hydraulic Components



| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--|------|---|
| 1 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 2 | Optional |
| 2 | 9002575 | Hydraulic Cylinder, 3 x 16" - 3000 PSI | 1 | |
| 3 | 9004442 | Hydraulic Hose, 1/4 x 54" - 3000 PSI | 1 | |
| 4 | 9006607 | Hydraulic Hose, 1/4 x 50" - 3000 PSI | 1 | |
| 5 | 93472 | Hydraulic Hose, 1/4 x 16" - 3000 PSI | 1 | |
| 6 | 9002888 | Hydraulic Hose, 1/4 x 27" - 3000 PSI | 1 | |
| 7 | 95192 | Bulkhead Union, 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 8 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 6 | |
| 9 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 10 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 11 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 10 | 9008596 | Hose Grips - Red (Pair) - Flow Door Open | 1 | Solid Red - Cylinder Extended |
| 12 | 9008596 | Hose Grips - Red (Pair) - Flow Door Close | 1 | Half Red/Half Gray - Cylinder Retracted |

Auger Tilt Hydraulic Components



| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|--|
| 1 | 9000925 | Hydraulic Hose, 1/4 x 78" - 3000 PSI | 2 | |
| 2 | 9000933 | Hydraulic Cylinder, 3 1/2 x 20 - 3000 PSI | 1 | |
| 3 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 9 | Optional |
| 4 | 9002155 | Tee, 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 1 | |
| 5 | 9002719 | Accumulator - 1800 PSI | 1 | |
| 6 | 9002720 | Adapter, 3/4-16 OR Male x 9/16-18 JIC Female | 1 | |
| 7 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 6 | |
| 8 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 9 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 10 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 11 | 9008599 | Brent Hose Grips (Blue Pair) - Auger Pivot Up | 1 | Solid Blue - Cylinder Extended |
| | 9008599 | Brent Hose Grips (Blue Pair) - Auger Pivot Down | 1 | Half Blue/Half Gray - Cylinder Retracted |

Auger Fold Hydraulic Components



| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|---|
| 1 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 9 | Optional |
| 2 | 9002199 | Reducer, 9/16-18 JIC Female x 9/16-18 JIC Male | 1 | |
| 3 | 9004730 | Hydraulic Cylinder, 3 x 22" - 3000 PSI | 1 | |
| 4 | 9006608 | Hydraulic Hose, 1/4 x 84" - 3000 PSI | 1 | |
| 5 | 93594 | Hydraulic Hose, 1/4 x 59" - 3000 PSI | 1 | |
| 6 | 95193 | Adapter, 9/16-18 JIC Female x 9/16-18 JIC Male | 5 | |
| 7 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 6 | |
| 8 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 9 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 10 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 44 | 9008597 | Brent Hose Grips (Green Pair) - Auger Raise | 1 | Solid Green - Cylinder Extended |
| 11 | 9008597 | Brent Hose Grips (Green Pair) - Auger Lower | 1 | Half Green/Half Gray - Cylinder Retracted |

EOH Spout Rotate & Tilt Hydraulic Components (Optional)


EOH Spout Rotate & Tilt Hydraulic Components (Optional)

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--|------|--|
| 1 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 5 | |
| 2 | 9003814 | Clamp Top Plate, 1/4 x 1 1/8 x 2 1/16 | 4 | |
| 3 | 9003816 | Clamp, Polypropylene | 4 | |
| 4 | 97445 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 O-Ring ADJ Male | 1 | |
| 5 | 9005135 | Hydraulic Cylinder, 1 1/2 x 8 - 3000 PSI | 1 | |
| 6 | 9008598 | Hose Grips - Yellow (Pair) - Spout Out | 1 | Solid Yellow - Cylinder Extended |
| 7 | 9003347 | Hydraulic Hose, 1/4 x 224" - 3000 PSI | 2 | |
| 8 | 9007626 | Hydraulic Motor | 1 | |
| 9 | 9006694 | Hydraulic Hose, 1/4 x 314" - 3000 PSI | 1 | |
| 10 | 9006695 | Hydraulic Hose, 1/4 x 324 1/2" - 3000 PSI | 1 | |
| 11 | 91257 | Large Flange Hex Nut, 5/16-18UNC Grade 5 | 2 | |
| 12 | 9390-031 | Capscrew, 5/16"-18UNC x 1 1/4" G5 | 2 | |
| 13 | 9390-034 | Capscrew, 5/16"-18UNC x 2" G5 | 2 | |
| 14 | 95193 | Adapter, 9/16-18 JIC Female x 9/16-18 JIC Male | 2 | |
| 15 | 9008598 | Hose Grips - Yellow (Pair) - Spout In | 1 | Half Yellow/Half Gray - Cylinder Retracted |
| 16 | 98435 | Adapter, 9/16-18 JIC Male x 9/16-18 O-Ring Male | 2 | |
| 17 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 18 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 19 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |

Cylinders

Please visit www.unverferth.com/parts/ for the most current parts listing.

Auger Flow Door Cylinder

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-----------------|-----|--------------------------------|
| | 9002575 | Cylinder 3 x 16 | 1 | 3/4-16 O-Ring Ports (3000 PSI) |
| 1 | 9003772 | Seal Kit | 1 | |

Auger Fold Cylinder

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-----------------|-----|--------------------------------|
| | 9004730 | Cylinder 3 x 22 | 1 | 3/4-16 O-Ring Ports (3000 PSI) |
| 1 | 9003772 | Seal Kit | 1 | |

Auger Tilt Cylinder

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---------------------|-----|--------------------------------|
| | 9000933 | Cylinder 3 1/2 x 20 | 1 | 3/4-16 O-Ring Ports (3000 PSI) |
| 1 | 9001081 | Seal Kit | 1 | |

Steering Cylinder

| ITEM | ART NO. | DESCRIPTION | QTY | NOTES |
|------|---------|-----------------------------------|-----|--------------------------------|
| | 9005991 | Cylinder 3 x 10, Welded-Dbl Ended | 1 | 3/4-16 O-Ring Ports (3000 PSI) |
| 1 | 9006027 | Seal Kit | 1 | |



Cylinders

Please visit www.unverferth.com/parts/ for the most current parts listing.

Suspension Cylinder

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|----------------------------|-----|---------------------------------|
| | 9005886 | Cylinder 6 x 12 (3000 PSI) | 4 | 3/4-16 & 1 1/16-12 O-Ring Ports |
| 1 | 9006026 | Seal Kit | 1 | |

Optional Spout Rotate Cylinder - 1 1/2" x 8"

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--------------------|-----|------------------------------------|
| | 9005135 | Cylinder 1 1/2 x 8 | 1 | #6 9/16-18 O-Ring Ports (3000 PSI) |
| 1 | 9005419 | Seal Kit | 1 | |

Auger Spout Tilt Cylinder

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--------------------|-----|------------------------------------|
| | 9005135 | Cylinder 1 1/2 x 8 | 1 | #6 9/16-18 O-Ring Ports (3000 PSI) |
| 1 | 9005419 | Seal Kit | 1 | |

Optional Jack Cylinder - 3" x 8"

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--------------------|-----|-------|
| | 9006422 | Cylinder, Complete | 1 | |
| 1 | 9007138 | Seal Kit | 1 | |



Gearbox Components



Gearbox Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|-----------------------------|
| | 9007366 | Gearbox Complete | 1 | Includes Items 1 through 22 |
| 1 | 9003453 | Reducer Bushing, 1/2-14 NPTF M x 1/8-27 NPTF F | 1 | |
| 2 | 9006381 | Glass Sight Plug | 1 | |
| 3 | 9007492 | Gearbox Housing Q800 w/Tapped Holes | 1 | |
| 4 | 9007493 | Gearbox Housing Q800 w/Through Holes | 1 | |
| 5 | 9007494 | Gearbox Shaft 2 1/4" Dia. | 1 | |
| 6 | 9007495 | Gear Shaft Assembly 29 Tooth, 2 1/4-17 Spline | 1 | |
| 7 | 9007496 | Gear 16 Tooth Splined | 1 | |
| 8 | 9007497 | Bearing Cup & Cone Set, 3.740 OD x 1 1/4 | 1 | |
| 9 | 9007498 | Bearing Cone 2 1/4 ID x 1 | 2 | |
| 10 | 9007499 | Bearing Cup 3.8437 OD x 0.7812 | 2 | |
| 11 | 9007500 | Bearing Cone 2 ID x 1.5312 | 1 | |
| 12 | 9007501 | Bearing Cup 4.125 OD | 1 | |
| 13 | 9007502 | End Cap | 1 | |
| 14 | 9007503 | Retaining Ring - External 2" Nominal Shaft Dia. | 1 | |
| 15 | 9007504 | Shim - 0.025 | 1 | |
| 16 | 9007505 | Shim - 0.030 | 1 | |
| 17 | 9007508 | Shaft Seal | 2 | |
| 18 | 9007511 | Shim - 0.005 | 2 | |
| 19 | 9007512 | Shim - 0.003 | 1 | |
| 20 | 903161-060 | Flange Screw 1/2-13UNC x 2 1/2 | 12 | |
| 21 | 92352 | Pressure Relief | 1 | |
| 22 | 95283 | Plug | 3 | |

Electrical Components - 5 Function Control Grip



Electrical Components - 5 Function Control Grip

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|--|-----|-------------------------------------|
| 1 | 9008106 | Front Harness - 260" | 1 | |
| 2 | 9009030 | Clearance Harness | 1 | |
| 3 | 9008100 | Rear Harness | 1 | |
| 4 | 92450 | 7-Way Plug | 1 | |
| 5 | 268678B | Light Guard Plate =Black= | 2 | |
| 6 | 273371G | Harness Cover =Green= | | |
| 6 | 273371R | Harness Cover =Red= | 4 | |
| 7 | 273894B | Light Bracket =Black= | 2 | |
| 8 | 273531B | Light Cover =Black= | 8 | |
| 9 | 271574B | Lamp Mount Plate =Black= | 1 | |
| 10 | 9001005 | Rubber Grommet | 9 | |
| 11 | 9008957 | Work Flood Lamp (LED) | 4 | |
| 12 | 9005688 | External Tooth Lock Washer | 1 | NOT SHOWN |
| 13 | 9007223 | Proximity Switch | 1 | |
| 14 | 9008252 | Joystick Controller Extension Harness | 1 | |
| 15 | 9008730 | Steering Valve | 1 | |
| 10 | 9006345 | LED Lamp - Red | | |
| 16 | 232169 | LED Lamp - Red - Replacement Kit | - 2 | Includes Lamp, & Items 14, 37, & 41 |
| 17 | 9005142 | LED Lamp - Amber | 2 | |
| 18 | 9005529 | Amber Light | 8 | |
| 19 | 9005542 | Light Harness - 2 Wire | 8 | |
| 20 | 9005654 | Rocker Switch Assembly | 1 | |
| 21 | 9008265 | L-Series Control Grip - 5 Function | 1 | |
| 22 | 9009069 | Clearance Harness | 1 | |
| 23 | 9007290 | "T" Main Wiring Harness - 189" | 1 | |
| 24 | 9007286 | Wiring Harness - 205" EOH for Proximity Switch | 1 | |
| 25 | 9005993 | Wiring Harness - 588" | 1 | |
| 26 | 252386 | Plug Assembly, 2 Pin Shroud | 1 | |
| 27 | 9008251 | Harness - Joystick Power | 1 | |
| 29 | 9007266 | Wire Harness, 218 5/16" (2 Pin Diverter) | 1 | |
| 31 | 91256 | Large Flange Screw 5/16"-18UNC x 3/4" | 4 | |
| 32 | 91257 | Flange Nut 5/16"-18UNC | 4 | |
| 33 | 95585 | Large flange Screw 3/8"-16UNC x 3/4" G5 | 8 | |
| 34 | 91263 | Large Flange Nut, 3/8-16UNC | 10 | Grade 5 |
| 35 | 95785 | Flange Screw 3/8"-16UNC x 1 1/2" | 1 | |
| 36 | 283788B | Mounting Bracket =Black= | 1 | |
| 37 | 97420 | Flange Screw, 1/4-20 x 3/4 | 2 | Grade 5 |
| 38 | 903172-350 | Pan Head Phillips Screw, #10-32UNF x 1 1/4" | 4 | |
| 39 | 9830-016 | Hex Nut, #10-32 | 20 | Grade 2 |
| 40 | 9404-013 | Lock Washer, #10 | 20 | |
| 41 | 9008956 | Switch Harness | 1 | |
| 42 | 91262 | Large Flange Screw, 3/8-16 x 1 | 1 | Grade 5 |
| 43 | 903172-346 | Pan Head Phillips Screw, #10-32UNF x 3/4" | 16 | |
| 44 | 9405-052 | Flat Washer, 3/16 | 16 | 1 |
| 45 | 293416 | EOH Block Assembly - 5 Spool Replacement Kit | 1 | 1 |
| | 86700 | Wiring Extension 120" (2 Pin) | 1 | |

Cut Out Clutch PTO Assembly



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|--------------------------------|
| | 9005230 | PTO Assembly Complete | | Includes Items 19 & 20 |
| 1 | 9005234 | Over-Running PTO Clutch Assembly | 1 | |
| 2 | 92529 | Cross & Bearing Kit | 2 | |
| 3 | 9002609 | Spring Pin 10x90 | 2 | |
| 4 | 9002610 | Inboard Yoke S4 | 1 | |
| 5 | 9004840 | Inner Profile | 1 | |
| 6 | 9004841 | Outer Profile | 1 | |
| 7 | 9002613 | Inboard Yoke S5 | 1 | |
| 8 | 9005235 | Cut Out Clutch (3200 N-m Setting) | 1 | 1 3/4-20 Spline 1000RPM |
| 9 | 9002615 | Shield Cone 7 Rib | 1 | |
| 10 | 9004843 | Outer Shield Tube Oval | 1 | |
| 11 | 9004844 | Inner Shield Tube Oval | 1 | |
| 12 | 92373 | Bearing Ring | 2 | |
| 13 | 92374 | Safety Chain | 1 | |
| 14 | 92372 | Screw | 2 | |
| 15 | 92377 | Decal Out | 1 | |
| 16 | 92378 | Decal In | 1 | |
| 17 | 93866 | Shield Cone 6 Rib | 1 | |
| 18 | 9005233 | Decal K64 | 1 | "Tighten to 75 FtLbs." |
| 19 | 93856 | Quick-Disconnect Kit | 1 | 1 3/4-20 Spline w/Metal Collar |
| 20 | 9005253 | Cut Out Clutch Lock Assembly | 1 | |
| 21 | 9005231 | PTO Front Half Assembly 1 3/4-20 Spline | 1 | |
| 22 | 9005232 | PTO Rear Half Assembly 1 3/4-20 Spline | 1 | |
| 23 | 9002513 | Reinforcing Collar | 1 | NOT SHOWN |

Cut Out Clutch PTO Assembly



<u>NOTE</u>: Cut Out Clutch (9005235) must be used with the Complete PTO Assembly (9005230). This <u>will not</u> work with the Standard PTO Assembly (9005245).

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-----------------------------------|-----|--------------------|
| | 9005235 | Cut Out Clutch (3500 N*m Setting) | | Includes Items 1-8 |
| 1 | 9005247 | Clutch Housing | 1 | |
| 2 | 9005248 | Clutch Hub 1 3/4-20 Spline | 1 | |
| 3 | 9005249 | Spring Pack | 1 | |
| 4 | 9005250 | Washer | 1 | |
| 5 | 9005251 | Retaining Ring | 1 | |
| 6 | 9005252 | Sealing Ring | 1 | |
| 7 | 9005253 | Clutch Clamp Cone Assembly | 1 | |
| 8 | 9005254 | Clutch Cam | 4 | |

Lower Auger Linkage Components



Lower Auger Linkage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|--------------------------------|
| 1 | 283600B | Idler Assembly =Black= | 1 | |
| 2 | 283605 | Tensioner Rod Weldment | 2 | |
| 3 | 94144 | Retaining Ring 1 1/4 | 4 | |
| 4 | 9003635 | Self-Lubricating Bushing, 1.4 OD x 1.25 ID x 3/4 | 6 | |
| 5 | TA500397 | Bushing, 1.875D x .074 | 2 | |
| 6 | 9005684 | Idler Sub Assembly | 2 | |
| 7 | 9005685 | Machine Washer, 3/4 | 4 | |
| 8 | 9390-149 | Capscrew, 3/4-10UNC x 3 | 2 | Grade 5 |
| 9 | 9404-033 | Lock Washer 3/4 | 2 | |
| 10 | 9003810 | Snap Ring | 2 | |
| 11 | 9005447 | Compression Spring, 1.415 OD x 2 1/2 | 2 | |
| 12 | 9405-104 | Flat Washer 3/4 SAE | 4 | |
| 13 | 9405-106 | Flat Washer 3/4 USS | 2 | |
| 14 | 284703 | Tensioner Bushing Weldment | 1 | |
| 15 | 9390-101 | Capscrew, 1/2-13UNC x 1 1/2 | 1 | Grade 5 |
| 16 | 9390-104 | Capscrew, 1/2-13UNC x 2 1/4 | 1 | Grade 5 |
| 17 | 9395-010 | Hex Jam Nut 1/2-13UNC | 1 | |
| 18 | 94981 | Locknut 1/2-13UNC | 4 | |
| 20 | 283619B | Idler Brace Plate =Black= | 1 | |
| 21 | 283603B | Idler Arm Weldment =Black= | 1 | |
| 22 | 283602B | Idler Arm Weldment =Black= | 1 | |
| 23 | 283601B | Idler Mount Weldment =Black= | 1 | |
| 24 | 283604B | Tensioner Weldment =Black= | 1 | |
| 25 | 9004590 | Pulley, 15" Dia. x 5 13/16 | 1 | |
| 26 | 9004591 | Pulley, 7 1/2" Dia. x 5 13/16 | 1 | |
| 27 | 9004813 | Split Bushing Hardware Kit | 1 | Includes Items: 27A, 27B & 27C |
| 27A | 9006263 | Bolt, 9/16-12UNC x 3 5/8 | 3 | Grade 5 |
| 27B | 9404-027 | Lock Washer, 9/16 | 3 | |
| 27C | 9399-086 | Set Screw, 3/8-16UNC x 1/2 | 1 | |
| | 9005565 | Flanged Bearing 2 1/4 ID | 2 | Includes Set Screw & Zerk |
| 28 | 93426 | Grease Zerk | 1 | |
| | 9399-223 | Set Screw 3/8-24UNF x 3/8 | 2 | |
| 29 | 9002562 | Keystock 1/2 x 1/2 x 2 1/2 | 2 | |
| 30 | 9394-014 | Hex Nut 5/8-11UNC | 8 | |
| 31 | 9006849 | Grease Zerk Cap | 4 | Ì |
| 32 | 9390-124 | Capscrew, 5/8-11UNC x 2 | 8 | Grade 5 |
| 33 | 9404-030 | Split Lock Washer, 5/8 | 8 | |
| 34 | 281675 | Drive Belt Set, 4 Strand (5V750) | 2 | |

(Continued on next page)

Lower Auger Linkage Components (continued)

| 35 | 9005074 | Hose/Type Nylon, 1/4" OD | 2.5 | Specify in Feet |
|----|----------|--|-----|---|
| 36 | 273118B | Shield Plate =Black= | 2 | |
| 37 | 273119B | Shield Weldment =Black= | 1 | |
| 38 | 97189 | Large Flange Hex Nut 1/4-20UNC | 6 | |
| 39 | 901101 | Flange Screw 1/4-20 UNC x 1 | 6 | Grade 5 |
| 40 | 9003949 | Hex Pipe Coupling | 2 | |
| 41 | 93426 | Grease Zerk 1/8 NPT | 2 | |
| 42 | 94981 | Locknut 1/2"-13UNC | 3 | |
| 43 | 9388-104 | Carriage Bolt, 1/2-13UNC x 1 1/2 | 1 | Grade 5 |
| 44 | 9007376 | Bushing, 4 5/8 0D x 2 1/4 ID x 2 1/16 w/ 1/2 Keyway & Capscrews | 1 | |
| 45 | 9399-059 | Set Screw, 1/4-20UNC x 3/8 | 1 | |
| 46 | 9404-021 | Lockwasher, 3/8 | 3 | |
| 47 | 284262 | Split Bushing Hardware Kit | 1 | Grade 5 |
| 48 | 9399-079 | Set Screw 5/16-18UNC x 1 1/2 Cup Point/Hex Socket | 2 | |
| 49 | 9394-004 | Hex Nut 5/16-18UNC | 2 | |
| 50 | 273121B | Bushing Weldment | 1 | |
| 51 | 901044 | Serrated Flange Bolt, 5/16-18UNC x 1 | 2 | |
| 52 | 91257 | Large Flange Hex Nut, 5/16-18UNC | 2 | |
| 53 | 9005073 | Quicklinc Fitting | 4 | |
| 54 | 9405-076 | Flat Washer 3/8 USS | 2 | |
| 55 | 9388-103 | Carriage Bolt, 1/2"-13UNC x 1 1/4" | 2 | |
| 56 | 294128B | Hose Caddy Replacement Kit =Black= | 1 | Refer to "Hitch & Tongue Components" Section |
| 57 | 9390-003 | Capscrew, 1/4-20UNC x 3/4 | 2 | Grade 5 |
| 58 | 9404-017 | Lock Washer, 1/4" | 2 | |
| 59 | 9405-062 | Flat Washer, 1/4" SAE | 4 | |
| 60 | 9405-066 | Flat Fender Washer, 1/4" | 2 | |

Notes

Lower Auger Door & Cover Components



Lower Auger Door & Cover Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|-----------------|
| 1 | 276557B | Cleanout Door Weldment =Black= | 1 | |
| 2 | 9007108 | Gasket w/Adhesive Backing for Clean-Out Door | A/R | Specify in Feet |
| 3 | 9006497 | Draw Latch | 2 | |
| 4 | 903171-574 | Flat Countersunk Screw #10-24UNC Phillips Machine Screw | 6 | |
| 5 | 902331 | Serrated Flange Hex Nut #10-24UNC | 6 | |
| 6 | 900068 | Retainer for Draw Latch | 3 | |
| 7 | 900067 | Washer | 3 | |
| 8 | 900066 | Stud Pin | 3 | |
| 9 | 900060 | Handle for Draw Latch | 3 | |
| 10 | 284714B | Locking Pipe Weldment with Roll Pin =Black= | 1 | |
| 11 | 9392-208 | Roll Pin 1/2" Dia. x 2 | 1 | |
| 12 | 284141G | Strike Plate =Green= | 1 | |
| 12 | 284141R | Strike Plate =Red= | | |
| 13 | 95585 | Capscrew/Large Flange 3/8"-16UNC x 3/4" G5 | 2 | |
| 14 | 91262 | Flange Screw 3/8"-16UNC x 1" G5 | 3 | |
| 15 | 91263 | Nut/Large Flange 3/8-16UNC G5 | 3 | |
| 16 | 9004918 | PTO Bell Cover | 1 | |
| 17 | 9004729 | Belt Cover/Shield | 1 | |
| 18 | 900059 | Flexible Draw Latch Asy w/Style R Keeper | 3 | |
| 19 | 9004940 | Pop Rivet | 6 | |

Auger Tube Components



Auger Tube Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|-------|
| 1 | 2001446B | Cover Plate =Black= | 1 | |
| 2 | 266285 | Cylinder Pin 1" Dia. x 4 1/2 | 1 | |
| 3 | 271119B | Fold Plate 6 1/2 x 8 =Black= | 1 | |
| 4 | 271124 | Nylon Fold Slide 2 x 8 | 4 | |
| 5 | 272645B | Switch Bracket =Black= | 1 | |
| 6 | 273121B | Bushing Weldment =Black= | 1 | |
| 7 | 293422B | Bearing Bracket Weldment =Black= | 1 | |
| 0 | 273255G | Auger Rest Weld't =Green= | 1 | |
| 8 | 273255R | Auger Rest Weld't =Red= | | |
| 0 | 273374G | Spacer/Bushing 2.5" OD x 1.75" ID x 9.9375" =Green= | -1 | |
| 9 | 273374R | Spacer/Bushing 2.5" OD x 1.75" ID x 9.9375" =Red= | 1 | |
| 10 | 276479G | Fold Linkage Weldment =Green= | 4 | |
| 10 | 276479R | Fold Linkage Weldment =Red= | 1 | |
| 11 | 276483 | Pin Weldment | 2 | |
| 10 | 276940G | Fold Linkage Weldment =Green= | 4 | |
| 12 | 276940R | Fold Linkage Weldment =Red= | 1 | |
| 13 | 276493 | Pin Weldment | 2 | |
| 14 | 276941 | Linkage Pin Weldment | 1 | |
| 15 | 276561 | Pivot Pin Weldment | 1 | |
| 10 | 276593G | Auger Hinge Weldment =Green= | 0 | |
| 16 | 276593R | Auger Hinge Weldment =Red= | 2 | |
| 17 | 9388-102 | Carriage Bolt, 1/2"-13UNC x 1" G5 | 4 | |
| 18 | 9003397 | Locking Flange Nut 1/2"-13UNC | 8 | |
| 19 | 276507B | Hanger Bearing Weldment =Black= | 1 | |
| 20 | 283335 | Poly Auger Stop Pad | 2 | |
| 01 | 283340G | Auger Rest Weldment =Green= | 4 | |
| 21 | 283340R | Auger Rest Weldment =Red= | 1 | |
| 22 | 289852B | Pivot Flange, Retainer Plate =Black= | 5 | |
| 23 | 284518B | Fold Plate =Black= | 1 | |
| 24 | 9388-104 | Carriage Bolt 1/2"-13UNC x 1 1/2" G5 | 4 | |
| 25 | 9001688 | Capscrew/Flat Head, 5/16-18UNC x 3/4 | 12 | |
| 26 | 9002199 | Reducer w/.060 Restrictor | 1 | |
| 27 | 9002446 | Adapter 9/16-18 O-Ring Male x 9/16-18 JIC Female | 1 | |
| 28 | 9003259 | Flange Screw 3/8"-16UNC x 1 1/4" G5 | 2 | |
| 29 | 9003398 | Lock Nut/Top 5/8"-11UNC | 5 | |
| 30 | 9004396 | Self Lube Bushing, 1.414" OD x 1.258" ID x 3/4" | 8 | |

Auger Tube Components (continued)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|---------|--------------|---|-----|-------|
| 31 | 9004397 | Self-Lubricating Bushing 1.131" OD x 1.008" ID x .75" | 2 | |
| 32 | 9004764 | 90° Elbow 1/8" NPTF Female | 1 | |
| 33 | 9005793 | Grease Pipe 1/8" SCH40 x 11" | 1 | |
| 34 | 9006084 | Retaining Ring 1 1/4" | 2 | |
| 35 | 9006785 | 90° Adapter 1/8" NPT | 7 | |
| 36 | 9007639 | Hydraulic Cylinder 3 1/2 x 20 (3000 PSI) | 1 | |
| 37 | 901044 | Flange Screw 5/16"-18UNC x 1" G5 | 2 | |
| 38 | 903171-660 | Flat Countersunk Head/Machine Screw, 5/16"-18UNC x 1" | 4 | |
| 39 | 91257 | Large Flange Hex Nut, 5/16"-18UNC | 2 | |
| 40 | 91263 | Nut/Large Flange 3/8"-16UNC | 6 | |
| 41 | 91266 | Flange Capscrew, 1/2"-13UNC x 1 1/4" | 2 | |
| 42 | 91267 | Nut / Flange, 1/2-13UNC | 4 | |
| 43 | 91299-146 | Capscrew, 3/4"-10UNC x 2 1/4" | 2 | |
| 44 | 9234PL | Flat Washer, 13/16 (Hardened) | 2 | |
| 46 | 9388-003 | Carriage Bolt, 1/4"-20UNC x 1" G5 | 4 | |
| 47 | 9390-055 | Capscrew, 3/8"-16UNC x 1" G5 | 4 | |
| 48 | 9390-112 | Capscrew, 1/2"-13 UNC x 4 1/2" G5 | 2 | |
| 49 | 9390-122 | Capscrew, 5/8"-11UNC x 1 1/2" G5 | 10 | |
| 50 | 9390-124 | Capscrew, 5/8"-11UNC x 2" G5 | 1 | |
| 51 | 9390-126 | Capscrew, 5/8"-11UNC x 2 1/2" G5 | 2 | |
| 52 | 9390-127 | Capscrew, 5/8"-11UNC x 2 3/4" G5 | 2 | |
| 53 | 9391-046 | Cotter Pin, 3/16" Dia. x 2" | 2 | |
| 54 | 9392-140 | Roll Pin, 1/4" Dia. x 2" | 1 | |
| 55 | 9394-016 | Hex Nut, 3/4-10UNC G5 | 2 | |
| 56 | 9404-030 | Lock Washer, 5/8" | 17 | |
| 57 | 9404-034 | Lock Washer, 3/4 | 2 | |
| 58 | 9405-086 | Flat Washer 1/2" SAE | 2 | |
| 59 | 94733 | Capscrew, 3/4"-10UNC x 3" G5 Full Threaded | 2 | |
| 60 | 97189 | Hex Nut/Large Flange 1/4"-20UNC | 4 | |
| 61 | 9874 | 90° Elbow 9/16-18 JIC Male x 3/4-16 O-Ring Male | 2 | |
| 62 | TA0-903850-0 | Cable Clamp (1/2" OD) | 4 | |
| <u></u> | 276684G | Lower Auger Housing Weldment =Green= | 4 | |
| 63 | 276684R | Lower Auger Housing Weldment =Red= | 1 | |
| 64 | 276501G | Upper Auger Housing Weldment =Green= | 4 | |
| 64 | 276501R | Upper Auger Housing Weldment =Red= | 1 | |
| 65 | 9405-088 | Flat Washer 1/2" | 1 | |
| 66 | 9404-025 | Lock Washer 1/2" | 1 | |
| 67 | 9390-100 | Capscrew 1/2"-13UNC x 1 1/4" | 1 | |
| 68 | 9405-098 | Flat Washer 5/8" SAE | 1 | |

Notes

Auger Grease Bank Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-------------------------------------|-----|-------------------------------------|
| 1 | 9008965 | Grease Hose 3/16" x 74" (1/8" NPT) | 1 | Lower Vertical Auger Hanger Bearing |
| 2 | 9008967 | Grease Hose 3/16" x 126" (1/8" NPT) | 2 | Upper Auger Pivot Pin |
| 3 | 9008961 | Grease Hose 3/16" x 48" (1/8" NPT) | 1 | |
| 4 | 9008960 | Grease Hose 3/16" x 44" (1/8" NPT) | 1 | |
| 5 | 9008958 | Grease Hose 3/16" x 30" (1/8" NPT) | 1 | |
| 6 | 9008959 | Grease Hose 3/16" x 38" (1/8" NPT) | 1 | Vertical Auger Tilt Pivot Rings |
| 7 | 9008962 | Grease Hose 3/16" x 55" (1/8" NPT) | 1 | |
| 8 | 9008964 | Grease Hose 3/16" x 70" (1/8" NPT) | 1 | |
| 9 | 9008963 | Grease Hose 3/16" x 58" (1/8" NPT) | 1 | |
| 10 | 9009052 | Grease Hose 3/16" x 200" (1/8" NPT) | 1 | Drag Auger Center Bearing |
| 11 | 9003949 | Coupler 1/8" NPT | 11 | |
| 12 | 93426 | Grease Zerk | 11 | |
| 13 | 9006849 | Grease Zerk Cap | 11 | |

Switch Assembly Components for Rotating Spout Option



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|----------------------------------|-----|-------|
| 1 | 272618 | Hydraulic Valve Assembly | 1 | |
| 2 | 272645B | Switch Bracket | 1 | |
| 3 | 276457B | Spout Motor Assembly | 1 | |
| 4 | 276556B | Sensor Plate | 1 | |
| 6 | 9007223 | Proximity Sensor with Connector | 1 | |
| 9 | 91257 | Hex Nut/Large Flange 5/16"-18UNC | 3 | |
| 10 | 91262 | Flange Screw 3/8"-16UNC x 1" G5 | 2 | |
| 11 | 91263 | Nut/Large Flange 3/8"-16UNC | 2 | |
| 13 | 9390-042 | Capscrew, 5/16"-18UNC x 5" G5 | 3 | |

Downspout Components



Downspout Components

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|-------|
| 1 | 276496B | Mount Lock Plate | 1 | |
| 2 | 276497 | Spacer/Bushing | 2 | |
| 3 | 276498B | Lock plate | 1 | |
| 4 | 276511 | Rack Plate | 1 | |
| 5 | 276512 | Pivot Pad | 6 | |
| 6 | 276513B | Spout Pivot Plate | 2 | |
| 7 | 276999B | Spout Assembly | 1 | |
| 8 | 276515B | Spout Weldment | 1 | |
| 9 | 276526B | Spout Weldment | 1 | |
| 10 | 9405-088 | Flat Washer 1/2" USS | 2 | |
| 11 | 9404-025 | Lock Washer 1/2" | 2 | |
| 12 | 9003810 | Snap Ring 3/4" | 2 | |
| 13 | 9008318 | Rubber Chute | 1 | |
| 14 | 9388-003 | Carriage Bolt 1/4"-20UNC x 1" G5 | 14 | |
| 15 | 9388-004 | Carriage Bolt 1/4"-20UNC x 1 1/4" G5 | 2 | |
| 16 | 9405-066 | Flat Washer 1/4" | 16 | |
| 17 | 97189 | Hex Nut/Large Flange 1/4"-20UNC | 24 | |
| 18 | 9008957 | LED Work Light | 3 | |
| 19 | 94763 | Fender Washer | 16 | |
| 20 | 9390-005 | Capscrew 1/4"-20UNC x 1" G5 | 8 | |
| 21 | 9003127 | Reflector 2 x 9 =AMBER= | 2 | |
| 22 | 9390-107 | Capscrew 1/2"-13UNC x 3" G5 | 2 | |
| 23 | 95193 | Adapter with 0.030 Restrictor | 2 | |
| 24 | 285290 | Sleeve Bushing .75" OD x .532" ID x 1.938 | 2 | |
| 25 | 276531B | Chute Strap | 2 | |
| 26 | 272646B | Light Bracket | 1 | |
| 27 | 9005135 | Cylinder 1 1/2 x 8 | 1 | |
| 28 | 97445 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 O-Ring ADJ Male | 1 | |
| 29 | 9001495 | Adapter 9/16-18 JIC Male x 9/16-18 O-Ring | 1 | |
| 30 | 9005685 | Washer 3/4" Dia. | 2 | |
| 31 | 276530 | Pivot Shaft 3/4" Dia. x 27 | 1 | |
| 32 | 276550B | Spacer Plate | 3 | |
| 33 | 276577B | Hose Bracket | 1 | |
| 34 | 9003396 | Lock Nut/Top 3/8"-16UNC | 2 | |
| 35 | 9003397 | Lock Nut/Top 1/2"-13UNC | 1 | |
| 36 | 9003398 | Lock Nut/Top 5/8"-11UNC | 7 | |
| 37 | 9003814 | Clamp Top Plate | 4 | |
| 38 | 9003816 | Double Hose Clamp (Pair) | 4 | |
| 39 | 9007837 | Shoulder Bolt 3/8" Dia. Socket Head, 5/16"-18UNC x 1 1/4" | 5 | |
| 40 | 9007843 | Sholder Bolt 3/8" Dia. Socket Head, 5/16"-18UNC x 1" | 10 | |
| 41 | 9008110 | Zerk 1/8-27 with Cap | 4 | |
| 42 | 91160 | Zerk 1/4-28 STT | 4 | |
| 43 | 91257 | Hex Nut/Large Flange 5/16"-18UNC | 4 | |
| 44 | 91262 | Flange Screw 3/8"-16UNC x 1" | 2 | |
| 45 | 91263 | Nut/Large Flange 3/8"-16UNC | 8 | |
| 46 | 9388-052 | Carriage Bolt 3/8"-16UNC x 1 1/4" | 1 | |
| 47 | 9390-034 | Capscrew 5/16"-18UNC x 2" G5 | 2 | |
| 48 | 9390-056 | Capscrew 3/8"-16UNC x 1 1/4" G5 | 1 | |
| 49 | 9390-101 | Capscrew 1/2"-13UNC x 1 1/2" G5 | 1 | |
| 50 | 9390-131 | Capscrew 5/8"-11UNC x 3 3/4" G5 | 2 | |
| 51 | 9405-064 | Flat Washer 1/4" USS | 15 | |
| 52 | 9405-086 | Flat Washer 1/2" SAE | 3 | |
| 53 | 9807 | Lock Nut/Top 5/16"-18UNC | 15 | |
| 54 | 272841B | Light Bracket | 1 | |

Weather Guard Tarp Components



Weather Guard Tarp Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|---|
| | 273518 | Tarp Kit with Split Arched End Caps | - | Not Included: Bows, End Caps and Items 59 through 62 |
| 1 | 9004355 | Screw 1/4-20UNC x 1 Self-Threading | 8 | |
| 2 | 273381 | Roll Tube Weldment | 1 | |
| 3 | 273382 | Fixed Tube Weldment | 1 | |
| 4 | 221668 | Pipe - 180" | 1 | |
| 5 | 273364 | Plate - Latch 171 1/4" (Front) | 1 | |
| 6 | 273365 | Plate - Latch 171 1/4" (Rear) | 1 | |
| 7 | 273501B | Handle Bracket Weldment | 1 | |
| 8 | 221722 | Bungee 3/8" Dia. x 204" | 1 | |
| 9 | 97189 | Hex Nut/Large Flange 1/4-20UNC | 8 | |
| 10 | 221749 | Tarp Handle Weldment | 1 | |
| 11 | 266689B | Tarp Short Stop Plate | 10 | |
| 12 | 9000787 | Trim-lok | A/R | 14 feet |
| 13 | 9005312 | Torx Head Machine Screw 3/8-16UNC x 1 | 11 | Grade 5 |
| 14 | 9005305 | Lynch Pin 3/8" x 3" | 1 | |
| 15 | 9003078 | Cap - Plastic (2 x 3) | 10 | |
| 16 | 9005990 | Cable Assembly 324" | 4 | Holds up to 6 |
| 17 | 9008111 | Poly Deflector 8" | 4 | |
| 18 | 9003378 | Rivet/Pop 3/16" | 2 | |
| 19 | 9004548 | Eye Bolt 3/8"-16UNC x 1 3/4" | 1 | |
| 20 | 9004947 | Plug 2" | 1 | |
| 21 | 221770B | Handle Retainer Weldment | 1 | |
| 22 | 9004949 | U-Clamp | 9 | |
| 23 | 9004968 | Plug 1" | 2 | |
| 24 | 9004969 | Handle | 1 | |
| 25 | 9004977 | U-Joint w/ 1 3/8-21 Spline | 1 | |
| 00 | 9005856 | Tarp 188 x 337 | 1 | |
| 26 | 9005581 | Tarp Repair Kit | - | |
| 27 | 9005088 | Plug 1 1/8 | 2 | |
| 28 | 9005089 | Plug 1 1/4 | 1 | |
| 29 | 9001396 | Pan Head Screw #10-16 x 1/2" | 1 | |
| 30 | TA806225 | Hose 1/2 EPDM | 1 | |
| 31 | 9005197 | Screw/Self Drilling #10-16 x 3/4 Pan Head | 9 | |
| 32 | 91262 | Screw/Large Flange 3/8-16UNC x 1 | 10 | Grade 5 |
| 33 | 91263 | Nut/Large Flange 3/8-16UNC | 71 | Grade 5 |
| 35 | 9390-055 | Capscrew 3/8-16UNC x 1 | 1 | Grade 5 |
| 36 | 9392-180 | Roll Pin 3/8" Dia. x 2" | 1 | |
| 37 | 903172-450 | Pan Head 3/8"-16UNC x 4 1/2" Phillips | 1 | |
| 38 | 9405-074 | Flat Washer 3/8 | 2 | |

(Continued on next page)

Weather Guard Tarp Components (continued)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|--------------|--|-----|---------------------------|
| 39 | 9398-012 | Elastic Stop Nut 3/8-16UNC | 1 | |
| 40 | 283425B | RH Bracket For Side Boards/Tarp Bow Weldment | 8 | |
| 41 | 276756B | RH-End Cap Weldment | 2 | |
| 42 | 276755B | LH-End Cap Weldment | 2 | |
| 43 | 291289B | Tarp Bow Weldment | 8 | |
| 44 | 902703-046 | Flat Socket Capscrew 3/8"-16UNC x 3" | 16 | |
| 45 | 97604 | Screw/Large Flange, 5/16-18 UNC x 1 | 32 | For SN B41110100 & Higher |
| 40 | 91256 | Screw/Large Flange, 5/16-18 UNC x 3/4 | 32 | For SN B41110099 & Lower |
| 46 | 9512 | Screw/Self Drilling 1/4-14 x 1 | 4 | |
| 47 | 95585 | Capscrew/Large Flange 3/8-16UNC x 3/4 | 20 | Grade 5 |
| 48 | 9928 | Locknut 3/8-16UNC | 1 | |
| 49 | 283427B | LH Bracket For Side Boards/Tarp Bow Weldment | 8 | |
| 50 | 281712B | Bracket Assembly | 4 | |
| 51 | 9005688 | Star Washer | 4 | |
| 52 | 9005696 | Fender Washer | 4 | |
| 53 | 9005727 | Plug | 4 | |
| 54 | TA0-907131-0 | Capscrew 3/8-16UNC x 4 1/2 (Full Threaded) | 4 | |
| 55 | 91257 | Hex Nut/Large Flange, 5/16-18 UNC | 32 | |
| 56 | 9405-074 | Flat Washer 3/8" | 2 | |
| 57 | 9404-021 | Lock Washer 3/8" | 2 | |
| 58 | 9390-056 | Capscrew 3/8-16UNC x 1 1/4 | 2 | Grade 5 |
| 59 | 9008952 | Hurricane Strap For 14 FT Wide Hopper | 2 | |
| 60 | 96972 | Screw/Self Tapping 3/8"-16UNC x 1" | 2 | |
| 61 | 9008972 | Flat Washer, 3/8" Aluminum | 4 | |
| 62 | 9008949 | Tarp Strap Spacer Bushing | 4 | |
| 63 | 294678B | Sideboard Doubler =Black= | 16 | For SN B41110100 & Higher |

Notes

Hydraulic Jack - Kit #294143B (Optional)



Hydraulic Jack - Kit #294143B (Optional)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|--|
| 1 | 271712B | Jack Weldment =Black= | 1 | |
| 2 | 271723B | Jack Foot Weldment =Black= | 1 | |
| 3 | 272587 | Pin, 1" Dia. x 3 1/8 | 1 | |
| 4 | 273808B | Jack Mount Weldment =Black= | 1 | |
| 5 | 9005426 | High Pressure Ball Valve | 1 | |
| 6 | 9006068 | Hydraulic Hose, 1/4 x 92" - 3000 PSI | 2 | |
| 7 | 9006173 | Elbow, 90° | 2 | |
| 8 | 9009047 | Hydraulic Cylinder, 3 1/2 x 8 - 3000 PSI | 1 | |
| 10 | 9008600 | Hose Grips - Black (Pair) - Raise Jack | 1 | Solid Black - Cylinder Extended |
| 11 | 9008600 | Hose Grips - Black (Pair) - Lower Jack | 1 | Half Black/Half Gray - Cylinder Retracted |
| 12 | 91192 | Retaining Ring, 1" | 2 | |
| 13 | 91383 | Male Tip Coupling | 2 | |
| 14 | 92199 | Center Locknut, 1-8UNC | 3 | |
| 15 | 9390-165 | Capscrew, 7/8-9UNC x 2 1/4 Grade 5 | 2 | |
| 16 | 9390-197 | Capscrew, 1-8UNC x 7 Grade 5 | 3 | |
| 17 | 9404-037 | Split Lock Washer, 7/8 | 2 | |
| 18 | 98508 | Adapter, 3/4-16 OR Male x 3/4-16 OR Male | 1 | |

Video System (Optional)



Video System (Optional)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|---|-----|---|
| | 265770 | Video System Kit for Front View | 1 | Includes Items 1,3,4,5,6,7,8 and own Instruction Sheet |
| | 9004506 | Additional Camera for Rear View | 1 | Includes Items 6 & 7 |
| 1 | TAAU14007 | Snap Clip, Adhesive | 10 | |
| 2 | 9512 | Self-Drilling Screw 1/4-14 x 1 | 10 | |
| 3 | 9006273 | Monitor, 7" LCD/LED | 1 | |
| 4 | 9004510 | Cable w/Fuse | 1 | |
| 5 | 9006274 | Camera | 1 | |
| 6 | 265771B | Bracket | 1 | |
| 7 | 9004513 | Cable, 65' | 1 | |
| 8 | 9000107 | Cable Tie | AR | |
| 9 | 9004506 | Camera Kit for Rear View with 65' Cable | 1 | |
| 10 | 9007174 | Camera Cable, 16 ft. | 1 | |





www.unverferth.com

MANUALS\\294486///February 2021-0//June 2021-1//August 2021-2//February 2022-3