



AVALANCHE® DOUBLE-AUGER GRAIN CARTS

MODEL 1596

(RIGHT-HAND UNLOAD)

Serial Number B41920100 & Higher

Part No. 295231

Brent 1596 Right-Hand Unload — Introduction

Foreword



This symbol identifies important safety messages. When you see it, read the message that follows and be alert to the possibility of personal injury.

Remember, safety instructions stated in this manual are for your protection. Read them carefully and follow them closely when working around or using this machine.

Read and study this manual completely before attempting to operate this implement. Take this manual to the field for handy reference when operating, adjusting, or servicing your machine.

When referenced, "Right-Hand" (RH) and "Left-Hand" (LH) side of the machine are determined by standing behind the machine and facing in the direction of travel.



Brent 1596 Right-Hand Unload — Introduction

Product Information

When ordering parts or when requesting further information or assistance, always give the following information:

- Machine name
- Model number
- Serial number

All products manufactured by Unverferth Mfg. Co., Inc. are warranted to be free from material and workmanship defects for one full year from time of consumer delivery. Your local dealer will gladly assist you with any warranty questions.

Please fill out and retain this portion for your records.

| Purchase Date | _Model | Serial No |
|----------------|--------|-----------|
| Dealer | Cit | <i></i> |
| Dealer Contact | | Phone |

IMPORTANT

• The information, specifications, and illustrations in the manual are based on information available at the time it was written. Due to continuing improvements in the design and manufacture of Unverferth products, all specifications and information contained herein are subject to change without notice.

Section ISafety

| General Hazard Information Safety Decals Following Safety Instructions Before Servicing Before Operating During Operation Before Transporting During Transport Pressurized Oil Driveline Safety Preparing for Emergencies. Wearing Protective Equipment | 1-3 1-5 1-5 1-6 1-6 1-7 1-7 1-8 |
|---|--|
| Section II | |
| Set-Up | |
| Set Up Checklist | 2-2 |
| Basic Cart Set-Up | |
| Hydraulic System | 2-3 |
| Wheel/Tire Set-up | |
| Auger Spout Cylinder Stop Removal | |
| PTO Brackets Removal | |
| Jack | |
| Optional Hydraulic Jack | |
| Steering Tandem Switch Box Connection | |
| Driveline Set-Up | |
| Coupling The Cut-Out Clutch | |
| SMV Emblem and SIS Decal | |
| Video System (Optional) | |
| Upper Ladder Extension to Operating Position | |
| Horizontal Cleanout Door Inspection | |
| Belt Engagement | 2-14 |
| Operational Check | |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL.
FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL.
FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL.
FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Section III Operation

| Operating Checklist | 3-2 |
|---|------|
| Preparing Tractor | 3-3 |
| Preparing Cart | 3-3 |
| Lubrication | 3-4 |
| Video System (Optional) | 3-4 |
| Hitching to Tractor | |
| Drawbar Connection | 3-5 |
| Jack Usage | 3-6 |
| Optional Hydraulic Jack Usage | 3-7 |
| Transport Chain Connection | 3-8 |
| Hydraulic Connections | 3-9 |
| Electrical Connections | 3-11 |
| Optional Implement Brake Connection | 3-11 |
| Towing | 3-12 |
| Electric Over Hydraulic Operation (Optional) | 3-13 |
| Manual Override for Optional Electric Over Hydraulic System | 3-16 |
| Vertical & Horizontal Cleanout Door Operation | |
| Vertical Cleanout Door | 3-18 |
| Horizontal Cleanout Door | 3-20 |
| Auger Operation | |
| PTO-Driven Auger | 3-22 |
| Auger Overload Procedure | 3-24 |
| Vertical Auger Fold | 3-25 |
| Auger Field Rest Position | 3-26 |
| Upper Auger Rest Adjustments | 3-28 |
| Steering Tandem | 3-29 |
| Troubleshooting | 3-30 |
| Ladder Operation | 3-32 |
| Weather Guard Tarp | 3-36 |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL.
FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL.
FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL.
FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Section IV Maintenance

| Lubrication - Cart | 4-2 |
|---|------|
| Hydraulic System | |
| Purge Hydraulic System | 4-4 |
| Relieving Hydraulic Pressure | 4-5 |
| Bleeding Procedure for EOH System | 4-5 |
| Bleeding Procedure for Braking System | 4-6 |
| Steering Tandem Maintenance | |
| Steering Tandem Troubleshooting | 4-7 |
| Steering Cylinder Rephasing | 4-9 |
| Steering Tandem Linkage Adjustment Procedures | |
| Outer Linkage | 4-10 |
| Center Linkage | |
| Steering Indicator Adjustment Procedures | 4-16 |
| Seasonal Storage | |
| Auger Driveline Bearings | |
| Gearbox with Sight Glass | 4-19 |
| Driveline Removal | |
| Clamping Cone Assembly | 4-19 |
| Auger System | |
| Vertical Auger | |
| Vertical Auger Timing | |
| Horizontal Auger | |
| Baffle Adjustment | |
| 5-Pin Driver Replacement | |
| Belt Tightener Adjustment | 4-30 |
| V-Belt Alignment | |
| Split Tapered Bushings | |
| Verify Telescoping PTO Shaft Length | |
| PTO Shaft & Clutch | |
| PTO Quick Disconnect | |
| Tarp Troubleshooting Inspection & Maintenance | |
| Electrical System Schematic | |
| Electrical Over Hydraulic (EOH) System Schematic (Optional) | |
| EOH Valve Electric Schematic 5 Spool (Optional) | |
| Braking System Schematic | 4-43 |
| Wheel Aut Torque Pequirements | 4 44 |
| Wheel Nut Torque Requirements | |
| Tire Pressure | |
| Tire Warranty Torque Chart - Hardware Grade 5 | |
| Torque Chart - Hardware Grade 8 | |
| Torque Chart - Hydraulic Fittings | |
| FOR SCALE INFORMATION, PLEASE REFER TO | |
| FOR TRACK INFORMATION, PLEASE REFER TO | |
| FOR UHARVEST INFORMATION, PLEASE REFER TO | |
| FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO | |
| FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE RE | |
| SYSTEM MANUAL | |

Section V Parts

| Please visit www.unverferth.com/parts/ for the most current parts | _ |
|---|-------------|
| Decals | |
| Ladder Components | |
| Touch-Up Paint | |
| Hitch, Jack, & Toolbox Components | |
| Axle & Hopper Components | |
| Steering Tandem Assembly Components | |
| Steering Tandem Indicator Components | |
| Steering Tandem Hub Components | |
| Brake Components | |
| Track Axle Components | |
| Track Panel Kit Components | |
| Sideboards | |
| Horizontal Auger Components | |
| Vertical Auger Flighting Components | |
| Lower Auger Door & Cover Components | |
| Lower Auger Linkage Components | |
| Idler Assembly Components | |
| Auger Tube Components | 5-32 |
| Auger Grease Bank | 5-36 |
| EOH Valve Functions and Wire Locations (Optional) | 5-37 |
| EOH Valve Assembly Components (Optional) | |
| EOH Tractor Circuit Hydraulic Components (Optional) | |
| Spout Rotate and Tilt Hydraulic Components | |
| Auger Tilt Hydraulic Components | |
| Auger Fold Hydraulic Components | |
| Steering Tandem Valve Hydraulic Components | |
| Flow Door Circuit Hydraulic Components | |
| Cylinders | |
| Hopper Flow Door Components Optional Spout Rotate Switch Assembly Components | |
| Downspout Components | |
| Rotating Spout Components | |
| Cut Out Clutch PTO Assembly | |
| Cut Out Clutch Components | |
| Gearbox Components | |
| Indicator Assembly | |
| Hopper Rear Electrical Components | |
| Electrical Components | 5-66 |
| Weather Guard Tarp | 5-68 |
| Hydraulic Jack - Kit #294142B (Optional) | 5-70 |
| Video System (Optional) | 5-71 |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. | |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | . I |
| FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUA | |
| FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP M FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER I | |
| TOIL WALLE DELIVERT STOLEN INFORMATION, FLEASE REFER TO TOUR WATER L | JLLI V EN Î |

Brent 1596 Right-Hand Unload — Introduction

| Notes | | |
|-------|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Section I Safety

| General Hazard Information | 1-2 |
|-------------------------------|-----|
| Safety Decals | 1-3 |
| Following Safety Instructions | 1-5 |
| Before Servicing | 1-5 |
| Before Operating | 1-6 |
| During Operation | 1-6 |
| Before Transporting | 1-6 |
| During Transport | |
| Pressurized Oil | |
| Driveline Safety | 1-8 |
| Preparing for Émergencies | |
| Wearing Protective Equipment | |

General Hazard Information

No accident-prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

A large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the field, or in the industrial plant, can be safer than the person who is at the controls. If accidents are to be prevented--and they can be prevented--it will be done by the operators who accept the full measure of their responsibility.

It is true that the designer, the manufacturer, and the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that, "the best kind of a safety device is a careful operator." We, at Unverferth Mfg. Co., Inc. ask that you be that kind of operator.



REMEMBER:

THINK SAFETY A CAREFUL OPERATOR IS THE BEST INSURANCE AGAINST AN

ACCIDENT!

SIGNAL WORDS



INDICATES AN EXTREMELY HAZARDOUS SITUATION OR ACTION THAT WILL RESULT IN SERIOUS INJURY OR DEATH.

A WARNING

INDICATES A HAZARDOUS SITUATION OR ACTION THAT COULD RESULT IN SERIOUS INJURY OR DEATH.



INDICATES AN UNSAFE SITUATION OR ACTION THAT MAY RESULT IN PERSONAL INJURY.


IMPORTANT


Is used for instruction on operating, adjusting, or servicing a machine.

Safety Decals

A WARNING

 REPLACE LOST, DAMAGED, PAINTED, OR UNREADABLE DECALS IMMEDIATELY. IF PARTS THAT HAVE DECALS ARE REPLACED, ALSO MAKE SURE TO INSTALL NEW DECALS. THESE DECALS INFORM AND REMIND THE OPERATOR WITH OPERATIONAL INFORMATION AND SAFETY MESSAGES.





Following Safety Instructions

Read and understand this operator's manual before operating.



- All machinery should be operated only by trained and authorized personnel.
- To prevent machine damage, use only attachments and service parts approved by the manufacturer.
- Always shut tractor engine off and remove key before servicing.



- Avoid personal attire such as loose fitting clothing, shoestrings, drawstrings, pants cuffs, long hair, etc., that may become entangled in moving parts.
- Do not allow anyone to ride on the implement. Make sure everyone is clear before operating machine or towing vehicle.



Never attempt to operate implement unless you are in the driver's seat.



Never enter a cart containing grain. Flowing grain traps and suffocates victims in seconds.



Before Servicing

Avoid working under an implement; however, if it becomes absolutely unavoidable, make sure the implement is safely blocked.



- Ensure that all applicable safety decals are installed and legible.
- When working around the implement, be careful not to be cut by sharp edges.
- To prevent personal injury or death, always ensure that there are people who remain outside the cart to assist the person working inside, and that all safe workplace practices are followed. There are restricted mobility and limited exit paths when working inside the implement.
- Secure drawbar pin with safety lock and lock tractor drawbar in fixed position.
- Explosive separation of a tire and rim can cause serious injury or death. Only properly trained personnel should attempt to service a tire and wheel assembly.
- Add sufficient ballast to tractor to maintain steering and braking control at all times. Do not exceed tractor's lift capacity or ballast capacity.

Before Operating

- Do not stand between towing vehicle and implement during hitching.
- Always make certain everyone and everything is clear of the machine before beginning operation.
- Verify that all safety shields are in place and properly secured.



- Ensure that all applicable safety decals are installed and legible.
- Secure drawbar pin with safety lock and lock tractor drawbar in fixed position.

During Operation

- Regulate speed to field conditions. Maintain complete control at all times.
- Never service or lubricate equipment when in operation.
- Always fold the auger to the field or transport position after unloading.
- Keep away from overhead power lines. Electrical shock can cause serious injury or death.



- Use extreme care when operating close to ditches, fences, or on hillsides.
- Do not leave towing vehicle unattended with engine running.

Before Transporting

- Secure transport chain to towing vehicle before transporting. DO NOT transport without chain.
- Check for proper function of all available transport lights. Make sure that all reflectors are clean
 and in place on machine. Make sure the SMV emblem and SIS decals are visible to approaching
 traffic.
- This implement may not equipped with brakes. Ensure that the towing vehicles have adequate weight and braking capacity to tow this implement.

During Transport

- Comply with all laws governing highway safety when moving machinery.
- Use transport lights as required by all laws to adequately warn operators of other vehicles.
- Regulate speed to road conditions and maintain complete control.
- Maximum transport speed of this implement should never exceed 20 m.p.h. as indicated on the
 machine. Maximum transport speed of any combination of implements must not exceed the lowest specified speed of the implements in combination. Do not exceed 10 m.p.h. during off-highway travel.
- Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.
- Do not transport grain cart on roads while loaded.
- It is probable that this implement is taller, wider and longer than the towing vehicle. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Pressurized Oil

- Relieve the hydraulic system of all pressure before adjusting or servicing. See hydraulic power unit manual for procedure to relieve pressure.
- High-pressure fluids can penetrate the skin and cause serious injury or death. Use cardboard or wood to detect leaks in the hydraulic system. Seek medical treatment immediately if injured by high-pressure fluids.
- Accumulators used in this hydraulic system can retain fluid under pressure even after tractor hydraulic valve is placed in FLOAT. See tractor operators manual for procedure to relieve pressure.
- · Hydraulic system must be purged of air before operating to prevent serious injury or death.
- Do not bend or strike high-pressure lines. Do not install bent or damaged tubes or hoses.
- Repair all oil leaks. Leaks can cause fires, personal injury, and environmental damage.
- Route hoses and lines carefully to prevent premature failure due to kinking and rubbing against other parts. Make sure that all clamps, guards and shields are installed correctly.
- Check hydraulic hoses and tubes carefully. Replace components as necessary if any of the following conditions are found:
 - End fittings damaged, displaced, or leaking.
 - Outer covering chafed/cut or wire reinforcing exposed.
 - Outer covering ballooning locally.
 - Evidence of kinking or crushing of the flexible part of a hose.

Driveline Safety

Do not allow children near equipment that is running or engaged.



- Do not exceed 1000 rpm PTO speed.
- Disengage the PTO, stop the tractor engine, and remove key from ignition before making inspections, or performing maintenance and repairs.
- Inspect the driveline, quick disconnect, overload shear-bolt limiter or clutch, and shielding often. Repair immediately. Use replacement parts and attaching hardware equivalent to the original equipment. Only alterations described in this manual for overall length adjustment are allowed. Any other alteration is prohibited.
- Avoid excessively long hardware or exposed and protruding parts which can snag and cause entanglement.
- Lubricate the driveline as recommended in the MAINTENANCE section.
- Keep hoses, wiring, ropes, etc. from dangling too close to the driveline.
- Install driveline and shields according to recommended lengths and attaching methods with recommended hardware. The driveline shield should rotate independently a full rotation and telescope freely. The retaining chain must be secured to the implement safety shield.
- Adjust drawbar to height and length recommended in the OPERATION section.
- Use caution when turning to avoid contact between tractor tires and driveline.
- Check the length of the telescoping members to ensure the driveline will not bottom out or separate when turning and/or going over rough terrain.
- Proper extended and collapsed lengths of the telescoping PTO shaft must be verified before first
 operation with each and every tractor. If the extended length of the PTO shaft is insufficient, it may
 become uncoupled during operation and cause serious injury or death from contact with uncontrolled flailing of PTO shaft assembly components.

Preparing for Emergencies

· Keep a first aid kit and properly rated fire extinguisher nearby.





Keep emergency numbers for fire, rescue, and poison control personnel near the phone.



Wearing Protective Equipment

Wear clothing and personal protective equipment appropriate for the job.





Wear steel-toed shoes when operating.



Wear hearing protection when exposed to loud noises.



Do not wear additional hearing impairing devices such as radio headphones, etc.



| Notes | |
|-------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

Section II Set-Up

| Set Up Checklist 2-2 |
|--|
| Basic Cart Set-Up |
| Hydraulic System2-3 |
| Wheel/Tire Set-up2-3 |
| Auger Spout Cylinder Stop Removal2-4 |
| PTO Brackets Removal2-4 |
| Jack |
| Optional Hydraulic Jack2-5 |
| Steering Tandem Switch Box Connection |
| Driveline Set-Up2-8 |
| Coupling The Cut-Out Clutch |
| SMV Emblem and SIS Decal2-9 |
| Video System (Optional) |
| Upper Ladder Extension to Operating Position |
| Horizontal Cleanout Door Inspection |
| Belt Engagement2-14 |
| Operational Check |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL.
FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL.
FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL.
FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Set Up Checklist

| er the cart has been completely assembled, use the following checklist and inspect the t. Check off each item as it is found satisfactory or after proper adjustment is made. |
|---|
| Set or Calibrate tractor PTO control engagement to MINIMUM setting. Refer to tractor operator's manual for setting information. |
| Remove auger spout cylinder stop. |
| Remove PTO brackets. |
| Torque wheel nuts and check tire pressure as specified in MAINTENANCE section. |
| Verify track has been aligned and is properly conditioned. (If applicable) |
| Inflate tires to specified air pressure. (if applicable) |
| Lubricate all grease fittings and check gearbox oil level. |
| Inspect cleanout door assembly for play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section. |
| Verify all safety decals are correctly located and legible. Replace if damaged. |
| Verify all reflective decals are correctly located. |
| Check SMV decal and SIS decals are in place, clean and visible. |
| Verify transport lights are working properly. |
| Verify PTO length, see "Verify Telescoping PTO Shaft Length" in MAINTENANCE section. |
| Align and properly tension belts/chains. See "Belt Tightener Adjustment" and "V-Belt Alignment" in MAINTENANCE section. |
| Ensure safety screens over horizontal auger are in place and properly secured. |
| Install transport chains and torque hardware to specification. See "Transport Chain Connection" in OPERATION section. |
| Paint all parts scratched in shipment. |
| Test run the augers. See "Auger Operation" in OPERATION section. |

Basic Set Up



Due to shipping requirements and various dealer-installed options, some initial cart set-up will be required after it arrives from the factory. Use the following procedures as needed for initial cart set-up.

Hydraulic System

Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.

Wheel/Tire Set Up

Tire Pressure

Tire pressure must be verified before first use and adjusted as necessary. Refer to MAINTENANCE section of this manual for information on tire pressure.

Wheel Nuts



IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGULARLY.
 SEE TORQUE PAGE IN THE MAINTENANCE SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

• Installing wheels without the proper inset/offset could result in hub or spindle failure. This will cause substantial damage to cart and is not covered by warranty. Inset/offset will vary depending on tire size. Consult dealer for proper inset/offset.

Basic Set Up (continued)

Auger Spout Cylinder Stop Removal

Remove the stop on the spout tilt cylinder at the front of the cart, before operating the spout.

IMPORTANT

Cylinder stop must be removed before operating the auger spout. Failure to remove stop will
result in damage to the cylinder and spout.





PTO Brackets Removal

Remove the PTO assembly and PTO brackets on the tongue, before operating the auger tilt or when connecting the driveline assembly to the tractor. Keep PTO brackets for seasonal storage. Refer to "Seasonal Storage" in MAINTENANCE section.

IMPORTANT

• PTO assembly and PTO brackets must be removed before operating the auger tilt or when connecting the driveline assembly to the tractor. Failure to remove PTO assembly and PTO brackets will result in damage to the PTO assembly, tongue, auger and tractor.






Basic Set Up (continued)

Jack

A WARNING


 UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. AL-WAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTEND-ED TO SUPPORT AN EMPTY CART ONLY.

Attach jack to left-inside frame using pin and hair pin. Pivot the jack 90 degrees and reinstall pin for field use.



Optional Hydraulic Jack

 Assemble hoses (9006068) and fittings to cylinder (9009047) as shown in figure 2-1. The valve needs to be assembled to the hose on the base end of the cylinder. Assemble the fittings on the cylinder so they face each other, then store the hydraulic hoses on the hose caddy.



Basic Set Up (continued)


Optional Hydraulic Jack


 Assemble the cylinder (9006422) and jack foot (271723B) to the jack weldment (271712B) as shown in figure 2-2 using 1"-8UNC x 7" capscrews (9390-197) and 1"-8UNC locknuts (92199).


NOTE: Ensure all jack leg weldment (271712B) joints can pivot freely, especially jack foot (271723B).

- 3. Tighten 1" hardware to jack leg weldment. (FIG. 2-2)
- 4. Attach the jack weldment (271712B) to the lower tabs behind the hitch plate on the tongue, shown in figure 2-3 using 1"-8UNC x 7" capscrews (9390-197) and 1"-8UNC locknuts (92199).
- 5. Tighten 1" hardware to jack leg weldment and allow the joint to pivot. (FIG. 2-3)

6. Align the base end of the cylinder with the lug on the top of the tongue and assemble the cylinder pin (272587) and snap rings (91192) shown in figure 2-4.








Basic Set Up (continued)

Steering Tandem Switch Box Connection

Connect the steering tandem "ON/OFF" switch box to the two pin weather pack connector located just behind grain cart 7-pin male receptacle. (Fig. 2-5)

NOTE: If a two pin extension is needed for the two pin weather pack, see "Electrical Components" in the PARTS section of manual.

Route switch and harness into tractor cab. From the switch box harness, connect the WHITE wire to ground and BLACK wire to +12VDC key-switched power source inside the tractor cab. Ensure "ON/OFF switch is "ON". (Fig. 2-5)



Basic Set Up (continued)

Driveline Set Up

Clean and grease the Implement Gearbox splined shaft. Gearbox shaft guard has access doors for installing and removing of driveline.


A DANGER

ENTANGLEMENT WITH THE DRIVELINE WILL CAUSE SERIOUS INJURY OR DEATH.
KEEP ALL GUARDS AND SHIELDS IN GOOD CONDITION AND PROPERLY INSTALLED
AT ALL TIMES. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOE
STRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC. THAT CAN BECOME ENTANGLED IN A ROTATING DRIVELINE.

Coupling The Cut-Out Clutch

Engage PTO drive shaft onto implement PTO shaft until retaining groove of implement PTO shaft aligns with clamping cone hole. Insert clamping cone into threaded hole, hand tighten. Torque cone to 75 ft.-lb. (Fig. 2-6)

NOTE: See MAINTENANCE section - PTO Quick Disconnect - for disassembly instructions.




Basic Set Up (continued)

SMV Emblem & SIS Decal

The reflective surface of the SMV must face rearward. This may require removal of film protecting the reflective surface or removing and reinstallation of the SMV. (Fig. 2-7)

When reinstalling the SMV make sure that it is mounted with the wide part of the SMV at the bottom.



Ensure the SIS decals (one on the front and one on the rear of the cart) are clean and visible. (Fig. 2-8)

For front and rear 20 M.P.H. SIS decals, order 9008715 & 9008714.

For front and rear 30 K.P.H. SIS decals, order 9008721 & 9008720.



Video System (Optional)

The video system includes its own installation instruction sheet. Reference the provided instruction sheet.

Basic Cart Set Up (continued)

Upper Ladder Extension to Operating Position


A WARNING

- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING IN-SIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFO-CATES VICTIMS IN SECONDS.


NOTE: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.

NOTE: To change ladder assembly positions, refer to "Ladder Operation" in the OPERATION section.

1. Move the upper ladder extension (289707B) from shipping position by removing the 5/16"-18UNC x 3/4" carriage bolts (9388-024), 5/16" flat washers (9405-064) and 5/16"-18UNC lock nuts (9008441). Keep hardware for next step. (FIG. 2-9)



- Using hardware from step 1, attach upper ladder extension to the higher set of holes to be in operating position. (FIG. 2-9 & FIG. 2-10)
- 3. Torque hardware to 17 ft.-lbs.



Basic Cart Set Up (continued)

Horizontal Cleanout Door Inspection

A WARNING


- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH.
 ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH.
 BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

NOTE: For cleanout door assembly operation, refer to "Vertical & Horizontal Cleanout Door Operation" in the OPERATION section.

<u>NOTE</u>: This procedure is a **two-person** process. One person operates the tensioner handle while the second person inspects the horizontal cleanout doors.

- Park the unit on a firm, level surface. Block the wheels/tracks on the machine to keep the unit from moving. Set the vehicle parking brake, shut off the engine and remove the ignition key.
- Use the tensioner handle, located on the lefthand side of the grain cart, behind the first panel to open and close the horizontal cleanout doors.
- Insert tensioner handle into cleanout door receiver coupler on the rear panel, and remove lynch pin from rockshaft. Keep lynch pin.
- 4. Rotate tensioner handle clockwise to open the doors. (Fig. 2-11 & 2-12)
- 5. Clean the door area of debris that may prevent the door from shutting completely. (Fig. 2-11 & 2-12)
- Inspect the cleanout door and rockshaft for loose hardware. Do not torque hardware. (Fig. 2-11 & 2-12)

(Continued on next page.)








Basic Cart Set Up (continued)

Horizontal Cleanout Door Inspection

- 7. If plate insert needs adjustment, loosen the two flat head machine screws holding the plate in position. (Fig. 2-13)
- 8. Ensure the plate inserts are aligned and fit into the belly pan cut-outs. (Fig. 2-13)
- NOTE: As the tensioner handle is rotated counterclockwise near the end of the close position, the coiled springs will extend to apply pressure to cleanout doors. If the doors do not close or visual door perimeter gaps are present, adjust the front to rear rockshaft starting at step 9. If doors close, go to step 13.
- 9. Loosen all the hardware in the slotted brackets connecting the cleanout door rockshaft to the grain cart tube. (Fig. 2-14)
- 10. Starting at the front of the cart, using a jack, push the rockshaft up and toward the runner tube. (Fig. 2-14)
- NOTE: Ideal distance between the runner tube and rockshaft is 3 1/4".
- 11. When the rockshaft is in position, torque the hardware previously loosened to 28 ft.-lbs.
- 12. Continue repositioning the rockshaft moving toward the back of the cart.






Basic Cart Set Up (continued)

Horizontal Cleanout Door Inspection

- Rotate the tensioner handle counter-clockwise to close the doors allowing the plate to fit and seal into the belly pan opening. (Fig. 2-15 & 2-16)
- 14. Open the doors and torque plate hardware to 17 ft.-lbs. (Fig. 2-16)
- 15. Close the doors and ensure all doors seal. (Fig. 2-16)
- 16. Insert lynch pin into rockshaft and return handle to storage location.





Basic Set Up (continued)

Belt Engagement

A WARNING

 MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

The unit is shipped without the tension applied to the belts. To engage the tensioner use the belt tensioner handle, located on the left-hand side of the grain cart, behind the first panel. (Fig. 2-17 and 2-18)





Basic Set Up (continued)

Operational Check

A WARNING

 MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. EN-SURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

IMPORTANT

• Before running the auger pivot, the vertical auger clean-out door must be closed to prevent machine damage.

Once set-up has been completed, run the cart to check for operation and functionality:

- 1. Lights Work, Turn, Brake
- 2. Flow Door
- 3. Flow Door Indicator
- 4. Auger Fold
- 5. Auger Pivot
- 6. Spout Rotate & Pivot (if applicable)
- 7. Auger Startup & Shut-down
- 8. Steering (if applicable)
- 9. Brakes (if applicable)







| Notes | |
|-------|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | , |

Section III Operation

| Operating Checklist | 3-2 |
|---|------|
| Preparing Tractor | 3-3 |
| Preparing Cart | 3-3 |
| Lubrication | 3-4 |
| Video System (Optional) | 3-4 |
| Hitching to Tractor | |
| Drawbar Connection | 3-5 |
| Jack Usage | 3-6 |
| Optional Hydraulic Jack Usage | 3-7 |
| Transport Chain Connection | 3-8 |
| Hydraulic Connections | 3-9 |
| Electrical Connections | 3-11 |
| Optional Implement Brake Connection | 3-11 |
| Towing | |
| Electric Over Hydraulic Operation (Optional) | 3-13 |
| Manual Override for Optional Electric Over Hydraulic System | 3-16 |
| Vertical & Horizontal Cleanout Door Operation | |
| Vertical Cleanout Door | 3-18 |
| Horizontal Cleanout Door | 3-20 |
| Auger Operation | |
| PTO-Driven Auger | 3-22 |
| Auger Overload Procedure | 3-24 |
| Vertical Auger Fold | 3-25 |
| Auger Field Rest Position | 3-26 |
| Upper Auger Rest Adjustments | 3-28 |
| Steering Tandem | 3-29 |
| Troubleshooting | 3-30 |
| Ladder Operation | 3-32 |
| Weather Guard Tarp | 3-36 |

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL.
FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL.
FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL.
FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Brent 1596 Right-Hand Unload — Operation

Operating Checklist ☐ Read and understand all safety precautions before operating cart. R.V. antifreeze needs to be completely flushed from the Water Delivery System and disposed of properly. Make certain the Water Delivery System only contains water before placing the Water Delivery System in service. (If applicable) ☐ Set or Calibrate tractor PTO control engagement to MINIMUM setting. Refer to tractor operator's manual for setting information. ☐ Torque wheel nuts and check tire pressure as specified in MAINTENANCE section. ☐ Verify track has been aligned and is properly conditioned. (If applicable) ☐ Inflate tires to specified air pressure. (if applicable) ☐ Lubricate all grease fittings and check gearbox oil level. ☐ Clean-out door assembly play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section. ☐ Inspect cleanout door assembly for play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section. ☐ Test operation and functionality of flow door indicator, auger fold, auger pivot, spout rotate, and spout tilt. ☐ Verify all reflective decals are correctly located. ☐ Check SMV sign and SIS decals are clearly visible with the cart attached to the tractor. ☐ Verify transport lights are working properly. Check and follow all regulations before towing on a road or highway. Userify that hitch height and length when attached to the tractor are sufficient to prevent severe bends in PTO U-joint angles. □ Verify PTO length, see "Verify Telescoping PTO Shaft Length" in MAINTENANCE section. ☐ Align and properly tension belts/chains. See "Belt Tightener Adjustment" and "V-Belt Alignment" in MAINTENANCE section. Ensure safety screens over horizontal auger are in place and properly secured. ☐ Install transport chains and torque hardware to specification. See "Transport Chain Connection" in **OPERATION** section. ☐ Test run the augers. See "Auger Operation" in OPERATION section.

Preparing Tractor

Before operating cart, read the tractor Operator's Manual and gain an understanding of its safe methods of operation.

Check the tractor brakes and transport lights. Make sure they are in proper working order.

On carts equipped with optional hydraulic brake system, make sure the tractor is equipped with the components necessary for operating the cart's hydraulic brakes. Consult your tractors Operator's Manual or your tractor dealer for the appropriate brake control system.

Check if the tractor has multiple PTO engagement modulation settings and has the latest PTO engagement software from the OEM. If unsure, contact your local dealer for tractor capabilities and recommended setting for grain cart operation.

Check the tractor hydraulic oil reservoir and add oil if needed.

Verify that the tractor is adequately ballasted for drawbar operation at the anticipated draft load. See tractor manual for ballasting instructions.

If possible, adjust the tractor drawbar vertically so the topside of the drawbar is approximately 17-22 inches from the ground. Ensure that the drawbar is locked in the center position.

On tractors equipped with a 3-point hitch, raise and secure the linkage to prevent interference with the cart tongue, hydraulic hoses and the hydraulic drive option during turning. It may be necessary to remove tractor 3-point quick attach to avoid damage during turning.

Preparing Cart

Perform the service checks as outlined below. Repair or replace any damaged or worn parts before operating.

Hardware

Check for loose bolts and nuts, and tighten as needed. Check again after the first half-day of operation.

Pivot Pins

Check that all pins are in place and in good condition. Replace any worn, damaged or missing pins.

Hitch

Check hitch wear plates for damage and wear. Ensure correct hitch adapter bushing is being used. Select correct size for the hitch pin/draw bar you are using.

NOTE: The cart comes standard with a Category 4 hitch. A Category 5 tongue is available. Contact your dealer for a CAT 5 tongue if required. Check that the drawbar is in the required 20" position and will adequately support loads.

Preparing Cart (continued)

Auger

Inspect auger for damage and wear.

Hydraulic System

Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.

Optional Hydraulic Brake System

On carts equipped with the optional hydraulic brake system, ensure hose is properly connected to the tractor's hydraulic trailer brake coupler. Consult your tractors Operator's Manual or your tractor dealer for more information.

Tires/Wheels

Check tire pressures and maintain at recommended values listed in the MAINTENANCE section of this manual.



 IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGU-LARLY. SEE TORQUE PAGE IN THE MAINTENANCE SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

Installing wheels without the proper inset/offset could result in hub or spindle failure. This will
cause substantial damage to cart and is not covered by warranty. Inset/offset will vary depending on tire size. Consult dealer for proper inset/offset.

For questions regarding new tire warranty, please contact your local original equipment tire dealer. **USED TIRES CARRY NO WARRANTY**. Tire manufacturers' phone numbers and web sites are listed in the MAINTENANCE section of this manual for your convenience.

Lubrication

Lubricate the cart as outlined in the MAINTENANCE section of this manual.

Video System (Optional)

IMPORTANT

Do not operate video system below 15°F. Damage to video system can occur.

The video system kit includes its own operation instruction sheet.



Hitching to Tractor

Drawbar Connection

This cart is intended to be hitched to a tractor drawbar. Do not attempt to hitch to any other location on the tractor other than the drawbar.

The cart comes with a CAT 4 hitch for use with a 2" pin and designed for a clevis-type tractor drawbar. If a 1 1/2" or 1 3/4" diameter hitch pin is used, a corresponding bushing must be inserted into the hitch tang and held in place with o-rings. If a bushing is already in the hitch, use a punch and hammer to remove and replace with the correctly sized bushing. (Figure 3-1)

A CAT 5 hitch tang is available, see dealer for parts.

NOTE: Use of the proper hitch pin/bushing will prevent excessive wear and tear on both the cart and tractor.

NOTE: Bushings and o-rings are stored in the toolbox on the right-hand side of the cart.

Lock tractor drawbar in center position.

Set tractor drawbar length to 20" from the end of the tractor PTO shaft to center of drawbar pinhole.


A WARNING


 DO NOT STAND BETWEEN THE CART AND TRACTOR WHEN HITCHING. ALWAYS ENGAGE PARKING BRAKE AND STOP ENGINE BEFORE INSERTING HITCH PIN.


Place wear shoe (281663-CAT 3; 281898-CAT 4; 281899-CAT 5) between tractor hitch and grain cart hitch. (Figure 3-2)

After inserting drawbar pin, secure drawbar pin with a locking device to prevent uncoupling during use.

NOTE: Hitch tang can be flipped providing a drawbar connection height difference of 2 7/8" (Figure 3-3). Position the hitch tang to help assure a level cart when loaded, or the rear of the hopper slightly higher than the front, to maintain rear slope cleanout. Whenever the hitch tang is flipped, the driveline clearances need to be reviewed.







Hitching to Tractor (continued)

A WARNING


 UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.

Jack Usage

Use jack to support an empty grain cart, never a loaded grain cart. Always have a loaded grain cart hooked to tractor. Attach jack to left inside frame using pin and hair pin. (Fig. 3-4) Pivot the jack 90 degrees and reinstall pin for field use. (Fig. 3-4)

IMPORTANT

 After cart is hitched to tractor, pivot jack to storage location shown in Fig. 3-5.





Hitching to Tractor (continued)

Optional Hydraulic Jack Usage

A WARNING

 HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.


IMPORTANT

• After cart is hitched to tractor, attach hydraulic hoses to tractor and retract hydraulic cylinder to store hydraulic jack between the frame rails.

Use hydraulic jack to support an empty grain cart, never a loaded grain cart. Always have a loaded grain cart hooked to tractor.

Always close the manual valve for the hydraulic jack for in-field use and when unhitched from the tractor.

- 1. Remove hoses from storage slots.
- 2. Attach jack cylinder hose couplers to tractor.
- 3. Open valve to allow hydraulic flow.
- 4. Use tractor hydraulic valve to extend cylinder and lift tongue.
- Once attached to tractor drawbar, retract cylinder to lower tongue and to raise jack into storage position.
- Close valve and then disconnect hose couplers from tractor.



- 7. Place hose couplers into storage caddy. Be sure to route hoses to clear PTO driveline during operation.
- 8. Check for leaks.

Hitching to Tractor (continued)


Transport Chain Connection

A CAUTION

- ALWAYS USE TRANSPORT CHAIN WHEN TRANSPORTING IMPLEMENTS. FAILURE TO USE A TRANSPORT CHAIN COULD CAUSE PERSONAL INJURY IF CART BECOMES DISENGAGED.
- REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED OR DAMAGED. DO NOT WELD TRANSPORT CHAIN.

Tractor must be equipped with a transport chain support. Always use intermediate support when connecting cart directly to a tractor. DO NOT use the intermediate chain support as the chain attaching point. Fig. 3-7 shows how the transport chain must be installed between cart and tractor.

The chain is rated for towing the grain cart empty on public roads. Never tow a loaded grain cart on public roads. Use only ASABE approved chains. Allow no more slack in chain than necessary to permit turning.



Hitching to Tractor (continued)

Hydraulic Connections

Clean hydraulic hose couplers before connecting to the tractor. For convenience, this unit is equipped with color hose grips attached to the hydraulic hoses. This will help in identifying the hose function and correct hook up. (FIG. 3-8)

For steering tandem, attach hydraulic hoses labeled "TURN LEFT" and "TURN RIGHT" into tractor hydraulic remote. Connect hydraulic hose "TURN LEFT" to extend port, and "TURN RIGHT" to retract port.

| Color | Function | | |
|----------|-------------------------------|--|--|
| Red | Flow Door Open and Close | | |
| Yellow | Spout Tilt In and Out | | |
| Tan | Joystick or Spout Rotate | | |
| Green | Auger Fold and Unfold | | |
| Blue | Auger Pivot Up and Down | | |
| Black | Jack Raise and Lower | | |
| Orange | Water Pump | | |
| Optional | Hydraulic Pressure and Return | | |
| Optional | Steering Tandem | | |
| Optional | Brakes | | |

After initial set-up or replacement of any hydraulic component on the cart, air must be removed from the cart's hydraulic system. Reference "Hydraulic System - Purge Hydraulic System" section in the MAINTENANCE section.

Route hoses away from areas that may cause abrasion or kinking of hoses during operation.

(Continued on next page)

Hitching to Tractor (continued)

Hydraulic Connections

Before disconnecting hoses from tractor, place tractor in Park and shut PTO off, operate auger fold and tilt to the lowest positions. Where possible, remove hydraulic pressure loads and avoid potential pressure buildup in the lines from long storage periods such as upper auger not in rest position. If equipped with hydraulic jack, extend jack to desired position, turn valve to closed position. See tractor operator's manual for proper procedure to relieve pressure from the lines. After SCV pressures have been relieved and tractor engine is off, disconnect hoses from tractor. Install couplers into storage slots provided.




Hitching to Tractor (continued)

Electrical Connections

This cart is equipped with a seven-pin SAE connector plug which will connect with the receptacle found on most newer tractors. If your tractor does not have this type of receptacle, an SAE J-560 seven-point socket can be purchased from your Unverferth dealer (Part number 92824). (Fig. 3-9)

NOTE: 7-pin connector must be plugged into the tractor in order for the spout system to operate.



The wiring schematic for this cart, shown in the MAINTENANCE section, complies with current ASABE Standards. Verify correct electrical function before using this cart.

Compliance with all lighting and marking laws is the responsibility of the operator at the time of travel.

See federal regulation 49 CFR 562; available at www.govinfo.gov for US federal law requirements.

See your Unverferth dealer for additional brackets, reflectors, or lights to meet your requirements.

Optional Implement Brake Connection

Connector should comply with ISO:5676 standards. Brake hydraulic hose is designated with blue color band. See tractor's operators manual for connection location.

Towing

Even if the cart is equipped with brakes, ensure that the towing vehicle has adequate weight and braking capacity to tow this implement. See towing vehicle manual for towing capacity. Never tow a loaded grain cart over public roads.

IMPORTANT

• To prevent damage to the cart brake system, manually release pressure from the cart hydraulic brakes if towing without a hydraulic brake equipped vehicle.

Maximum speed of cart should never exceed 20 m.p.h. Do not exceed 10 m.p.h. during off-highway travel. Do not exceed 8 m.p.h. when cart is fully loaded.

Secure drawbar pin with a locking device and lock tractor drawbar in centered position.

The PTO drive shaft needs to be placed in the storage position on the tongue or properly attached to the tractor. See "Coupling The Cut-Out Clutch" in SET UP section and "PTO Shaft and Clutch" in MAINTENANCE section before connecting the PTO drive shaft to the tractor.

Secure transport chain to tractor chain support before towing.

A CAUTION

• THE STANDARD TRANSPORT CHAIN PROVIDED IS FOR THE BASIC CART WHEN TOWED EMPTY FOR ROAD TRAVEL.

Regulate speed to road conditions and maintain complete control.

It is probable that this cart is taller, wider and longer than the towing tractor. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.

Verify brake operation/release before towing.


Always fold auger into storage position when auger is not in use.

Electric Over Hydraulic Operation (Optional)

Before operating cart, familarize yourself with the functions associated with the joystick controller by operating with an empty cart.

The joystick comes with a mounting pin allowing storage inside the tractor cab when not in use.

- 1. Connect the red wire from power harness (9008251) to a key-switched +12VDC power supply. (Fig. 3-10)
- 2. Connect the white wire from power harness (9008251) to ground. (Fig. 3-10)




Electric Over Hydraulic Operation (Optional) (continued)

- 3. Connect the Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.
- 4. Place the remote in continuous detent so that the Hydraulic Pressure hose is pressurized and set the hydraulic flow to a maximum 6 gal/min to minimum 4 gal/min.
- To fold auger out from transport to operating position, push down the auger unfold button on joystick face until the upper and lower auger are engaged and fold linkage is over center. See Fig. 3-11.


NOTE: Joystick has a double tap feature, which allows the operator to quickly double tap a function in order to operate it for a set time. If the auger fold or auger unfold buttons are double tapped, the function will stay on for 60 seconds to complete the full cycle without holding the buttons down. Pressing either of those buttons during these timed cycles will CANCEL the cycle. This double tap feature only applies to auger fold and unfold functions.

- 6. To pivot spout OUT away from cart, push hat switch toward OUT. Hold the switch until desired position is achieved. See Fig. 3-11.
- 7. To pivot spout IN toward cart, push hat switch toward IN. Hold the switch until desired position is achieved. See Fig. 3-11.
- 8. To pivot the entire auger UP, press and hold the auger pivot UP button until the desired height is achieved. See Fig. 3-11.
- 9. To pivot the entire auger DOWN, press and hold the auger pivot DOWN button until the desired height is achieved. See Fig. 3-11.




Electric Over Hydraulic Operation (Optional) (continued)


 To open flow door, rotate the switch upwards. Observe flow door indicator to determine when to release trigger and stop flow door movement. See Fig. 3-12.



To close flow door, rotate the switch downwards.
 Observe the flow door indicator and release trigger when door is closed to desired position.
 See Fig. 3-13.



- 12. To fold auger from operating position to transport position:
- A. Rotate spout to centered position. Align the checker flag with the upper auger to locate center as shown in Fig. 3-14.
- B. Press auger FOLD button on joystick.
- C. Hold FOLD button until upper auger is on field rest or in transport position.
- 13. Once unloading is complete, stop hydraulic flow. <u>ALWAYS</u> stop continuous detent when auger functions are not required or active.



Manual Override for Optional Electric Over Hydraulic System

WARNING

- MOVING OR ROTATING AUGER COMPONENTS CAN CAUSE SERIOUS INJURY OR MA-CHINE DAMAGE. BEFORE OPERATING MANUAL OVERRIDE(S), ENSURE EVERYONE IS AWAY FROM THE SPOUT AND THAT THE SPOUT WILL NOT CONTACT ANY OTHER PARTS OF THE GRAIN CART. ALL CONTROL SWITCHES ARE DEACTIVATED WHILE UTILIZING MANUAL OVERRIDE(S).
- MOVING OR ROTATING PTO COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH.
 DO NOT OPERATE PTO WHILE UTILIZING MANUAL OVERRIDE(S).


NOTE: Manual override operation is intended for emergency use ONLY and is not intended for continuous operation.


NOTE: 7-pin connector must be plugged into the tractor in order for the spout system to operate.

- 1. Park the empty grain cart on a firm and level surface. Block the tires/tracks on the machine to keep it from moving. Set the tractor's parking brake.
- 2. Connect the Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.

NOTE: Center rotating spout before activating auger fold.


- To operate the manual override functions, place the tractor SCV remote in continuous detent so that the Hydraulic Pressure hose is pressurized.
- Remove cover plate (272606B) from the bottom of the lower auger housing to access the EOH block assembly.
- NOTE: Only one cartridge valve (9008416 & 9008463) must be in the top or bottom detent position at a time to function properly. All other valves must be in the middle detent postion. (FIG 3-15 & 3-16)
- Operate the desired function on valve (9008416 & 9008463) by rotating the manual override knurled knob from the locked neutral position. (FIG. 3-15 & 3-16)






Manual Override for Optional Electric Over Hydraulic System (continued)

- 6. Push and hold the manual override button on valve (9008438). (FIG. 3-17)
- 7. Once the desired position is reached, release manual override button on valve (9008438).
- 8. Return knurled knob to center and lock valve (9008416) & (9008463) in position. (FIG. 3-15 & 3-16)
- NOTE: Refer to "Troubleshooting" for EOH, vertical auger and/or rotating spout issues in the OPERATION section.
- 9. Turn off hydraulic circuit when done. Correct electric/hydraulic system before continued use. Consult your dealer for service and parts.





Vertical & Horizontal Cleanout Door Operation


A WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH.
 ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

NOTE: Raise the vertical auger to ensure clearance between cleanout door and tongue to open and remove the cleanout door from the vertical lower auger

Vertical Cleanout Door

- Park the empty grain cart on a firm and level surface. Block the tires/tracks on the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
- 2. To completely close cleanout door, ensure the vertical auger cleanout door top edge clears the vertical position stop (key stop). (FIG. 3-18)
- 3. Attach eye bolt ends of over center latches to the hooks on the vertical auger. (FIG. 3-18)
- 4. Clasp the over center latch handles to lock the door in the closed position. (FIG. 3-18)



- 5. Inspect and verify cleanout door perimeter for gaps. Ensure all grain dust and filings are removed that may prevent the door from shutting completely.
- 6. If gaps are present, unclasp the over center latch and tighten eye bolt to improve door seal on the vertical auger.
- 7. Rehook eye bolt to vertical auger and clasp the over center latch.


NOTE: Repeat closing the door and inspection, as necessary.

Vertical & Horizontal Cleanout Door Operation (continued)


Vertical Cleanout Door

NOTE: Remove the vertical auger cleanout door to improve vertical auger cleaning.

- 8. To open and remove the vertical auger cleanout door, unclasp the over center latch. (FIG. 3-19)
- 9. Unhook the eye bolt from the vertical auger and open the cleanout door. (FIG. 3-19)



- The hinge on the vertical auger cleanout door is set on a pin. Lift and remove the cleanout door from the vertical auger. Keep vertical auger cleanout door. (FIG. 3-20)
- 11. Inspect and verify all debris is removed from inside the vertical auger housing.
- 12. Reattach the vertical cleanout door to the vertical auger.





Vertical & Horizontal Cleanout Door Operation (continued)


Horizontal Cleanout Door

Use the tensioner handle, located on the left-hand side of the grain cart, behind the first panel to open and close the horizontal cleanout doors.

 Insert tensioner handle into the cleanout door receiver coupler on the rear panel, and remove lynch pin from rockshaft. Keep lynch pin. (FIG. 3-21)







Handle Horizontal Is In

Closed Position

Remove & Keep

Lynch Pin

4. Inspect and verify all debris is removed that may prevent the doors from shutting completely. (FIG. 3-23)

NOTE: If cleanout doors do not function properly, refer to "Horizontal Cleanout Door Inspection" in SET UP section for more information.

5. Remove lynch pin from rockshaft and rotate handle counter-clockwise and clockwise to check for smooth door operation.



Vertical & Horizontal Cleanout Door Operation (continued)

Horizontal Cleanout Door

6. Rotate handle counter-clockwise to close doors and ensure all doors seal. (FIG. 3-24)



7. Insert and lock lynch pin into rockshaft and return handle to storage location. (FIG. 3-25)



Auger Operation

PTO Driven Auger

▲ DANGER

ELECTROCUTION WILL CAUSE SERIOUS INJURY OR DEATH.
 ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT. KEEP
 AWAY FROM ALL ELECTRICAL LINES AND DEVICES.



A WARNING

- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL IN-JURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE THE CART, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE CART.
- 1. Before loading cart or operating auger, verify the flow control door is closed.
- NOTE: If spout rotate moves out of center, the auger will not unfold to unloading position. The spout must be manually rotated to center position. See "Manual Override for Optional Electric Over Hydraulic System" in the OPERATION section.
- Choose an area free from obstructions and unfold auger into unloading position. Allow sufficient time for the cylinder to fully engage the two augers and over-center latch to fully engage.
- 4. Engage PTO at low engine RPM, then increase engine RPM until 1000 PTO RPM is reached.



- 5. Open flow control door to desired unloading rate. Numbers on the auger tube provide a point of reference for operator convenience. (FIG. 3-26)
- 6. To slow or stop grain flow, close flow door, rather than reducing tractor RPM. Close flow door fully when unloading is complete.

NOTE: If an overload occurs, see "Auger Overload Procedure."


<u>NOTE</u>: It is not recommended to disengage auger with flow control door open. Auger system will require substantially more torque to start, placing extra stress on both cart and tractor driveline.

Cart is equipped with baffles that can be adjusted to accommodate the flow of different materials and/or torque demands associated with different materials. See the MAINTENANCE section for the procedure.

Auger Operation (continued)

- 7. When auger is empty, reduce PTO rpm to idle, and stop PTO.
- 8. After PTO has come to a complete stop, the checker flag needs to align with the upper auger to center spout as shown in FIG. 3-27.
- 9. Once spout is centered, fold auger to the transport position or field position.

NOTE: Spout can be TILTED to any position, but must be ROTATED to center for auger to fold.



Auger Operation (continued)

Auger Overload Procedure

IMPORTANT

• Extensive operation while the clutch is slipping may damage drive components.

NOTE: When over loading occurs, drivelines equipped with cut-out clutch will make a "clicking" noise when torque has been exceeded. Immediately shut off PTO and shut the flow door.

NOTE: Once PTO RPM has significantly decreased, cut-out clutch will automatically reset.

- 1. Close flow door.
- With the PTO off and driveline stopped, disengage the belt tensioner using the belt tensioner handle, this disengages the horizontal auger from the drivetrain. (FIG. 3-28)
- 3. Restart and engage the tractor PTO at low engine RPM.
- 4. Increase engine RPM until 850 to 1,000 PTO RPM is reached to empty the vertical auger.
- 5. Once vertical auger is empty, stop PTO.
- 6. With the tractor PTO off and driveline stopped, reengage the belt tensioner using the belt tensioner handle. Return handle to storage. (FIG. 3-29)

Fig. 3-28

Handle up is in disengaged position



- 7. Restart and engage the tractor PTO at low engine RPM.
- 8. Increase engine RPM until 850 to 1,000 PTO RPM is reached to empty the drag auger.

<u>NOTE</u>: If the grain cannot be relieved by above method, open bottom clean out doors (see "Vertical & Horizontal Clean-Out Door Operation" in this section) to remove grain from auger before repeating these steps to clean out auger.

Auger Operation (continued)

Vertical Auger Fold

WARNING

 DO NOT STAND ON LADDER OR FRAME UNLESS TRACTOR ENGINE IS TURNED OFF AND KEYS ARE REMOVED FROM THE IGNITION.

Actuate hydraulic auger fold circuit to pivot vertical auger between transport and operating positions. When unfolding auger, allow sufficient time for cylinder to rotate the outside fold link into an over-center position. (FIG. 3-30)


<u>NOTE</u>: Auger spout will not rotate until auger is fully extended and auger will not fold until the spout is centered.



Auger Operation (continued)


Auger Field Rest Position


1. Extend auger to the unload position. Shut-off tractor's engine and remove the ignition key.




- Remove hairpin cotter from latch pin (Figure 3-31) and pull latch pin towards you to disengage (Figure 3-32). Raise auger rest stand up to field transport position and release latch pin. Make sure the pin is engaged in the field transport position hole and re-install hairpin removed earlier in this step.
- 3. Fold auger back to field transport position (Figure 3-33), making sure bracket engages the auger rest tube and activates the auger switch.

NOTE: Auger rest bracket is factory adjusted. Capscrews can be used for re-alignment of bracket.








Auger Operation (continued)


Auger Field Rest Position (continued)

4. Extend auger to the unload position. Shut-off tractor's engine and remove the ignition key.



- Remove hairpin and pull latch pin towards you to disengage. Lower auger rest stand to the transport position and release the latch pin (Figure 3-34). Make sure the pin is engaged in the transport position hole and re-install hairpin removed earlier in this step.
- 6. Move auger down to road transport position. (Figure 3-35)






Auger Operation (continued)

Upper Auger Rest Adjustments

- 1. Loosen mounting capscrews of auger rest bracket. (Figure 3-36)
- Raise auger approximately 6" out of the lower rest and install cylinder stops on the fold cylinder to prevent the auger from lowering unexpectedly.
- Position upper auger rest as needed so that it appears to be centered over the lower auger rest tube.
- 4. Hand tighten the mounting capscrews of the auger rest bracket.
- 5. Remove the cylinder stops installed in step 2, and lower the auger down into the lower rest.



6. Ensure the upper auger rest contacts the lower tube evenly. Finish tightening mounting capscrews.

Steering Tandem

Steering Tandem Indicator

Steering Tandem Tire position can be determined by observing indicator arrow located on the lower left portion of front panel.


NOTE: Indicator is best observed when auger is in field transport position.

Steering Tandem Operation

The steerable tandem has three different settings: Auto-Steer, Lock and Manual.

The defaulted function of the steering tandem is **Auto-Steer**. **Auto-Steer** is achieved when switch is in "OFF" position. (Regardless of tractor hydraulic lever position) This function allows grain cart tires to steer freely and to trail tractor.

To lock current steering position of tandem: Turn "ON/OFF" switch to "ON" and have tractor hydraulic remote lever in neutral position. This function may be used to hold steering position when moving back and forth along side of semi trailer.



To Manual steer tandem:

Turn "ON/OFF" switch to "ON" and move tractor hydraulic remote lever to extend or retract depending on steering direction and hydraulic connections noted earlier. This function may be used when backing unit into shed, or to make a reverse travel turn in opposite direction of forward turn.

<u>NOTE</u>: It is important to keep cylinders correctly phased. See "Steering Cylinder Rephasing" in the MAINTENANCE section.

NOTE: It is recommended to take scale readings with the wheels inline and vehicle stopped for maximum accuracy. See scale manual for more information.

Optional Implement Brake System for Steering Tandem

This system is for tractors with hydraulic trailer brake option. Once connected and properly bled, this system sends pressure to the implement's brakes when the brake pedal is used. After the brake pedal is released, pressure is removed from the implement calipers. Always check brake operation with an empty cart and familiarize the effectiveness as the load increases in the cart.

Troubleshooting

| Problem | Possible Cause | Corrective Action |
|--|--|--|
| No Electric Over Hydraulic (EOH) Functions work | Not getting 12 Volt power supply to the power harness in the tractor | Check the connections to the main power harness in the tractor cab, and check the 5 AMP fuse in the fuse holder of the main power harness. Replace fuse if necessary. |
| | Not getting good connection at Deutch connectors in the harnesses | Unplug the Deutsch connectors at the hitch point and in the extension harness (if used). Clean up the connectors with electrical contact cleaner. Make sure the connectors are aligned correctly and re-connect them. |
| | Not pressurizing the correct hydraulic hose | Make sure the quick couplers are properly connected to the tractor SCV and the Hydraulic Pressure line is being pressurized when engaging the tractor SCV. |
| Auger unfolds, but won't fold back in to transport position | Rotating Spout is not in the folding position | Rotate the spout so it is positioned straight down or forward in order to fold the auger into transport position. |
| | Rotating spout switch is faulty or out of adjustment | Make sure the spout is in the centered position. Press and hold the manual override button on the electric over hydraulic (EOH) valve on the auger fold cylinder while someone operates the hydraulic remote to fold the auger back to the transport position. Inspect the switch assembly near the rotating spout cylinder. The clearance between the end of the proximity switch and the barrel of the rotating spout cylinder must not exceed 1/4". |
| Auger unfolds part way and stops | Debris in the EOH block on the auger fold cylinder | Fold auger, remove hydraulic pressure, and remove the Coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil. |
| | Rotating Spout switch is out of adjustment or has been activated. | With the auger folded in to the lower transport rest, have some- one depress and hold the switch at the vertical auger hinge plate. Use any means necessary to depress the switch without placing your hands or other body parts near the pinch points. With the switch depressed, rotate the spout to the folding position. |

Troubleshooting (continued)

Problem Possible Cause Corrective Action

| Spout rotate does not operate | 7 pin connector is not plugged into tractor. | Plug in 7 pin connector to same power source as the 5 function controller. | |
|--|--|--|--|
| | Proximity Switch at the auger hinge is not getting Power or Ground. | Check power and ground to the proximity switch harness on the vertical auger. | |
| Rotating spout will not function | Proximity Switch at the hinge plate is not adjusted correctly | This proximity switch has a 1/4" effective operating range. The upper auger hinge plate needs to be within that range when it is unfolded in to the operating position. Adjust the proximity switch in or out in order for the sensor to activate when it is in the operating position. | |
| | Switch located at the hinge plate of the vertical auger is not getting power, ground or is defective | Check the ground wire on the top plate of the lower vertical auger and on the left hand standard just behind the front plate of the harness. Unplug the 3 pin connector on the hinge plate proximity switch. With a multi-meter or test light, confirm that the pin in socket B has +12V constant power and socket A has +12V when the sensor is activated. | |
| One single function will not work | Defective coil on the EOH valve for that function | Loosen the cap for the coils associated with that function on the EOH valve. Depress the button on the remote, and determine if the coils are getting magnetized. Inspect the wiring connectors to these coils, and replace the coil if necessary. | |
| | Defective valve on the EOH valve for that function | Remove the coil and the cartridge valve on the EOH valve block for that function. Replace the valve if it doesn't operate when the coil is magnetized. | |
| | Debris in the EOH block at the base of the vertical auger | Remove the coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil. | |
| Functions continue to operate after the button on the remote is released | Tractor hydraulic flow is set too high | Turn tractor hydraulic flow down so that flow doesn't exceed 6 gallons per minute. | |
| | Defective valve on the EOH valve for that function | Remove the coil and the cartridge valve on the EOH valve block for that function, and replace the cartridge. | |

Ladder Operation

A WARNING

- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING IN-SIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFO-CATES VICTIMS IN SECONDS.

NOTE: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.

NOTE: Ensure upper ladder extension is attached to higher holes on the ladder. Reference "Upper Ladder Extension to Operating Position" section in the SET UP section.

NOTE: Always use lock pin in the working and storage position to lock the ladder extension. The lock pin can be inserted in either left-hand or right-hand ladder hole. (FIGS. 3-37 & 3-38)






Ladder Operation (continued)

Storage to Working Position


- 1. Standing in front of ladder, place hands on outside ladder handles.
- 2. Keep one hand on ladder handle and with opposite hand, remove lock pin from ladder extension. Retain for future use. (FIG. 3-39)




 With hands back on ladder handles, push ladder towards hopper bin and lift ladder extension to unseat ladder extension rod from the cradle. (FIG. 3-40)



THE LADDER IS NOW FREE TO PIVOT.



4. Slowly swing ladder outward until hinge is fully extended and locks in the working position. (FIG. 3-41)




Ladder Operation (continued)

Storage to Working Position

- Lift and seat ladder extension into shorter leg of "J slot". (FIG. 3-42)
- 6. Using lock pin from step 2, insert lock pin into ladder extension and ladder. (FIG. 3-6)


A WARNING

 FALLING FROM AN UNSECURED LADDER MAY CAUSE SERIOUS INJURY OR DEATH. ALWAYS INSERT LOCK PIN BEFORE CLIMBING.



Working to Storage Position

- 7. Standing in front of ladder, place hands on outside ladder handles.
- 8. Keep one hand on ladder handle and with opposite hand, remove lock pin from ladder extension. Retain for future use. (FIG. 3-42)
- With hands back on ladder handles, lift and unseat ladder extension from shorter leg of "J slot". (FIG. 3-42)
- 10. Lower ladder extension until fully seated in longer leg of "J slot". (FIG. 3-43)




- 11. Keep one hand on ladder handle and with opposite hand, reach between ladder rungs and grab the ladder hinge hole. (FIG. 3-44)
- 12. Slowly lift ladder hinge until the ladder starts folding.
- 13. Remove hand from ladder hinge hole and place onto ladder handle.
- 14. Slowly push ladder towards hopper bin.




Ladder Operation (continued)

Working to Storage Position

15. Lower ladder extension and seat ladder extension rod onto the cradle. (FIG. 3-45)



16. Using lock pin from step 8, insert lock pin into ladder extension and ladder. (FIG. 3-46)



Weather Guard Tarp

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.

IMPORTANT

- Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.
- Tarp should not be used if it is torn or the bungee cords are frayed or show damage. If water pools on the tarp adjust tension of tarp cables and/or arm springs as required.

Always use adequate caution when operating tarp.

Make sure tarp is open before unloading or loading.

Make sure nobody is near the tarp system before and during operating.

Do not operate tarp with cart hoisted in an elevated position.

If tarp is covered with snow, it is important to remove snow before operating.

End caps must be free from grain that may be piled on them. Grain should not be heaped higher than the end caps or tarp bows.

Tarp may be fully opened or completely closed while in transit. However, the closed position is recommended.

Ensure everyone who operates the tarp is familiar with the correct procedures outlined in this manual.


Weather Guard Tarp (continued)

Procedure

- 1. Using both hands, carefully remove crank handle from holder. (FIG. 3-47)
- 2. Roll tarp to the desired location, choosing either a fully open or fully closed position.
- 3. To close the tarp, roll the main tarp tube clockwise up under the latch plate. Next, bring the crank handle down perpendicular to the ground. Continue by lifting it up into the crank retainer.

NOTE: Crank handle U-joint may need to be re-indexed on tarp tube to achieve correct tension.

- 4. Place crank handle in holder.
- 5. To open tarp, turn the main tarp tube counter clockwise until the tarp is fully open. Place crank handle in holder.



| Notes | | |
|-------|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |


Section IV Maintenance

| Lubrication - Cart | . 4-2 |
|--|--------|
| Hydraulic System | |
| Purge Hydraulic System | . 4-4 |
| Relieving Hydraulic Pressure | . 4-5 |
| Bleeding Procedure for EOH System | . 4-5 |
| Bleeding Procedure for Braking System | . 4-6 |
| Steering Tandem Maintenance | |
| Steering Tandem Troubleshooting | . 4-7 |
| Steering Cylinder Rephasing | . 4-9 |
| Steering Tandem Linkage Adjustment Procedures | |
| Outer Linkage | . 4-10 |
| Center Linkage | . 4-14 |
| Steering Indicator Adjustment Procedures | . 4-16 |
| Seasonal Storage | . 4-17 |
| Auger Driveline Bearings | . 4-18 |
| Gearbox with Sight Glass | . 4-19 |
| Driveline Removal | |
| Clamping Cone Assembly | . 4-19 |
| Auger System | |
| Vertical Auger | . 4-20 |
| Vertical Auger Timing | . 4-21 |
| Horizontal Auger | . 4-22 |
| Baffle Adjustment | . 4-23 |
| 5-Pin Driver Replacement | . 4-25 |
| Belt Tightener Adjustment | . 4-30 |
| V-Belt Alignment | |
| Split Tapered Bushings | . 4-32 |
| Verify Telescoping PTO Shaft Length | . 4-33 |
| PTO Shaft & Clutch | . 4-35 |
| PTO Quick Disconnect | . 4-37 |
| Tarp Troubleshooting Inspection & Maintenance | . 4-38 |
| Electrical System Schematic | . 4-39 |
| Electrical Over Hydraulic (EOH) System Schematic (Optional) | . 4-41 |
| EOH Valve Electric Schematic 5 Spool (Optional) | . 4-42 |
| Braking System Schematic | . 4-43 |
| Wheels & Tires | |
| Wheel Nut Torque Requirements | . 4-44 |
| Tire Pressure | . 4-45 |
| Tire Warranty | . 4-47 |
| Torque Chart - Hardware Grade 5 | . 4-48 |
| Torque Chart - Hardware Grade 8 | . 4-49 |
| Torque Chart - Hydraulic Fittings | |
| | |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL. | |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL. | |
| FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MANUAL. FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP MANUAL. | ΙΔΙ |


FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER DELIVERY SYSTEM MANUAL.

Lubrication

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.



Lubrication (continued)



Unverferth Mfg. recommends use of NLGI #2 Extreme Pressure grease.

The lubrication locations and recommended schedule are as follows:

| ITEM | DESCRIPTION | POINT | LUBRICANT | QTY. | HOURS |
|------|---|---------------------|-----------|------------------|----------------------|
| А | Grease Bank for Auger Pivot Pin - Vertical Upper Auger Hinge | 2 | EP-2 | 2 Shots | Daily |
| В | PTO Driveshaft | 3 | EP-2 | 1 Shot | See Chart Above |
| С | Gearbox Remove Cover - Check oil level every 2 weeks. Replace oil every season. Refer to Gearbox in MAINTENANCE section for instructions. | 1 | EP80W90 | Approx 85 oz. | Once Every Season |
| E* | Grease Bank for Hanger Bearing - Vertical Lower Auger See note below* | 1 | EP-2 | 2 Shots* | Monthly |
| F | Top Bearing - Vertical Upper Auger | 1 | EP-2 | 1 Shot | Each Season |
| G | Grease Bank for Horizontal Auger End & Center Bearings | 2 | EP-2 | 2 Shots | Monthly |
| Н | Grease Bank for Auger Pivot Rings - Front & Rear Auger Hinge | 7 | EP-2 | 2 Shots | Daily |
| K | Grease Slide Plate | 1 | EP-2 | 1 Shot | Each Season |
| L | Tongue Pivot Bushing | 2 (one per side) | EP-2 | 2 Shots | Daily |
| М | Front Horizontal Auger Bearing & Gearbox Support Bearing | 2 | EP-2 | 1 Shot | Weekly |
| N | Hubs | 4 | EP-2 | Repack | 2 Years |
| 0 | Rod Ends of Steering Linkage | 4 | EP-2 | 2 Shots | Weekly |
| Р | Tandem Pivot | 4 | EP-2 | 3 Shots | Daily |
| Q | Steering Pivot Pin | 2 | EP-2 | 3 Shots | Weekly |
| R | Spindle Retainer Pivot Pin | 4 | EP-2 | 2 Shots | Monthly _k |

*NOTE: Hanger bearing contains hydraulic shut-off grease zerk (9005240) with pressure relief to prevent over-greasing that could push bearing seals out. If grease is coming out of the relief on the zerk, this is normal and the bearing contains enough grease.

Hydraulic System

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the grain cart requires little maintenance.

Replacing Hoses/Fittings/Cylinders:

- 1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3000 psi.
- 2. Do not use hoses, fittings and cylinders that have pipe threads.
- 3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings according to "Torque Chart" in this section.
- 4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
- 5. Always purge the hydraulic system after servicing.

Purge Hydraulic System

A WARNING

- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING.
 SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SE-RIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.



KEEP CLEAR OF PINCH POINT AREAS.



Purge air from system as follows:

- A. Disconnect the rod end of all cylinders in a circuit and block up cylinders so the rod can completely extend and retract without contacting any other component.
- B. Pressurize the system and maintain system at full pressure for at least 5 seconds after cylinder rods stop moving. Check that all cylinders have fully extended or retracted.
- C. Check oil reservoir in hydraulic power source and refill as needed.
- D. Pressurize system again to reverse the motion of step B. Maintain pressure on system for at least 5 seconds after cylinder rods stop moving. Check that cylinders have fully extended or retracted.
- E. Check for hydraulic leaks using cardboard or wood. Tighten connections according to directions in Torque Chart.
- F. Repeat steps B, C, D, and E 3-4 times.
- G. Depressurize hydraulic system and connect cylinder rod clevises to their mating lugs.

IMPORTANT

Machine damage will occur if the cylinder is incorrectly installed.

Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.

Hydraulic System (continued)

Relieving Hydraulic Pressure

To relieve hydraulic pressure in the system, be sure hydraulic motor is disengaged and/or hydraulic cylinder is not exerting force on the system. Next, consult tractor operators manual for procedure to relieve pressure.

Bleeding Procedure For EOH System

A WARNING

- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

Open and close the flow door. Unfold and fold the vertical auger. Operate the spout tilt, spout rotate, and auger tilt. Perform these functions several times.

Bleeding Procedure For Braking System


A WARNING

- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

<u>NOTE</u>: System is intended for tractors with hydraulic trailer brakes. If your tractor does not have hydraulic trailer brakes, contact your dealer for support.

NOTE: This procedure is a **two-person** process. One person operates the brake pedal while the second person loosens the bleeder screw on the brake caliper.

- 1. If using a tractor, set the tractor parking brake, but leave tractor engine on throughout the procedure. Brakes can be attached to either the front or rear set of wheels. Attach hydraulic brake coupler on the cart to the implement brake port at the rear of the tractor.
- 2. Apply and hold pressure to brake pedal.
- 3. Attach 1/4" hose to fitting. Put hose in an approved container. Loosen the bleeder screw, at the top of the brake caliper, on caliper of the closest wheel located in the hydraulic circuit. If necessary, pump the brake pedal to extract all air from the system. Once air bubbles are no longer present, tighten the bleeder screw. (Fig. 4-1)
- 4. Repeat steps 2 and 3 to the next brake caliper in the brake circuit. Repeat until all brakes are bled.
- 5. Do a final tightness check of all caliper bleed screws before beginning cart operation. Check that brakes actuate and release properly with tractor brake pedal.



Steering Tandem Maintenance

Periodically check tire alignment and linkages for damage. Remove trash and/or dirt that may have accumulated and possibly interfere with steering performance.

Alignment of tires can be changed by adjustment of linkage(s). See "Steering Tandem Linkage Adjustment Procedures" in this section.

Steering Tandem Troubleshooting

NOTE: Always perform the below steps with an empty cart.


Tire Misalignment:

- 1. First, rephase the steering cylinders by using the "Steering Cylinder Rephasing" procedure in this section.
- Steer the left set of tires until all tire edges are inline and straight forward. Check
 the opposite side. If both tire edges are equally out of alignment, then the center
 linkage needs adjustment. See "Steering Tandem Linkage Adjustment Procedures" in
 this section.
- 3. If only one tire on the opposite side is not straight, then that tire linkage needs adjustment. See "Steering Tandem Linkage Adjustment Procedures" in this section.

Failure to Auto-Steer:

- 1. If the cylinders get out of phase with the linkages, the steering tandem will not autosteer. See "Steering Cylinder Rephasing" procedure in this section.
- 2. If grease zerks are present, heavily grease the 4 spindle retainer pivot pins and 2 steering pivot pins. For grease zerk locations, see "Lubrication" in this section. After long periods of inactivity, the pins can seize in the bushing. Once the pins are greased, manual steer the wheels in both directions using the "Steering Cylinder Rephasing" procedure. If wheel assemblies do not rotate freely, grease again and repeat cylinder rephasing procedure.
- 3. Make sure the steering axle control switch is in the OFF/Auto-Steer position. (Fig. 4-2)
- 4. Check for debris that may be obstructing tie-rod movement.

(Continued on next page)




Steering Tandem Maintenance (continued)

Steering Tandem Troubleshooting


NOTE: Always perform the below steps with an empty cart.

Failure to Manual-Steer:

- 1. Make sure the steering axle control switch is in the ON position. (Fig. 4-3)
- 2. Make sure the hydraulic hoses are attached properly.
- 3. Make sure hydraulic circuit is on.



4. Check harness connection on the steering valve located on the cross axle, make sure there is 12-Volts to the solenoid on the valve attached to the cross axle. (Fig. 4-4)



Steering Indicator Misalignment:

1. Straighten the wheels, if the steering indicator is not centered, follow "Steering Indicator Adjustment Procedure" in this section.

Steering Tandem Maintenance (continued)

Steering Cylinder Rephasing

A WARNING

- UNEXPECTED IMPLEMENT MOVEMENT CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT SERVICE OR MAKE ADJUSTMENTS TO IMPLEMENT WHILE THE TOWING VEHICLE IS RUNNING.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.




NOTE: It is recommended to rephase the cylinders at the start of each day, with an empty cart. Doing this operation helps keep alignment.


NOTE: Do not block tires since they are being manually steered.

- Park the empty unit on a firm, level surface. Set the towing vehicle's parking brake. Tractor hydraulics are required for some steps, shut off engine and remove ignition key when hydraulic functions are complete.
- 2. Turn the steering axle control switch to the "ON/Manual-Steer" position, and ensure the hydraulic lever is in float. (Fig. 4-5)
- Manually steer the tires with the tractor hydraulics completely in one direction and hold hydraulic lever for a 5 seconds.
- Turn the tires completely in the opposite direction and hold the hydraulic lever for a 5 seconds.
- 5. Repeat the process in steps 3 & 4 if the cylinders are not fully extending.

NOTE: Fully extended cylinder should measure 28.25" center-of-pin to center-of-pin.

- 6. If a cylinder does not fully extend after repeating steps 3 & 4, remove a cotter pin and pin from the rod end of the steering cylinder. (Fig. 4-6)
- 7. Position the rod end so it will not contact anything as it extends and retracts.
- 8. Rephase the cylinder as described in steps 3 & 4.
- 9. Reattach the rod end of the cylinder to the steering turntable once the cylinders are rephased. (Fig. 4-6)





Steering Tandem Linkage Adjustment Procedures

A WARNING

- UNEXPECTED IMPLEMENT MOVEMENT CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT SERVICE OR MAKE ADJUSTMENTS TO IMPLEMENT WHILE THE TOWING VEHICLE IS RUNNING.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.



 FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 16,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.


NOTE: Before adjusting linkages, perform "Steering Cylinder Rephasing" procedure in the MAINTE-NANCE section.

NOTE: Do not block tires since they are being manually steered.

Outer Linkage

1. Park the empty unit on a firm, level surface. Set the towing vehicle's parking brake. Tractor hydraulics are required for some steps, shut off engine and remove ignition key when hydraulic functions are complete. Turn the Steering Tandem switch to the "ON" position, and ensure the hydraulic lever is in float.

- 2. Remove weight from the tires by using a safe lifting device rated for a minimum of 16,000 lbs.
- 3. Adjust the cylinder on the RIGHT-HAND side of the cart until the center-of-pin to center-of-pin measurement on the cylinder attaching pins is 24.25". This measurement is the center point of the cylinder stroke. (Fig. 4-7)






Steering Tandem Linkage Adjustment Procedures (continued)


Outer Linkage

4. Inspect the turntable plate on top of the tandem arm. With the cylinder pin-to-pin measurement at 24.25", the furthest front and furthest rear edges of the plate should be perpendicular to the tandem arm. If it is not, check the fit of the cylinder base end and rod end pins with both the cylinder and mating bushings for wear or deformation. Replace worn or damaged parts, if necessary. (Fig. 4-8)



5. Inspect the bushing underneath the tandem arm. With the cylinder pin-to-pin measurement at 24.25", the head of the pin going through the knuckle joint and the head of the bolt going into the splined pivot pin and bushing should be within 3/8" of a straight line with the tandem arm. (Fig. 4-9)

NOTE: If the linkage pin is more than 1" out of alignment, remove the splined bushing and rotate to align the linkage pin.




NOTE: If the linkage pin is between 3/8" to 1" out of alignment, there may be an issue with the spline position on either the pivot weldment (283651B - left-hand / 283652B - right-hand) or bushing weldment (283648) and may require the replacement of one or more of these parts.


Steering Tandem Linkage Adjustment Procedures (continued)

Outer Linkage

- 6. With the cylinder pin-to-pin measurement at 24.25", ensure the wheels on the right-hand side are straight. If they are not, adjust the outer linkages until the wheels are straight. (Fig. 4-10 & 4-11)
- 7. If the tires are removed, use the hub face to align as shown in Fig. 4-10.




 If the tires are assembled, check alignment across the outside center of the tires. Due to variation in rubber tire profile, adjust the alignment until the front and rear of both tires are within 1/2" of being inline. (Fig. 4-11)



Steering Tandem Linkage Adjustment Procedures (continued)

Outer Linkage


- For outer linkage adjustment, remove the set screws on the turntable for the link being adjusted, and remove the 1 1/4"-7UNC x 3 1/2" capscrews assembled through the tie rod end. Keep hardware for reassembly. (Fig. 4-12)
- 10. Loosen jam nuts at the tie rod end. (Fig. 4-12)
- 11. Adjust tie rod in 1/2 turn increments while checking wheel alignment between adjustments. (Fig. 4-12)
- 12. Once the wheels are aligned, tighten jam nuts on tie rod ends. (Fig. 4-12)
- 13. Reassemble the 1 1/4"-7UNC x 3 1/2" capscrews and set screws.
- 14. Repeat steps 3 through 13 on the left-hand side, if necessary. Otherwise, continue to center linkage adjustment.




Steering Tandem Linkage Adjustment Procedures (continued)

Center Linkage

- 1. Reset the right-hand cylinder pin-to-pin to 24.25" and check alignment of the wheels on the left-hand side of the cart.
- 2. If the center of both wheels is too far IN, the center linkage needs to be EXTENDED. (Fig. 4-13)



3. If the center of both wheels is too far OUT, the center linkage needs to be SHORTENED. (Fig. 4-14)




Steering Tandem Linkage Adjustment Procedures (continued)

Center Linkage

NOTE: One end of the center linkage has a left-hand thread jam nut. Identify the left-hand thread prior to adjusting to prevent over tightening the jam nut.


- 4. For center linkage adjustment, loosen the jam nut on both ends. (Fig. 4-15)
- 5. Loosen the tapered bushing on each end by tapping it outward. (Fig. 4-15)
- 6. When the tapered bushings have been loosened, the center linkage can be rotated to shorten or extend.
- 7. Adjust the center linkage until the wheels are inline.
- 8. Once the wheels are aligned, retighten the jam nuts on both ends.



Steering Indicator Adjustment Procedures

Use this procedure:

- * To center indicator when tires are straight forward.
- 1. Straighten the wheels, and loosen the hex nuts (91263) on the u-bolt (9004865) attached to the center tie-rod. (FIG. 4-16)
- 2. Adjust the u-bolt (9004865) to center the red indicator (283749R) on the front of the cart, and retighten the hex nuts (91263).



| ITEM | PART NO. | DESCRIPTION |
|------|----------|-----------------------------|
| 1 | 283742 | Saddle Clamp |
| 2 | 283749R | Indicator Weldment =Red= |
| 3 | 283744 | Plate |
| 4 | 9004865 | U-Bolt 3/8-16 x 3 5/8 |
| 5 | 9004866 | Push / Pull Cable (Includes |
| | | 9005109) |
| 6 | 9005109 | Rod End |
| 7 | 91263 | Flange Nut 3/8-16 |
| 8 | 9390-053 | Capscrew, 3/8-16 UNC x 3/4 |
| 9 | 9404-021 | Lock Washer 3/8 |
| 10 | 9405-076 | Flat Washer 3/8 |

Seasonal Storage

Always open flow door, horizontal and vertical auger cleanout doors to remove any remaining grain and to allow moisture to dry.

Wash machine inside and out before storing to remove dirt and debris that can draw and collect moisture. When using pressure washers maintain an adequate distance so not to force water into bearings.

Reattach PTO brackets (291974G or 291974R) to the inside right hand side of the tongue and place PTO assembly on brackets

Lubricate machine at all points outlined.

Repaint all areas where paint has been removed to keep rust from developing. Rust will affect grain flow.

Coat exposed cylinder piston rods with rust preventative material if applicable.

Inspect machine for parts that may need to be replaced so they may be ordered in the off season.



If unit is equipped with a scale indicator, electric hydraulic controls or steering controls, store these indoors in a dry location.


Close the tarp to keep debris out of the hopper.

Auger Driveline Bearings

IMPORTANT

• Periodically check set screws in all bearings at either end of the driveline for tightness.





Gearbox with Sight Glass


When checking the oil level of the gearbox, the vertical auger should be tilted all the way down.

For adequate lubrication the oil should be visible in the sight glass. Fill with oil to the sight glass only. (Fig. 4-20)

Maximum gearbox life:

Check oil level every 2 weeks.

Replace oil every season with approximately 85 oz. 80W90 EP lubricant.



Driveline Removal


A WARNING

• MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

Gearbox shaft guard has access doors for installing and removing of driveline.

Clamping Cone Assembly

Use a hammer and punch and moderately hit the end of clamping cone, as shown. Back off the clamping cone 1/2 turn. Continue alternating punch and unscrewing clamping cone until clamping cone can be removed by hand. (FIG. 4-21)



Auger System

Vertical Auger


Annually check all bolts, nuts, and set screws. Perform lubrication as specified.

Before servicing the vertical auger, park the unit on a firm, level surface. Block the wheels/ tracks to keep the machine from moving. Raise vertical auger to discharge position and close horizontal auger flow door. Set the tractor parking brake, turn off tractor engine, remove ignition key, and disconnect PTO shaft and hydraulic lines from tractor.

NOTE: The lower auger position is indexed from the drive dog / tube flange hinge surface as shown. (Fig. 4-22)

<u>NOTE</u>: Hanger bearing contains zerk (9005240) with pressure relief to prevent over-greasing that could push bearing seals out. If grease comes out of the relief on the zerk, this is normal and the bearing has enough grease.

NOTE: The starting distance for the folding linkage pin center-to-center is 13 3/4".





Auger System (continued)

Vertical Auger Timing

1. For the lower vertical auger, use the finishing edge of the flighting as a 12 o'clock reference. Position the drive dog so the driving edge is at the 11 o'clock position. (FIG. 4-23)


NOTE: Looking down at the lower flighting (FIG. 4-23) the auger rotation will be counterclockwise. When looking up at the upper flighting (FIG. 4-24) the auger rotation will be clockwise.





- 2. For the upper auger, use the starting edge of the flighting as a 12 o'clock reference. Postion the driven edge of the drive pin at the 4 o'clock position. (FIG. 4-24)
- 3. When engaged, the upper flighting should follow the lower flighting. (FIG. 4-25)

NOTE: Upper flighting should trail the lower flighting from minimum of 10 degrees to a maximum of 90 degrees.



Auger System (continued)


Horizontal Auger

Annually check all bolts, nuts, and set screws. Perform lubrication as specified.

NOTE: With new flighting, the outside diameter is about 3/4" from the bottom belly pan. Always set bearing height using the flighting centerline measurement. See FIG. 4-26.

NOTE: Shims are available from your Brent dealer to achieve 10 1/8" measurement.

To adjust the bearing height down, shim with washers between the bearing and the hanger bracket. To adjust the bearing height up, shim with washers between the bearing bracket and the sides of the cart. When adjusting the height up, washers will need to be placed with one on each side so the bearing stays centered.



Baffle Adjustment

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE THE CART, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE CART.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL IN-JURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.

Refer to the following reasons for baffle adjustment:

NOTE: To unload the cart evenly from front to back the openings should increase in height from back to front.

- 1. If higher flow is desired and torque is not the limiting factor, raise each baffle to an incremental amount and rerun.
- 2. If more material remains at the back of the cart towards the end of the unloading cycle, the back baffles should be adjusted upward in incremental amounts and rerun.
- 3. If more material remains at the front of the cart towards the end of the unloading cycle, the back baffles should be adjusted downward in incremental amounts and rerun.
- 4. If the cart requires more torque than what is available at times during the unloading cycle, then all baffles should be adjusted downward in incremental amounts.

Baffle Adjustment (continued)


The horizontal auger baffles are factory-set at the lowest position. This position results in the lowest power requirements and longest flighting life. Once grain has been run through the unit, adjustments can be made to achieve the ideal unloading performance.

Before making any baffle adjustments, close horizontal auger flow door. Securely block the grain cart, set the tractor parking brake, turn off tractor engine and remove ignition key.

If a higher flow is desired and torque is not a factor, loosen the (2) flange nuts on each baffle, see figure 4-9. Use the lift handle to raise each baffle to the desired position, retighten both flange nuts, see figures 4-27 & 4-28.

NOTE: DO NOT REMOVE ANY SCREEN PAN-ELS. The flange nuts are best accessed using an extended socket wrench and 9/16" socket through the screen panel openings.

NOTE: Screen removed in figure 4-28 for illustration only.







5-Pin Driver Replacement

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING IN-SIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL IN-JURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 1,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

NOTE: Open the flow gates all the way.

 Park the unit on a firm, level surface. Block the wheels to keep the machine from moving. Set the vehicle parking brake, shut off the engine and remove the ignition key and disconnect the PTO shaft or hydraulic drivelines from the tractor.




2. Remove the bolts in both middle grates inside the cart. Remove the grates. (Figure 4-29)

NOTE: Retain all hardware for reassembly.


- 3. Disconnect grease line. (Figure 4-30)
- 4. Remove the hanger bearing bolts on each side of the auger.
- 5. Remove capscrews and lock washers holding bearing onto the hanger bearing plate.






5-Pin Driver Replacement (continued)


Remove the hanger bearing bracket to allow access to work on the bearing and shaft. Remove two center tube connecting capscrews in the horizontal auger. (Figure 4-31)



- 7. Remove the SMV bracket located on the rear auger cover. (Figure 4-32)
- 8. Remove the capscrews from the auger cover. (Figure 4-32)



9. Pry the auger from the auger tube. (Figure 4-33)




10. Using a safe lifting device rated for a minimum 1,000 lbs., pull the rear auger out 3 feet using a strap. (Figure 4-34)



5-Pin Driver Replacement (continued)

- 11. Remove the original 5-pin driver, bearing and the bushing insert. (Figure 4-35 & Figure 4-36)
- 12. Discard 5-pin driver.






- 13. Substantially coat bushing insert with antiseize.
- 14. Slide bushing insert into front auger and ensure tube holes are aligned. (Figure 4-36 & Figure 4-37)




NOTE: Make sure the set screws on bearing are towards the front of the cart. (Figure 4-38)

- 15. Slide bearing onto 5-pin driver. (Figure 4-38)
- 16. Insert new 5-pin driver into front auger and ensure tube holes are aligned.
- Install front capscrews, spacer bushings and locknuts 180 degrees from each other and assemble spacer bushings on threaded side of capscrews. Hand tighten hardware. (Figure 4-38)




5-Pin Driver Replacement (continued)

- 18. Install hanger bracket. Leave the capscrews loose attaching hanger bracket to the cart. Attach hanger bracket to the bearing. (Figure 4-39)
- 19. Reattach grease line components. (Figure 4-39)




- NOTE: Rear auger flighting should lead the front auger flighting.
- 20. Slide the rear auger forward. Align the pins and holes with the rear auger pipe. (Figure 4-40)




21. Extend a string tightly from front to rear to check horizontal auger alignment. Measure the string to the auger tube either in front or behind the hanger bearing. If this dimension is 1/8" greater than the measurement taken in the front and rear, shims (8GA - 286419B or 12GA - 286424B) are required on top of the center hanger bearing. Ideally the center measurement should be equal to or 1/8" lower than the measurements on the ends of the augers. (Figure 4-41)

NOTE: The shims are 1/8" thick each. Add as needed. See "Auger System - Horizontal Auger" in MAINTENANCE section for more details.

- 22. Torque hanger bracket capscrews to 130 ft.lbs. See Figure 4-39.
- 23. Torque auger capscrews to 200 ft.-lbs. (Figure 4-42)





5-Pin Driver Replacement (continued)

- 24. Torque hardware for the rear auger cover and SMV bracket back onto the cart. (Figure 4-43)
- 25. Reinstall ALL the grates.



Belt Tightener Adjustment

IMPORTANT

- Do not use belt dressing.
- Keep grease and oil off of belt and pulleys.

NOTE: Pulleys do not need to be removed to remove/replace belt.


Due to prolonged use, belt wear may be evident causing slack. To correct this, follow these steps.

 Park the unit on a firm, level surface. Block the wheels to keep the machine from moving. Set the vehicle parking brake, shut off the engine and remove the ignition key from the towing vehicle.




A WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS DISCONNECT POW-ER SOURCE BEFORE SERVICING. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FAS-TENED BEFORE OPERATING UNIT.
- Remove PTO assembly from gearbox input shaft.
- 3. Detension the belt as outlined in OPERATION section. Remove belt tensioner handle.
- Remove cover and inspect belts for misalignment, loose parts and cracks. Replace if necessary with a matched set. See Fig. 4-46.








Belt Tightener Adjustment (continued)

- Belt tension is adjusted with hex nuts below the spring. All belt tension MUST be released from linkage. Loosen outer hex nut and adjust inner nut to establish a 3 1/16" pre-load dimension between the heavy washers. Tighten the outer hex nut against inner nut to lock position. (Fig. 4-47)
- 6. Check the lower belt pulley to ensure belt is aligned in their grooves and with the belt tensioner handle, engage the roller/idler linkage against the belt and over-center stop. The compressed spring should now be approximately 1 3/4" between the washers and generating a force of approximately 480 lbs. against the belt. (Fig. 4-48)
- 7. Release and tighten belt multiple times to confirm positions and final adjustments. See Fig. 4-48 and Fig. 4-49.
- Tighten belt to retain them into the lower pulley for cover guard assembly. Reinstall the cover guard and the PTO shaft to the gearbox input shaft. Clear work area and test run drivetrain for 3 minutes at no greater than 1000 RPM.

A WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- 9. Disengage PTO and turn off tractor. Through the cover access door, check the compressed spring length is approximately 1 3/4" between the washers and check each belt for uniform tension. If more adjustment is needed, refer to Steps 5 through 7. If no additional spring adjustment is available, then both belts must be replaced with a new matched set.

NOTE: Always replace belts in matched sets.







V-Belt Alignment

- 1. Pulleys must be aligned with the fixed idler. Belts should be centered on idler for longest belt life. (Fig. 4-50)
- 2. After tightening taper-lock bushing hardware, lay a straight edge across face of the drive and driven belt pulleys to ensure alignment between the grooves on the pulleys.

Split Tapered Bushings

Check annually for tight engagement to driveshaft. Torque three bolts progressively to values shown:

- 1 3/4" Bore (Gearbox) 30 ft-lbs.
- 2 1/4" Bore (Horizontal Auger) 75 ft.-lbs.

Some gap must remain between flange & hub when bushing is properly tightened.

To remove from shaft, remove capscrews and insert them in tapped holes in bushing flange. Tighten progressively until bushing disengages.



Verify Telescoping PTO Shaft Length

PROPER EXTENDED AND COLLAPSED LENGTHS OF THE TELESCOPING PTO SHAFT MUST BE VERIFIED BEFORE FIRST OPERATION. IF THE EXTENDED LENGTH OF THE PTO SHAFT IS NOT SUFFICIENT, IT MAY BECOME UNCOUPLED IN OPERATION AND CAUSE SERIOUS INJURY OR DEATH FROM CONTACT WITH UNCONTROLLED FLAIL-ING OF PTO SHAFT ASSEMBLY COMPONENTS.

IMPORTANT

Check the length of the telescoping members to insure the driveline will not bottom out or separate when turning and/or going over rough terrain.

Consult your OEM dealer for recommended drawbar and PTO set up.

An excessive collapsed length can result in damage to the PTO driveline and attached components. This is most likely to occur during extreme turning angles and/or travel over rough terrain. Conditions are amplified on tractors with tracks operating in uneven terrain, particularly rice levies. Damaged driveline components can result in unsafe operation and severely reduced driveline component life.

Check the length of the telescoping members to ensure the driveline will not bottom out or separate when turning and/or going over rough terrain.

NOTE: Do not exceed 10 degrees beyond a straight pull line while operating the PTO. To verify proper extended and collapsed lengths, use the following procedure:


| 1. | Fully collapse | PTO | shaft | and | measure | length |
|----|------------------|-----|-------|-----|---------|--------|
| | "L" (Fig. 4-51). | | | | | |

Enter here:____(1)

(Verify that outer tube does not bottom out on surrounding plastic shield components).


2. Pull apart PTO telescoping shaft ends and measure lengths "T" & "C" (Fig. 4-52)


Add "T" + "C" measurements together Enter total here:____(2)



- a. Subtract line 1 from line 2
 - Enter here:____(a)
- b. Divide line (a) by 2 Enter here:___
- c. Add line (b) to line 1. Enter here:____(c)
- d. Subtract 3 inches from line (c)

Enter here:____(d)







This is the maximum recommended extended length.

Verify Telescoping PTO Shaft Length (continued)

- 4. Hitch tractor drawbar to cart, ensuring that tractor and cart are on level ground and coupled as straight as practical.
- 5. Connect PTO shaft to tractor, and measure length "L" from same points as used in step 1. Ensure that this measurement does not exceed the maximum recommended extended length calculated in step 3 above. If necessary, choose a shorter drawbar position, or obtain a longer PTO shaft assembly before operating cart.
- 6. Position the tractor to obtain the tightest turning angle, relative to the cart (Fig. 4-53).
- 7. Measure the length "L" from the same points as used in step 1. This distance must be at least 1.5 inches greater than the distance measured in step 1. If necessary, adjust the length of the PTO shaft by cutting the inner and outer plastic guard tubes and inner and outer sliding profiles by the same length. Round off all sharp edges and remove burrs before greasing and reassembling shaft halves.







PTO Shaft and Clutch


Length Adjustment (Figs. F1 - F4)

NOTE: Maximum operating length, see step 3d on page 4-33.

- 1. To adjust length, hold the half-shafts next to each other in the shortest working position and mark them.
- 2. Shorten inner and outer guard tubes equally.
- 3. Shorten inner and outer sliding profiles by the same length as the guard tubes.
- 4. Round off all sharp edges and remove burrs. Grease sliding profiles.











A WARNING


• CHECK THE LENGTH OF THE TELESCOPING MEMBERS TO INSURE THE DRIVELINE WILL NOT BOTTOM OUT OR SEPARATE WHEN TURNING AND/OR GOING OVER ROUGH TERRAIN.


To Dismantle Guard (Figs. J1 - J4)

- 1. Remove locking screw.
- 2. Align bearing tabs with cone pockets.
- 3. Remove half-guard.
- 4. Remove bearing ring.












PTO Shaft and Clutch (continued)


To Assemble Guard (Figs. K1 - K5)


- 1. Grease yoke groove and inner profile tube.
- 2. Fit bearing ring in groove with recesses facing profile tube.
- 3. Slip on half-guard.
- 4. Turn cone until it engages correctly.
- 5. Install locking screw.














To Assemble Cone (Figs. L1 - L3)

- Dismantle guard (Figs. J1 J3). Remove old cone (e.g. cut open with knife). Take off chain. Place neck of new cone in hot water (approx. 80° C / 180° F) and pull onto bearing housing (Fig. L1).
- 2. Turn guard cone into assembly position (Fig. L2). Further assembly instructions for guard (Figs. K1 K5).
- 3. Reconnect chain if required (Fig. L3).









PTO Quick Disconnect


Coupling

Slide clamp yoke or cut-out clutch onto connecting shaft. Make sure the location hole for the clamping cone is positioned above the annular groove of the connecting shaft. Screw appropriate clamping cone into the location hole. Slightly moving the clamp yoke or clutch to and from in the axial direction will help drive in the clamping cone. Check the clamp yoke or clutch for a tight and safe fit and continue to check at regular intervals. Retighten the clamping cone as necessary. Torque clamping cone to 75 ft.-lbs.

When over loading occurs, the clutch disengages and will repeatedly attempt to reset. The clutch will create a repeated "clicking" noise when resetting. Torque demand must decrease for clutch to reset.








Uncoupling

First dislodge the clamping cone with a punch and hammer from its current position. Unscrew the clamping cone a partial turn. Use the punch and hammer again to help alleviate the torque resistance on the wrench, if necessary. After a few cycles, the clamping cone will move freely with low torque resistance for the removal process.



Tarp Troubleshooting Inspection & Maintenance

| PROBLEM | SOLUTION |
|---------------------------|---|
| TARP SAGS IN MIDDLE AREAS | 1. BOWS MAY BE BENT OR ADJUSTED TOO LOW |
| | 2. MISSING OR LOOSE RIDGE STRAP REPLACE OR RETIGHTEN |
| | 3. TENSION MAY BE TOO LOOSE. U-JOINT MAY NEED TO BE ADJUSTED ON SPLINED SHAFT TO PROVIDE MORE TENSION |
| HOLES OR TEARS IN TARP | 1. CONSULT YOUR LOCAL DEALER FOR REPAIRS |
| | 2. ORDER TARP REPAIR KIT FROM DEALER |
| | 3. WHEN NEW TARP OR PARTS ARE NEEDED ALWAYS REPLACE WITH ORIGINAL PARTS |

Inspection and Maintenance

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.

IMPORTANT

- Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.
- Tarp should not be used if it is torn or the bungee cords are frayed or show damage. If water pools on the tarp adjust tension of tarp cables and/or arm springs as required.

Periodic preventive maintenance should be practiced. Inspect tarp and hardware often for abrasions or loosened bolts that may need adjustment and/or repair. Check bungee cords for wear and adjust tension at the beginning of the season and again half way through the season.

Tears in tarp should be addressed before further tarp operation. If water pools on tarp, adjust tension of tarp cables and/or arm springs.

If installed correctly, tarp should always operate as well as when first installed. If tarp does not pass this simple inspection, make all appropriate repairs or adjustments immediately before serious damage occurs.

Electrical System Schematic

GRAIN CART WIRES


White -- Ground

Green -- Right amber flashing lamp Yellow -- Left amber flashing lamp


Brown -- Tail light

Black -- Interior & Auger Lights

Red -- Brake Lights Blue -- NOT USED





ELECTRIC TARP




NOTE: See separate electric tarp manual for additional information.

- SELECT A DESIRED MOUNTING LOCATION AS CLOSE TO THE BATTERY AS POSSIBLE.
 USING THE RELAY AS A TEMPLATE, MARK THE CENTERS OF THE MOUNTING HOLES.
- USING A 1/4" DRILL BIT, DRILL THE HOLES MARKED IN THE PREVIOUS STEP. MOUNT THE RELAY USING THE PROVIDED BOLTS AND NUTS.
- WIRE THE RELAY ACCORDING TO THE WIRING DIAGRAM.
 APPLY DIELECTRIC GREASE TO ALL ELECTRICAL CONNECTIONS.






Optional Electric Over Hydraulic Valve Electric Schematic 5 Spool



| PORT | END OF CYLINDER | FUNCTION | |
|------|-----------------|------------------|--|
| Α | BUTT END | FLOW DOOR | |
| В | RAM END | FLOW DOOR | |
| С | RAM END | AUGER FOLD | |
| D | BUTT END | AUGER FOLD | |
| E | RAM END | SPOUT TILT | |
| F | BUTT END | SPOUT TILT | |
| G | RAM END | SPOUT ROTATE | |
| Н | BUTT END | SPOUT ROTATE | |
| I | BUTT END | AUGER TILT | |
| J | RAM END | AUGER TILT | |
| Р | | TRACTOR PRESSURE | |
| Т | | TRACTOR RETURN | |



Wheels and Tires

Wheel Nut Torque Requirements



 IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagram 1.

NOTE: Do not use anti-seize on wheel hardware.

| WHEEL HARDWARE | | | |
|------------------|------------|--|--|
| SIZE FOOT-POUNDS | | | |
| 3/4-16 (UNF) | 365 ftlbs. | | |
| M22x1.5 | 475 ftlbs. | | |




DIAGRAM 1

Wheels and Tires (continued)

Tire Pressure

The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. It is important that tires are inspected after unit is loaded. Start with minimum pressure. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. Do not exceed maximum recommended tire pressure. Each tire must be inflated to 35 PSI max to seat the beads, deflated to 5-10 PSI, then reinflated to the tire's max PSI when mounting.

Tire Pressure for Grain Carts

| | | Load Index / Ply | |
|-----------|---------------------------|------------------|----------|
| Tire Make | Tire Size | Rating | Max. PSI |
| Firestone | 23.1x26 R-3 | 12 | 32 |
| | 23.1x26 R-1 | 12 | 32 |
| | 28Lx26 R-3 | 12 | 26 |
| | 24.5x32 R-3 | 12 | 32 |
| | 24.5x32 R-1 | 12 | 32 |
| | 30.5x32 R-1 | 14 | 28 |
| | 30.5x32 R-3 | 14 | 28 |
| | 30.5x32 R-3 | 16 | 34 |
| | 30.5x32 R-1 | 16 | 26 |
| | 35.5x32 R-3 | 20 | 36 |
| | 76x50.00x32 HF-3 | 16 | 40 |
| | 76x50.00x32 HF-3 | 20 | 50 |
| | 800/65R32 R-1W | 172A8 | 44 |
| | 800/60R32 R-3 | 181B | 46 |
| | 900/65R32 R-3 | 191B | 46 |
| | 900/60R32 R-1 | 176A8 | 44 |
| | 1250/50R32F IF/CFO R-1WNP | 201D | 46 |
| | 1250/50R32F IF/CFO R-1W | 188B | 30 |
| | 520/85R38 R-1 | 155A8 | 29 |
| | 520/85R38 R-1 | 173A8 | 64 |
| | 480/80R42 R-1 | 151A8 | 36 |
| | 520/85R42 R-1 | 157A8 | 29 |
| | 520/85R42 R-1 | 165A8 | 51 |
| | 520/85R42 IF/CFO R-1 | 169A8/B | 35 |
| | 520/85R42 R-1W | 169B | 35 |
| | 420/80R46 R-1 | 151A8 | 44 |
| | 480/80R46 R-1 | 158A8 | 44 |
| | 380/90R46 R-1 | 152B | 51 |

Wheels and Tires (continued)

Tire Pressure (continued)

| Tire Make | Tire Size | Load Index / Ply Rating | Max. PSI |
|----------------|------------------|----------------------------|----------|
| Titan/Goodyear | 23.1x26 R-3 | 10 | 26 |
| | 23.1x26 R-1 | 10 | 26 |
| | 24.5R32 R-1 | 169A8/B (5-Star) | 48 |
| | 24.5x32 R-3 | 12 | 32 |
| | 24.5x32 R-1 | 12 | 32 |
| | 30.5x32 R-3 | 16 | 26 |
| | 30.5x32 R-3 | 14 | 22 |
| | 30.5x32 R-1 | 14 | 22 |
| | 480/80x42 R-1 | 166A8 | 23 |
| | 1100/45R46 F-1W | 195D | 35 |
| Mitas | 650/75R32 R-1W | 172A8 | 58 |
| | 900/60x32 R-1W | 176A8 | 41 |
| | 900/70R32 R-1W | 188A8 | 53 |
| | 1050/50x32 R-1W | 178A8 | 41 |
| | 1250/50R32 R-1W | 188A8 | 41 |
| | 900/60x38 R-1W | 181A8 | 44 |
| | 520/85x42 R-1W | 162A8 | 44 |
| | 650/65x42 R-1W | 168A8 | 44 |
| Alliance | 35.5LR32 | 193A8 | 44 |
| | 900/60R32 R-1W | 192D | 46 |
| | 1050/50R32 R-1W | 185A8 | 63 |
| | 1250/50R32 R-1W | 201B | 46 |
| Trelleborg | VF1050/50R32 R-1 | 198D | 52 |
| | 900/50R32 R-1W | 181A8 | 55 |
| | 900/60x32 | 176LI | 44 |
| | 850/55R42 R-1W | 161A8 | 32 |

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Following are phone numbers and Websites for your convenience:

Firestone www.firestoneag.com

Phone 800-847-3364

Titan www.titan-intl.com Phone 800-USA-BEAR or Goodyear

Fax 515-265-9301

Trelleborg www.trelleborg.com

Phone 866-633-8473

www.mitas-tires.com Continental/Mitas

> Phone 704-542-3422 Fax 704-542-3474

Alliance www.atgtire.com

Phone 781-325-3801

Complete Torque Chart

Capscrews - Grade 5

NOTE:

- Grade 5 capscrews can be identified by three radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

| SIZE | FOOT Pounds | NEWTON Meters |
|----------|----------------|------------------|
| 1/4-20 | 8-10 | 11-13 |
| 1/4-28 | 9-11 | 12-15 |
| 5/16-18 | 15-17 | 20-23 |
| 5/16-24 | 17-19 | 23-26 |
| 3/8-16 | 25-28 | 34-38 |
| 3/8-24 | 28-31 | 38-42 |
| 7/16-14 | 40-45 | 54-61 |
| 7/16-20 | 45-50 | 61-68 |
| 1/2-13 | 62-68 | 84-92 |
| 1/2-20 | 68-75 | 92-102 |
| 9/16-12 | 90-98 | 122-133 |
| 9/16-18 | 100-110 | 134-148 |
| 5/8-11 | 120-135 | 162-183 |
| 5/8-18 | 124-137 | 168-186 |
| 3/4-10 | 200-220 | 270-300 |
| 3/4-16 | 210-230 | 285-310 |
| 7/8-9 | 330-350 | 425-475 |
| 7/8-14 | 360-380 | 460-515 |
| 1-8 | 500-525 | 675-710 |
| 1-14 | 540-560 | 730-760 |
| 1 1/8-7 | 600-635 | 815-860 |
| 1 1/8-12 | 665-700 | 920-950 |
| 1 1/4-7 | 850-895 | 1150-1215 |
| 1 1/4-12 | 940-990 | 1275-1340 |
| 1 3/8-6 | 1125-1175 | 1525-1590 |
| 1 3/8-12 | 1280-1335 | 1735-1810 |
| 1 1/2-6 | 1500-1560 | 2035-2115 |
| 1 1/2-12 | 1685-1755 | 2285-2380 |

IMPORTANT

• Follow these torque recommendations except when specified in text.

Complete Torque Chart

Capscrews - Grade 8

NOTE:

- Grade 8 capscrews can be identified by six radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.





| SIZE | FOOT POUNDS | NEWTON METERS |
|----------|----------------|------------------|
| 5/16-18 | 20-22 | 27-30 |
| 5/16-24 | 21-23 | 28-31 |
| 3/8-16 | 35-39 | 47-53 |
| 3/8-24 | 36-41 | 49-55 |
| 7/16-14 | 54-58 | 73-78 |
| 7/16-20 | 55-60 | 75-80 |
| 1/2-13 | 82-88 | 110-120 |
| 1/2-20 | 94-99 | 125-135 |
| 9/16-12 | 127-134 | 170-180 |
| 9/16-18 | 147-155 | 199-210 |
| 5/8-11 | 160-170 | 215-230 |
| 5/8-18 | 165-175 | 225-235 |
| 3/4-10 | 280-295 | 380-400 |
| 3/4-16 | 330-365 | 445-495 |
| 7/8-9 | 410-430 | 555-580 |
| 7/8-14 | 420-440 | 570-595 |
| 1-8 | 630-650 | 850-880 |
| 1-14 | 680-700 | 920-950 |
| 1 1/8-7 | 900-930 | 1220-1260 |
| 1 1/8-12 | 930-950 | 1260-1290 |
| 1 1/4-7 | 1250-1300 | 1695-1760 |
| 1 1/4-12 | 1280-1320 | 1735-1790 |


IMPORTANT

• Follow these torque recommendations except when specified in text.

Hydraulic Fittings - Torque and Installation


SAE Flare Connection (J. I. C.)

- 1. Tighten nut with finger until it bottoms the seat.
- 2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



SAE Straight Thread O-Ring Seal

- 1. Insure jam nut and washer are backed up to the back side of smooth portion of elbow adapter.
- 2. Lubricate o-ring
- 3. Thread into port until washer bottoms onto spot face.
- 4. Position elbows by backing up adapter.
- 5. Tighten jam nut.




Section V Parts

| Please visit www.unverferth.com/parts/ for the most current par | ts listing. |
|---|-------------|
| Decals | |
| Ladder Components | |
| Touch-Up Paint | |
| Hitch, Jack, & Toolbox Components | |
| Axle & Hopper Components | |
| Steering Tandem Assembly Components | |
| Steering Tandem Indicator Components | |
| Steering Tandem Hub Components | 5-14 |
| Steering Tandem Wheels & Tires | 5-15 |
| Brake Components | 5-16 |
| Track Axle Components | 5-18 |
| Track Panel Kit Components | |
| Sideboards | |
| Horizontal Auger Components | 5-22 |
| Vertical Auger Flighting Components | 5-24 |
| Lower Auger Door & Cover Components | 5-26 |
| Lower Auger Linkage Components | 5-28 |
| Idler Assembly Components | 5-30 |
| Auger Tube Components | 5-32 |
| Auger Grease Bank | 5-36 |
| EOH Valve Functions and Wire Locations (Optional) | |
| EOH Valve Assembly Components (Optional) | |
| EOH Tractor Circuit Hydraulic Components (Optional) | 5-40 |
| Spout Rotate and Tilt Hydraulic Components | |
| Auger Tilt Hydraulic Components | 5-44 |
| Auger Fold Hydraulic Components | 5-45 |
| Steering Tandem Valve Hydraulic Components | |
| Flow Door Circuit Hydraulic Components | |
| Cylinders | |
| Hopper Flow Door Components | |
| Optional Spout Rotate Switch Assembly Components | |
| Downspout Components | |
| Rotating Spout Components | |
| Cut Out Clutch PTO Assembly | |
| Cut Out Clutch Components | |
| Gearbox Components | |
| Indicator Assembly | |
| Hopper Rear Electrical Components | |
| Electrical Components | |
| Weather Guard Tarp | |
| Hydraulic Jack - Kit #294142B (Optional) | |
| Video System (Optional) | |
| FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL | |
| FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL | |
| FOR UHARVEST INFORMATION, PLEASE REFER TO YOUR UHARVEST MAN | |
| FOR ELECTRIC TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC TARP FOR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO YOUR WATER | |

SYSTEM MANUAL.


Decals



Decals (continued)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|--------------|---|-----|----------------------|
| 1 | 9003127 | Reflector 2x9 =AMBER= | 9 | |
| 2 | 9003474 | Decal, DANGER (Electrical Lines) | 1 | |
| 3 | 9003475 | Decal, WARNING (Cut & Crush) | 4 | |
| 4 | 9003476 | Decal, WARNING (No Riders) | 2 | |
| 5 | 9003477 | Decal, IMPORTANT (Operation) | 1 | |
| 6 | 9004271 | Decal, Avalanche | 1 | |
| 7 | 9004966 | Decal, IMPORTANT (Cart Loading) | 1 | |
| 8 | 9006588 | Decal, Brent Logo | 4 | |
| 9 | 9006589 | Decal, Stripe | 15 | |
| 10 | 9006592 | Decal, 1596 | 4 | |
| 11 | 9008626 | Decal, Flow Control Indicator | 1 | |
| 12 | 9008151 | Decal, IMPORTANT (PTO Engagement) | 1 | |
| 13 | 9008594 | Decal, Hose Legend | 1 | |
| 4.4 | 9008714 | Decal, Rear SIS 20 MPH | 1 | |
| 14 | 9008720 | Decal, Rear SIS 30 KPH | 1 | |
| 45 | 9008715 | Decal, Front SIS 20 MPH | 1 | |
| 15 | 9008721 | Decal, Front SIS 30 KPH | 1 | |
| 16 | 9008947 | Decal, Grease | 4 | |
| 17 | 94094 | Decal, WARNING (Tongue Rise) | 2 | |
| 18 | 95046 | Decal, DANGER (Entanglement) | 2 | |
| 19 | 95445 | Decal, DANGER (Do Not Use Hands) | 1 | |
| 20 | 95839 | Decal, WARNING (Pinch Point) | 5 | |
| 21 | 97575 | Decal, CAUTION (Transport Chain) | 1 | |
| 22 | 97961 | Decal, WARNING (Read Manual) | 1 | |
| 23 | TA1-906109-0 | Decal, WARNING (Moving Parts Crush/Cut) | 1 | |
| 24 | 91605 | Decal, FEMA | 1 | |
| 25 | 95008 | Decal, CAUTION (Slippery Surface) | 1 | |
| 26 | 98229 | Decal, WARNING (Falling Equipment) | 1 | |
| 27 | 9003478 | Decal, DANGER Never Play | 1 | |
| 28 | 9005971 | Decal, WARNING (Suspension) | 1 | |
| 29 | TA510514 | SMV Emblem | 1 | |
| 30 | 9008925 | Decal, Grease Bank | 1 | |
| 31 | 93705 | Caulk, for Seams (Clear) | 1 | Not Shown |
| 32 | 94754 | Decal, UM Wheel Systems | 1 | |
| 33 | 9009168 | Decal, WARNING (Ladder Lock Pin) | 1 | |
| 34 | 9009447 | Decal, Steering Indicator | 1 | Steering Tandem Only |
| 35 | 900024 | Decal, WARNING (High Pressure) | 1 | |

Ladder Components




Ladder Components

Please visit www.unverferth.com/parts/ for the most current parts listing.


| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|-------|
| 1 | 2003029 | Nylon Bushing, .625" OD x .406" ID x .380" | 6 | |
| 2 | 289294B | Plate-Bracket, Ladder =Black= | 1 | |
| 3 | 2003030 | Nylon Bushing, .875" OD x .531" ID x .563" | 4 | |
| 4 | 9405-088 | Flat Washer, 1/2" USS | 6 | |
| 5 | 9390-107 | Capscrew, 1/2"-13UNC x 3" G5 | 4 | |
| 6 | 9003397 | Lock Nut/Top, 1/2"-13UNC | 4 | |
| 7 | TA620384 | Plastic Stop, 1" Dia. x .250" | 8 | |
| 8 | 9005305 | Lynch Pin 3/8" Dia. x 3" | 1 | |
| 9 | 99985 | Button Head Socket, 3/8"-16UNC x 1 1/4" | 2 | |
| 10 | 9008159 | Lock Nut/Top, 3/8"-16UNC | 6 | |
| 11 | 9003503 | Rivet 3/16 X 1/4 | 8 | |
| 12 | 289284B | Ladder Link Weldment =Black= | 1 | |
| 13 | 9390-057 | Capscrew, 3/8"-16UNC x 1 1/2" G5 | 4 | |
| 14 | 289328B | Ladder Extension Weldment =Black= | 1 | |
| 15 | 289326B | Ladder Weldment =Black= | 1 | |
| 16 | 289715B | Step Weldment =Black= | 1 | |
| 17 | 289707B | Ladder Extension Weldment =Black= | 1 | |
| 18 | 289840B | Ladder Bracket =Black= | 1 | |
| 19 | 289844B | Ladder Weldment =Black= | 1 | |
| 20 | 9388-029 | Carriage Bolt, 5/16"-18UNC x 2" G5 | 4 | |
| 21 | 9405-064 | Flat Washer, 5/16" ID (1/4" Nominal) USS | 9 | |
| 22 | 901527 | Lock Nut/Center, 5/16"-18UNC | 9 | |
| 23 | 9388-024 | Carriage Bolt, 5/16"-18UNC x 3/4" G5 | 4 | |
| 24 | 9388-102 | Carriage Bolt, 1/2"-13UNC x 1" G5 | 4 | |
| 25 | 91267 | Flange Nut 1/2-13 UNC G5 | 4 | |
| 26 | 9004998 | Rivet Burr, 3/16" | 4 | |
| 27 | 9390-027 | Capscrew, 5/16"-18UNC x 5/8" G5 | 1 | |
| 28 | 97879 | Nylon Lanyard | 1 | |

Touch-Up Paint



| PAINT | SPRAY |
|--------------|---------|
| Black | 97013 |
| Green | 97015 |
| Red | 97301 |
| Primer, Gray | 9500082 |
| Off White | 97016 |
| Silver Mist | 97012 |

Hitch, Jack, & Toolbox Components




| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-----------------------------------|-----|-------|
| 1 | 91267 | Flange Nut, 1/2-13UNC Grade 5 | 2 | |
| 2 | 271687B | Spring Retainer Plate =Black= | 2 | |
| 3 | 9390-053 | Capscrew, 3/8-16UNC x 3/4 Grade 5 | 3 | |
| 4 | 271800G | Tongue Weldment =Green= | 4 | 4 |
| 4 | 271800R | Tongue Weldment =Red= | | |
| 5 | 273237 | Nylon Pad | 2 | |

Hitch, Jack, & Toolbox Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|-----------------|
| 6 | 273368 | Pin, 2 Dia. x 7 3/4 | 2 | |
| 7 | 294128B | Hose Caddy Replacement Kit | 1 | |
| 7A | 294083B | Hose Caddy Weldment =Black= | 1 | |
| 7B | 294085B | Hose Caddy Cover =Black= | 1 | |
| 7C | 294086 | Hose Retainer | 1 | |
| 7D | 9000787 | Trim - Edge | 1/2 | Specify in Feet |
| 7E | 9003848 | Hose Wrap | 3 | Specify in Feet |
| 7F | 91256 | Large Flange Capscrew 5/16-18UNC x 3/4 Grade 5 | 6 | |
| 8 | 282875B | CAT 4 Hitch =Black= | 1 | |
| 8A | 282329B | CAT 5 Hitch =Black= | 1 | |
| 9 | 282876 | CAT 4 Hitch Pin, 1 Dia. x 5 1/2 | 1 | |
| 9A | 281691 | CAT 5 Hitch Pin, 1 Dia. x 7 3/8 | 1 | |
| 10 | 284780 | Hitch Bar | 1 | Non-Scale |
| 10A | 9004913 | Scale Hitch Bar 3 3/4" Dia. with 16 ft. Cable CAT 4 | 1 | |
| 10B | 9008135 | Scale Hitch Bar 3 3/4" Dia. with 16 ft. Cable CAT 5 | 1 | |
| | 291974G | PTO Bracket =Green= | | |
| 11 | 291974R | PTO Bracket =Red= | 2 | |
| 12 | 9008857 | Window & Trim Assembly 14 15/32" x 19 21/32" | 1 | |
| 13 | 9001917 | Tension Bushing, 1 1/2" ID | 1 | |
| 14 | 9001968 | Trailer Connector Holder | 1 | |
| 15 | 9002130 | Split Tension Bushing, 1 3/4" ID | 1 | |
| 16 | 9008680 | Window & Trim Assembly 17 7/32" x 19 21/32" | 2 | |
| 17 | 9004898 | Chain | 1 | |
| 18 | 9005011 | Jack | 1 | |
| 19 | 9005230 | PTO Assembly Complete | 1 | |
| 20 | 9005259 | 0-Ring | 4 | |
| 21 | 9005473 | Split Tension Bushing, 2 3/8 Dia. | 4 | |
| 22 | 9008634 | Box Storage | 1 | |
| 23 | 9006456 | Spring, 4.75 Thick | 2 | |
| 24 | 9006457 | Spring, 2.50 Thick | 2 | |
| 25 | 91192 | Retaining Ring, 1" | 2 | |
| 26 | 91257 | Large Flange Hex Nut, 5/16-18UNC Grade 5 | 14 | |
| 27 | 9005376 | U-Nut | 3 | |
| 28 | 271891B | Shield Tube =Black= | 1 | |
| 29 | 91299-191 | Capscrew, 1-8UNC x 4 Grade 8 | 1 | |
| 30 | 92199 | Center Locknut, 1-8UNC | 2 | |
| 31 | 9007632 | Jack Pin, 7/8 Dia. x 4 7/8 with Chain | 1 | |
| 32 | 9390-003 | Capscrew, 1/4-20UNC x 3/4 Grade 5 | 14 | |
| 33 | 9390-006 | Capscrew, 1/4-20UNC x 1 1/4 Grade 5 | 2 | |
| 34 | 9390-130 | Capscrew, 5/8-11UNC x 3 1/2 Grade 5 | 2 | |
| 35 | 91299-195 | Capscrew, 1-8UNC x 6 Grade 8 | 1 | |
| 36 | 9390-464 | Capscrew, 1-8UNC x 10 Grade 5 | 4 | |
| 37 | 9936 | Locknut, 1/4-20UNC Grade 5 | 2 | |
| 38 | 903171-663 | Phillips Head Machine Screw, 5/16-18UNC x 1 1/2 | 8 | |
| 39 | 9405-064 | Flat Washer, 1/4 | 4 | |
| 40 | 94763 | Fender Washer, 2" Dia. | 2 | |
| 41 | 95905 | Center Locknut, 5/8-11UNC | 2 | |
| 42 | 9663 | Locknut, 1-8UNC Grade 5 | 4 | |
| 43 | 281663 | Poly Wear Shoe For CAT 3 | 1 | |
| 44 | 281898 | Poly Wear Shoe For CAT 4 | 1 | |
| 45 | 281899 | Poly Wear Shoe For CAT 5 | 1 | |


Axle & Hopper Components



Axle & Hopper Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|--|--|
| 1 | 271562B | Front Link Arm Weldment =Black= | 1 | |
| 2 | 271563B | Rear Link Arm Weldment =Black= | 1 | |
| 3 | 271566B | Stop Bushing =Black= | 1 | |
| 4 | 271664B | Cleanout Door Weldment W/Holes =Black= | 7 | |
| 5 | 273753B | Door Latch Weldment =Black= | 1 | |
| 6 | 282414B | Wheel Well Brace =Black= | 2 | |
| 7 | 282416B | Cross Tube Weldment =Black= | 3 | |
| 8 | 295875B | Cross Tube Weldment =Black= | 1 | For SN B42340100 & Higher (Tracks Only) For SN B42340099 & Lower |
| | 284945B | | | (Tracks Only) |
| 9 | 286414B | Door Pivot Bracket =Black= | 7 | |
| 10 | 286417 | Door Linkage Spring | 14 | |
| 11 | 286418B | Cleanout Door Doubler Plate =Black= | 14 | |
| 12 | 9003396 | Locknut, 3/8-16UNC Grade 5 | 14 | |
| 13 | 9003397 | Locking Flange Nut, 1/2-13UNC | 1 | |
| 14 | 9005305 | Lynch Pin, 3/8 Dia. x 3 | 1 | |
| 15 | 9006351 | Clamp | 7 | |
| 16 | 9006352 | Top Plate | 7 | |
| 17 | 9007108 | Rubber Gasket | 14 | |
| 18 | 91257 | Large Flange Hex Nut, 5/16-18UNC Grade 5 | 28 | |
| 19 | 91262 | Large Flange Screw, 3/8-16UNC x 1 Grade 5 | 48 | |
| 20 | 91263 | Large Flange Nut, 3/8-16UNC Grade 5 | 48 | |
| 21 | 91266 | Flange Screw, 1/2-13UNC x 1 1/4 Grade 5 | 16 | |
| 22 | 91267 | Flange Nut, 1/2-13UNC Grade 5 | 16 | |
| 23 | 9390-015 | Capscrew, 1/4-20UNC x 3 1/2 Grade 5 | 14 | |
| 24 | 9390-056 | Capscrew, 3/8-16UNC x 1 1/4 Grade 5 | 14 | |
| 25 | 9390-108 | Capscrew, 1/2-13UNC x 3 1/4 Grade 5 | 1 | |
| 26 | 9390-113 | Capscrew, 1/2-13UNC x 5 Grade 5 | _ 2 | For SN B42340100 & Higher |
| | 9390-114 | Capscrew, 1/2-13UNC x 5 1/2 Grade 5 | | For SN B42340099 & Lower |
| 27 | 903171-660 | Flat Head Machine Screw, 5/16-18UNC x 1 | 28 | |
| 28 | 9405-070 | Flat Washer, 5/16 USS | 28 | |
| 29 | 9405-076 | Flat Washer, 3/8 USS | 14 | |
| 30 | 97189 | Large Flange Hex Nut, 1/4-20UNC | 15 | |
| 31 | 9800 | Locknut, 1/2-13UNC Grade 5 | 2 | |
| 32 | TA8B95 | Hairpin Cotter, 1/8 Dia. x 1 15/16 | 14 | |
| 33 | 272740G | Shim Plate, 8GA =Green= | 2 | |
| | 272740R | Shim Plate, 8GA =Red= | | |
| 34 | 272741G | Shim Plate, 14GA =Green= | 1 | |
| | 272741R | Shim Plate, 14GA =Red= | + | |
| 35 | 272745G | Outer Cap Bolt Plate, 3/8" =Green= | 2 | |
| | 272745R | Outer Cap Bolt Plate, 3/8" =Red= | + | |
| 36 | 272814G | Rear Runner Brace Weldment =Green= | 1 | |
| | 272814R | Rear Runner Brace Weldment =Red= | 1 - | |
| 37 | 9390-170 | Capscrew, 7/8-9UNC x 3 1/2 Gr.5 | 8 | |
| 38 | 98420 | Locknut, 7/8-9UNC Gr.8 | 8 | |

Steering Tandem Assembly Components



| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------------------------|------|---|
| 1 | 283648B | Steering Retainer Weldment =Black= | 2 | |
| 2 | 283651B | Pivot Weldment LH =Black= | 1 | |
| 3 | 283652B | Pivot Weldment RH =Black= | 1 | |
| 4 | 283653B | Axle Weldment =Black= | 1 | |
| 5 | 283657B | Tandem Weldment RH =Black= | 1 | |
| 6 | 283658B | Tandem Weldment LH =Black= | 1 | |
| 7 | 283679 | Washer 3 5/8" Dia. | 4 | |
| 8 | 283694 | Kingpin Weldment | 4 | |
| 9 | 283696B | Spindle Retainer Weldment LH =Black= | 2 | For Models with 35.5x32 & 900/60x32 Tires |
| 9 | 283755B | Spindle Retainer Weldment LH =Black= | 2 | For Models with 24.5x32 & 30.5x32 Tires |
| 10 | 283697B | Spindle Retainer Weldment RH =Black= | 2 | For Models with 35.5x32 & 900/60x32 Tires |
| 10 | 283756B | Spindle Retainer Weldment RH =Black= | 2 | For Models with 24.5x32 & 30.5x32 Tires |
| 11 | 283698 | Washer 5 3/4" Dia. | 12 | |

Steering Tandem Assembly Components

Please visit www.unverferth.com/parts/ for the most current parts listing.


| I | TEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|----------|-------------|--------------------|--|--------|------------------------|
| Γ. | 12 | 283712B | Tie Rod Assembly - Center =Black= | 1 | Includes Items 13 - 19 |
| П | 13 | 283761 | Bushing, 2 1/2" Dia. x 1 1/2" Dia. x 2 5/16 | 2 | |
| | 14 | 283766B | Center Tie Rod Weldment =Black= | 1 | |
| | 15 | 9004743 | Male Rod End Bearing, 1 1/4-12UNF | 1 | Right-Hand Threaded |
| | 16 | 9004744 | Male Rod End Bearing, 1 1/4-12UNF | 1 | Left-Hand Threaded |
| | 17 | 9004827 | Hex Jam Nut 1 1/4-12UNF | 1 | Left-Hand Threaded |
| | 18 | 9005263 | Belleville Washer | 2 | |
| Ш | 19 | 9395-023 | Hex Jam Nut 1 1/4-12UNF | 2 | Right-Hand Threaded |
| ١. | 20 | 283713B | Tie Rod Assembly - Rear =Black= | 2 | Includes Items 21 - 23 |
| | 21 | 283709B | Rear Tie Rod Weldment =Black= | 2 | |
| | 22 | 9004743 | Male Rod End Bearing, 1 1/4-12UNF | 2 | Right-Hand Threaded |
| Ш | 23 | 9395-023 | Hex Jam Nut 1 1/4-12UNF Grade 5 | 2 | |
| Ι. | 24 | 283714B | Tie Rod Assembly - Front =Black= | 2 | Includes Items 25 - 27 |
| | 25 | 283704B | Front Tie Rod Weldment =Black= | 2 | |
| | 26 | 9004743 | Male Rod End Bearing, 1 1/4-12UNF | 2 | Right-Hand Threaded |
| Ш | 27 | 9395-023 | Hex Jam Nut 1 1/4-12UNF | 2 | |
| L | 28 | 283715 | Washer 3 1/4" Dia. | 2 | |
| | 29 | 283725 | Pin Weldment | 2 | |
| L | 30 | 283731 | Washer 2" Dia. | 4 | |
| | 31 | 267200B | Hub & Spindle Asy For M22 Studs =Black= | 4 | |
| | | 267201B | Hub & Spindle Asy For 3/4" Studs =Black= | 4 | |
| L | 33 | 283760 | Washer 3 3/8" Dia. (Hardened) | 8 | |
| L | 34 | 283770 | Spacer Bushing | 2 | |
| L | 35 | 283774B | Indicator Weldment =Black= | 1 | |
| ١, | 36 | 283782B | Axle Brace Assembly =Black= | 2 | Includes Items 37 - 39 |
| | 37 | 283779B | Axle Brace Weldment - Left Hand =Black= | 2 | |
| | 38 | 283781B | Axle Brace Weldment - Right Hand =Black= | 2 | |
| Ш | 39 | 9395-041 | Hex Jam Nut, 1 1/4-7UNC Grade 5 | 2 | |
| L | 40 | 283787 | Pivot Bushing Weldment | 4 | |
| L | 41 | 808254 | Adjusting Nut 1 1/4-7UNC Grade 5 | 4 | N L O |
| H | 42 | 9000106 | Cable Tie, 6" | A/R | Not Shown |
| | 43 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 2 | Not Observe |
| L | 44 | 9004130 | Spiral Hose Wrap | 4 | Not Shown |
| H | 45 | 9003749 | Self Lubricating Bearing | 4 | |
| | 46 47 | 9004738 | Self Lubricating Bushing Self Lubricating Thrust Bearing | 8 | |
| | | 9004746 | | - | |
| \vdash | 48 49 | 9004752 9004854 | Retaining Ring, 4 1/2" Dia. Hydraulic Cylinder, 2 1/2 x 8" - 3000 PSI | 2 | |
| | 50 | 9004856 | Hose Clamp | | |
| H | 51 | 9004857 | Top Plate Hose Clamp | 6 | |
| | 52 | 9004857 | Steering Valve | 6 1 | |
| \vdash | 53 | 9004881 | Hydraulic Hose, 1/2 x 153" - 3000 PSI | 1 | Not Shown |
| \vdash | 54 | 9004882 | Hydraulic Hose, 1/2 x 73" - 3000 PSI | 2 | Not Shown |
| \vdash | 55 | 90046623 | Split Bushing | 4 | INOC OHOWII |
| \vdash | 56 | 91177 | Retaining Ring 1 1/4" | 4 | |
| \vdash | 57 | 91268 | Tension Bushing 1 1/4 OD x 1 ID x 1 | 4 | |
| | 58 | 92470 | Castle Nut 2-12UNF Grade 5 | 4 | |
| \vdash | 59 | 92470 | Spindle Washer (Hardened) | 4 | |
| | วช | 92412 | Johnnale Mastier (Hardened) | 4 | |

(Continued on next page)

Steering Tandem Assembly Components (continued)


| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|------------|--|------|----------------------|
| 60 | 93426 | Grease Zerk | 10 | |
| 61 | 93586 | 45° Elbow 3/4-16 JIC Male x 3/4-16 OR Male | 2 | |
| 62 | 9390-009 | Capscrew 1/4-20UNC x 2 Grade 5 | 2 | |
| 63 | 9390-033 | Capscrew 5/16-18UNC x 1 3/4 Grade 5 | 4 | |
| 64 | 9390-053 | Capscrew 3/8-16UNC x 3/4 Grade 5 | 4 | |
| 65 | 9390-100 | Capscrew 1/2-13UNC x 1 1/4 Grade 5 | 4 | |
| 66 | 9390-122 | Capscrew 5/8-11UNC x 1 1/2 Grade 5 | 4 | |
| 67 | 9390-136 | Capscrew 5/8-11UNC x 6 Grade 5 | 4 | |
| 68 | 9390-145 | Capscrew, 3/4-10UNC x 2 | 4 | |
| 69 | 9390-184 | Capscrew 1-8UNC x 2 1/4 | 4 | |
| 70 | 9390-185 | Capscrew 1-8UNC x 2 1/2 | 4 | |
| 71 | 91299-1458 | Capscrew 1 x 3 1/2 UNS Grade 8 | 4 | |
| 72 | 9390-215 | Capscrew 1 1/4-7UNC x 3 1/2 Grade 5 | 4 | |
| 73 | 9390-217 | Capscrew 1 1/4-7UNC x 4 Grade 5 | 4 | |
| 74 | 9390-065 | Capscrew 3/8-16UNC x 3 1/2 Grade 5 | 4 | |
| 74A | 902875 | Locknut 3/8-16UNC | 4 | |
| 75 | 9394-020 | Hex Nut, 1-8UNC Grade 5 | 2 | |
| 76 | 9399-084 | Set Screw 3/8-16UNC x 3/8 | 4 | Cup Point/Hex Socket |
| 77 | 9404-017 | Lock Washer 1/4 | 4 | |
| 78 | 9404-021 | Lock Washer 3/8 | 4 | |
| 79 | 9404-025 | Lock Washer 1/2 | 4 | |
| 80 | 9404-029 | Lock Washer 5/8 | 4 | |
| 81 | 9404-033 | Lock Washer, 3/4 | 4 | |
| 82 | 9404-041 | Lock Washer, 1 | 4 | |
| 83 | 9405-076 | Flat Washer 3/8 (USS) | 4 | |
| 84 | 9405-088 | Flat Washer 1/2 (USS) | 4 | |
| 85 | 9405-106 | Flat Washer, 3/4 | 4 | |
| 86 | 95905 | Center Locknut, 5/8-11UNC | 2 | |
| 87 | 9863 | 90° Elbow 3/4-16 JIC Male x 3/4-16 OR Male | 2 | |
| 88 | 9864 | Adapter, 3/4-16 JIC Male x 3/4-16 OR Male | 2 | |
| 89 | 804685 | Hardened Washer | 8 | |
| 90 | 9008441 | Elastic Lock Nut 1" UNS Grade 8 | 8 | |

Steering Tandem Indicator Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|----------------------------|-----|-------|
| 1 | 283742 | Saddle Clamp | 1 | |
| 2 | 283749R | Indicator Weldment =Red= | 1 | |
| 3 | 283774B | Indicator Weldment =Black= | 1 | |
| 4 | 9004865 | U-Bolt 3/8-16 x 3 5/8 | 1 | |
| 5 | 9005168 | Push / Pull Cable 264" | 1 | |
| 6 | 9005109 | Rod End | 1 | |
| 7 | 91263 | Flange Nut 3/8-16 | 2 | |
| 8 | 9390-053 | Capscrew, 3/8-16 UNC x 3/4 | 2 | |
| 9 | 9404-021 | Lock Washer 3/8 | 2 | |
| 10 | 9405-076 | Flat Washer 3/8 | 3 | |


Steering Tandem Hub Components



| ITE | М | PART NO. | DESCRIPTION | QTY | NOTES |
|-----|---|----------|--|-----|--|
| | | 283739B | Hub Sub-Asy with M22 x 1.5 Hdw =Black= | | |
| | | 283739G | Hub Sub-Asy with M22 x 1.5 Hdw =Green= | | Includes Items 2-4 - For Models with 35.5x32 & 900/60x32 Tires |
| , | 1 | 283739R | Hub Sub-Asy with M22 x 1.5 Hdw =Red= | 2 | 33.3x32 & 900/00x32 Tiles |
| ' | | 283763B | Hub Sub-Asy with 3/4-16UNF Hdw =Black= | 4 | Includes there 0.4 5 M LL 30 |
| | | 283763G | Hub Sub-Asy with 3/4-16UNF Hdw =Green= | | Includes Items 2-4 - For Models with 24.5x32 & 30.5x32 Tires |
| 1 | | 283763R | Hub Sub-Asy with 3/4-16UNF Hdw =Red= | | 24.3x32 & 30.3x32 Tiles |
| | 2 | 92462 | Outer Bearing Cup | 2 | HM212011 |
| | 3 | 92476 | Inner Bearing Cup | 2 | HM218210 |
| | | 267288 | Stud & Nut Kit M22 x 1.5 | | For Models with 35.5x32 & 900/60x32 |
| | 4 | 9007001 | Stud Bolt M22 x 1.5 x 4 | 20 | Tires |
| | | 94794 | Stud Bolt 3/4-16UNF x 3 Grade 8 | | For Models with 24.5x32 & 30.5x32 Tires |
| 5 | 5 | 9006347 | Scale Spindle, 3 3/4" Dia. | 4 | |
| 6 | 6 | 92565 | Seal | 2 | 37605SA |
| 7 | 7 | 92464 | Outer Bearing Cone | 2 | HM212049 |
| | | 286171B | Hub Cap "Bolt-On Type" =Black= | | |
| 8 | } | 286171G | Hub Cap "Bolt-On Type" =Green= | 2 | |
| | | 286171R | Hub Cap "Bolt-On Type" =Red= | | |
| Ć |) | 284230 | Gasket | 2 | |
| 1 | 0 | 92470 | Castle Nut, 2-12UNF Grade 5 | 2 | |
| 1 | 1 | 92472 | Spindle Washer (Hardened) | 2 | |
| 1: | 2 | 92545 | Inner Bearing Cone | 2 | HM218248 |
| 1 | 3 | 9390-026 | Capscrew 5/16-18UNC x 1/2 Grade 5 | 8 | |
| 1- | 4 | 9390-064 | Capscrew 3/8-16UNC x 3 1/4 Grade 5 | 2 | |
| | | 267288 | Stud & Nut Kit M22 x 1.5 | | For Models with 35.5x32 & 900/60x32 |
| 1 | 5 | 97319 | Flange Cap Nut M22 x 1.5 | 20 | Tires |
| | | 92458 | Wheel Nut 3/4-16UNF Grade 8 | | For Models with 24.5x32 & 30.5x32 Tires |
| 1 | 6 | 902875 | Locknut, 3/8-16UNC | 2 | |
| 1 | 7 | 91160 | Grease Zerk | 2 | |

Steering Tandem Wheels & Tires

Please visit www.unverferth.com/parts/ for the most current parts listing.




TIRES

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Tire manufacturers' phone numbers and websites are listed in Maintenance Section for your convenience.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|------------------------|----------|--|
| 1 | 14316 | Wheel & Tire Assembly | 4 | 27x32 / 30.5B32 R-3 |
| l | 92417 | Wheel Only | 4 | 27x32 |
| 1 | 17404 | Wheel & Tire Assembly | 4 | 31x32 / 35.5LB32 R-3 (Off-White) |
| l | 17275 | Wheel Only | 4 | 31x32 |
| 1 | 17404SM | Wheel & Tire Assembly | 4 | 31x32 / 35.5LB32 R-3 (Silver Mist) |
| l | 17274SM | Wheel Only | 4 | 31x32 |
| 1 | 17627 | Wheel & Tire Assembly | 4 | 27x32 / 900/60-32 R-1W |
| l | 17273W0 | Wheel Only | 4 | 27x32 |
| | 19976 | Wheel & Tire Accombly | 4 | 27 x 32 / TLIF800/65R32 R-1W (Off-White) |
| 1 | 19976SM | ─Wheel & Tire Assembly | | 27 x 32 / TLIF800/65R32 R-1W (Silver Mist) |
| | 92417 | Wheel Only | V i 4 i | 27 x 32 (Off-White) |
| | 92417SM | Wheel Only | | 27 x 32 (Silver Mist) |
| | 17944 | Wheel & Tire Assembly | 4 | 30 x 32 / 900/60R32 R-1 (Off-White) |
| 1 | 17944SM | Whose a mo necessary | <u> </u> | 30 x 32 / 900/60R32 R-1 (Silver Mist) |
| ' | 17943W0 | Wheel Only | 4 | 30 x 32 (Off-White) |
| | 17943SM | | <u> </u> | 30 x 32 (Silver Mist) |
| 2 | 93300 | Valve Stem | 4 | |
| 3 | 901207 | Valve Stem Adapter | - | |

Brake Components (Optional)

(Requires tractor with Implement Braking)




Brake Components (Optional)

(Requires tractor with Implement Braking)


| ITE | EM | PART NO. | DESCRIPTION | QTY | NOTES |
|-----|----|----------|--|-----|---------------|
| - | l | 283711 | Brake Rotor Plate | 2 | |
| 2 | 2 | 9003735 | Cable Tie, 11" Long | 24 | |
| 3 | 3 | 9004762 | Brake Assembly | 2 | |
| | 3A | 9007135 | Brake Pad - Outer | 1 | Quantity Per |
| | 3B | 9007136 | Brake Pad - Inner | 1 | Brake Caliper |
| | 3C | 9007137 | Seal Kit | 1 | (Not Shown) |
| 4 | 1 | 9004829 | Hose Marker Sleeve = Brake Pressure | 1 | |
| į | 5 | 9004885 | Hose, 1/4 x 148 (3000 PSI) | 2 | |
| (| 3 | 9004886 | Hose, 1/4 x 408 (3000 PSI) | 1 | |
| 7 | 7 | 9005173 | Quick Coupler | 1 | |
| 3 | 3 | 9006005 | Adapter, 9/16-18 JIC M x 18x1.5 M | 1 | |
| Ś |) | 9390-147 | Capscrew, 3/4-10 UNC x 2 1/2 Grade 5 | 12 | |
| 1 | 0 | 9390-348 | Capscrew, 5/8-18 UNF x 2 Grade 5 | 20 | |
| 1 | 1 | 9404-029 | Lock Washer, 5/8 | 20 | |
| 1 | 2 | 9404-033 | Lock Washer, 3/4 | 12 | |
| 1 | 3 | 97711 | Adapter, 9/16-18 JIC M x 7/16-20 O-R M | 2 | |
| 1 | 4 | 9875 | Tee, 9/16-18 JIC M | 1 | |
| 1 | 5 | 286237 | Shim | 16 | Use as Needed |
| 1 | 6 | 9007162 | Brakes Information Tag | 1 | |

Track Axle Components




| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|-------------------------------------|-----|---|
| 1 | 268838B | Axle Mount =Black= | 4 | |
| | 282035B | Axle Weldment =Black= | 1 | Equalizer Tracks |
| 2 | 282744B | Axle Weldment =Black= | 1 | Standard Tracks & Optional Long axle for Equalizer tracks |
| 3 | 282876 | Hitch Pin, 1" Dia. x 5 1/2 | 8 | |
| 4 | 9005811 | Scale Bar, 3.50" (SHOWN) | 4 | |
| 4 | 282745 | Load Bar, 3.50" - Non-Scale | 4 | |
| 5 | 91192 | Retaining Ring 1" | 16 | |
| 6 | 92199 | Locknut, 1-8UNC | 2 | |
| 7 | 91299-1457 | Capscrew 1-14UNS x 3 1/4 Grade 8 | 16 | |
| 8 | 9390-464 | Capscrew 1-8UNC x 10 Grade 5 | 2 | |
| 9 | 9008441 | Elastic Lock Nut 1-14UNS Grade 8 | 16 | |
| 10 | 9404-041 | Lock Washer, 1 | 8 | |
| 11 | 804685 | Washer, 1 1/16" ID | 32 | |
| 12 | 282689B | Cover Plate =Black= | 2 | |
| 13 | 282690 | Washer 8 1/2" OD | 4 | |
| 14 | 282102 | Track Pivot Shaft, 7" Dia. x 19 1/8 | 2 | Equalizer Tracks |
| 14 | 282742 | Track Pivot Shaft 7" Dia. x 19 3/16 | 2 | Standard Tracks |
| 15 | 93426 | Grease Zerk | 2 | Standard Tracks |
| 16 | 9390-184 | Capscrew 1-8UNC x 2 1/4 Grade 5 | 8 | |
| 17 | 9006785 | 90° Adapter 1/8"NPT | 2 | Equalizer Tracks |
| 18 | 9006816 | Adapter 1/8"NPT | 2 | Equalizer Tracks |

Track Panel Kit Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|----------------------------------|-----|----------------------------|
| | 284213G | Track Panel Kit =Green= | | Includes Itams 1 through 6 |
| | 284213R | Track Panel Kit =Red= | _ | Includes Items 1 through 6 |
| 4 | 284212G | Track Panel Plate =Green= | 4 | |
| ı | 284212R | Track Panel Plate =Red= | 4 | |
| 2 | 9005376 | U-nut, 3/8-16UNC | 24 | |
| 3 | 9405-076 | Flat Washer, 3/8" USS | 64 | |
| 4 | 9404-021 | Lock Washer, 3/8" | 44 | |
| 5 | 9390-056 | Capscrew, 3/8"-16UNC x 1 1/4" G5 | 44 | |
| 6 | 9394-006 | Hex Nut, 3/8"-16UNC | 20 | |


Sideboards



Sideboards

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|-------|
| 1 | 220032B | Angle Brace Tube =Black= | 5 | |
| 2 | 271574B | Lamp Mount Bracket =Black= | 1 | |
| 3 | 281713B | End Cap Weldment =Black= | 2 | |
| 4 | 282319B | Cross Brace Bracket Weldment =Black= | 1 | |
| 5 | 282321B | Board Weldment Center LH =Black= | 1 | |
| 6 | 282553B | Board Weldment Center RH =Black= | 1 | |
| 7 | 282554B | Board Weldment Front RH =Black= | 1 | |
| 8 | 282555B | Board Weldment Rear RH =Black= | 1 | |
| 9 | 282562B | Board Weldment Front LH =Black= | 1 | |
| 10 | 282563B | Board Weldment Rear LH =Black= | 1 | |
| 11 | 294100B | Board Front =Black= | 1 | |
| 12 | 294101B | Board Rear =Black= | 1 | |
| 13 | 9003259 | Flange Screw, 3/8"-16UNC x 1 1/4" G5 | 11 | |
| 14 | 9004626 | Hinge | 6 | |
| 15 | 9008957 | LED Work Light | 1 | |
| 16 | 9008857 | Window & Trim Assembly 14 15/32" x 19 21/32" | 2 | |
| 17 | 9008933 | Pan Head Screw #8-18UNC x 1/2" | 24 | |
| 18 | 91256 | Screw/Large Flange, 5/16"-18UNC x 3/4" G5 | 26 | |
| 19 | 91257 | Hex Nut/Large Flange, 5/16"-18UNC G5 | 28 | |
| 20 | 91262 | Screw/Large Flange, 3/8"-16UNC x 1 | 22 | |
| 21 | 91263 | Hex Nut/Large Flange, 3/8"-16UNC G5 | 72 | |
| 22 | 9512 | Self-Drilling Screw, 1/4"-14 x 1" | 4 | |
| 23 | 95585 | Capscrew/Large Flange, 3/8"-16UNC x 3/4" G5 | 40 | |
| 24 | 97604 | Flange Screw, 5/16"-18UNC x 1" G5 | 2 | |


Horizontal Auger Components



Horizontal Auger Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|---|-----|-------------|
| 1 | 283097G | Cover Plate =Green= | 1 | |
| 1 | 283097R | Cover Plate =Red= | ' | |
| 2 | 283895 | Spacer Bushing, 1 1/4" OD x 0.813" ID x 1 1/8" | 2 | |
| 3 | 286282 | Adapter/Shaft Bushing Weldment =Primed= | 1 | |
| 4 | 286381B | Bearing Mounting Bar =Black= | 1 | |
| 5 | 286424B | Bearing Shim Plate =Black= | 2 | As Required |
| 6 | 283537 | Auger Shaft 2.25" Dia. | 1 | |
| 7 | 91299-157 | Capscrew, 3/4"-10UNC x 6" Grade 8 | 2 | |
| 8 | 9802 | Lock Nut, 3/4"-10UNC | 2 | |
| 9 | 294130B | Front Auger Weldment =Black= | 1 | |
| 10 | 293954B | Rear Auger Weldment =Black= | 1 | |
| 11 | 293957 | Auger Coupler Shaft Weldment | 1 | |
| 12 | 9002479 | Adapter 1/8"-27 NPTF Male x 1/8"-27 NPSM Female Swivel Nut | 1 | |
| 13 | 9002492 | Bearing/Flanged 2" Dia. | 1 | |
| 14 | 9002689 | Hose 1/8" x 12", 3000 PSI | 1 | |
| 15 | 9004731 | Pillow Block Bearing with 2 1/2" Bore | 1 | |
| 16 | 9004764 | 90° Elbow 1/8" Female NPTF x 1/8" Female NPTF | 1 | |
| 17 | 9005072 | 90° Elbow 1/4" Tube x 1/8"-27 NPTF Swivel Nut | 1 | |
| 18 | 9006964 | Nipple 1/8" NPT Male x 1/8" NPT Male | 1 | |
| 19 | 91262 | Capscrew, 3/8"-16UNC x 1" G5 | 21 | |
| 20 | 91267 | Lock Nut, 1/2"-13UNC | 2 | |
| 21 | 9388-104 | Carriage Bolt, 1/2"-13UNC x 1 1/2" G5 | 2 | |
| 22 | 9390-124 | Capscrew, 5/8"-11UNC x 2" G5 | 4 | |
| 23 | 9390-160 | Capscrew, 3/4"-10UNC x 7 1/2" G5 | 2 | |
| 24 | 9394-014 | Hex Nut, 5/8"-11UNC Grade 5 | 4 | |
| 25 | 9404-029 | Lock Washer, 5/8" | 6 | |
| 26 | 9802 | Lock Nut, 3/4"-10UNC | 2 | |


Vertical Auger Flighting Components



Vertical Auger Flighting Components

| ITE | M | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----|------------|--|-----|----------------------|
| 1 | | 9007366 | Gearbox Assembly, 800 Series | 1 | |
| 2 | | 9404-030 | Lock Washer, 5/8" | 10 | |
| 3 | | 9390-124 | Capscrew, 5/8"-11UNC x 2" G5 | 8 | |
| 4 | | 9005073 | Quicklinc Fitting 1/4" Tube x 1/8" NPT | 2 | |
| 5 | | 9005074 | Tube 1/4" OD | 1 | |
| 6 |) | 9388-104 | Carriage Bolt, 1/2"-13UNC x 1 1/2" G5 | 5 | |
| 7 | , | 9390-122 | Capscrew, 5/8"-11UNC x 1 1/2" G5 | 12 | |
| 8 | | 293420B | Bearing Bracket Weldment =Black= | 1 | |
| 9 | | 9004731 | Pillow Block Bearing, 2 1/2" Bore | 1 | |
| 1(| 0 | 284636 | Grease Pipe | 1 | |
| 1 | 1 | 9003397 | Lock Nut/Top, 1/2"-13UNC | 4 | |
| 12 | 2 | 9004764 | 90° Elbow, 1/8" NPTF Female | 1 | |
| 13 | 3 | 9002492 | Bearing 2" Dia. Flanged | 1 | |
| 14 | 4 | 9004899 | Spring - 10 Coils | 4 | |
| 15 | 5 | 284986 | Hood Pivot Pin Weldment | 1 | |
| 16 | 6 | 9390-137 | Capscrew, 5/8"-11UNC x 6 1/2" G5 | 4 | |
| 17 | 7 | 9801 | Lock Nut, 5/8"-11UNC | 4 | |
| 18 | 8 | 9404-025 | Lock Washer, 1/2" | 6 | |
| 19 | 9 | 283515 | Auger Tube Adapter | 1 | |
| 20 | 0 | 288813 | Drive Dog, Double Lobe | 1 | |
| 2 | 1 | 9390-159 | Capscrew, 3/4"-10UNC x 7" G5 | 2 | |
| 22 | 2 | 9802 | Lock Nut, 3/4"-10UNC | 2 | |
| 23 | 3 | 9007377B | Dust Cover =Black= | 1 | |
| 24 | 4 | 407699 | Washer Plate, 2 1/2" Dia. | 1 | |
| 2 | 5 | 9390-100 | Capscrew, 1/2"-13UNC x 1 1/4" G5 | 5 | |
| _ 26 | 6 | 294131B | Lower Auger Replacement Kit (Black) | 1 | Includes Items 27-29 |
| | 27 | 287802 | Auger Drive Plate Assembly | 1 | Includes Items 28-29 |
| | 28 | 9007000 | Drive Head Pin | 5 | |
| | 29 | 902614-238 | Spiral Pin, 1/2" Dia. x 2 3/4" | 1 | |
| _ 30 | 0 | 289850B | Upper Auger Weldment =Black= | 1 | Includes Items 31-37 |
| | 31 | 284626 | Flex Coupler Bushing Assembly | 1 | |
| | 32 | 281912 | Soft Start Kit | 1 | Includes items 33-37 |
| | 33 | 9004878 | Self Lubricating Washer | 1 | |
| | 34 | 9390-119 | Capscrew, 1/2"-13UNC x 8" G5 | 1 | |
| | 35 | 410511 | Spacer Bushing | 1 | |
| | 36 | 9800 | Locknut, 1/2"-13UNC | 1 | |
| | 37 | 281283 | Soft Start Assembly | 1 | |
| 38 | 8 | 286419B | Bearing Shim Plate =Black= | 1 | |


Lower Auger Door & Cover Components



Lower Auger Door & Cover Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|--|-----|-----------------|
| 1 | 284141G | Strike Plate =Green= | 1 | |
| ' | 284141R | Strike Plate =Red= |] ' | |
| 2 | 95585 | Capscrew/Large Flange 3/8-16UNC x 3/4 | 5 | Grade 5 |
| 3 | 9004918 | PTO Bell Cover | 1 | |
| 4 | 9004729 | Belt Cover/Shield | 3 | |
| 5 | 900060 | Handle for Draw Latch | 3 | |
| 6 | 900068 | Retainer for Draw Latch | 3 | |
| 7 | 900066 | Stud Pin for Draw Latch | 3 | |
| 8 | 900067 | Washer for Draw Latch | 3 | |
| 9 | 900059 | Flexible Draw Latch Asy w/Style R Keeper | 3 | |
| 10 | 9004940 | Pop Rivet | 6 | |
| 11 | 9004998 | Rivet Washer/Burr 3/16" | 6 | |
| 12 | 91263 | Large Flange Nut 3/8-16 UNC | 2 | Grade 5 |
| 13 | 284714B | Locking Pipe Weldment with Roll Pin | 1 | |
| 13 | 9392-208 | Roll Pin 1/2" Dia. x 2 | - | |
| 14 | 9007108 | Gasket w/Adhesive Backing for Clean-Out Door | A/R | Specify in Feet |
| 15 | 9006497 | Plate - Latch | 2 | |
| 16 | 289854B | Cleanout Door Weldment =Black= | 1 | |
| 17 | 903171-574 | Countersunk Screw #10-24 UNC | 4 | |
| 18 | 902331 | Flange Hex Nut #10-24 (Serrated) | 4 | |


Lower Auger Linkage Components



Lower Auger Linkage Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|--|
| 1 | 9004590 | Pulley, 15" Dia. x 5 13/16" | 1 | |
| 2 | 9007376 | Bushing, 4 5/8" OD x 2 1/4" ID x 2 1/16" With 1/2" Keyway & Includes Capscrews | 1 | Includes Items 3, 4, 5 |
| 3 | 9404-021 | Lock Washer, 3/8" | 3 | |
| 4 | 9399-059 | Set Screw, 1/4"-20UNC x 3/8" | 1 | |
| 5 | 284262 | Split Bushing Hardware Kit | 1 | Includes Capscrews & Items 3 & 4 |
| 6 | 9002562 | Keystock, 1/2" x 1/2" x 2 1/2" | 2 | |
| 7 | 9004591 | Pulley, 7 1/2" Dia. x 5 13/16" | 1 | |
| 8 | 9004813 | Bushing, 6 5/8" OD x 2 1/4 ID" x 3 3/4" With 1/2" Keyway & Includes Capscrews | 1 | Includes Items 9, 10, 11 |
| 9 | 9006263 | Bolt, 9/16"-12UNC x 3 5/8" | 3 | Grade 5 |
| 10 | 9404-027 | Lock Washer, 9/16" | 3 | |
| 11 | 9399-107 | Set Screw, 1/2"-13UNC x 5/8" | 1 | |
| 12 | 9005073 | Quicklinc Fitting | 4 | |
| 13 | 9005074 | Hose/Type Nylon, 1/4" OD | 2 | (Specify in Feet) |
| 14 | 9405-076 | Flat Washer, 3/8" | 2 | |
| 15 | 281675 | Drive Belt Set, 4 Strand (5V750) | 1 | |
| 16 | 9004729 | Belt Cover | 1 | |
| 17 | 900059 | Flexible Draw Latch Asy w/Style R Keeper | 3 | |
| 18 | 9004940 | Pop Rivet | 6 | |
| 19 | 900067 | Washer for Draw Latch | 3 | |
| 20 | 900066 | Stud Pin for Draw Latch | 3 | |
| 21 | 900068 | "E" Retainer for Draw Latch | 3 | |
| 22 | 900060 | Handle for Draw Latch | 3 | |
| 23 | 9003690 | Hex Pipe Coupling | 1 | |
| 24 | 9004998 | Rivet Washer/Burr 3/16" | 6 | |
| 25 | 9005565 | Flange Bearing 2 1/4" ID - 4 Bolt | 2 | |
| 26 | 9399-084 | Set Screw 3/8"-16UNC x 3/8" | 4 | |
| 27 | 9390-124 | Capscrew, 5/8"-11UNC x 2" | 8 | Grade 5 |
| 28 | 9003398 | Lock Nut/Top, 5/8"-11UNC | 4 | |
| 29 | 9003949 | Hex Pipe Coupling 1/8" NPT Female | 1 | |
| 30 | 93426 | Grease Zerk, 1/8" NPT | 2 | |
| 31 | 9394-004 | Hex Nut, 5/16"-18UNC | 2 | Grade 5 |
| 32 | 9399-079 | Set Screw, 5/16"-18UNC x 1 1/2" Cup Point/Hex Socket | 2 | |
| 33 | 9404-030 | Lock Washer, 5/8" | 4 | |
| 34 | 9394-014 | Hex Nut, 5/8"-11UNC | 4 | Grade 5 |
| 35 | 900058 | Draw Latch Base | 3 | |
| 36 | 9388-104 | Carriage Bolt, 1/2"-13UNC x 1 1/2" | 3 | Grade 5 |
| 37 | 94981 | Locknut, 1/2"-13UNC | 3 | |
| 38 | 9008466 | Lock Nut/Center Jam, 1/2"-13UNC | 2 | |
| 39 | 9388-103 | Carriage Bolt, 1/2"-13UNC x 1 1/4" G5 | 2 | |
| 40 | 283600B | Idler Assembly | 1 | Refer to "Idler Assembly Components" for parts list. |


Idler Assembly Components



Idler Assembly Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|---------------------|
| | 283600B | Idler Assembly | 1 | Includes Items 1-26 |
| 1 | 283601B | Idler Mount Weldment | 1 | |
| 2 | 283602B | Idler Arm Weldment | 1 | |
| 3 | 283603B | Idler Arm Weldment | 1 | |
| 4 | 283604B | Tensioner Weldment | 1 | |
| 5 | 283605 | Tensioner Rod Weldment | 2 | |
| 6 | 283619B | Idler Brace Plate | 1 | |
| 7 | 284703 | Tensioner Bushing Weldment | 1 | |
| 8 | 9003635 | Self-Lubricating Bushing, 1.4" OD x 1.25" ID x 3/4" | 6 | |
| 9 | 9003810 | Snap Ring, 3/4" | 2 | |
| 10 | 9005447 | Spring, 1.415" Dia. x 2 1/2" | 2 | |
| 11 | 9005684 | Idler Sub Assembly | 2 | |
| 12 | 9005685 | Machine Washer, 3/4" | 4 | |
| 13 | 9390-101 | Capscrew 1/2"-13UNC x 1 1/2" | 1 | Grade 5 |
| 14 | 9390-104 | Capscrew, 1/2"-13UNC x 2 1/4" | 1 | Grade 5 |
| 15 | 9390-149 | Capscrew, 3/4"-10UNC x 3" | 2 | Grade 5 |
| 16 | 9390-003 | Capscrew, 1/4"-20UNC x 3/4" | 2 | Grade 5 |
| 17 | 9395-010 | Hex Jam Nut, 1/2-13UNC | 1 | Grade 5 |
| 18 | 9404-033 | Lock Washer, 3/4" | 2 | |
| 19 | 9405-104 | Flat Washer, 3/4" | 4 | |
| 20 | 9405-106 | Flat Washer, 3/4" | 2 | |
| 21 | 94144 | Retaining Ring, 1 1/4" | 4 | |
| 22 | 94981 | Locknut, 1/2"-13UNC | 1 | |
| 23 | TA500397 | Bushing, 1.875"D x .074" | 2 | |
| 24 | 9404-017 | Lock Washer, 1/4" | 2 | |
| 25 | 9405-062 | Flat Washer, 1/4" SAE | 4 | |
| 26 | 9405-066 | Flat Fender Washer, 1/4" | 2 | |

Auger Tube Components



Auger Tube Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|--|----------|---------|
| , | 283518G | Cover Plate =Green= | 1 | |
| 1 | 283518R | Cover Plate =Red= |] ' | |
| 2 | 295240G | Lower Auger Housing Replacement Kit =Green= | 1 | |
| | 295240R | Lower Auger Housing Replacement Kit =Red= | ' | |
| 3 | 284438G | Upper Auger Housing Weldment =Green= | 1 | |
| 3 | 284438R | Upper Auger Housing Weldment =Red= | ' | |
| 4 | 289842 | Auger Hinge Pin | 1 | |
| 5 | 293960G | Auger Fold Linkage Weldment =Green= | 1 | |
| | 293960R | Auger Fold Linkage Weldment =Red= | | |
| 7 | 9003440 | Self Lube Bushing | 4 | |
| 8 | 272579G | Auger Support Weldment =Green= | 1 | |
| L ° | 272579R | Auger Support Weldment =Red= | ' | |
| 9 | 284549 | Pivot Pin, 1" Dia. x 13 1/16 | 1 | |
| 10 | 284555 | Pin Weldment, 1" Dia. (5 1/8) | 2 | |
| 11 | 284557 | Pin Weldment, 1" Dia. (4 7/8) | 1 | |
| 12 | 9004741 | Self Lubricating Bushing, 1.75 OD x 1.50 ID x 1 1/2 | 2 | |
| 10 | 289857G | Pivot Weldment =Green= | | |
| 13 | 289857R | Pivot Weldment =Red= | 2 | |
| 14 | 9003412 | Split Output Bushing (1" ID) | 2 | |
| 15 | 9003636 | Self Lube Bushing (1" ID) | 2 | |
| 16 | 284464B | Pivot Flange, Retainer Plate =Black= | 5 | |
| 17 | 284518B | Fold Plate, 6 x 8 =Black= | 1 | |
| 18 | 271119B | Fold Plate, 6 1/2 x 8 =Black= | 1 | |
| 19 | 271124 | Nylon Fold Slide, 2 x 8 | 4 | |
| 20 | 93415 | Zerk, 90° 1/4-28 Thread | 5 | |
| 21 | 9001688 | Flat Head Capscrew, 5/16-18UNC x 3/4 | 12 | |
| 22 | 9390-123 | Capscrew, 5/8-11UNC x 1 3/4 Grade 5 | 7 | |
| 23 | 9390-003 | Capscrew, 1/4-20UNC x 3/4 Grade 5 | 10 | |
| 24 | 91160 | Grease Zerk | 10 | |
| 25 | 91299-146 | Capscrew, 3/4-10UNC x 2 1/4 Grade 8 | 8 | |
| 27 | 9392-136 | Roll Pin, 1/4" Dia. x 1 1/2 | 5 | |
| 28 | 9405-098 | Flat Washer, 5/8" | 2 | Grade 5 |
| 29 | 902875 | Center Lock Nut, 3/8"-16UNC | 2 | |
| 30 | 9404-017 | Lock Washer, 1/4 | 10 | |
| 31 | 9404-034 | Lock Washer, 3/4 | 8 | |
| 32 | 9234PL | Flat Washer, 13/16 (Hardened) | 8 | |
| 34 | 9390-122 | Capscrew, 5/8-11UNC x 1 1/2 Grade 5 | 12 | |
| 35 | 9404-030 | Lock Washer, 5/8 | 19 | |
| 26 | 284493G | Middle Pivot Tube, 2 1/2 OD x 7 5/8 =Green= | 1 | |
| 36 | 284493R | Middle Pivot Tube, 2 1/2 OD x 7 5/8 =Red= | <u> </u> | |
| 37 | 9003757 | Gasket, 1/4 x 1/2 | 1 | |
| 38 | 9390-124 | Capscrew, 5/8-11UNC x 2 Grade 5 | 2 | |


(Continued on next page)

Auger Tube Components (continued)

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|-------|
| 39 | 266285 | Cylinder Pin, 1" Dia. x 4 1/2 | 1 | |
| 40 | 9003397 | Locking Flange Nut, 1/2-13UNC Grade 5 | 4 | |
| 41 | 272583 | Stop Bushing, 3/4 Dia. x 7/8 | 1 | |
| 42 | 9405-088 | Flat Washer, 1/2 USS | 2 | |
| 43 | 9001868 | Locking Collar, 3/4" | 1 | |
| 44 | 272376 | Lock Pin, 3/4 Dia. x 6 3/4 | 1 | |
| 45 | 9392-182 | Roll Pin, 3/8 Dia. x 2 1/2 | 2 | |
| 46 | 9000933 | Auger Tilt Hydraulic Cylinder, 3 x 22" 3000 PSI | 1 | |
| 47 | 9004772 | Spring | 1 | |
| 48 | 9391-046 | Cotter Pin, 3/16 Dia. x 2 | 4 | |
| 49 | 272574 | Pad, 1/2 x 3 x 6 1/2 | 2 | |
| F0 | 272553G | Auger Rest Weldment =Green= | 1 | |
| 50 | 272553R | Auger Rest Weldment =Red= | 1 | |
| 51 | 903171-662 | Flat Head Machine Screw, 5/16-18UNC x 1 1/4 | 4 | |
| 52 | 91266 | Flange Screw, 1/2-13UNC x 1 1/4 Grade 5 | 4 | |
| 53 | 91257 | Large Hex Flange Nut, 5/16-18UNC Grade 5 | 4 | |
| 54 | 284687 | Fold Linkage Weldment | 2 | |
| 55 | 272587 | Pin, 1 Dia. x 3 1/8 | 2 | |
| 56 | 91192 | Retaining Ring, 1" | 4 | |
| 57 | 9006491 | Clevis | 2 | |
| 58 | 9004730 | Hydraulic Cylinder, 3 x 22" - 3000 PSI | 1 | |
| 59 | 92424 | Hairpin Cotter | 1 | |
| 60 | 294462B | Cover Plate | 1 | |
| 61 | 900060 | Handle for Draw Latch | 3 | |
| 62 | 900068 | Retainer for Draw Latch | 3 | |
| 63 | 900066 | Stud Pin for Draw Latch | 3 | |
| 64 | 900067 | Washer for Draw Latch | 3 | |
| 66 | 9394-016 | Hex Nut 3/4-10UNC | 2 | |
| 67 | 94733 | Capscrew 3/4"-10UNC x 3" Full Threaded | 2 | |
| 68 | 9003398 | Locknut 5/8"-11UNC | 1 | |
| 69 | 293385 | Auger Linkage Pin Weldment | 2 | |
| 70 | 9390-005 | Capscrew, 1/4"-20UNC x 1" Grade 5 | 2 | |
| 71 | 9008559 | Cable Clamp, 1 1/2" Dia. x 3/4" (SS) | 2 | |
| 72 | 91262 | Flange Screw, 3/8"-16UNC x 1" Grade 5 | 2 | |
| 73 | 91263 | Flange Nut, 3/8"-16UNC | 2 | |
| 74 | 250104 | Pin 1" Dia. x 4" | 1 | |
| 75 | 804572 | Pin 1" Dia. x 3 1/2" | 1 | |


| Notes |
|--|
| Please visit www.unverferth.com/parts/ for the most current parts listing. |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

Auger Grease Bank Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-------------------------------------|-----|-------------------------------------|
| 1 | 9008965 | Grease Hose 3/16" x 74" (1/8" NPT) | 1 | Lower Vertical Auger Hanger Bearing |
| 2 | 9008967 | Grease Hose 3/16" x 126" (1/8" NPT) | 2 | Upper Auger Pivot Pin |
| 3 | 9008961 | Grease Hose 3/16" x 48" (1/8" NPT) | 1 | |
| 4 | 9008960 | Grease Hose 3/16" x 44" (1/8" NPT) | 1 | |
| 5 | 9008958 | Grease Hose 3/16" x 30" (1/8" NPT) | 1 | |
| 6 | 9008959 | Grease Hose 3/16" x 38" (1/8" NPT) | 1 | Vertical Auger Tilt Pivot Rings |
| 7 | 9008962 | Grease Hose 3/16" x 55" (1/8" NPT) | 1 | |
| 8 | 9008964 | Grease Hose 3/16" x 70" (1/8" NPT) | 1 | |
| 9 | 9008963 | Grease Hose 3/16" x 58" (1/8" NPT) | 1 | |
| 10 | 9008968 | Grease Hose 3/16" x 134" (1/8" NPT) | 1 | Drag Auger Center Bearing |
| 11 | 9003949 | Coupler 1/8" NPT | 11 | |
| 12 | 93426 | Grease Zerk | 11 | |
| 13 | 9006849 | Grease Zerk Cap | 11 | |


EOH Valve Functions and Wire Locations Optional




| PORT | END OF CYLINDER | FUNCTION |
|------|-----------------|------------------------------|
| Α | BUTT END | Flow Door |
| В | RAM END | Flow Door |
| С | RAM END | Auger Fold |
| D | BUTT END | Auger Fold |
| E | RAM END | Spout Tilt Out |
| F | BUTT END | Spout Tilt In |
| G | RAM END | Spout Rotate Back |
| Н | BUTT END | Spout Rotate Front |
| I | BUTT END | Auger Tilt Down |
| J | RAM END | Auger Tilt Up |
| Р | | Tractor Pressure |
| Т | | Tractor Return |

EOH Valve Assembly Components Optional


Please visit www.unverferth.com/parts/ for the most current parts listing.







Cartridge Valve (9008416) & (9008463) Middle Detent Position




NOTE: Refer to "Manual Override for Optional Electric Over Hydraulic System" in OPERATION section.

EOH Valve Assembly Components Optional

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--|------|--|
| 1 | 293416 | EOH Block Assembly - 5 Spool Replacement Kit | 1 | Includes Items 2-7 and Instruction Sheet |
| 2 | 9003856 | Pilot Check Valve | 4 | |
| 3 | 9005769 | Coil - 12 VDC DN-40 | 11 | |
| 4 | 9008667 | Manifold Block - 5 Spool | 1 | |
| 5 | 9008416 | Cartridge Valve - 4 Way, 3 Position - Closed Center w/Detented Manual Override | 3 | Includes Retaining Cap |
| | 9003906 | Seal Kit | - | |
| 6 | 9008463 | Cartridge Valve - 4 Way, 3 Position - Open Center w/Detented Manual Override | 2 | Includes Retaining Cap |
| | 9003906 | Seal Kit | - | |
| 7 | 9008438 | Cartridge Valve - 2 Way, 2 Position w/Push Type Manual Overide | 1 | |
| | 9003904 | Seal Kit | - | |


EOH Tractor Circuit Hydraulic Components (Optional)



EOH Tractor Circuit Hydraulic Components (Optional)

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|---|
| 1 | 95802 | Hydraulic Hose, 1/2 x 205" - 3000 PSI | 1 | |
| 2 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 1 | |
| 3 | 9008601 | Hose Grips - Tan (Pair) - Hydraulic Return | 1 | Half Tan/Half Gray - Cylinder Retracted |
| 4 | 9008601 | Hose Grips - Tan (Pair) - Hydraulic Pressure | 1 | Solid Tan - Cylinder Extended |
| 5 | 9006527 | JIC Tube Reducer 9/16-18 UNF Male x 9/16-UNF Female | 1 | |
| 6 | 901568 | Elbow, 90° Extra Long 3/4-16 JIC x 3/4-16 Male 0-Ring | 1 | |
| 7 | 91257 | Large Flange Hex Nut, 5/16-18UNC Gr.5 | 3 | |
| 8 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 9 | 98508 | Adapter 3/4-16 O-Ring Male x 3/4-16 O-Ring Male | 2 | |
| 10 | 9006994 | Check Line Valve 145 PSI | 1 | |
| 11 | 9390-042 | Capscrew, 5/16-18UNC x 4 Gr.5 | 3 | |
| 12 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 1 | |
| 13 | 294462B | Valve Cover Plate | 1 | Also Order Item #15 |
| 14 | 9005403 | 120 Micron Hydraulic Filter | 1 | |
| 15 | 9008564 | Decal, CAUTION (Valve Block) | 1 | Add To Inside Cover Plate #13 |


Spout Rotate and Tilt Hydraulic Components



Spout Rotate and Tilt Hydraulic Components


| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--|------|--|
| 1 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 9 | For EOH Option (Optional) |
| 2 | 9007124 | Hydraulic Cylinder, 1 1/2 x 3 - 3000 PSI | 1 | |
| 3 | 9003814 | Clamp Top Plate, 1/4 x 1 1/8 x 2 1/16 | 2 | |
| 4 | 9003816 | Clamp, Polypropylene | 3 | |
| 5 | 9004379 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 OR ADJ Male | 1 | |
| 6 | 9005135 | Hydraulic Cylinder, 1 1/2 x 8 - 3000 PSI | 1 | |
| 7 | 9006579 | Hydraulic Hose, 1/4 x 321" - 3000 PSI | 2 | |
| 8 | 9006580 | Hydraulic Hose, 1/4 x 312" - 3000 PSI | 2 | |
| 9 | 9006581 | Hydraulic Hose, 1/4 x 295" - 3000 PSI | 1 | |
| 10 | 9006582 | Hydraulic Hose, 1/4 x 290" - 3000 PSI | 1 | |
| 11 | 91257 | Large Flange Hex Nut, 5/16-18UNC Grade 5 | 1 | |
| 12 | 9390-031 | Capscrew, 5/16-18UNC x 1 1/4 Grade 5 | 1 | |
| 13 | 9390-037 | Capscrew, 5/16-18UNC x 2 3/4 Grade 5 | 1 | |
| 14 | 95193 | Adapter, 9/16-18 JIC Female x 9/16-18 JIC Male | 5 | |
| 15 | 98435 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 4 | |
| 16 | 9876 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Female | 1 | |
| 17 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 18 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 19 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 20 | 9008598 | Hose Grips - Yellow (Pair) - Spout Out | 1 | Solid Yellow - Cylinder Extended |
| 21 | 9008598 | Hose Grips - Yellow (Pair) - Spout In | 1 | Half Yellow/Half Gray - Cylinder Retracted |

Auger Tilt Hydraulic Components




| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|--|
| 1 | 9000925 | Hydraulic Hose, 1/4 x 78" - 3000 PSI | 2 | |
| 2 | 9000933 | Hydraulic Cylinder, 3 1/2 x 20 - 3000 PSI | 1 | |
| 3 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 9 | Optional |
| 4 | 9002155 | Tee, 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 1 | |
| 5 | 9002719 | Accumulator - 1800 PSI | 1 | |
| 6 | 9002720 | Adapter, 3/4-16 OR Male x 9/16-18 JIC Female | 1 | |
| 7 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 6 | |
| 8 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 9 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 10 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 11 | 9008599 | Hose Grips - Blue (Pair) - Auger Pivot Up | 1 | Half Blue/Half Gray - Cylinder Retracted |
| 12 | 9008599 | Hose Grips - Blue (Pair) - Auger Pivot Down | 1 | Solid Blue - Cylinder Extended |

Auger Fold Hydraulic Components




| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|---|
| 1 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 9 | Optional |
| 2 | 9002199 | Reducer, 9/16-18 JIC Female x 9/16-18 JIC Male | 1 | 0.060 Restrictor |
| 3 | 9004730 | Hydraulic Cylinder, 3 x 22" - 3000 PSI | 1 | |
| 4 | 9006608 | Hydraulic Hose, 1/4 x 84" - 3000 PSI | 1 | |
| 5 | 93594 | Hydraulic Hose, 1/4 x 59" - 3000 PSI | 1 | |
| 6 | 9003303 | Adapter, 9/16-18 JIC Female x 9/16-18 JIC Male | 1 | 0.045 (Blue) Restrictor |
| 7 | 9874 | Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male | 6 | |
| 8 | 9897 | Elbow, 90° 9/16-18 JIC Male x 9/16-18 JIC Male | 2 | |
| 9 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 10 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 11 | 9008597 | Hose Grips - Green (Pair) - Auger Raise | 1 | Solid Green - Cylinder Extended |
| 12 | 9008597 | Hose Grips - Green (Pair) - Auger Lower | 1 | Half Green/Half Gray - Cylinder Retracted |

Steering Tandem Valve Hydraulic Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|---------------------------------------|
| 1 | 9004854 | Cylinder, 2 1/2 x 8 | 2 | |
| 2 | 91383 | Male Coupler | 8 | 3/4-16 F O-Ring |
| 3 | 9864 | Adapter | 2 | 3/4-16 JIC M x 3/4-16 M O-Ring |
| 4 | 9863 | 90° Elbow | 2 | 3/4-16 JIC M x 3/4-16 M O-Ring |
| 5 | 9001495 | Adapter | 2 | 9/16-18 JIC M x 9/16-18 M O-Ring |
| 6 | 9004881 | Hose, 1/2 x 153" | 1 | 3/4-16 JIC F x 3/4-16 JIC F |
| 7 | 9004882 | Hose, 1/2 x 73" | 2 | 3/4-16 JIC F 90° Elbow x 3/4-16 JIC F |
| 8 | 98057 | Hose, 1/4 x 372" | 2 | 9/16-18 JIC F x 3/4-16 M O-Ring |
| 9 | 9004831 | Sleeve, Hose Marker | 1 | Grey, Turn Left |
| 10 | 9004832 | Sleeve, Hose Marker | 1 | Grey, Turn Right |
| 11 | 9008730 | Steering Valve, 2800 PSI | 1 | Includes Items 15, 16, 17 |
| 12 | 9390-009 | Capscrew, 1/4-20UNC x 2 | 2 | Grade 5 |
| 13 | 9404-017 | Lock Washer, 1/4 | 2 | |
| 14 | 93586 | 45° Elbow | 2 | |
| 15 | 9008731 | Valve, 2-Position, 2-Way with Coil, 12V DC | 1 | |
| 16 | 9005664 | Pressure Relief Valve | 2 | |
| 17 | 9005665 | Valve Block | 1 | 7 |


Flow Door Circuit Hydraulic Components



| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|---|------|---|
| 1 | 9001495 | Adapter, 9/16-18 JIC Male x 9/16-18 OR Male | 9 | Optional |
| 2 | 9002575 | Hydraulic Cylinder, 3 x 16" - 3000 PSI | 1 | |
| 3 | 9004442 | Hydraulic Hose, 1/4 x 54" - 3000 PSI | 1 | |
| 4 | 9006607 | Hydraulic Hose, 1/4 x 50" - 3000 PSI | 1 | |
| 5 | 93472 | Hydraulic Hose, 1/4 x 16" - 3000 PSI | 1 | |
| 6 | 9002888 | Hydraulic Hose, 1/4 x 27" - 3000 PSI | 1 | |
| 7 | 95192 | Bulkhead Union | 2 | 9/16-18 JIC Male x 9/16-18 JIC Male |
| 8 | 9874 | Elbow, 90° | 6 | 9/16-18 JIC Male x 3/4-16 OR ADJ Male |
| 9 | 91383 | Male Tip Coupling, 3/4-16 | 2 | |
| 10 | 9897 | Elbow, 90° | 2 | 9/16-18 JIC Male x 9/16-18 JIC Male |
| 11 | 9005574 | Hydraulic Hose, 1/4 x 208" - 3000 PSI | 2 | |
| 12 | 9008596 | Hose Grips - Red (Pair) - Flow Door Open | 1 | Solid Red - Cylinder Extended |
| 13 | 9008596 | Hose Grips - Red (Pair) - Flow Door Close | 1 | Half Red/Half Gray - Cylinder Retracted |

Cylinders

Please visit www.unverferth.com/parts/ for the most current parts listing.



Auger Fold Cylinder - 3" x 22"

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|-------|
| | 9004730 | Cylinder, Complete | 1 | |
| 1 | 9003772 | Seal Kit | 1 | |

Auger Flow Door Cylinder - 3" x 16"

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|-------|
| | 9002575 | Cylinder, Complete | 1 | |
| 1 | 9003772 | Seal Kit | 1 | |

Auger Tilt Cylinder - 3 1/2" x 20"


| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|-------|
| | 9000933 | Cylinder, Complete | 1 | |
| 1 | 9001081 | Seal Kit | 1 | |

Auger Spout Tilt Cylinder - 1 1/2" x 8"

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|------------------------------------|
| | 9005135 | Cylinder, Complete | 1 | #6 9/16-18 0-Ring Ports (3000 PSI) |
| 1 | 9005419 | Seal Kit | 1 | |

Cylinders (continued)

Please visit www.unverferth.com/parts/ for the most current parts listing.



Optional Spout Rotate Cylinder - 1 1/2" x 4"

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|-------|
| | 9007124 | Cylinder, Complete | 1 | |


Steering Tandem Cylinder - 2 1/2" x 8"

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|-------|
| | 9004854 | Cylinder, Complete | 2 | |
| 1 | 91387 | Seal Kit | 2 | |

Optional Jack Cylinder - 3 1/2" x 8"

| ITEM | PART NO. | DESCRIPTION | QTY. | NOTES |
|------|----------|--------------------|------|-------|
| | 9009047 | Cylinder, Complete | 1 | |
| 1 | 9007880 | Seal Kit | 1 | |


Hopper Flow Door Components



Hopper Flow Door Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|---|-----|---|
| 1 | 294156B | Flow Door Linkage Kit =Black= | 1 | |
| 2 | 284721B | Restrictor Weldment | 8 | |
| 3 | 284723B | Center Door Weldment Left-Hand | 1 | |
| 4 | 284724B | Center Door Weldment Right-Hand | 1 | |
| 5 | 266285 | Idler Pin 1" Dia. x 4 1/2 | 1 | |
| 6 | 271112 | Idler Pin 1" Dia. x 4 | 1 | |
| 7 | 294072B | Front Tent Service Kit =Black= | 1 | Includes: Front Tent Weldment, Baffle Plates, Spray Paint & Instruction Sheet |
| 8 | 294073B | Rear Tent Service Kit =Black= | 1 | Includes: Rear Tent Weldment, Baffle Plates, Spray Paint & Instruction Sheet |
| 9 | 284889B | Flow Door Service Kit (Black) | 1 | Includes Items: 10, 11, 12, 13, 17, 28, 29, 30, 31 |
| 10 | 284855B | Front Door Weldment Left-Hand =Black= | 1 | |
| 11 | 284854B | Front Door Weldment Right-Hand =Black= | 1 | |
| 12 | 284850B | Rear Door Weldment Left-Hand =Black= | 1 | |
| 13 | 284849B | Rear Door Weldment Right-Hand =Black= | 1 | |
| 14 | 282488B | Cover Plate =Black= | 1 | |
| 15 | 804572 | Pin 1" Dia. x 3 1/2 | 1 | |
| 16 | 9002575 | Cylinder 3x16 | 1 | |
| 17 | 9003396 | Locknut 3/8-16UNC | 16 | |
| 19 | 9390-103 | Capscrew 1/2-13UNC x 2 Grade 5 | 4 | |
| 20 | 9391-046 | Cotter Pin 3/16" Dia. x 2 | 6 | |
| 21 | 9394-010 | Hex Nut 1/2-13UNC Grade 5 | 4 | |
| 22 | 9404-025 | Lock Washer 1/2" | 4 | |
| 23 | 95585 | Capscrew/Large Flange 3/8-16UNC x 3/4 | 68 | Grade 5 |
| 24 | 9874 | 90° Elbow 9/16-18 JIC Male x 3/4-16 O-Ring Adj Male Boss | 2 | |
| 25 | 93426 | Grease Zerk | 1 | |
| 26 | 9005073 | Quicklinc Fitting 1/4 Tube x 1/8 NPT Straight | 1 | |
| 27 | 9005074 | Tube, Nylon 1/4" OD | 1 | |
| 28 | 284168 | Spacer Bushing, 2 1/4 OD x 1/2 | 16 | |
| 29 | 284169 | Roller Bushing | 16 | |
| 30 | 9005471 | Flat Washer, 3/8 | 16 | |
| 31 | 91299-057 | Capscrew, 3/8-16UNC x 1 1/2 | 16 | |
| 32 | 9008159 | Automation Lock Nut/Top 3/8"-16UNC | 68 | Grade F |
| 33 | 91263 | Nut/Large Flange 3/8"-16UNC Grade 5 | 24 | |
| 34 | 9005072 | Quicklinc Fitting 1/4 Tube x 1/8 NPT Elbow | 1 | |


Optional Spout Rotate Switch Assembly Components



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|------------------------------------|-----|-------|
| 1 | 295174B | Switch Plate Bracket =Black= | 1 | |
| 2 | 9007223 | Proximity Sensor with Connector | 1 | |
| 3 | 97420 | Flange Screw, 1/4-20UNC x 3/4 Gr.5 | 2 | |
| 4 | 97189 | Large Flange Nut, 1/4-20UNC | 2 | |

| Notes |
|--|
| Please visit www.unverferth.com/parts/ for the most current parts listing. |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |


Downspout Components



Downspout Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------------|--|-----|------------------|
| 1 | 9004899 | Spring-Compression | 4 | |
| 2 | 9404-025 | Lock Washer, 1/2 | 15 | |
| 3 | 9404-030 | Lock Washer, 5/8 EXTRA | 20 | |
| 4 | 95585 | Capscrew/Lrg Flg, 3/8-16UNC x 3/4 Gr.5 | 4 | |
| 5 | 9801 | Locknut/Top, 5/8-11UNC | 4 | |
| 6 | 91257 | Flange Nut, 5/16-18UNC | 10 | |
| 7 | 9390-137 | Capscrew, 5/8-11UNC x 6 1/2 Gr.5 | 4 | |
| 8 | 93974 | Washer, 3 x 2 | 4 | |
| 9 | 91178 | Retaining Ring | 1 | |
| 10 | 272620B | Plate-Hose Bracket | 1 | |
| 11 | 9003816 | Poly Clamp Pair (0.54) | 7 | |
| 12 | 9003814 | Top Plate | 6 | |
| 13 | 9390-037 | Capscrew, 5/16-18UNC x 2 3/4 Gr.5 | 1 | |
| 14 | 9390-132 | Capscrew, 5/8-11UNC x 4 Gr.5 | 1 | |
| 15 | 284691B | Bracket-Linkage | 1 | |
| 16 | 285290 | Bushing-Sleeve | 3 | |
| 17 | 9876 | Elbow, 9/16-18 JIC M/F | 2 | |
| 18 | 285219 | Pin Weldment | 2 | |
| 19 | 9005687 | Snap Ring, 1/2" | 2 | |
| 20 | 9405-086 | Flat Washer, 1/2 SAE | 2 | |
| 21 | 284699B | Linkage Weldment | 1 | |
| 22 | 9390-108 | Capscrew, 1/2-13UNC x 3 1/4 Gr.5 | 1 | |
| 23 | 272619 | Bushing-Sleeve | 1 | |
| 24 | 268905 | Bushing Spacer | 2 | |
| 25 | 272571 | Bushing-Sleeve | 1 | |
| 26 | 9390-111 | Capscrew, 1/2-13UNC x 4 Gr.5 | 1 | |
| 27 | 9390-032 | Capscrew, 5/16-18UNC x 1 1/2 Gr.5 | 1 | |
| 28 | 272570B | Plate-Hose Bracket | 1 | |
| 29 | 91263 | Large Flange Nut, 3/8-16UNC | 4 | |
| 30 | 9390-038 | Capscrew, 5/16-18UNC x 3 Gr.5 | 2 | |
| 31 | 284986 | Pin Weldment-Pivot, Hood | 1 | |
| 32 | 95193 | Adapter 9/16-18 JICF x 9/16-18 JICM | 2 | 0.030 Restrictor |
| 33 | 9876 | 90° Elbow 9/16-18 JICF x 9/16-18 JICM | 2 | |
| 34 | 295174B | Plate-Switch Bracket | 1 | |
| 35 | 271338B | Linkage Weldment =Black= | 1 | |
| 36 | 9390-034 | Capscrew, 5/16-18UNC x 2 Gr.5 | 3 | |
| 37 | 9007124 | 1 1/2" x 3" Hydraulic Cylinder | 1 | |
| 38 | 97189 | Large Flange Nut, 1/4-20UNC | 2 | |
| 39 | 97420 | Flange Screw, 1/4-20UNC x 3/4" Gr.5 | 2 | |

Rotating Spout Components



Rotating Spout Components


Please visit www.unverferth.com/parts/ for the most current parts listing.

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|--------|------------|--|-----|-----------------------------|
| 112101 | 295161B | | | Includes Items 1 through 34 |
| 1 | 268571 | Sleeve Bushing 3/4 Dia. x 0.532 Dia. x 2 3/8 | 1 | moldado Italia i anough di |
| 2 | 295163B | Spout Weldment =Black= | 1 | |
| 3 | 295162B | Hood Weldment =Black= | 1 | |
| 4 | 272562B | Deflector Weldment =Black= | 1 | |
| 5 | 272565B | Strap Chute Plate =Black= | 2 | |
| 6 | 272646B | Light Bracket =Black= | 1 | |
| 7 | 272596 | Pivot Shaft | 1 | |
| 8 | 272599 | Wear Ring | 1 | |
| 9 | 272600B | Hood Shim Plate =Black= | 1 | |
| 10 | 273656 | Sleeve Bushing 3/4 Dia. x 0.532 Dia. x 1 11/16 | 1 | |
| 11 | 9001495 | Adapter 9/16-18 JIC Male x 9/16-18 OR Male | 1 | |
| 12 | 903171-660 | Flat Countersunk Head Machine Screw 5/16"-18UNC x 1" | 4 | |
| 13 | 9003810 | External Retaining Ring 3/4" | 2 | |
| 14 | 9005085 | Self Lubricating Bushing | 1 | |
| | 9005135 | Cylinder 1 1/2 x 8 | 1 | |
| 15 | 9005419 | Seal Kit | 1 | |
| 16 | 9008122 | Trim-Lok | 7 | |
| 17 | 9006421 | Auger Hood 22" | 1 | |
| 18 | 9008957 | Work Light LED | 3 | |
| 20 | 91257 | Hex Flange Nut 5/16-18 Grade 5 | 8 | |
| 21 | 9388-003 | Carriage Bolt 1/4-20 x 1 Grade 5 | 8 | |
| 22 | 9390-005 | Capscrew 1/4-20 UNC x 1 Grade 5 | 6 | |
| 23 | 9390-105 | Capscrew 1/2-13 UNC x 2 1/2 Grade 5 | 1 | |
| 24 | 9390-108 | Capscrew 1/2-13 UNC x 3 1/4 Grade 5 | 1 | |
| 25 | 97420 | Flange Screw, 1/4-20 x 3/4 Grade 5 | 4 | |
| 26 | 903171-660 | Flat Head Machine Screw 5/16-18 UNC x 1 | 4 | |
| 27 | 9404-025 | Split Lock Washer, 1/2 | 2 | |
| 28 | 9405-066 | Fender Washer 1/4" | 8 | |
| 29 | 9405-088 | Flat Washer 1/2 USS | 2 | |
| 30 | 94763 | Fender Washer, 2" OD x 5/16 ID | 12 | |
| 31 | 95193 | 95193 Adapter 9/16-18 JIC Female x 9/16-18 JIC Male | | |
| 32 | 97189 | Large Hex Flange Nut 1/4-20 UNC Grade 5 | 18 | |
| 33 | 97445 | Elbow 90° 9/16-18 JIC Male x 9/16-18 OR ADJ Male | 1 | |
| 34 | 272841B | Light Bracket | 1 | |

NOTE: If installing UHarvest centering sensors on an older unit, the hood 273635B and pivot pin 284986 needs replaced.




Cut Out Clutch PTO Assembly



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|---|-----|--------------------------------|
| | 9005230 | PTO Assembly Complete | | Includes Items 21 & 22 |
| 1 | 9005234 | Over-Running PTO Clutch Assembly | 1 | 1 3/4-20 Spline 1000RPM |
| 2 | 92529 | Cross & Bearing Kit | 2 | |
| 3 | 9002609 | Spring Pin 10x90 | 2 | |
| 4 | 9002610 | Inboard Yoke S4 | 1 | |
| 5 | 9004840 | Inner Profile | 1 | |
| 6 | 9004841 | Outer Profile | 1 | |
| 7 | 9002613 | Inboard Yoke S5 | 1 | |
| 8 | 9005235 | Cut Out Clutch (3200 N-m Setting) | 1 | 1 3/4-20 Spline 1000RPM |
| 9 | 9002615 | Shield Cone 7 Rib | 1 | |
| 10 | 9004843 | Outer Shield Tube Oval | 1 | |
| 11 | 9004844 | Inner Shield Tube Oval | 1 | |
| 12 | 92373 | Bearing Ring | 2 | |
| 13 | 92374 | Safety Chain | 1 | |
| 14 | 92372 | Screw | 2 | |
| 15 | 92377 | Decal Out | 1 | |
| 16 | 92378 | Decal In | 1 | |
| 17 | 93866 | Shield Cone 6 Rib | 1 | |
| 18 | 9005233 | Decal K64 | 1 | "Tighten to 75 FtLbs." |
| 19 | 93856 | Quick-Disconnect Kit | 1 | 1 3/4-20 Spline w/Metal Collar |
| 20 | 9005253 | Clutch Clamp Cone Assembly | 1 | |
| 21 | 9005231 | PTO Front Half Assembly 1 3/4-20 Spline | 1 | |
| 22 | 9005232 | PTO Rear Half Assembly 1 3/4-20 Spline | 1 | |
| 23 | 9002513 | Reinforcing Collar | 1 | NOT SHOWN |

Cut Out Clutch Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



NOTE: Cut Out Clutch (9005235) must be used with the Complete PTO Assembly (9005230). This will not work with the Standard PTO Assembly (9005245).

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|-----------------------------------|-----|--------------------|
| | 9005235 | Cut Out Clutch (3500 N*m Setting) | | Includes Items 1-8 |
| 1 | 9005247 | Clutch Housing | 1 | |
| 2 | 9005248 | Clutch Hub 1 3/4-20 Spline | 1 | |
| 3 | 9005249 | Spring Pack | 1 | |
| 4 | 9005250 | Washer | 1 | |
| 5 | 9005251 | Retaining Ring | 1 | |
| 6 | 9005252 | Sealing Ring | 1 | |
| 7 | 9005253 | Clutch Clamp Cone Assembly | 1 | |
| 8 | 9005254 | Clutch Cam | 4 | |


Gearbox Components



Gearbox Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|-----------------------------|
| | 9009060 | Gearbox Complete | 1 | Includes Items 1 through 22 |
| 1 | 9003453 | Reducer Bushing, 1/2-14 NPTF M x 1/8-27 NPTF F | 1 | |
| 2 | 9006381 | Glass Sight Plug | 1 | |
| 3 | 9009431 | Gearbox Housing Q800 w/Tapped Holes | 1 | |
| 4 | 9009430 | Gearbox Housing Q800 w/Through Holes | 1 | |
| 5 | 9007494 | Gearbox Shaft 2 1/4" Dia. | 1 | |
| 6 | 9007495 | Gear Shaft Assembly 29 Tooth, 2 1/4-17 Spline | 1 | |
| 7 | 9007496 | Gear 16 Tooth Splined | 1 | |
| 8 | 9007497 | Bearing Cup & Cone Set, 3.740 OD x 1 1/4 | 1 | |
| 9 | 9007498 | Bearing Cone 2 1/4 ID x 1 | 2 | |
| 10 | 9007499 | Bearing Cup 3.8437 OD x 0.7812 | 2 | |
| 11 | 9007500 | Bearing Cone 2 ID x 1.5312 | 1 | |
| 12 | 9007501 | Bearing Cup 4.125 OD | 1 | |
| 13 | 9007502 | End Cap | 1 | |
| 14 | 9007503 | Retaining Ring - External 2" Nominal Shaft Dia. | 1 | |
| 15 | 9007504 | Shim - 0.025 | 1 | |
| 16 | 9007505 | Shim - 0.030 | 1 | |
| 17 | 9007508 | Shaft Seal | 2 | |
| 18 | 9007511 | Shim - 0.005 | 2 | |
| 19 | 9007512 | Shim - 0.003 | 1 | |
| 20 | 903161-060 | Flange Screw 1/2-13UNC x 2 1/2 | 12 | |
| 21 | 92352 | Pressure Relief | 1 | |
| 22 | 95283 | Plug | 3 | |


Indicator Assembly



Indicator Assembly

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|------------------------------|-----|-----------------------------|
| | 271584 | Complete Indicator Assembly | 1 | Includes Items 1 through 17 |
| 1 | 271582 | Push Rod Indicator | 1 | |
| 2 | 271585 | Bushing - Coupler | 1 | |
| 3 | 271589 | Cable Tube (Push Rod) | 1 | |
| 4 | 271593 | Reducer Bushing | 1 | |
| 5 | 271595R | Flow Door Indicator =Red= | 1 | |
| 6 | 9006610 | Seal (Wiper) | 1 | |
| 7 | 9006611 | Inner Cable (Conduit) - 3/16 | 1 | |
| 8 | 9008612 | Seal (Shaft) | 1 | |
| 9 | 9006630 | Rod End, 3/8" | 1 | |
| 10 | 9006634 | Connector Fitting | 1 | |
| 11 | 9006635 | Quad Ring | 1 | |
| 12 | 9006636 | Wear Ring | 1 | |
| 13 | 271597 | Wire Stop | 1 | |
| 14 | 9006640 | Hose Fitting | 1 | |
| 15 | 9006641 | Snap Ring | 1 | |
| 16 | 9006644 | Retaining Ring - Internal | 1 | |
| 17 | 271586 | Plastic Tubing - 81" | 1 | |


Hopper Rear Electrical Components



Hopper Rear Electrical Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|----------------------------------|-----|-------|
| 1 | 282305G | Upper Harness Cover =Green= | 2 | |
| | 282305R | Upper Harness Cover =Red= | | |
| 2 | 282307B | SMV Bracket | 1 | |
| 2 | 282308G | Harness Cover Plate RH =Green= | | |
| 3 | 282308R | Harness Cover Plate RH =Red= | l | |
| 4 | 282309G | Harness Cover Plate LH =Green= | 1 | |
| 4 | 282309R | Harness Cover Plate LH =Red= | l | |
| 5 | 284358B | Lamp Assembly LH | 1 | |
| 6 | 284359B | Lamp Assembly RH | 1 | |
| 7 | 9390-003 | Capscrew 1/4-20UNC x 3/4 Grade 5 | 14 | |
| 8 | 9394-002 | Hex Nut 1/4-20UNC Grade 5 | 14 | |
| 9 | 9404-017 | Lock Washer 1/4" | 14 | |
| 10 | 9405-064 | Flat Washer 1/4" | 10 | |
| 11 | 9829 | SMV Emblem | 1 | |

Electrical Components




Electrical Components

| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|------------|---|-----|---------------------------------------|
| 1 | 272645B | Switch Plate Bracket =Black= | 1 | |
| 2 | 252386 | Plug Assembly, 2 Pin Shroud | 1 | |
| 3 | 9008969 | Wiring Harness - 226" (w/2-Pin Connectors) | 1 | |
| 4 | 9005618 | Relay - 12VDC | 4 | |
| 5 | 271574B | Lamp Mount Plate =Black= | 1 | |
| 7 | 9830-016 | Hex Nut, #10-32 | 4 | Grade 2 |
| 8 | 9008957 | Work Light (LED) (w/2-Pin Connector) | 4 | |
| 10 | 9008956 | Switch Wiring Harness (w/2-Pin Shroud Connectors) | 1 | |
| 11 | 9007223 | Proximity Switch | 2 | |
| 12 | 9008252 | Joystick Controller Extension Harness | 1 | |
| 13 | 903172-350 | Phillips Pan Head Screw, #10-32UNF x 1-1/4" | 4 | |
| 14 | 9008501 | Front Harness - 296" (w/2 Pin Shroud Connectors) | 1 | |
| 15 | 9004858 | Steering Valve | 1 | |
| 16 | 9006282 | LED Lamp - Red | 2 | |
| 17 | 232170 | LED Lamp - Red - Replacement Kit | 2 | Includes Lamp, & Items 7, 13, 16 & 26 |
| 18 | 9005142 | LED Lamp - Amber | 2 | |
| 19 | 9006107 | Micro Dot, LED Amber Light | 6 | |
| 20 | 97420 | Flange Screw, 1/4-20 x 3/4 | 2 | Grade 5 |
| 21 | 9005654 | Rocker Switch Assembly | 1 | |
| 22 | 293416 | EOH Block Assembly - 5 Spool Replacement Kit | 1 | |
| 23 | 9008265 | L-Series Control Grip - 5 Function | 1 | |
| 24 | 9006480 | Rear Harness | 1 | |
| 25 | 9006520 | Clearance Harness | 2 | |
| 26 | 9404-013 | Lock Washer, #10 | 4 | |
| 27 | 9006907 | Power Harness, 2-Pin | 1 | |
| 28 | 9007290 | "T" Main Wiring Harness - 189" | 1 | |
| 29 | 9007286 | Wiring Harness - 205" EOH for Proximity Switch | 1 | |
| 32 | 9005993 | Wiring Harness - 588" | 1 | |
| 33 | 91262 | Large Flange Screw, 3/8-16 x 1 | 2 | Grade 5 |
| 34 | 91263 | Large Flange Nut, 3/8-16UNC | 2 | Grade 5 |
| 35 | 92450 | 7-Way Plug | 1 | |
| 36 | 284358B | Lamp Assembly Left-Hand | 1 | |
| 37 | 284370B | Lamp Mount Weldment Left-Hand | 1 | |
| 38 | 9003125 | Reflector 2 x 9 Fluorescent - Red / Orange | 2 | |
| 39 | 9003126 | Reflector 2 x 9 =Red= | 2 | |
| 40 | 9003127 | Reflector 2 x 9 = Amber= | 2 | |
| 41 | 284359B | Lamp Assembly Right-Hand | 1 | |
| 42 | 284371B | Lamp Mount Weldment Right-Hand | 1 | |
| 43 | 283788B | Mounting Bracket =Black= | 1 | |
| 44 | 9008251 | Harness - Joystick Power | 1 | |
| 45 | 86700 | Wiring Extension 120" (2 Pin) | 1 | |
| 46 | 9007266 | Wire Harness, 218 5/16" (2 Pin Diverter) | 1 | |



Weather Guard Tarp




| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|------------------------------------|-----|-------|
| | 221653 | Tarp Kit with Arched End Caps | - | |
| 1 | 9004355 | Screw 1/4-20UNC x 1 Self-Threading | 6 | |
| 2 | 221789 | Roll Tube Weldment | 1 | |
| 3 | 221615 | Fixed Tube Weldment | 1 | |
| 4 | 221668 | Pipe - 180" | 1 | |

Weather Guard Tarp


| | Please visit www.unverferth.com/parts/ for the most current parts listing | | | | |
|------|---|--|-------------|-----------|--|
| ITEM | PART NO. | DESCRIPTION | QTY | NOTES | |
| 5 | 221680 | Plate - Latch 149 1/2" (Front) | 1 | | |
| 6 | | Plate - Latch 149 1/2" (Rear) | 1 | | |
| 7 | | Handle Bracket Weldment | 1 | | |
| 8 | | Bungee 3/8" Dia. x 204" | 1 | | |
| 9 | | Hex Nut/Large Flange 1/4-20UNC | 6 | | |
| 10 | | Tarp Handle Weldment | 1 | <u> </u> | |
| 11 | | Tarp Short Stop Plate | | | |
| | 266689B | | 6 A/D | | |
| 12 | 9000787 9005312 | Trim-lok | A/R | | |
| 13 | | Torx Head Machine Screw 3/8-16UNC x 1 Grade 5 | 8 | | |
| 13A | 9009089 | Torx Head Machine Screw 3/8-16UNC x 1 1/4 Grade 5 | 1 | | |
| 14 | | Lynch Pin 3/8" x 3" | 1 | | |
| 15 | | Cap - Plastic (2 x 3) | 6 | | |
| 16 | | Cable Assembly | 4 | | |
| 17 | | Poly Deflector 8" | 3 | | |
| 18 | | Rivet/Pop 3/16" | 2 | | |
| 19 | | Eye Bolt 3/8-16UNC x 1 3/4 | 1 | | |
| 20 | | Plug 2" | 1 | | |
| 21 | | Handle Retainer Weldment | 1 | | |
| 22 | 9004949 | U-Clamp | 9 | | |
| 23 | | Plug 1" | 2 | | |
| 24 | | Handle | 1 | | |
| 25 | 9004977 | U-Joint w/ 1 3/8-21 Spline | 1 | | |
| 26 | 9005046 | Tarp 166 x 293 | 1 | | |
| 27 | | Plug 1 1/8 | 2 | | |
| 28 | | Plug 1 1/4 | 1 | | |
| 29 | | Pan Head Screw #10-16 x 1/2" | 1 | | |
| 30 | | Hose 1/2 EPDM | 1 | | |
| 31 | 9005197 | Screw/Self Drilling #10-16 x 3/4 Pan Head | 9 | <u> </u> | |
| 32 | 91262 | Screw/Large Flange 3/8-16UNC x 1 Grade 5 | 8 | | |
| 33 | | Nut/Large Flange 3/8-16UNC Grade 5 | 33 | | |
| 34 | 283427B | Tarp Bow Bracket =Black= (Left Hand Side) | | | |
| | | | 6 | | |
| 35 | 9390-055 | Capscrew 3/8-16UNC x 1 Grade 5 | | | |
| 36 | | Roll Pin 3/8" Dia. x 2" | 1 | | |
| 37 | 903172-450 | Phillips Pan Head Screw 3/8"-16UNC x 4-1/2" | 1 | | |
| 38 | | Flat Washer 3/8 | 3 | | |
| 39 | | Elastic Stop Nut 3/8-16UNC | 1 | | |
| 40 | 283425B | Tarp Bow Bracket =Black= (Right Hand Side) | 6 | | |
| 41 | | End Cap Weldment | 2 | | |
| 42 | 283424B | Tarp Bow Weldment | 6 | | |
| 44 | | Capscrew 3/8-16UNC x 1 1/4 Grade 5 | 2 | | |
| 45 | | Flat Socket Countersunk Capscrew 3/8"-16UNC x 3" (RH Thread) | 12 | | |
| 46 | | Screw/Self Drilling 1/4-14 x 1 | 4 | | |
| 47 | 95585 | Capscrew/Large Flange 3/8-16UNC x 3/4 Grade 5 | 8 | | |
| 48 | 9928 | Locknut 3/8-16UNC | 1 | | |
| 49 | 9005581 | Tarp Patch Kit | 1 | Not Shown | |
| 50 | | Bracket and U-Nut Asy | 4 | | |
| 51 | | Star Washer | 4 | İ | |
| 52 | 9005696 | Fender Washer | 4 | | |
| 53 | 9005727 | Plug | 4 | | |
| 54 | | Capscrew 3/8-16UNC x 4 1/2 (Full Threaded) | 4 | | |
| 55 | 97604 | Flange Screw 5/16"-18UNC x 1" Grade 5 | 24 | | |
| 56 | | Hex Nut/Large Flange 5/16"-18UNC | 24 | 1 | |
| 57 | | Hurricane Strap For 12 FT Wide Hopper | 2 | 1 | |
| 58 | 96972 | Screw/Self Tapping 3/8"-16UNC x 1" | 2 | | |
| 59 | | Flat Washer, 3/8" Aluminum | 4 | | |
| 60 | 9008972 | Tarp Strap Spacer Bushing | 4 | | |
| | | Sideboard Doubler =Black= | 12 | | |
| 61 | 294660B | Joiuenuaru Duunier =Diack= | 12 | l | |

Hydraulic Jack - Kit #294142B (Optional)



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|----------|--|-----|---|
| 1 | 271712B | Jack Weldment =Black= | 1 | |
| 2 | 271723B | Jack Foot Weldment =Black= | 1 | |
| 3 | 272587 | Pin, 1" Dia. x 3 1/8 | 1 | |
| 4 | 9005426 | High Pressure Ball Valve | 1 | |
| 5 | 9006068 | Hydraulic Hose, 1/4 x 92" - 3000 PSI | 2 | |
| 6 | 9006173 | Elbow, 90° | 2 | |
| 7 | 9009047 | Hydraulic Cylinder, 3 x 8 - 3000 PSI | 1 | |
| 8 | 9008600 | Hose Grips - Black (Pair) - Raise Jack | 1 | Half Black/Half Gray - Cylinder Retracted |
| 9 | 9008600 | Hose Grips - Black (Pair) - Lower Jack | 1 | Solid Black - Cylinder Extended |
| 10 | 91192 | Retaining Ring, 1" | 2 | |
| 11 | 91383 | Male Tip Coupling | 2 | |
| 12 | 92199 | Center Locknut, 1-8UNC | 3 | |
| 13 | 9390-197 | Capscrew, 1-8UNC x 7 Grade 5 | 3 | |
| 14 | 98508 | Adapter, 3/4-16 OR Male x 3/4-16 OR Male | 1 | |

Video System (Optional)



| ITEM | PART NO. | DESCRIPTION | QTY | NOTES |
|------|-----------|--|-----|---|
| | 265770 | Video System Kit for Front View | 1 | Includes Items 1 - 8 and own Instruction Sheet |
| | 9004506 | Additional Camera for Rear View | 1 | Includes Items 6 & 7 |
| 1 | TAAU14007 | Snap Clip, Adhesive | 10 | |
| 2 | 9512 | Self-Drilling Screw 1/4-14 x 1 | 10 | |
| 3 | 9006273 | Monitor, 7" LCD/LED | 1 | |
| 4 | 9004510 | Cable w/Fuse | 1 | |
| 5 | 9006274 | Camera | 1 | |
| 6 | 265771B | Bracket | 1 | |
| 7 | 9004513 | Cable, 65' | 1 | |
| 8 | 9000106 | Cable Tie | AR | |
| 9 | 9004506 | Camera Kit for Rear View with 65' Cable | 1 | |
| 10 | 9007174 | Extension Cable 16' For CH Series Camera | 1 | |



