

***BRENT* Grain Handling**

**AVALANCHE® DOUBLE-AUGER
GRAIN CARTS
MODELS 1198 & 1398**

1198 = Serial Number B42890100 & Higher
1398 = Serial Number B42880100 & Higher

Part No. 296160


Foreword

 This symbol identifies important safety messages. When you see it, read the message that follows and be alert to the possibility of personal injury.

Remember, safety instructions stated in this manual are for your protection. Read them carefully and follow them closely when working around or using this machine.

Read and study this manual completely before attempting to operate this implement. Take this manual to the field for handy reference when operating, adjusting, or servicing your machine.

When referenced, “Right-Hand” (RH) and “Left-Hand” (LH) side of the machine are determined by standing behind the machine and facing in the direction of travel.



Product Information

When ordering parts or when requesting further information or assistance, always give the following information:

- Machine name
- Model number
- Serial number

All products manufactured by Unverferth Mfg. Co., Inc. are warranted to be free from material and workmanship defects for one full year from time of consumer delivery. Your local dealer will gladly assist you with any warranty questions.

Please fill out and retain this portion for your records.

Purchase Date _____ Model _____ Serial No. _____

Dealer _____ City _____

Dealer Contact _____ Phone _____



IMPORTANT

- *The information, specifications, and illustrations in the manual are based on information available at the time it was written. Due to continuing improvements in the design and manufacture of Unverferth products, all specifications and information contained herein are subject to change without notice.*

Table of Contents

Section I Safety

General Hazard Information	1-2
Safety Decals	1-3
Following Safety Instructions	1-6
Before Servicing or Operating	1-7
During Operation	1-7
Before Transporting	1-8
During Transport	1-8
Driveline Safety	1-9
Pressurized Oil	1-10
Preparing for Emergencies	1-11
Wearing Protective Equipment	1-11

Section II Set Up

Set Up Checklist	2-2
Driveline Install	
Driveline Set Up	2-3
Coupling The Cut-Out Clutch	2-4
PTO Brackets Removal	2-4
Transport Chain - For SN B44410100 & Higher	2-5
Auger Set Up	
7-Pin Connections & Auger Pivot Slide Wood Removal	2-6
Auger Spout Cylinder Stop Removal	2-7
Auger Spout Rotate Shipping Bracket Removal	2-7
Auger Transport Positions	2-8
Auger Transport Rest Set Up	2-9
Jack & Optional Hydraulic Jack Set Up	2-10
Jack	2-10
Install Hydraulic Jack (Optional)	2-10
Upper Ladder Extension	2-12
Wheel & Tire Set Up	2-13
SMV Emblem & SIS Decal	2-14
Video System (Optional)	2-14
Belt Engagement	2-15
Operational Check	2-16

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Table of Contents

**Section III
Operation**

Operating Checklist..... 3-2

Preparing Tractor..... 3-3

Preparing Cart..... 3-3

Hitching to Tractor

 Drawbar Connection 3-5

 Jack Usage..... 3-6

 Optional Hydraulic Jack Usage 3-7

 Transport Chain Connection..... 3-9

 Hydraulic Connections 3-10

 Electrical Connections..... 3-12

 Towing 3-13

Hitching to Cart (Optional) - For SN B44410100 & Higher

 Rear Hitch Connection..... 3-14

 Transport Chain Connection..... 3-15

 Electrical Connection 3-16

Auger Operation

 PTO-Driven Auger 3-17

 Vertical Auger Fold..... 3-19

 Auger Field Rest Position..... 3-20

 Auger Road Transport Position..... 3-21

 Upper Auger Rest Adjustments 3-22

 Auger Overload Procedure..... 3-23

Electric Over Hydraulic Operation (Optional) 3-24

 Electric/Hydraulic Connection..... 3-24

 Auger Fold & Spout Operation..... 3-25

 Flow Door Operation 3-26

 Auger Fold to Transport 3-26

Cart Loading Sequence..... 3-27

Vertical & Horizontal Cleanout Door Operation 3-28

 Closing Vertical Cleanout Door..... 3-28

 Opening Vertical Cleanout Door 3-29

 Horizontal Cleanout Door..... 3-30

Ladder Operation..... 3-32

 Side Ladder Operation 3-32

 Rear Ladder Operation 3-36

Rear Access Door Operation..... 3-38

Rear Drop Hitch Operation (Optional)..... 3-40

 Storage to Working Position..... 3-40

 Working to Storage Position 3-41

 Rear Drop Hitch Adjustment 3-42

Video System (Optional)..... 3-43

Weather Guard Tarp..... 3-43

 Wireless Receiver and Control Box Location..... 3-45

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Table of Contents

**Section IV
Maintenance**

Lubrication - Cart 4-2

PTO Driveshaft Lubrication 4-4

Hydraulic System 4-5

 Purge Hydraulic System 4-5

Wheel, Hub, Spindle Disassembly and Assembly 4-6

Wheels & Tires

 Wheel Nut Torque Requirements 4-8

 Tire Pressure 4-9

 Tire Warranty 4-11

Walking Tandem Option 4-12

 Inner Dual Wheel Access 4-12

 Row Spacing Adjustment 4-13

Gearbox 4-15

Manual Override for Optional Electric Over Hydraulic System 4-16

Manual Override for SCV Controlled Spout Rotate & Auger Fold 4-19

Auger System 4-21

 Vertical Auger Height Check 4-21

 Vertical Auger Timing 4-23

 Horizontal Auger 4-24

Auger Driveline Bearings 4-25

Belt Tightener Adjustment 4-26

V-Belt Alignment 4-28

 Split Tapered Bushings 4-29

Driveline Removal 4-30

Seasonal Storage 4-32

Baffle Adjustment 4-31

Horizontal Cleanout Door Adjustment 4-34

Verify Telescoping PTO Shaft Length 4-36

PTO Shaft Length Adjustment 4-38

PTO Shaft & Clutch 4-39

Hydraulic Jack Cylinder Replacement 4-41

Horizontal Auger Removal & Replacement 4-43

Troubleshooting 4-49

Tarp Troubleshooting Inspection & Maintenance 4-51

Electrical System Schematic 4-52

Electrical Over Hydraulic (EOH) System Schematic - 5 Function Optional 4-59

Optional Electric Over Hydraulic Valve Electric Schematic 5 Function 4-60

SCV Controlled Inline Valve Assemblies - Electric Schematic 4-61

Torque Chart - Hardware Grade 5 4-62

Torque Chart - Hardware Grade 8 4-63

Hydraulic Fittings - Torque and Installation 4-64

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Table of Contents

**Section V
Parts**

Decals..... 5-2

Touch-Up Paint..... 5-5

Vertical Auger Flighting Components..... 5-6

Horizontal Auger Components..... 5-8

Hopper Cross Brace & Cleanout Door Components..... 5-10

Hopper Flow Door Components..... 5-12

Front and Rear Flow Door Components..... 5-14

Flow Door Indicator Assembly..... 5-16

Side Ladder Components..... 5-18

Front End Components..... 5-20

Sideboards - Model 1198..... 5-22

Sideboards - Model 1398..... 5-23

Axle & Hub Components - Model 1198 Single Wheels..... 5-24

Axle & Hub Components - Model 1398 Single Wheels..... 5-26

Walking Tandem Assembly Components..... 5-28

Walking Tandem Mounting Components..... 5-30

Wheels & Tires..... 5-31

Dual Wheels & Tires..... 5-31

Track Axle Components - 36x148, 42x131, 42x148, & 50x148..... 5-32

Track Axle Components - 36x112 & 36x131..... 5-34

Track Panel Kit Components..... 5-35

Rear Drop Hitch Components (Optional) - For SN B44410100 & Higher..... 5-36

Rear Ladder Components - For SN B44410100 & Higher..... 5-37

Rear Access Door Components - For SN B44410100 & Higher..... 5-38

Lower Auger Cleanout Door, Covers & Rest Components..... 5-40

Lower Auger Linkage Components..... 5-42

Idler Assembly Components..... 5-44

Lower Auger Retaining Components..... 5-46

Auger Fold Linkage Components..... 5-48

EOH Valve Functions & Wire Locations 5 Spool (Optional)..... 5-51

EOH Valve Assembly Components 5 Spool (Optional)..... 5-52

EOH Tractor Circuit Hydraulic Components (Optional)..... 5-54

EOH Spout Rotate and Tilt Hydraulic Components (Optional)..... 5-56

Auger Pivot Hydraulic Components..... 5-58

Auger Fold Hydraulic Components..... 5-59

Flow Door Circuit Hydraulic Components..... 5-60

SCV Controlled Inline Valve Assemblies - Valve Functions & Wire Locations..... 5-61

SCV Controlled Inline Valve Assembly Components..... 5-62

SCV Controlled Inline Valve - Auger Fold Hydraulic Components..... 5-63

SCV Controlled Inline Valve - Spout Rotate Hydraulic Components..... 5-64

Cylinders..... 5-65

Auger Grease Bank Components..... 5-66

(Continued on next page)

Table of Contents

Switch Assembly Components for Rotating Spout	5-68
Downspout Components	5-70
Cut Out Clutch PTO Assembly	5-72
Cut Out Clutch Components	5-73
Gearbox Components	5-74
Hopper Rear Electrical Components	5-76
Electrical Components	5-78
Weather Guard Tarp	5-80
Hydraulic Jack - Kit #296288B (Optional)	5-82
Video System (Optional)	5-84

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Section I

Safety

General Hazard Information	1-2
Safety Decals	1-3
Following Safety Instructions	1-6
Before Servicing or Operating	1-7
During Operation	1-7
Before Transporting	1-8
During Transport.....	1-8
Driveline Safety.....	1-9
Pressurized Oil	1-10
Preparing for Emergencies.....	1-11
Wearing Protective Equipment	1-11

General Hazard Information

No accident-prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

A large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the field, or in the industrial plant, can be safer than the person who is at the controls. If accidents are to be prevented--and they can be prevented--it will be done by the operators who accept the full measure of their responsibility.

It is true that the designer, the manufacturer, and the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that, "the best kind of a safety device is a careful operator." We, at Unverferth Mfg. Co., Inc. ask that you be that kind of operator.



REMEMBER:
THINK SAFETY
A CAREFUL OPERATOR IS THE
BEST INSURANCE AGAINST AN
ACCIDENT!

SIGNAL WORDS



INDICATES AN EXTREMELY HAZARDOUS SITUATION OR ACTION THAT WILL RESULT IN SERIOUS INJURY OR DEATH.



INDICATES A HAZARDOUS SITUATION OR ACTION THAT COULD RESULT IN SERIOUS INJURY OR DEATH.




INDICATES AN UNSAFE SITUATION OR ACTION THAT MAY RESULT IN PERSONAL INJURY.



Is used for instruction on operating, adjusting, or servicing a machine.

Safety Decals (continued)




95839



9008947



9005971



95839



95445



9009168



95839



95008



9003476



9003478



9003475



900024



98229




9008947



Part No. 9003127
Reflector AMBER

LEFT-HAND UNLOAD SHOWN
RIGHT-HAND UNLOAD SIMILAR

Safety Decals (continued)



Following Safety Instructions

- Read and understand this operator's manual before operating.



- All machinery should be operated only by trained and authorized personnel.

- To prevent machine damage, use only attachments and service parts approved by the manufacturer.

- Always shut towing vehicle engine off & remove key before servicing the implement.



- Avoid personal attire such as loose fitting clothing, shoestrings, drawstrings, pants cuffs, long hair, etc., that may become entangled in moving parts.

- Do not allow anyone to ride on the implement. Make sure everyone is clear before operating machine.



- Never attempt to operate implement unless you are in the driver's seat.

- Never enter a cart containing grain. Flowing grain traps and suffocates victims in seconds.



Before Servicing or Operating

- Avoid working under an implement; however, if it becomes absolutely unavoidable, make sure the implement is safely blocked. 
- Ensure that all applicable safety decals are installed and legible.
- When working around the implement, be careful not to be cut by sharp edges.
- To prevent personal injury or death while servicing, always ensure that there are people who remain outside the cart to assist the person working inside, and that all safe workplace practices are followed. There are restricted mobility and limited exit paths when working inside the implement.
- Secure drawbar pin with safety lock and lock tractor drawbar in fixed position.
- Explosive separation of a tire and rim can cause serious injury or death. Only properly trained personnel should attempt to service a tire and wheel assembly.
- Add sufficient ballast to tractor to maintain steering and braking control at all times. Do not exceed tractor's hitch capacity or ballast capacity.
- Do not stand between towing vehicle and implement during hitching. 
- Verify that all safety shields are in place and properly secured. 
- Always make certain everyone and everything is clear of the machine before beginning operation.

During Operation

- Regulate speed to working conditions. Maintain complete control at all times.
- Never service or lubricate equipment when in operation.
- Keep away from overhead power lines. Electrical shock can cause serious injury or death. 
- Use extreme care when operating close to ditches, fences, or on hillsides.
- Do not leave towing vehicle unattended with engine running.

Before Transporting

- Verify transport chain capacity meets or exceeds weight capacity of all towed implements. Secure transport chain to towing vehicle before transporting. **DO NOT** transport without chain.
- Check for proper function of all available transport lights. Make sure that all reflectors are clean and in place on machine. Make sure the SMV emblem and SIS decals are visible to approaching traffic.
- Make sure auger is folded and vertical auger assembly is positioned in its narrowest configuration.
- This implement is not equipped with brakes. Ensure that the towing vehicle has adequate weight and braking capacity for all towed equipment.

During Transport

- Comply with all laws governing highway safety when moving machinery.
- Use transport lights as required by all laws to adequately warn operators of other vehicles.
- Regulate speed to road conditions and maintain complete control.
- Maximum transport speed of this implement should never exceed 20 m.p.h. as indicated on the machine. Maximum transport speed of any combination of implements must not exceed the lowest specified speed of the implements in combination. Do not exceed 10 m.p.h. during off-highway travel.
- Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.
- Do not transport grain cart on roads while loaded.
- It is probable that this implement is taller, wider and longer than the towing vehicle. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Driveline Safety

- Do not allow children near equipment that is running or engaged.
- Do not exceed 1000 r.p.m. PTO speed.
- Disengage the PTO, stop the tractor engine, and remove key from ignition before making inspections, or performing maintenance and repairs.
- Inspect the driveline, quick disconnect, overload shear-bolt limiter or clutch, and shielding often. Repair immediately. Use replacement parts and attaching hardware equivalent to the original equipment. Only alterations described in this manual for overall length adjustment are allowed. Any other alteration is prohibited.
- Avoid excessively long hardware or exposed and protruding parts which can snag and cause entanglement.
- Lubricate the driveline as recommended in the MAINTENANCE section.
- Keep hoses, wiring, ropes, etc. from dangling too close to the driveline.
- Install driveline and shields according to recommended lengths and attaching methods with recommended hardware. The driveline shield should rotate independently a full rotation and telescope freely. The retaining chain must be secured to the implement safety shield.
- Adjust drawbar to height and length recommended in the OPERATION section.
- Use caution when turning to avoid contact between tractor tires and driveline.
- Check the length of the telescoping members to ensure the driveline will not bottom out or separate when turning and/or going over rough terrain. Refer to “PTO Shaft Length Adjustment” in MAINTENANCE section.
- Proper extended and collapsed lengths of the telescoping PTO shaft must be verified before first operation with each and every tractor. If the extended length of the PTO shaft is insufficient, it may become uncoupled during operation and cause serious injury or death from contact with uncontrolled flailing of PTO shaft assembly components. Refer to “PTO Shaft Length Adjustment” in MAINTENANCE section.



Pressurized Oil

- Relieve the hydraulic system of all pressure before adjusting or servicing. See tractor operator's manual for procedure to relieve pressure.

- High-pressure fluids can penetrate the skin and cause serious injury or death. Leaks of high-pressure fluids may not be visible. Use cardboard or wood to detect leaks in the hydraulic system. Seek medical treatment immediately if injured by high-pressure fluids. 

- Accumulators used in this hydraulic system can retain fluid under pressure even after tractor hydraulic valve is placed in FLOAT. See tractor operators manual for procedure to relieve pressure.

- Hydraulic system must be purged of air before operating to prevent serious injury or death.

- Do not bend or strike high-pressure lines. Do not install bent or damaged tubes or hoses.

- Repair all oil leaks. Leaks can cause fires, personal injury, and environmental damage.

- Route hoses and lines carefully to prevent premature failure due to kinking and rubbing against other parts. Make sure that all clamps, guards and shields are installed correctly.

- Check hydraulic hoses and tubes carefully. Replace components as necessary if any of the following conditions are found:
 - End fittings damaged, displaced, or leaking.
 - Outer covering chafed/cut or wire reinforcing exposed.
 - Outer covering ballooning locally.
 - Evidence of kinking or crushing of the flexible part of a hose.

Preparing for Emergencies

- Keep a first aid kit and properly rated fire extinguisher nearby.



- Keep emergency numbers for fire, rescue, and poison control personnel near the phone.



Wearing Protective Equipment

- Wear clothing and personal protective equipment appropriate for the job.



- Wear steel-toed shoes when operating.



- Wear hearing protection when exposed to loud noises.



- Do not wear additional hearing impairing devices such as radio headphones, etc.



Notes

Section II Set Up

Set Up Checklist.....	2-2
Driveline Install	
Driveline Set Up.....	2-3
Coupling The Cut-Out Clutch.....	2-4
PTO Brackets Removal.....	2-4
Transport Chain - For SN B44410100 & Higher.....	2-5
Auger Set Up	
7-Pin Connections & Auger Pivot Slide Wood Removal.....	2-6
Auger Spout Cylinder Stop Removal.....	2-7
Auger Spout Rotate Shipping Bracket Removal.....	2-7
Auger Transport Positions.....	2-8
Auger Transport Rest Set Up.....	2-9
Jack & Optional Hydraulic Jack Set Up.....	2-10
Jack.....	2-10
Install Hydraulic Jack (Optional).....	2-10
Upper Ladder Extension.....	2-12
Wheel & Tire Set Up.....	2-13
SMV Emblem & SIS Decal.....	2-14
Video System (Optional).....	2-14
Belt Engagement.....	2-15
Operational Check.....	2-16

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Set Up Checklist

After the cart has been completely assembled, use the following checklist and inspect the cart. Check off each item as it is found satisfactory or after proper adjustment is made.

- Set or Calibrate tractor PTO control engagement to MINIMUM setting. Refer to tractor operator's manual for setting information.
- Remove auger spout cylinder stop.
- Remove auger spout rotate shipping bracket.
- Remove PTO from shipping brackets, install onto gearbox input shaft and set in PTO holder. Remove PTO shipping brackets.
- For Right-Hand unload with water delivery, install transport rest (296086G/R/BM). See "Auger Transport Rest Set Up" in this section.
- Move upper ladder extension from shipping to operating position. See "Upper Ladder Extension to Operating Position" in this section.
- Torque wheel nuts and check tire pressure as specified in MAINTENANCE section.
- Verify track has been aligned and is properly conditioned. (If applicable)
- Inflate tires to specified air pressure. (if applicable)
- Lubricate all grease fittings and check gearbox oil level.
- Inspect cleanout door assembly for play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section.
- Verify all safety decals are correctly located and legible. Replace if damaged.
- Verify all reflective decals are correctly located.
- Check SMV decal and SIS decals are in place, clean and visible.
- Verify transport lights are working properly.
- Verify PTO length, see "Verify Telescoping PTO Shaft Length" in MAINTENANCE section.
- Align and properly tension belts. See "Belt Tightener Adjustment" and "V-Belt Alignment" in MAINTENANCE section.
- Ensure screens over horizontal auger are in place and properly secured.
- Install transport chain and torque hardware to specification. See "Transport Chain Connection" in OPERATION section.
- If a rear drop hitch is used, ensure grain cart transport chain rating exceeds the total gross weight of all towed implements and attachments.
- Paint all parts scratched in shipment.
- Test run the augers. See "Auger Operation" in OPERATION section.
- Check hydraulics for leaks and check hose routing.

Driveline Install


Driveline Set Up

DANGER

- ENTANGLEMENT WITH THE DRIVELINE WILL CAUSE SERIOUS INJURY OR DEATH. KEEP ALL GUARDS AND SHIELDS IN GOOD CONDITION AND PROPERLY INSTALLED AT ALL TIMES. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOE STRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC. THAT CAN BECOME EN-TANGLED IN A ROTATING DRIVELINE.

WARNING

- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
 - TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.
 - EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
 - KEEP HANDS CLEAR OF PINCH POINT AREAS.
 - FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
1. Remove PTO assembly from the tongue.
 2. Attach PTO onto the gearbox input splined shaft and use the PTO holder as shown below. (FIG. 2-1)
 3. Clean and grease the Implement Gearbox splined shaft. Gearbox shaft guard has access doors for installing and removing of driveline.




Driveline Install (continued)

Coupling The Cut-Out Clutch

Engage PTO drive shaft onto implement PTO shaft until retaining groove of implement PTO shaft aligns with clamping cone hole. Insert clamping cone into threaded hole, hand tighten. Torque cone to 75 ft.-lb. (Fig. 2-2)

NOTE: See MAINTENANCE section - PTO Quick Disconnect - for disassembly instructions.

Fig. 2-2



PTO Brackets Removal

Remove the PTO assembly and PTO brackets on the tongue, before operating the auger pivot or when connecting the driveline assembly to the tractor. Keep PTO brackets for seasonal storage. Refer to “Seasonal Storage” in MAINTENANCE section. (FIG. 2-3)

IMPORTANT

- PTO assembly and PTO brackets must be removed before operating the auger pivot or when connecting the driveline assembly to the tractor. Failure to remove PTO assembly and PTO brackets will result in damage to the PTO assembly, tongue, auger and tractor.




FIG. 2-3

Transport Chain - For SN B44410100 & Higher

CAUTION

- ALWAYS USE TRANSPORT CHAIN WHEN TRANSPORTING IMPLEMENTS. FAILURE TO USE A TRANSPORT CHAIN COULD CAUSE PERSONAL INJURY OR DAMAGE IF IMPLEMENTS BECOME DISENGAGED.
- REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED OR DAMAGED. DO NOT WELD TRANSPORT CHAIN.
- USE ONLY AN UNVERFERTH ASABE TRANSPORT CHAIN WITH A WEIGHT RATING EXCEEDING THE GROSS COMBINED WEIGHT OF ALL TOWED IMPLEMENTS. CONTACT YOUR UNVERFERTH DEALER FOR ADDITIONAL INFORMATION.

All grain carts feature a transport chain as standard equipment. This transport chain is sized for towing an empty grain cart only **OR** an empty grain cart and upto 20,000 lbs. on the grain cart optional rear hitch. Verify the transport chain used.

Refer to “Front End Components” in PARTS section for transport chain part number and/or weight capacity. (FIG. 2-4)

When an implement is towed behind a grain cart, the transport chain on the grain cart must be sized accordingly. See tractor operator’s manual for proper attachment and contact your Unverferth dealer for more information.



FIG. 2-4

Auger Set Up

WARNING



- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. LEAKS OF HIGH-PRESSURE FLUIDS MAY NOT BE VISIBLE. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.

7-Pin Connection & Auger Pivot Slide Wood Removal

1. Close the vertical cleanout door.
3. Hitch cart to tractor. Refer to “Hitching to Tractor” in the OPERATION section.
4. Park the empty cart on a firm, level surface. Block the machine to keep it from moving. Set the tractor's parking brake. Leave tractor on throughout procedure.
5. Attach the 7-pin connector to tractor. (FIG. 2-5)

NOTE: Auger hydraulic functions will not operate without power and ground via the 7-pin connector.

6. Use tractor SCV to pivot auger up.
7. Remove and discard the wood block from the auger pivot. (FIG. 2-6)
8. Cycle auger pivot all the way up and down to ensure movement is free.
9. Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.




Auger Set Up (continued)

Auger Spout Cylinder Stop Removal

1. Extend spout cylinder before removing the shipping stop. (Figs. 2-7 and 2-8)
2. Support spout to prevent movement while removing the shipping stop from the spout tilt cylinder. (Figs. 2-7 and 2-8)

IMPORTANT

- *Cylinder stop must be removed before operating the auger spout. Failure to remove stop will result in damage to the cylinder and spout.*




Auger Spout Rotate Shipping Bracket Removal

Remove and discard the auger spout rotate shipping bracket, before operating the spout. (Fig. 2-9)

IMPORTANT

- *Shipping bracket must be removed before operating the auger spout rotate. Failure to remove bracket will result in damage to the hydraulic motor and spout.*



Auger Set Up (continued)

Auger Transport Positions

⚠ WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

IMPORTANT

- Upper auger must be in Road Transport Position for public road travel.
- Position vertical auger with discharge hood within hopper width for public road travel.

Auger transport rest bracket can be adjusted in multiple positions:

Shipping Position



Road Transport Position



Field Rest Position



Auger Set Up (continued)

Auger Transport Rest Set Up

IMPORTANT

- For Right-Hand unload with water delivery, do not fold auger to shipping position. Folding auger to shipping position may damage auger, spout and water delivery. Transport rest is ONLY for use on the road.




1. Hitch cart to tractor. Refer to “Hitching to Tractor” in the OPERATION section.
2. Park the empty cart on a firm, level surface. Block the machine to keep it from moving. Set the tractor’s parking brake. Unfold auger to the unload position. Shut-off tractor’s engine and remove the ignition key.



3. Remove 5/16”-18UNC x 1” capscrews (9390-030) and 5/16”-18UNC locknuts (901527) from transport rest (296086G/R/BM) and field rest (295556G/R/BM). Keep 5/16” hardware. (FIG. 2-16)
4. Pivot transport rest 90° from field rest. (FIG. 2-17)
5. Using previously removed 5/16” hardware and 5/16”-18UNC x 1” socket head bolts (9007843) and 5/16”-18UNC locknuts (901527), attach transport rest to field rest. (FIG. 2-17)
6. Torque 5/16” hardware to 17 ft.-lbs.

NOTE: To change transport positions, refer to “Auger Operation” in the OPERATION section.

7. How about “slowly fold auger to test alignment of field and transport rest brackets.” Adjust alignment bolts as needed. Fig 2-18



Jack & Optional Hydraulic Jack Set Up


Jack

WARNING

- **UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.**

Attach jack to left-inside frame using pin and hair pin. (Fig. 2-19) Pivot the jack 90 degrees and reinstall pin for field use.


Fig. 2-19



Install Hydraulic Jack (Optional)

1. Assemble hoses (9006068) and fittings to cylinder (9009047) as shown in figure 2-20. The valve needs to be attached to the hose on the butt end of the cylinder. Assemble the fittings on the cylinder so they face each other, then store the hydraulic hoses on the hose caddy.

Fig. 2-20



Jack & Optional Hydraulic Jack Set Up (continued)

Install Hydraulic Jack (Optional)

⚠ WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.

2. Assemble the cylinder (9009047) and jack foot (271723B) to the jack weldment (271712B) as shown in figure 2-21 using 1"-8UNC x 7" capscrews (9390-197) and 1"-8UNC locknuts (92199).




NOTE: Ensure all jack leg weldment (271712B) joints can pivot freely, including jack foot (271723B).

3. Tighten 1" hardware to jack leg weldment and allow the cylinder and jack foot to freely pivot. (Fig. 2-21)

4. Using a safe lifting device rated for 100 lbs., attach the jack weldment (271712B) to the lower tabs behind the hitch plate on the tongue using 1"-8UNC x 7" capscrews (9390-197) and 1"-8UNC locknuts (92199). See figure 2-21.

5. Tighten 1" hardware to jack leg weldment and allow the joint to pivot. (Fig. 2-22)

6. Align the base end of the cylinder with the lug on the top of the tongue and assemble the cylinder pin (272587) and snap rings (91192) shown in figure 2-23.



Upper Ladder Extension




⚠ WARNING

- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFOCATES VICTIMS IN SECONDS.

NOTE: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.

NOTE: To change ladder assembly positions, refer to “Ladder Operation” in the OPERATION section.

1. Move the upper ladder extension (289707B) from shipping position by removing the 5/16”-18UNC x 3/4” carriage bolts (9388-024), 5/16” flat washers (9405-064) and 5/16”-18UNC lock nuts (9008441). Keep hardware for next step. (Fig. 2-24)
2. Using hardware from step 1, attach upper ladder extension to the higher set of holes to be in operating position. (Fig. 2-24, Fig. 2-25 and 2-26)
3. Torque hardware to 17 ft.-lbs.



Wheel & Tire Set Up

Tire Pressure

Tire pressure must be verified before first use and adjusted as necessary. Refer to MAINTENANCE section of this manual for information on tire pressure.

Wheel Nuts

⚠ WARNING

- **FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.**
- **EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.**
- **KEEP HANDS CLEAR OF PINCH POINT AREAS.**
- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.**

⚠ CAUTION

- **IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGULARLY. SEE TORQUE PAGE IN THE MAINTENANCE SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.**

IMPORTANT

- *Install wheels with tires in the narrowest position. Installing wheels without the proper inset/outset could result in hub or spindle failure. This will cause substantial damage to cart and is not covered by warranty. Inset/outset will vary depending on tire size. Consult dealer for proper inset/offset.*

Wheel nuts must be torqued to specification. Refer to MAINTENANCE section for proper wheel nut torque.

The wheel dish will put the tires to the narrowest or widest position.

SMV Emblem & SIS Decal



The reflective surface of the SMV must face rearward. This may require removal of film protecting the reflective surface or removing and reinstallation of the SMV. (Fig. 2-27)

When reinstalling the SMV make sure that it is mounted with the wide part of the SMV at the bottom.

Ensure the front and rear SIS decals are clean and visible after shipping. (FIG. 2-28)

For 20 M.P.H. SIS decals, order 9008715 for the front & 9008714 for the rear.

For 30 K.P.H. SIS decals, order 9008721 for the front & 9008720 for the rear.



Belt Engagement

WARNING

- **MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.**

The unit is shipped without tension applied to the belts. To engage the tensioner use the belt tensioner handle, located on the front left-hand side of the grain cart, behind the first panel. Verify the belts are correctly aligned and are seated in both sheaves. If belt hangs over edge of sheave, detention idler, adjust and retention idler. (Fig. 2-29 and 2-30)

Rotate the handle downwards to engage tensioner. (Fig. 2-29)

NOTE: See MAINTENANCE section - V-Belt Alignment - for more details.



Operational Check

WARNING

- **MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.**

IMPORTANT

- *Before running the auger pivot, the vertical auger cleanout door must be closed to prevent machine damage.*

NOTE: The grain cart must have 12V power (blue wire) on the 7-pin plug. Without 12VDC, the auger fold and spout rotate will not operate.

Perform the clean-out door steps to prepare the cart for operation:

1. Retrieve lynch pin from toolbox for the horizontal clean-out doors.
2. Close clean-out doors. Refer to “Vertical & Horizontal Clean-Out Door Operation” in the OPERATION section.

Once set-up has been completed, run the cart to check for operation and functionality:

1. Lights - Work, Turn, Brake
2. Flow Door
3. Flow Door Indicator
4. Auger Fold
5. Auger Pivot
6. Spout Rotate
7. Spout Tilt
8. Auger Startup & Shut-down
9. Tarp
10. Video System Camera (if applicable)
11. Scale (if applicable)



Section III Operation

Operating Checklist.....	3-2
Preparing Tractor.....	3-3
Preparing Cart.....	3-3
Hitching to Tractor	
Drawbar Connection	3-5
Jack Usage.....	3-6
Optional Hydraulic Jack Usage	3-7
Transport Chain Connection.....	3-9
Hydraulic Connections	3-10
Electrical Connections.....	3-12
Towing	3-13
Hitching to Cart (Optional) - For SN B44410100 & Higher	
Rear Hitch Connection.....	3-14
Transport Chain Connection.....	3-15
Electrical Connection	3-16
Auger Operation	
PTO-Driven Auger	3-17
Vertical Auger Fold.....	3-19
Auger Field Rest Position.....	3-20
Auger Road Transport Position.....	3-21
Upper Auger Rest Adjustments	3-22
Auger Overload Procedure.....	3-23
Electric Over Hydraulic Operation (Optional)	3-24
Electric/Hydraulic Connection.....	3-24
Auger Fold & Spout Operation.....	3-25
Flow Door Operation	3-26
Auger Fold to Transport.....	3-26
Cart Loading Sequence.....	3-27
Vertical & Horizontal Cleanout Door Operation	3-28
Closing Vertical Cleanout Door.....	3-28
Opening Vertical Cleanout Door	3-29
Horizontal Cleanout Door.....	3-30
Ladder Operation.....	3-32
Side Ladder Operation	3-32
Rear Ladder Operation - For SN B44410100 & Higher.....	3-36
Rear Access Door Operation - For SN B44410100 & Higher	3-38
Rear Drop Hitch Operation (Optional) - For SN B44410100 & Higher.....	3-40
Storage to Working Position.....	3-40
Working to Storage Position	3-41
Rear Drop Hitch Adjustment	3-42
Video System (Optional).....	3-43
Weather Guard Tarp.....	3-43
Wireless Receiver and Control Box Location.....	3-45

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM
INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Operating Checklist

- Read and understand all safety precautions before operating cart.
- R.V. antifreeze needs to be completely flushed from the Water Delivery System and disposed of properly. Make certain the Water Delivery System only contains water before placing the Water Delivery System in service. (If applicable)
- Set or Calibrate tractor PTO control engagement to MINIMUM setting. Refer to tractor operator's manual for setting information.
- Torque wheel nuts and check tire pressure as specified in MAINTENANCE section.
- Verify track has been aligned and is properly conditioned. (If applicable)
- Verify track grease pump reservoir is full. Refer to track auto grease pump instruction sheet (282986) for setting information.
- Inflate tires to specified air pressure. (if applicable)
- Lubricate all grease fittings and check gearbox oil level.
- Inspect cleanout door assembly for play or movement, refer to "Vertical & Horizontal Clean-Out Door Operation" in the OPERATION section.
- Test operation and functionality of work lights, flow door, flow door indicator, auger fold, auger pivot, spout rotate, spout tilt, tarp, rear access door and if equipped, rear drop hitch, hydraulic jack stand, scale, joystick, scale remote display, video system, and water delivery system.
- Verify all reflective decals are correctly located.
- Check SMV sign and SIS decals are clearly visible with the cart attached to the tractor and implement grain cart optional rear hitch.
- Verify all transport lights are working properly. Check and follow all regulations before towing on a road or highway.
- Verify tractor drawbar height and length. See "Preparing Tractor" in this section.
- Verify rear drop hitch height and length. See "Rear Drop Hitch (Optional)" in this section.
- Verify PTO length, see "Verify Telescoping PTO Shaft Length" in MAINTENANCE section.
- Align and properly tension belts. See "Belt Tightener Adjustment" and "V-Belt Alignment" in MAINTENANCE section.
- Ensure screens over horizontal auger are in place and properly secured.
- Ensure all cleanout doors and rear access door are closed and latched.
- Ensure side and rear ladders are in storage position.
- Ensure transport chain is properly sized, installed and attached. See "Transport Chain Connection" in OPERATION section.
- Test run the augers. See "Auger Operation" in OPERATION section.

Preparing Tractor

Before operating cart, read the tractor Operator's Manual and gain an understanding of its safe methods of operation.

Check the tractor brakes and transport lights. Make sure they are in proper working order.

If equipped, check the tractor and cart electric tarp connection. Refer to electric roll tarp manual (26487) for details.

Set tractor PTO modulation to **MINIMUM**. Check that your tractor has the latest PTO engagement software from the OEM. If unsure, contact your local dealer for tractor capabilities and recommended setting for grain cart operation.

Read the tractor Operator's Manual for more information on tractor drawbar distance.

Check the tractor hydraulic oil reservoir and add oil if needed.

Verify that the tractor is adequately ballasted for drawbar operation at the anticipated draft load. See tractor manual for ballasting instructions.

If possible, adjust the tractor drawbar vertically so the topside of the drawbar is approximately 17-22 inches from the ground. Ensure that the drawbar is locked in the center position.

NOTE: The grain cart comes with a CAT 4 hitch utilizing a 2" diameter pin. For 1398 only, a CAT 5 hitch is available for a 2 3/4" diameter pin.

CAUTION

- **USE OF NON-MATCHING CATEGORY HITCH AND TRACTOR DRAWBAR CONNECTION WILL RESULT IN POOR HITCH PERFORMANCE AS WELL AS DAMAGE TO TRACTOR, IMPLEMENT OR BOTH.**

Hitch pin sizes for each Category to help properly identify drawbar category.

Category 4	2" Dia. (50 mm)
Category 5	2-3/4 Dia. (70 mm)

On tractors equipped with a 3-point hitch, raise and secure the linkage to prevent interference with the cart tongue, hydraulic hoses and the hydraulic drive option during turning. It may be necessary to remove tractor 3-point quick attach to avoid damage during turning.

Preparing Cart

Perform the service checks as outlined below. Repair or replace any damaged or worn parts before operating.

Hardware

Check for loose bolts and nuts, and tighten as needed. Check again after the first half-day of operation.

Pivot Pins

Check that all pins are in place and in good condition. Replace any worn, damaged or missing pins.

Preparing Cart (continued)

Hitch

Check hitch wear plates for damage and wear. Be aware of the size of hitch adapter bushing that is being used. Select correct size for the hitch pin/draw bar you are using.

Rear Drop Hitch (Optional) - For SN B44410100 & Higher

Check rear drop hitch wear plates for damage and wear. Check that the hitch pin is in place and in good condition. Replace any worn, damaged or missing hitch pin.

Auger

Inspect auger for damage and wear.

Hydraulic System

Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.

Tires/Wheels

Check tire pressures and maintain at recommended values listed in the MAINTENANCE section of this manual.



CAUTION

- **IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGULARLY. SEE TORQUE PAGE IN THE MAINTENANCE SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.**

IMPORTANT

- *Install wheels with tires in the narrowest position. Installing wheels without the proper inset/offset could result in hub or spindle failure. This will cause substantial damage to cart and is not covered by warranty. Inset/offset will vary depending on tire size. Consult dealer for proper inset/offset.*

For questions regarding new tire warranty, please contact your local original equipment tire dealer. **USED TIRES CARRY NO WARRANTY.** Tire manufacturers' phone numbers and web sites are listed in the MAINTENANCE section of this manual for your convenience.

Hitching to Tractor

Drawbar Connection

This cart is intended to be hitched to a tractor drawbar. Do not attempt to hitch to any other location on the tractor other than the drawbar.

The cart comes with a CAT 4 hitch for use with a 2" pin and designed for a clevis-type tractor drawbar. If a 1 1/2" or 1 3/4" diameter hitch pin is used, a corresponding bushing must be inserted into the hitch tang and held in place with o-rings. (Figure 3-1)

NOTE: For 1398 only, CAT 5 tongue is available. Contact your dealer for a CAT 5 tongue, if required.

NOTE: Use of the proper hitch pin/bushing will prevent excessive wear and tear on both the cart and tractor.

NOTE: Bushings and o-rings are stored in the toolbox on the right-hand side of the cart.

Lock tractor drawbar in center position.

Refer to the tractor Operator's Manual for information on tractor drawbar length.

WARNING

- **DO NOT STAND BETWEEN THE CART AND TRACTOR WHEN HITCHING. ALWAYS ENGAGE PARKING BRAKE AND STOP ENGINE BEFORE INSERTING HITCH PIN.**

Place wear shoe (281663-CAT 3; 281898-CAT 4; 281899-CAT 5) between tractor hitch and grain cart hitch. (Figure 3-2)

4. After inserting drawbar pin, secure drawbar pin with a locking device to prevent uncoupling during use.

NOTE: Hitch tang can be flipped providing a drawbar connection height difference of 2 7/8" (Figure 3-3). Position the hitch tang to help assure a level cart when loaded, or the rear of the hopper slightly higher than the front, to maintain rear slope cleanout. Whenever the hitch tang is flipped, the driveline clearances need to be reviewed.

FIG. 3-1





FIG. 3-2

2 7/8" Higher Than
The Standard Position




FIG. 3-3

Hitching to Tractor (continued)

WARNING

- UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.

Jack Usage

Use jack to support an empty grain cart, never a loaded grain cart. Always have a loaded grain cart hooked to tractor. Attach jack to left inside frame using pin and hair pin. Pivot the jack 90 degrees and reinstall pin for field use. (Fig. 3-4)

IMPORTANT

- After cart is hitched to tractor, pivot jack to storage location shown in Fig. 3-5.

Fig. 3-4




Fig. 3-5



Hitching to Tractor (continued)


Optional Hydraulic Jack Usage

WARNING

- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. LEAKS OF HIGH-PRESSURE FLUIDS MAY NOT BE VISIBLE. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**
- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.**
- **OPENING OF HYDRAULIC VALVE CAN CAUSE SUDDEN MACHINE MOVEMENT. KEEP CLEAR OF MACHINE WHEN OPENING VALVE.**

IMPORTANT

- *After cart is hitched to tractor, attach hydraulic hoses to tractor and retract hydraulic cylinder to store hydraulic jack between the frame rails. (FIG. 3-6)*




Use hydraulic jack to support an empty grain cart, never a loaded grain cart. Always have a loaded grain cart hooked to tractor.

Always close the manual valve for the hydraulic jack for in-field use and when unhitched from the tractor.


Hitching to Tractor (continued)

1. Remove hoses from storage slots.
2. Attach jack cylinder hose couplers to tractor.
3. Open valve to allow hydraulic flow.
4. Use tractor hydraulic valve to extend cylinder and lift tongue.
5. Once attached to tractor drawbar, retract cylinder to lower tongue and to raise jack into storage position.
6. Close valve, relieve pressure on couplers (see tractor operators manual for procedure) and then disconnect hose couplers from tractor.
7. Place hose couplers into storage caddy. Be sure to route hoses to clear PTO driveline during operation.
8. Check for leaks.

For SN B44410099 & Lower



For SN B44410099 & Lower



Hitching to Tractor (continued)

Transport Chain Connection

CAUTION

- ALWAYS USE TRANSPORT CHAIN WHEN TRANSPORTING IMPLEMENTS. FAILURE TO USE A TRANSPORT CHAIN COULD CAUSE PERSONAL INJURY IF CART BECOMES DISENGAGED.
- REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED, DAMAGED OR NOT FUNCTIONING. DO NOT WELD TRANSPORT CHAIN.
- USE ONLY AN UNVERFERTH ASABE TRANSPORT CHAIN WITH A WEIGHT RATING EXCEEDING THE GROSS COMBINED WEIGHT OF ALL TOWED IMPLEMENTS. CONTACT YOUR UNVERFERTH DEALER FOR ADDITIONAL INFORMATION.

This transport chain is sized for towing an empty grain cart only **OR** an empty grain cart and upto 20,000 lbs. on the optional grain cart rear hitch.

See tractor operator's manual for proper chain attachment. Fig. 3-9 shows how the transport chain must be installed between the tractor and grain cart.




Fig. 3-9

Hitching to Tractor (continued)**Hydraulic Connections**

Clean hydraulic hose couplers before connecting to the tractor. For convenience, this unit is equipped with color-coded hose grips attached to the hydraulic hoses. This will help in identifying the hose function and correct hook up. (FIG. 3-8)

NOTE: For SN B44410100 & higher, the (+ extend port) and (- retract port) is indicated on the hose grip. For SN B44410099 & lower, the half gray color hose grip is for the retract port.

Color	Function
Red	Flow Door Open / Close
Yellow	Spout Tilt In / Out
Tan	Joystick / Spout Rotate
Green	Auger Fold / Unfold
Orange	Auger Pivot Up / Down
Black	Jack Raise / Lower
Blue	Water Pump

After initial set-up or replacement of any hydraulic component on the cart, air must be removed from the cart's hydraulic system. Reference "Hydraulic System - Purge Hydraulic System" section in the MAINTENANCE section.

Route hoses away from areas that may cause abrasion or kinking of hoses during operation.

Hitching to Tractor (continued)

Hydraulic Connections

Before disconnecting hoses from tractor, place tractor in Park and shut PTO off, operate auger fold and pivot to the lowest positions. Where possible, remove hydraulic pressure loads and avoid potential pressure buildup in the lines from long storage periods such as upper auger not in rest position. If equipped with hydraulic jack, extend jack to desired position, turn valve to closed position. See tractor operator's manual for proper procedure to relieve pressure from the lines. After SCV pressures have been relieved and tractor engine is off, disconnect hoses from tractor. Install couplers into storage slots provided. (FIGS. 3-10 & 3-11)



Hitching to Tractor (continued)

Electrical Connections

This cart is equipped with a seven-pin SAE connector plug which will connect with the receptacle found on most newer tractors. If your tractor does not have this type of receptacle, an SAE J-560 seven-point socket can be purchased from your Unverferth dealer (Part number 92824). (FIG. 3-12)

NOTE: 7-pin connector must be plugged into the tractor with power to the center pin for the spout system to operate.

The wiring schematic for this cart, shown in the MAINTENANCE section, complies with AS-ABE Standards. Always verify correct electrical function before using this cart.

If equipped, check the tractor and cart electric tarp connection. Refer to electric roll tarp manual (26487) for details.

This unit is equipped with Side Marker lights for enhanced visibility. These lights will have different functionality depending upon the tractor lighting selection.


- When the tractor field lights switch is on; the Side Marker lights and the amber turn signal lights are on solid and will not flash.
- When the flashers and/or turn signal is on; the Side Marker lights flash in unison with their respective side's amber turn lamp.

Compliance with all lighting and marking laws is the responsibility of the operator at the time of travel.

See federal regulation 49 CFR 562; available at www.govinfo.gov for US federal law requirements.

See your Unverferth dealer for additional brackets, reflectors, or lights to meet your requirements.

Fig. 3-12



Hitching to Tractor (continued)

Towing

Ensure that the towing vehicle has adequate weight and braking capacity to tow this grain cart and upto 20,000 lbs. on the optional grain cart rear hitch. See towing vehicle manual for towing capacity. Never tow a loaded grain cart over public roads.

Maximum speed of cart should never exceed 20 m.p.h. Do not exceed 10 m.p.h. during off-highway travel. Do not exceed 8 m.p.h. when cart is fully loaded.

Secure drawbar pin with a locking device and lock tractor drawbar in centered position.

The PTO drive shaft must be properly attached to the tractor during transport. See “Coupling The Cut-Out Clutch” in SET UP section and “PTO Shaft and Clutch” in MAINTENANCE section before connecting the PTO drive shaft to the tractor.

Secure transport chain to tractor chain support before towing.

CAUTION

- THE STANDARD TRANSPORT CHAIN IS DESIGNED ONLY FOR AN EMPTY GRAIN CART DURING ROAD TRAVEL.

IMPORTANT

- Upper auger must be in Road Transport Position for public road travel.
- Position vertical auger with discharge hood within hopper width for public road travel.

Regulate speed to road conditions and maintain complete control.

It is probable that this cart is taller, wider and longer than the towing tractor. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.

Always have auger folded into road transport position when auger is not in use. (FIG. 3-13)



FIG. 3-13

Road Transport Position Shown


Rear Drop Hitch (Optional)

Rear Hitch Connection


1. Verify the grain cart transport chain capacity is sized for both an empty grain cart and the rear hitch capacity of 20,000 lbs. Do not proceed until the grain cart transport chain meets or exceeds the combined implement road transport weight.

NOTE: Refer to “Front End Components” in PARTS section for transport chain part number and/or weight capacity.

2. Move rear drop hitch to the operation position, then connect the tongue of the header transport to the rear drop hitch. (Fig. 3-14)
3. Using 1 1/2” dia. hitch pin (9009656), insert the hitch pin and keeper. (Fig. 3-14)
4. If header transport has brakes, attach the brake cable to the rear drop hitch. (Fig. 3-14)



5. Connect transport chains and electrical connection of the header transport to the rear drop hitch. (Fig. 3-15)



Rear Drop Hitch (Optional) (continued)


Transport Chain Connection

CAUTION

- ALWAYS USE TRANSPORT CHAIN WHEN TRANSPORTING IMPLEMENTS. FAILURE TO USE A TRANSPORT CHAIN COULD CAUSE PERSONAL INJURY IF CART BECOMES DISENGAGED.
- REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED OR DAMAGED. DO NOT WELD TRANSPORT CHAIN.
- USE ONLY AN UNVERFERTH ASABE TRANSPORT CHAIN WITH A WEIGHT RATING EXCEEDING THE GROSS COMBINED WEIGHT OF ALL TOWED IMPLEMENTS. CONTACT YOUR UNVERFERTH DEALER FOR ADDITIONAL INFORMATION.

This transport chain is sized for towing an empty grain cart only **OR** an empty grain cart and upto 20,000 lbs. on the optional grain cart rear hitch on public roads.

Fig. 3-16 shows how the transport chain must be installed between header cart and rear drop hitch.



Rear Drop Hitch (continued)

Electrical Connection

The rear drop hitch is equipped with a 7-blade connector which will connect to the plug on most newer header carts to be towed behind the cart. (Fig. 3-14)


The wiring schematic for this connector, shown in the MAINTENANCE section, complies with current ASABE Standards. Verify correct electrical function before using this connector.

Compliance with all lighting and marking laws is the responsibility of the operator at the time of travel.

See federal regulation 49 CFR 562; available at www.govinfo.gov for US federal law requirements.

IMPORTANT

- *The rear ladder MUST be folded into storage position to prevent damage when towing with the rear drop hitch.*



Auger Operation

PTO Driven Auger

DANGER

- ELECTROCUTION WILL CAUSE SERIOUS INJURY OR DEATH. ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT. KEEP AWAY FROM ALL ELECTRICAL LINES AND DEVICES.



WARNING

- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL INJURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.

1. Before loading cart or operating auger, verify that the flow control door is closed.

NOTE: If spout rotate moves out of center, the auger will not unfold to unloading position. The spout must be manually rotated to center position. See “Manual Override for Optional Electric Over Hydraulic System” in the MAINTENANCE section.


2. Choose an area free from obstructions and unfold auger into unloading position. Allow sufficient time for the cylinder to fully engage the two augers and over-center latch to fully engage.
3. Engage PTO at low engine RPM, then increase engine RPM until 1000 PTO RPM is reached.

IMPORTANT

- Operating the PTO at less than 1000 RPM can result in damage to the PTO and driveline components in addition to excessive auger wear and cart vibration
4. Open flow control door to desired unloading rate. Numbers on the auger tube provide a point of reference for operator convenience. (FIG. 3-18)
 5. To slow or stop grain flow, close flow door, do not reduce tractor RPM. Close flow door fully when unloading is complete.

NOTE: If an overload occurs, see “Auger Overload Procedure.”


NOTE: It is not recommended to disengage auger with flow control door open. Auger system will require substantially more torque to start, placing extra stress on both cart and tractor driveline. Cart is equipped with baffles that can be adjusted to accommodate the flow of different materials and/or torque demands associated with different materials. See the MAINTENANCE section for the procedure.



Auger Operation (continued)

6. When auger is empty, reduce PTO rpm to idle, and stop PTO.
7. After PTO has come to a complete stop, align the checkered flag decals to locate center as shown in FIG. 3-19.
8. Once spout is centered, fold auger to the transport position or field position.

NOTE: Spout can be TILTED to any position, but must be ROTATED to center for auger to fold.



Auger Operation (continued)

Vertical Auger Fold

WARNING

- DO NOT STAND ON LADDER OR FRAME UNLESS TRACTOR ENGINE IS TURNED OFF AND KEYS ARE REMOVED FROM THE IGNITION.

Actuate hydraulic auger fold circuit to pivot vertical auger between transport and operating positions. When unfolding auger, allow sufficient time for cylinder to rotate the outside fold link into an over-center position. (FIG. 3-20)

NOTE: Auger spout will not rotate until auger is fully extended and auger will not fold until the spout is centered. It may be necessary to manually rotate auger spout in order to unfold the auger. See “Manual Override for Optional Electric Over Hydraulic System” in the MAINTENANCE section for details.



Fig. 3-20

Road Transport
Position Shown

Auger Operation (continued)

Auger Field Rest Position

IMPORTANT



- Auger field rest is *ONLY* for use in the field. Auger must be folded to road transport position during road transport.
1. Extend auger to the unload position. Shut-off tractor's engine and remove the ignition key.



2. Remove hairpin cotter from latch pin (Figure 3-21) and pull latch pin to disengage (Figure 3-22). Raise auger rest stand up to field position and release latch pin. Make sure the pin is engaged in the field position hole and re-install hairpin removed earlier in this step.

3. Fold auger back to field rest position (Figure 3-23), making sure upper auger rest engages the field rest tube and activates the auger switch.

NOTE: Upper auger rest is factory adjusted. Bolts can be used for re-alignment of upper auger rest. See Fig. 3-23.



Auger Operation (continued)

Auger Road Transport Position

1. Extend auger to the unload position. Shut-off tractor's engine and remove the ignition key.




2. Remove hairpin and pull latch pin towards you to disengage. Lower field rest to the road transport position and release the latch pin (Figure 3-24). Make sure the pin is engaged in the road transport position hole and re-install hairpin removed earlier in this step.
3. Fold auger down to road transport position. (FIG. 3-25)



Auger Operation (continued)

Upper Auger Rest Adjustments

1. Loosen mounting capscrews of upper auger rest. (FIG. 3-26)
2. Raise auger approximately 6" out of the transport rest and install cylinder stops on the fold cylinder to prevent the auger from lowering unexpectedly.
3. Position upper auger rest as needed so that it appears to be centered over the transport rest tube.
4. Hand tighten the mounting capscrews of the upper auger rest.
5. Remove the cylinder stops installed in step 2, and lower the auger down into the transport rest.
6. Ensure the upper auger rest contacts the lower tube evenly.
7. Torque mounting capscrews to 65 ft.-lbs.



Auger Operation (continued)

Auger Overload Procedure


IMPORTANT

- Extensive operation while the clutch is slipping may damage drive components.

NOTE: When over loading occurs, drivelines equipped with cut-out clutch will make a “clicking” noise when torque has been exceeded. Immediately shut off PTO and shut the flow door.

NOTE: Once PTO RPM has significantly decreased, cut-out clutch will automatically reset.

1. Close flow door.
2. Shut-off the engine and remove the ignition key.



3. With the PTO off and driveline stopped, disengage the belt tensioner using the belt tensioner handle, this disengages the horizontal auger from the drivetrain. (FIG. 3-27)
4. Restart and engage the tractor PTO at low engine RPM.
5. Increase engine RPM until 1,000 PTO RPM is reached to empty the vertical auger.



IMPORTANT

- Operating the PTO at less than 1000 RPM can result in damage to the PTO and driveline components in addition to excessive auger wear and cart vibration.

6. Once vertical auger is empty, stop PTO.
7. Shut-off the engine and remove the ignition key.



8. With the tractor PTO off and driveline stopped, reengage the belt tensioner using the belt tensioner handle. Return handle to storage. (FIG. 3-28)
9. Restart and engage the tractor PTO at low engine RPM.
10. Increase engine RPM until 1,000 PTO RPM is reached to empty the drag auger.

NOTE: If the grain cannot be relieved by above method, open bottom clean out doors (see “Vertical & Horizontal Clean-Out Door Operation” in this section) to remove grain from auger before repeating these steps to clean out auger.

Electric Over Hydraulic Operation (Optional)


Electric/Hydraulic Connection

Before operating cart, familiarize yourself with the functions associated with the joystick controller by operating with an empty cart.

The joystick comes with a mounting pin allowing storage inside the tractor cab when not in use.


1. Connect the red wire from power harness (9008251) to a key-switched +12VDC power supply. (Fig. 3-29)
2. Connect the white wire from power harness (9008251) to ground. (Fig. 3-22)

Fig. 3-29



NOTE: 7-pin connector must be plugged into the tractor with power to the center pin for the spout system to operate.

Kit #296250



Electric Over Hydraulic Operation (Optional) (continued)

Auger Fold & Spout Operation

1. Connect the Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.
2. Place the remote in continuous detent so that the Hydraulic Pressure hose is pressurized and set the hydraulic flow to a maximum 6 gal/min to minimum 4 gal/min.
3. To fold auger out from transport to operating position, push down the auger unfold button on joystick face until the upper and lower auger are engaged and fold linkage is over center. See Fig. 3-30.

NOTE: Joystick has a double tap feature, which allows the operator to quickly double tap a function in order to operate it for a set time. If the auger fold or auger unfold buttons are double tapped, the function will stay on for 60 seconds to complete the full cycle without holding the buttons down. Pressing either of those buttons during these timed cycles will CANCEL the cycle. This double tap feature only applies to auger fold and unfold functions.

4. To pivot spout OUT away from cart, push hat switch toward OUT. Hold the switch until desired position is achieved. See Fig. 3-30.
5. To pivot spout IN toward cart, push hat switch toward IN. Hold the switch until desired position is achieved. See Fig. 3-30.
6. To pivot the entire auger UP, press and hold the auger pivot UP button until the desired height is achieved. See Fig. 3-30.
7. To pivot the entire auger DOWN, press and hold the auger pivot DOWN button until the desired height is achieved. See Fig. 3-30.

NOTE: For steps 8 and 9, the directions are reversed for a right-hand unload cart.

8. To pivot the spout FORWARD, push hat switch RIGHT. Hold the switch until desired position is achieved. See Fig. 3-30.
9. To pivot the spout REARWARD, push hat switch LEFT. Hold the switch until desired position is achieved. See Fig. 3-30.




Fig. 3-30

Electric Over Hydraulic Operation (Optional) (continued)

Flow Door Operation

1. To open flow door, rotate the switch upwards. Observe flow door indicator to determine when to release trigger and stop flow door movement. See Fig. 3-31.

2. To close flow door, rotate the switch downwards. Observe the flow door indicator and release trigger when door is closed to desired position. See Fig. 3-32.

Fig. 3-31





Fig. 3-32




Auger Fold to Transport

NOTE: Refer to “Troubleshooting” for EOH, vertical auger and/or rotating spout issues in the MAINTENANCE section.

1. To fold auger from operating position to transport position:
 - A. Rotate spout to centered position. Align the checkered flag decals to locate center as shown in Fig. 3-33.
 - B. Press auger FOLD button on joystick.
 - C. Hold FOLD button until upper auger is on field rest or in transport position.

2. Once unloading is complete, stop hydraulic flow. **ALWAYS** stop continuous detent when auger functions are not required or active.

Fig. 3-33



Cart Loading Sequence

WARNING

- NEVER LOAD THE REAR OF A GRAIN CART FIRST. LOAD THE CART EVENLY TO MAINTAIN WEIGHT ON THE TRACTOR DRAWBAR. LOADING ONLY THE FRONT, OR ONLY THE REAR, CAN CAUSE A LOSS OF CONTROL.

 - TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.

 - UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO THE TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.

 - NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFOCATES VICTIMS IN SECONDS.
1. Ensure auger flow door is closed before loading cart.
 2. Fill the cart starting just forward of the axle until nearly full.

NOTE: Overfilling the front or rear area of the hopper can result in reduced control of the cart when towing.

3. Fill the rear area of the hopper before topping off the front area. This maintains proper weight on the hitch of the tractor.


Vertical & Horizontal Cleanout Door Operation

WARNING


- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

Closing Vertical Cleanout Door

1. Raise the vertical auger to highest position.
2. Park the empty grain cart on a clean level surface. Block the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.



3. To completely close cleanout door, ensure the vertical auger cleanout door top edge clears the vertical position stop (key stop). (FIG. 3-34)
4. Attach eye bolt ends of over center latches to the hooks on the vertical auger. (FIG. 3-34)
5. Clasp the over center latch handles to lock the door in the closed position. (FIG. 3-34)
6. Inspect and verify cleanout door perimeter for gaps. Ensure all grain dust and filings are removed that may prevent the door from shutting completely.
7. If gaps are present, unclasp the over center latch and tighten eye bolt to improve door seal contact on the vertical auger.



8. Rehook eye bolt to vertical auger and clasp the over center latch.

NOTE: Repeat steps 4 - 8, as necessary.



Vertical & Horizontal Cleanout Door Operation (continued)

Opening Vertical Cleanout Door


1. Raise the vertical auger to highest position.
2. Park the empty grain cart on a clean level surface. Block the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.

NOTE: Remove the vertical auger cleanout door to improve vertical auger clean-out.

3. To open and remove the vertical auger cleanout door, unclasp the over center latch. (FIG. 3-35)
4. Unhook the eye bolt from the vertical auger and open the cleanout door. (FIG. 3-35)



5. The hinge on the vertical auger cleanout door is set on a pin. Lift and remove the cleanout door from the vertical auger. Keep vertical auger cleanout door. (FIG. 3-36)
6. Inspect and verify all debris is removed from inside the vertical auger housing.
7. Reattach the vertical cleanout door to the vertical auger.




Vertical & Horizontal Cleanout Door Operation (continued)


Horizontal Cleanout Door

Use the tensioner handle, located on the left-hand side of the grain cart, behind the first panel to open and close the horizontal cleanout doors.


1. Park the empty grain cart on a clean level surface. Block the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.



2. Insert tensioner handle into the cleanout door receiver coupler on the rear panel, and remove lynch pin from rockshaft. Keep lynch pin. (FIG. 3-37)



3. Rotate the tensioner handle clockwise to open the cleanout doors. (FIG. 3-38)
4. Insert and lock lynch pin into rockshaft. (FIG. 3-38)



5. Inspect and verify all debris is removed that may prevent the doors from shutting completely. (FIG. 3-39)

NOTE: As the tensioner handle is rotated counter-clockwise near the end of the close position, the coiled springs will extend to apply pressure to cleanout doors. If the doors do not close or visible door perimeter gaps are present, adjust the rockshaft. See “Horizontal Cleanout Door Adjustment” in the MAINTENANCE section.




6. Remove lynch pin from rockshaft and rotate handle counter-clockwise and clockwise to check for smooth door operation.


Vertical & Horizontal Cleanout Door Operation (continued)

Horizontal Cleanout Door

7. Rotate handle counter-clockwise to close doors and ensure all doors seal. (FIG. 3-40)



8. Insert and lock lynch pin into rockshaft and return handle to storage location. (FIG. 3-41)



Ladder Operation

Side Ladder Operation

WARNING

- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFOCATES VICTIMS IN SECONDS.

NOTE: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.

NOTE: Ensure upper ladder extension is attached to higher holes on the ladder. Reference “Upper Ladder Extension to Operating Position” section in the SET UP section.

NOTE: Always use lock pin in the working and storage position to lock the ladder extension. The lock pin can be inserted in either left-hand or right-hand ladder hole. (FIGS. 3-42 & 3-43)



Ladder Operation (continued)




Storage to Working Position

1. Standing in front of ladder, place hands on outside ladder handles.
2. Keep one hand on ladder handle and with opposite hand, remove lock pin from ladder extension. Retain for future use. (FIG. 3-44)
3. With hands back on ladder handles, push ladder towards hopper bin and lift ladder extension to unseat ladder extension rod from the cradle. (FIG. 3-45)

CAUTION

- THE LADDER IS NOW FREE TO PIVOT.

4. Slowly swing ladder outward until hinge is fully extended and locks in the working position. (FIG. 3-46)




Ladder Operation (continued)

Storage to Working Position

5. Lift and seat ladder extension into shorter leg of “J slot”. (FIG. 3-47)
6. Using lock pin from step 2, insert lock pin into ladder extension and ladder. (FIG. 3-47)

WARNING

- **FALLING FROM AN UNSECURED LADDER MAY CAUSE SERIOUS INJURY OR DEATH. ALWAYS INSERT LOCK PIN BEFORE CLIMBING.**




Working to Storage Position

7. Standing in front of ladder, place hands on outside ladder handles.
8. Keep one hand on ladder handle and with opposite hand, remove lock pin from ladder extension. Retain for future use. (FIG. 3-47)
9. With hands back on ladder handles, lift and unseat ladder extension from shorter leg of “J slot”. (FIG. 3-47)
10. Lower ladder extension until fully seated in longer leg of “J slot”. (FIG. 3-48)




11. Keep one hand on ladder handle and with opposite hand, reach between ladder rungs and grab the ladder hinge hole. (FIG. 3-49)
12. Slowly lift ladder hinge until the ladder starts folding.
13. Remove hand from ladder hinge hole and place onto ladder handle.
14. Slowly push ladder towards hopper bin.




Ladder Operation (continued)

Working to Storage Position

- 15. Lower ladder extension and seat ladder extension rod onto the cradle. (FIG. 3-50)



- 16. Using lock pin from step 8, insert lock pin into ladder extension and ladder. (FIG. 3-51)



Ladder Operation (continued)

Rear Ladder Operation - For SN B44410100 & Higher

⚠ WARNING



- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.
- DO NOT ALLOW ANYONE TO RIDE ON THE LADDER. MAKE SURE EVERYONE IS CLEAR BEFORE OPERATING MACHINE OR TOWING VEHICLE.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER A CART CONTAINING GRAIN. FLOWING GRAIN TRAPS AND SUFFOCATES VICTIMS IN SECONDS.

NOTE: Ensure ladder and steps are free from snow/debris before changing ladder positions and climbing.

NOTE: The lower ladder section must be raised and locked in the storage position when not used.


Storage to Working Position

1. Park the empty grain cart on a firm and level surface. Block the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
2. While holding ladder handle, remove rubber latch from holder. (FIG. 3-52 and 3-53)






Ladder Operation (continued)

3. Slowly swing the lower ladder section completely down to working position. (FIG. 3-54)



Working to Storage Position

1. Slowly lift and swing the lower ladder section up to storage position. (FIG. 3-55)
2. Attach rubber latch to holder to lock ladder in storage position. (FIG. 3-56 and 3-57)






Rear Access Door Operation - For SN B44420100 and Higher

⚠ WARNING

- ENSURE SCREENS OVER HORIZONTAL AUGERS ARE IN PLACE AND PROPERLY SECURED.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

1. Park the empty grain cart on a firm and level surface. Block the tracks on the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
2. Maintain contact with either left or right side Outer handles then turn both door latches 180 degrees counter clockwise. (Fig. 3-54)
3. Use bottom door handle to open door by pushing in. (Fig. 3-55)
4. Push rear access door inward until it stops. While maintaining contact with the outer handles, enter the grain cart.
5. To exit, use inner door handle to open the rear access door, place hand on inner handle and exit grain cart. (Fig. 3-55)
6. While maintaining contact with outer handles, use outer door handle to close the rear access door. (Fig. 3-56)
7. Turn both door latches 180 degrees to lock the rear access door. (Fig. 3-56)



Rear Drop Hitch Operation (Optional) For SN B44420100 and Higher



⚠ WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

Storage to Working Position

NOTE: Keep rear drop hitch in storage position when not in use.

1. Park the empty grain cart on a firm and level surface. Block the tracks on the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
2. Attach a safe lifting device rated for a minimum of 150lbs to the rear drop hitch.
3. Remove the keeper from the pivot pin, then remove the hitch pin from the rear drop hitch. (Fig. 3-57)
4. Slowly pivot rear drop hitch to desired position. (Fig. 3-58)
5. Reinstall pivot pin and keeper into rear drop hitch.. (Fig. 3-58)







Rear Drop Hitch Operation (Optional) For SN B44420100 and Higher (continued)

⚠ WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

Rear Drop Hitch Adjustment

1. Park the empty grain cart on a firm and level surface. Block the tracks on the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
2. Remove the nuts, washers, and bolts from the rear drop hitch.
3. Remove hitch tang and re-install in one of the four positions depending on the height that is needed to maintain a level trailer tongue. There will be a difference of $6 \frac{3}{4}$ " from position 1 to position 4. (Fig. 3-59 through 3-62)
4. Reinstall the nuts, washers, and bolts to the rear drop hitch and torque to specification.



Video System (Optional)

IMPORTANT

- *Do not operate video system below 15°F. Damage to video system can occur.*

The video system includes its own operation instruction sheet.

Weather Guard Tarp

⚠ WARNING

- **TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.**
- **FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.**

IMPORTANT

- *Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.*
- *Tarp should not be used if it is torn or the bungee cords are frayed or show damage. Fully close tarp with tension on the latch plate to prevent water from pooling.*

Always use adequate caution when operating tarp.

If equipped, refer to electric roll tarp manual (26487) for operation details.

Open and close the tarp evenly.

Make sure tarp is open before loading.

Make sure all persons are clear of the tarp system before and during operating.

Do not operate tarp with cart hoisted in an elevated position.

If tarp is covered with snow, it is important to remove snow before operating.

End caps must be free from grain that may be piled on them. Grain should not be heaped higher than the end caps or tarp bows.

Tarp may be fully opened or completely closed while in transit. However, the closed position is recommended.

Ensure everyone who operates the tarp is familiar with the correct procedures outlined in this manual.

Weather Guard Tarp (continued)

NOTE: If equipped with wireless electric roll tarp, skip to step 7 on next page. For weather guard tarp, continue to step 1.


1. Using both hands, carefully remove tarp handle weldment from tube holder. (FIG. 3-69)
2. Roll tarp to the desired location, choosing either a fully open or fully closed position.
3. To close the tarp, rotate the roll tube clockwise up under the latch plate.
4. Make sure tarp is positioned evenly over latch plate length.

NOTE: Do not tighten if tarp overlaps end of the latch plate. Tearing of the tarp may occur. Reposition tarp, as necessary.

5. Bring the tarp handle weldment down perpendicular to the ground. Continue by lifting it up into the tube holder.

NOTE: Tarp handle weldment U-joint may need to be re-indexed on roll tube to achieve correct tension.

6. To open tarp, turn the roll tube counter clockwise until the tarp is fully open. Place tarp handle weldment in tube holder.





Weather Guard Tarp (continued)


Wireless Receiver and Control Box Location

NOTE: Refer to electric roll tarp manual (26487) for wireless operation details.

7. Wireless receiver (9009632) and control box (9005398) mount to the left-hand standard behind the vertical auger as shown. (FIGS. 3-70 & 3-71)



8. Control box wires route along the front of the cart following the isobus harness.
9. Dual connector plug (9005327) attaches to the socket on the back of the tractor as shown. (FIG. 3-72)
10. When electric tarp is not in use, place connector plug into storage caddy. Be sure to route connector plug harness to clear PTO driveline during operation.



Notes


Section IV Maintenance

Lubrication - Cart	4-2
PTO Driveshaft Lubrication	4-4
Hydraulic System	4-5
Purge Hydraulic System	4-5
Wheel, Hub, Spindle Disassembly and Assembly.....	4-6
Wheels & Tires	
Wheel Nut Torque Requirements.....	4-8
Tire Pressure	4-9
Tire Warranty	4-11
Walking Tandem Option	4-12
Inner Dual Wheel Access	4-12
Row Spacing Adjustment.....	4-13
Gearbox	4-15
Manual Override for Optional Electric Over Hydraulic System	4-16
Manual Override for SCV Controlled Spout Rotate & Auger Fold	4-19
Auger System.....	4-21
Vertical Auger Height Check	4-21
Vertical Auger Timing	4-23
Horizontal Auger	4-24
Auger Driveline Bearings	4-25
Belt Tightener Adjustment.....	4-26
V-Belt Alignment	4-28
Split Tapered Bushings.....	4-29
Driveline Removal	4-30
Seasonal Storage	4-32
Baffle Adjustment.....	4-31
Horizontal Cleanout Door Adjustment	4-34
Verify Telescoping PTO Shaft Length	4-36
PTO Shaft Length Adjustment	4-38
PTO Shaft & Clutch.....	4-39
Hydraulic Jack Cylinder Replacement.....	4-41
Horizontal Auger Removal & Replacement.....	4-43
Troubleshooting.....	4-49
Tarp Troubleshooting Inspection & Maintenance	4-51
Electrical System Schematic.....	4-52
Electrical Over Hydraulic (EOH) System Schematic - 5 Function Optional.....	4-59
Optional Electric Over Hydraulic Valve Electric Schematic 5 Function.....	4-60
SCV Controlled Inline Valve Assemblies - Electric Schematic	4-61
Torque Chart - Hardware Grade 5.....	4-62
Torque Chart - Hardware Grade 8.....	4-63
Hydraulic Fittings - Torque and Installation	4-64


FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM
INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.

Lubrication

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.



Lubrication



To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.

Unverferth Mfg. recommends use of NLGI #2 Extreme Pressure grease.

The lubrication locations and recommended schedule are as follows:

ITEM	DESCRIPTION	POINT	LUBRICANT	QTY.	HOURS
A	PTO Driveshaft	3	EP-2	1 Shot	See Chart Below
B	Grease Bank for Auger Pivot Pin - Vertical Upper Auger Hinge	2	EP-2	2 Shots	Daily
C	Gearbox - Check oil level every 2 weeks. Replace oil every season. Refer to Gearbox in MAINTENANCE section for instructions.	1	EP80W90	Approx 85 oz.	Once Every Season
D	Discharge Spout Pivot Grease Points	6	EP-2	1 Shot	Monthly
E*	Grease Bank for Hanger Bearing - Vertical Lower Auger *See note below.	1	EP-2	2 Shots*	Monthly
F	Top Bearing - Vertical Upper Auger	1	EP-2	1 Shot	Each Season
G	Grease Bank for Horizontal Auger End & Center Bearings	2	EP-2	2 Shots	Monthly
H	Grease Bank for Auger Pivot Rings - Front & Rear Auger Hinge	7	EP-2	2 Shots	Daily
I	Hubs	2 / 4	EP-2	Repack	Annually
J	Walking Beam Pivot	2	EP-2	3 Shots	Weekly
K	Grease Slide Plate	1	EP-2	1 Shot	Each Season
L	Tongue Bushing - 1 per side	2	EP-2	2 Shots	Daily
M	Front Horizontal Auger Bearing & Gearbox Support Bearing	2	EP-2	2 Shots	Weekly
N	Walking Tandem Main Frame Pivot	2	EP-2	2 Shots	Each Season
O	Spout Tilt Cylinder Pin	2	EP-2	3 Shots	Weekly
P	Rear Hitch Pivot Pin	2	EP-2	2 Shots	Monthly

***NOTE:** Hanger bearing contains hydraulic shut-off grease zerk (9005240) with pressure relief to prevent over-greasing that could push bearing seals out. If grease is coming out of the relief on the zerk, this is normal and the bearing contains enough grease.


PTO Driveshaft Lubrication

Lubricate with NLGI grade 2 grease before starting work and every 8 operating hours. Clean and grease PTO driveshaft before each prolonged period of non-use. Molded nipples on the shield near each shield bearing are intended as grease fittings and should be lubricated every 8 hours of operation! Check and grease the guard tubes in winter to prevent freezing.


NOTE: Inner & outer profile tubes must have lubrication to operate successfully regardless of whether a grease fitting is provided for that purpose! Inner & outer profile tubes without fittings should be pulled apart and grease should be added manually.

Fig. 4-1

LUBRICATION INSTRUCTIONS FOR DRIVE LINE




8hrs




Cross journal


20hrs



Inner tube



Shield retaining bearing



Push-pin set

COAT INNER AND OUTER PROFILES AT BEGINNING AND END OF EACH SEASON

Hydraulic System

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the grain cart requires little maintenance.

Replacing Hoses/Fittings/Cylinders:

1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3,000 psi.
2. Do not use hoses, fittings and cylinders that have pipe threads.
3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings according to “Torque Specifications” in the MAINTENANCE section.
4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
5. Always purge the hydraulic system after servicing.

Purge Hydraulic System

WARNING

- **HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.**
- **RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR’S MANUAL FOR PROPER PROCEDURES.**
- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. LEAKS OF HIGH-PRESSURE FLUIDS MAY NOT BE VISIBLE. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**
- **KEEP CLEAR OF PINCH POINT AREAS.**
- **FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RASING, OR LOWERING.**



Purge air from system as follows:

- A. Clear all personnel and objects from the area, including where the machine will have full range of motion during the hydraulic movement. Remove transport locks from the machine.
- B. Pressurize the system and maintain the system at full pressure for at least 5 seconds after the cylinder rods stop moving, or hydraulic motors have completed the required movement. Check that all movements are fully completed.
- C. Check oil reservoir in the hydraulic power source and refill as needed.
- D. Pressurize the system again to reverse the motion of step B. Maintain pressure on the system for at least 5 seconds after the cylinder rods stop moving, or hydraulic motors have completed the required movement. Check that all movements are fully completed.
- E. Check for hydraulic oil leaks using cardboard or wood. Tighten connections according to directions in the Torque Specifications in the MAINTENANCE section.
- F. Repeat steps in B, C, D, and E 10-12 times.

IMPORTANT

- *Machine damage will occur if the cylinder is incorrectly installed.*

Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.

Wheel, Hub and Spindle Disassembly and Assembly

WARNING

- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.**
- **FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.**

CAUTION

- **IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.**

IMPORTANT

- *Remove only one wheel and tire from a side at any given time in the following procedure.*
1. Hitch cart to tractor. Park the empty cart on a firm, level surface. Set the tractor's parking brake, shut off engine and remove key. 
 2. With cart empty, use safe lifting and load holding devices rated at 30,000 lbs. to support the weight of your grain cart. Place the safe lifting device under the axle closest to the tire.
 3. Use a safe lifting device rated for at least 3,000 lbs to support the wheel and tire during removal.

WARNING

- **FOR WALKING TANDEM DUAL WHEELS, INNER WHEEL AND TIRE MAY FALL FROM HUB CAUSING SERIOUS INJURY OR DEATH. ALWAYS SUPPORT INNER WHEEL WHEN REMOVING OUTER WHEEL.**

4. If only changing wheel and tire, skip to Step 8; otherwise continue with Step 4.


Remove the hardware retaining the hubcap. Next, remove the hubcap, gasket, cotter pin, castle nut and spindle washer. Remove hub with bearings from old spindle using a 200 lb. safe lifting device.

5. Inspect the spindle and replace if necessary. If spindle does not need to be replaced, skip to Step 6; otherwise continue with Step 5.

Remove the bolt and lock nut that retains the spindle to the axle. Using a safe lifting device rated for 200 lbs., replace the old spindle with a new spindle. Coat axle contact length of spindle shaft (scale or non-scale) with anti-seize lubricant prior to installation. If installing scale spindle, install with 'top' decal facing upwards. Reuse bolt and lock nut to retain spindle to axle. For walking tandem units, use the hole closest to the hub to retain spindle. Tighten as outlined in MAINTENANCE section.

Wheel, Hub and Spindle Disassembly and Assembly (continued)

6. Remove seal and inspect bearings, spindle washer, castle nut and cotter pin. Replace if necessary. Pack both bearings with approved grease and reinstall inner bearing. Install new seal in hub with garter spring facing the outside of hub by tapping on flat plate that completely covers seal while driving it square to hub. (FIG. 4-2) Install until flush with back face of hub. Using a safe lifting device rated for 200 lbs., install hub assembly onto spindle. Install outer bearing, spindle washer and castle nut.



7. Slowly tighten castle nut while spinning the hub until drag causes the hub to stop freely spinning. Do not use an impact! Turn castle nut counterclockwise until the hole in the spindle aligns with the next notch in castle nut. Hub should spin smoothly with little drag and no end play. If play exists, tighten to next notch of castle nut. If drag exists, then back castle nut to next notch of castle nut. Spin and check again. Install cotter pin. Clean face for hub cap gasket and install gasket, grease-filled hub cap and retain hubcap with hardware removed. Tighten hubcap hardware in alternating pattern.
8. Attach the wheel(s) and tire(s) to the hub using the same rated safe lifting device for removal. Tighten wheel nuts to appropriate requirements and recheck as outlined in the Wheel and Tire section of this manual.
9. Raise cart, remove safe load holding devices and lower tire to the ground.

Wheels and Tires

Wheel Nut Torque Requirements

CAUTION

- IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagram 1.

NOTE: Do not use anti-seize on wheel hardware.

WHEEL HARDWARE	
SIZE	FOOT-POUNDS
3/4-16 (UNF)	365 ft.-lbs.
M22x1.5	475 ft.-lbs.




DIAGRAM 1

Wheels and Tires (continued)

Tire Pressure

The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. **It is important that tires are inspected after unit is loaded.** Start with minimum pressure. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. **Do not exceed maximum recommended tire pressure.** Each tire must be inflated to 35 PSI max to seat the beads, deflated to 5-10 PSI, then reinflated to the tire's max PSI when mounting.

Tire Pressure for Grain Carts			
Tire Make	Tire Size	Load Index / Ply Rating	Max. PSI
Firestone	23.1x26 R-3	12	32
	23.1x26 R-1	12	32
	28Lx26 R-3	12	26
	24.5x32 R-3	12	32
	24.5x32 R-1	12	32
	30.5x32 R-1	14	28
	30.5x32 R-3	14	28
	30.5x32 R-3	16	34
	30.5x32 R-1	16	26
	35.5x32 R-3	20	36
	76x50.00x32 HF-3	16	40
	76x50.00x32 HF-3	20	50
	800/65R32 R-1W	172D	41
	800/60R32 R-3	181B	46
	900/65R32 R-3	191B	46
	900/60R32 R-1	176A8	44
	1250/50R32F IF/CFO R-1WNP	201D	46
	1250/50R32F IF/CFO R-1W	188B	30
	520/85R38 R-1	155A8	29
	520/85R38 R-1	173A8	64
	480/80R42 R-1	151A8	36
	520/85R42 R-1	157A8	29
	520/85R42 R-1	165A8	51
	520/85R42 IF/CFO R-1	169A8/B	35
	IF520/85R42 R-1W	169B	35
	VF520/85R42 R-1W	177B	35
	420/80R46 R-1	151A8	44
	480/80R46 R-1	158A8	44
	380/90R46 R-1	152B	51

Wheels and Tires (continued)

Tire Pressure (continued)

Tire Pressure for Grain Carts			
Tire Make	Tire Size	Load Index / Ply Rating	Max. PSI
Titan/Goodyear	23.1x26 R-3	10	26
	23.1x26 R-1	10	26
	24.5R32 R-1	169A8/B (5-Star)	48
	24.5x32 R-3	12	32
	24.5x32 R-1	12	32
	30.5x32 R-3	16	26
	30.5x32 R-3	14	22
	30.5x32 R-1	14	22
	480/80x42 R-1	166A8	23
1100/45R46 F-1W	195D	35	
Mitas	650/75R32 R-1W	172A8	58
	650/75R32 R-1	176A8	41
	800/65R32 R-1W	172A8	46
	900/60x32 R-1W	176A8	41
	900/70R32 R-1W	188A8	53
	1050/50x32 R-1W	178A8	41
	1250/50R32 R-1W	188A8	41
	900/60x38 R-1W	181A8	44
	520/85x42 R-1W	162A8	44
	650/65x42 R-1W	168A8	44
Alliance	30.5B32	18-Ply	36
	35.5LR32	193A8	44
	900/60R32 R-1W	192D	46
	1050/50R32 R-1W	185A8	52
	1250/50R32 R-1W	201B	46
Trelleborg	VF1050/50R32 R-1	198D	52
	900/50R32 R-1W	181A8	55
	900/60x32	176LI	44
	850/55R42 R-1W	161A8	32

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Following are phone numbers and Websites for your convenience:

Firestone	www.firestoneag.com Phone 800-847-3364
Titan or Goodyear	www.titan-intl.com Phone 800-USA-BEAR Fax 515-265-9301
Trelleborg	www.trelleborg.com Phone 866-633-8473
Continental/Mitas	www.mitas-tires.com Phone 704-542-3422 Fax 704-542-3474
Alliance	www.atgtire.com Phone 781-325-3801

Walking Tandem Option

WARNING

- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL SAFE LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- OUTER WHEEL AND TIRE MAY FALL FROM HUB CAUSING SERIOUS INJURY OR DEATH. ALWAYS SUPPORT OUTER WHEEL WHEN SERVICING INNER WHEEL.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.

CAUTION

- WHEN CHANGING TIRES OR ROW SPACING, IT IS IMPORTANT TO FOLLOW THE STEPS BELOW TO MAINTAIN STABILITY OF THE CART. CHANGE ONE SIDE AT A TIME.
- IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Inner Dual Wheel Access

Use the following procedure to service the inside dual tires.

1. Park the cart on a firm level surface and hitch cart to tractor and chock tractor wheels.
2. Using a safe lifting device rated for 30,000 lbs., raise one side of cart by lifting under the outer end of rear support tube.
3. Using a safe lifting device rated for 4,000 lbs., support the rear portion of the walking tandem assembly.
4. Remove rear retaining hardware, then pivot walking tandem assembly outward to access inner wheel.

Walking Tandem Option (continued)

Inner Dual Wheel Access (continued)

NOTE: Walking tandem assembly must be suitably supported during and after pivoting.

5. After inner wheel service is complete, pivot walking tandem back into position.
6. Reattach and torque capscrews removed in step 4.
7. Remove safe load holding devices.



Row Spacing Adjustment

From the factory, the machine will straddle 30" rows. The following procedure will allow the machine to straddle 36" rows. This procedure involves switching inner and outer tire positions and moving the entire assembly out approximately 9". (FIG. 4-4)

1. Park the empty cart on a firm, level surface. Block the tires on the machine to keep it from moving. Set the tractor's parking brake, shut off the engine, remove the ignition key and disconnect the PTO shaft and hydraulics from the tractor and cart.
2. Using a safe lifting device rated for 30,000 lbs., raise one side of cart by lifting under the outer end of rear support tube.
3. Using a safe lifting device rated for 4,000 lbs., support the rear portion of the walking tandem assembly.
4. Remove the rear retaining hardware. Then pivot walking tandem to access inner wheel.



NOTE: Walking tandem assembly must be suitably supported during and after pivoting.

5. Remove the 1 1/8" bolt and loosen front axle beam clamp bolts and extend front pivot beam out approximately 9 inches.
6. Retain same original tread direction and reinstall the previous "Outer" side of tire to the inside hub and the previous "Inner" side of tire to the outer hub.
7. Pivot walking tandem assembly in towards the cart and align bracket mounting holes with cross beam mounting plate. Use outer holes.
8. Reinstall 1 1/8" bolt and torque 640 ft.-lbs. Reinstall rear retaining hardware, tighten front beam clamp bolts and torque 260 ft.-lbs. Lower cart to the ground.

Use same procedures for the opposite side of cart.

Walking Tandem Option (continued)

Use the following procedures for extending the entire assembly only.

1. Using a safe lifting device rated for 30,000 lbs., raise one side of cart by lifting under the outer end of rear support tube. Using a safe lifting device rated for 4,000 lbs., to support weight of tires and walking beam assembly.
2. Loosen the front axle clamp hardware. Remove the 1 1/8" bolt located toward the center of the front axle. Remove the rear retaining hardware.
3. Set rear assembly to desired width. Adjust front sliding extension to match rear. Verify alignment side-to-side. Tighten clamp bolts and reinstall 1 1/8" hardware.

Use same procedures to opposite side of cart.

Gearbox

When checking the oil level of the gearbox, the vertical auger should be pivoted all the way down.

For adequate lubrication the oil should be visible in the sight glass. Fill with oil to the sight glass only.

For Maximum gearbox life:

Check oil level every 2 weeks.

Replace oil every season with approximately 85 oz 80W90 EP lubricant.




Fig. 4-5

Manual Override for Optional Electric Over Hydraulic System

⚠ WARNING


- MOVING OR ROTATING AUGER COMPONENTS CAN CAUSE SERIOUS INJURY OR MACHINE DAMAGE. BEFORE OPERATING MANUAL OVERRIDE(S), ENSURE EVERYONE IS AWAY FROM THE SPOUT AND THAT THE SPOUT WILL NOT CONTACT ANY OTHER PARTS OF THE GRAIN CART. ALL CONTROL SWITCHES ARE DEACTIVATED WHILE UTILIZING MANUAL OVERRIDE(S).
- MOVING OR ROTATING PTO COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT OPERATE PTO WHILE UTILIZING MANUAL OVERRIDE(S).
- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RASING, OR LOWERING.

IMPORTANT

- Spout must be centered before operating the auger fold. Align checker flag decals to ensure spout rotate is centered.

NOTE: Manual override operation is intended for emergency use ONLY and is not intended for continuous operation. Spout may rotate into cart causing damage.

NOTE: Manual override operation allows the spout and auger to move regardless of location.



1. Park the empty grain cart on a firm and level surface. Block the machine to keep it from moving. Set the tractor's parking brake. Keep engine running.

Manual Override for Optional Electric Over Hydraulic System
(continued)

2. Remove cover plate (295569B) from the bottom of the lower auger housing to access the EOH block assembly. Keep cover plate. (FIG. 4-7)
3. Connect the desired Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.
4. To operate the manual override function, place the tractor SCV remote in continuous detent so that the Hydraulic Pressure hose is pressurized.

(continued on next page.)



Manual Override for Optional Electric Over Hydraulic System (continued)

NOTE: Only one cartridge valve (9008416 & 9008463) must be in the top or bottom detent position at a time to function properly. All other valves must be in the middle detent position. (FIG. 4-8 & 4-9)

5. Operate the desired function on valve (9008416 & 9008463) by rotating the manual override knurled knob from the locked neutral position. (FIG. 4-8, 4-9, & 4-11)
6. Push and hold the manual override button on valve (9008438). (FIG. 4-10)
7. Once the desired position is reached, release manual override button on valve (9008438).
8. Return knurled knob to center and lock valve (9008416) & (9008463) in position. (FIG. 4-8, 4-9 & 4-11)

NOTE: Refer to “Troubleshooting” for EOH, vertical auger and/or rotating spout issues in the MAINTENANCE section.

9. Turn off hydraulic circuit when done. Correct electric/hydraulic system before continued use. Consult your dealer for service and parts.
10. Replace cover plate (272606B) from step 2 to the bottom of the lower auger housing.




FIG. 4-8




FIG. 4-9



FIG. 4-11




FIG. 4-10

Manual Override for SCV Controlled Spout Rotate & Auger Fold

WARNING


- MOVING OR ROTATING AUGER COMPONENTS CAN CAUSE SERIOUS INJURY OR MACHINE DAMAGE. BEFORE OPERATING MANUAL OVERRIDE(S), ENSURE EVERYONE IS AWAY FROM THE SPOUT AND THAT THE SPOUT WILL NOT CONTACT ANY OTHER PARTS OF THE GRAIN CART. ALL CONTROL SWITCHES ARE DEACTIVATED WHILE UTILIZING MANUAL OVERRIDE(S).
- MOVING OR ROTATING PTO COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT OPERATE PTO WHILE UTILIZING MANUAL OVERRIDE(S).
- FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RASING, OR LOWERING.

IMPORTANT

- Spout must be centered before operating the auger fold. Align checkered flag decals to ensure spout rotate is centered.

NOTE: Manual override operation is intended for emergency use ONLY and is not intended for continuous operation. Spout may rotate into the cart causing damage.

NOTE: Manual override operation allows the spout and auger to move regardless of location.




1. Park the empty grain cart on a firm and level surface. Block the machine to keep it from moving. Set the tractor's parking brake. Keep engine running.
2. Remove cover plate (295569B) from the bottom of the lower auger housing to access the auger fold / spout rotate interlock valve assemblies. Keep cover plate.
3. Connect the desired spout rotate hoses (tan hose grips) or auger fold hoses (green hose grips) to the tractor SCV.
4. To operate the manual override function, set tractor SCV to a maximum of 4 gpm and place the tractor SCV for the desired function in continuous detent in the direction of flow that operates the spout rotate or auger fold direction desired.

Manual Override for SCV Controlled Spout Rotate & Auger Fold (continued)


NOTE: Operate one cartridge valve (9009186) at a time. Keep other valve in normal position. (FIG. 4-13 & 4-14)

5. Locate the desired valve (9009186). (FIG 4-13)



6. Pull and hold the knob out on valve from normal position to manual override position. (FIG. 4-14)
7. Once the desired position is reached, release knob on valve from manual override back to normal position.
8. Turn off hydraulic circuit when done. Correct electric/hydraulic system before continued use. Consult your dealer for service and parts.

NOTE: Refer to “Troubleshooting” and for inline valve, vertical auger and/or rotating spout issues in the MAINTENANCE section.



9. Replace cover plate (295569B) from step 2 to the bottom of the lower auger housing. (FIG. 4-15)



Auger System

WARNING

- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL INJURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 2,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING MACHINE.
- WHEN WORKING AROUND THE IMPLEMENT, BE CAREFUL NOT TO BE CUT BY SHARP EDGES.




Vertical Auger Height Check

Before servicing the vertical auger, park the unit on a firm, level surface. Block the machine to keep it from moving. Raise vertical auger to discharge position and close horizontal auger flow door. Set the tractor parking brake, turn off tractor engine, remove ignition key, and disconnect PTO shaft and hydraulic lines from tractor.

Annually check all bolts, nuts, and set screws for tightness. Replace the vertical auger top bearing hardware, as necessary. (FIG. 4-16)

(Continued on next page)



Auger System (continued)

Vertical Auger Height Check (continued)

NOTE: The lower auger position is indexed from the drive dog / tube flange hinge surface as shown. (Figs. 4-18 & 4-19)

Fig. 4-19




Fig. 4-17

Align Upper Auger Center Pipe With Auger Tube Flange





Fig. 4-18

***IMPORTANT: Align Top Flat Surfaces Of Drive Dog And Auger Tube Flange**



Auger System (continued)

Vertical Auger Timing

1. For the lower vertical auger, use the top edge of the flighting as a 12 o'clock reference. Position the drive dog so the driving edge is at the 11 o'clock position. (FIG. 4-20)

NOTE: Looking down at the lower flighting (FIG. 4-20) the auger rotation will be counter-clockwise. When looking up at the upper flighting (FIG. 4-21) the auger rotation will be clockwise.

2. For the upper auger, use the outer edge of the flighting as a 12 o'clock reference. Position the driven edge of the drive pin at the 4 o'clock position. (FIG. 4-21)

3. When engaged, the upper flighting should follow the lower flighting. (FIG. 4-22)

NOTE: Upper flighting should trail the lower flighting from minimum of 10 degrees to a maximum of 90 degrees.





Fig. 4-22

Lower Auger

Fig. 4-20




Drive Dog
Driving Edge
At 11 O'Clock
Reference

Finishing Edge
of Flighting At
12 O'Clock
Reference.

Upper Auger

Fig. 4-21

Starting Edge of Flighting At 12 O'Clock Reference.



Drive Pin At 4 O'Clock
Reference

Auger System (continued)


Horizontal Auger

Annually check all bolts, nuts, and set screws. Perform lubrication as specified in “Lubrication” section.

NOTE: With new flighting, the outside diameter is about 3/4” from the bottom belly pan. Always set bearing height using the flighting centerline measurement. See FIG. 4-23.

NOTE: Shims are available from your Brent dealer to achieve 10 1/8” measurement.


To adjust the bearing height down, shim with washers between the bearing and the hanger bracket. To adjust the bearing height up, shim with washers between the bearing bracket and the sides of the cart. When adjusting the height up, washers will need to be placed with one on each side so the bearing stays centered.



Auger Driveline Bearings

IMPORTANT

- Periodically check set screws in all bearings at either end of the driveline for tightness. (FIG. 4-24 & 4-25)



Belt Tightener Adjustment

IMPORTANT

- Do not use belt dressing.
- Keep grease and oil off of belt and pulleys.

NOTE: Pulleys do not need to be removed to remove/replace belt.

Due to prolonged use, belt wear may be evident causing slack. To correct this, follow these steps.


1. Park the unit on a firm, level surface. Block the machine to keep it from moving. Set the vehicle parking brake, shut off the engine and remove the ignition key from the towing vehicle.



WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

2. Remove PTO assembly from Gearbox input shaft.
3. Detension the belt as outlined in OPERATION section. Remove belt tensioner handle.
4. Remove cover and inspect belts for misalignment, loose parts and cracks. Replace if necessary with a matched set. See Fig. 4-28.



Belt Tightener Adjustment (continued)


5. Belt tension is adjusted with hex nuts below the spring. All belt tension **MUST** be released from linkage. Loosen outer hex nut and adjust inner nut to establish a 3 1/16" pre-load dimension between the heavy washers. Tighten the outer hex nut against inner nut to lock position. (Fig. 4-29)
6. Check the lower belt pulley to ensure belt is aligned in their grooves. Using the belt tensioner handle, engage the roller/idler linkage against the belt and over-center stop. The compressed spring should now be approximately 1 3/4" between the washers and generating a force of approximately 480 lbs. against the belt. (Fig. 4-30)
7. Release and tighten belt multiple times to confirm positions and final adjustments. See Fig. 4-30 and Fig. 4-31.
8. Tighten belt to reinstall the cover guard and the PTO shaft to the gearbox input shaft. Clear work area and test-run drivetrain for 3 minutes at 1000 PTO RPM.

⚠ WARNING

- **MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.**

9. Disengage PTO, turn off towing vehicle and remove the ignition key. Through the cover access door, check the compressed spring length is approximately 1 3/4" between the washers and check each belt for uniform tension. If more adjustment is needed, refer to Steps 5 through 7. If no additional spring adjustment is available, then both belts must be replaced with a new matched set.

NOTE: Always replace belts in matched sets.



V-Belt Alignment

1. Pulleys must be aligned with the fixed idler. Belts should be centered on idler for longest belt life. (Fig. 4-32)



Fig. 4-32

2. After tightening taper-lock bushing hardware, lay a straight edge across face of the drive and driven belt pulleys to ensure alignment between the grooves on the pulleys. (FIG. 4-33)




Fig. 4-33

V-Belt Alignment (continued)

Split Tapered Bushings


Check annually for tight engagement to driveshaft. Torque three bolts progressively the following values.

For the smaller gearbox bushing (9007376): 3/8"-16UNC hardware. Torque to 75 ft-lbs.

For the larger horizontal auger bushing (9004813): 9/16"-12UNC hardware. Torque to 90 ft.-lbs.

Some gap must remain between flange & hub when bushing is properly tightened.

To remove from shaft, remove capscrews and insert them in tapped holes in bushing flange. Tighten progressively until bushing disengages.



Driveline Removal

DANGER

- ENTANGLEMENT WITH THE DRIVELINE WILL CAUSE SERIOUS INJURY OR DEATH. KEEP ALL GUARDS AND SHIELDS IN GOOD CONDITION AND PROPERLY INSTALLED AT ALL TIMES. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOE STRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC. THAT CAN BECOME ENTANGLED IN A ROTATING DRIVELINE.

WARNING

- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.

Gearbox shaft guard has access doors for installing and removing of driveline.

1. Remove clamping cone/retaining bolt.
2. Use a hammer and punch, if needed, to moderately hit the end of clamping cone/retaining bolt, as shown. (FIG. 4-35)
3. Once clamping cone/retaining bolt is removed, slide torque limiter off gearbox splined input shaft.




Fig. 4-35

Seasonal Storage

Always open and keep open the flow door, horizontal and vertical auger cleanout doors to remove any remaining grain and to allow moisture to dry.

Wash machine inside and out before storing to remove dirt and debris that can draw and collect moisture. When using pressure washers maintain an adequate distance so not to force water into bearings.

Reattach PTO brackets (296155Y) to the inside right-hand side of the tongue and place PTO assembly on brackets.

Lubricate machine at all points outlined.

Repaint all areas where paint has been removed to keep rust from developing. Rust will affect grain flow.

Coat exposed cylinder piston rods with rust preventative material if applicable.

Inspect machine for parts that may need to be replaced so they may be ordered in the off season.

If unit is equipped with a scale indicator or electric hydraulic controls store these indoors in a dry location.

Close the tarp to keep debris out of the hopper.

Rear access door is latched closed.

Ladders are in storage position.



Baffle Adjustment

WARNING

- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE THE CART, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE CART.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL INJURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.

The horizontal auger baffles are factory-set at the lowest position. This position results in the lowest power requirements and longest flighting life. Once grain has been run through the unit, adjustments can be made to achieve the ideal unloading performance.

Refer to the following reasons for baffle adjustment:

NOTE: To unload the cart evenly from front to back the openings should increase in height from back to front.

- If higher flow is desired and torque is not the limiting factor, raise each baffle to an incremental amount and rerun.
- If more material remains at the back of the cart towards the end of the unloading cycle, the back baffles should be adjusted upward in incremental amounts and rerun.
- If more material remains at the front of the cart towards the end of the unloading cycle, the back baffles should be adjusted downward in incremental amounts and rerun.
- If the cart requires more torque than what is available at times during the unloading cycle, then all baffles should be adjusted downward in incremental amounts.

(Continued on next page)



Baffle Adjustment (continued)

Before making any baffle adjustments, close horizontal auger flow door. Securely block the grain cart, set the tractor parking brake, turn off tractor engine and remove ignition key.

If a higher flow is desired and torque is not a factor, loosen the (2) flange nuts on each baffle, see figure 4-37. Use the lift handle to raise each baffle to the desired position, retighten both flange nuts, see figures 4-37 & 4-38.

NOTE: DO NOT REMOVE ANY SCREEN PANELS. The flange nuts are best accessed using an extended socket wrench and 9/16" socket through the screen panel openings.

NOTE: Screen removed in figure 4-38 for illustration only.




Horizontal Cleanout Door Adjustment

WARNING


- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEANOUT DOORS ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.

1. Park the unit on a firm, level surface. Block the machine to keep it from moving. Set the tractor parking brake, turn off tractor engine, remove ignition key, and disconnect PTO shaft.
2. Loosen all the hardware in the slotted brackets connecting the cleanout door rockshaft to the grain cart tube. (Fig. 4-39)
3. Starting at the front of the cart, using a jack, push the rockshaft up and toward the runner tube. (Fig. 4-39)




NOTE: Ideal distance between the runner tube and rockshaft is 3 1/4". (FIG. 4-40)

4. When the rockshaft is in position, torque the hardware previously loosened to 28 ft.-lbs.
5. Continue repositioning the rockshaft moving toward the back of the cart.




Horizontal Cleanout Door Adjustment (continued)

6. Rotate the tensioner handle counter-clockwise to close the doors allowing the plate to fit and seal into the belly pan opening. (Fig. 4-41)



7. If plate insert needs adjustment, loosen the two flat head machine screws holding the plate in position. (Fig. 4-42)
8. Ensure the plate inserts are aligned and fit into the belly pan cut-outs. (Fig. 4-42)
9. Close the doors and ensure all doors seal.
10. Insert lynch pin into rockshaft and return handle to storage location.



Verify Telescoping PTO Shaft Length

⚠ WARNING

- PROPER EXTENDED AND COLLAPSED LENGTHS OF THE TELESCOPING PTO SHAFT MUST BE VERIFIED BEFORE FIRST OPERATION WITH EACH TRACTOR. IF THE EXTENDED LENGTH OF THE PTO SHAFT IS NOT SUFFICIENT, IT MAY BECOME UNCOUPLED IN OPERATION AND CAUSE SERIOUS INJURY OR DEATH FROM CONTACT WITH UNCONTROLLED FLAILING OF PTO SHAFT ASSEMBLY COMPONENTS.

IMPORTANT

- Check the length of the telescoping members to ensure the driveline will not bottom out or separate when turning and/or going over rough terrain.

An excessive collapsed length can result in damage to the PTO driveline and attached components. This is most likely to occur during extreme turning angles and/or travel over rough terrain. Conditions are amplified on tractors with tracks operating in uneven terrain, particularly rice levies. Damaged driveline components can result in unsafe operation and severely reduced driveline component life.

NOTE: Do not exceed 10 degrees beyond a straight pull line while operating the PTO. To verify proper extended and collapsed lengths, use the following procedure:

1. Fully collapse PTO shaft and measure length "L" (Figure 4-43).

Enter here: _____ (1)

(Verify that outer tube does not bottom out on surrounding plastic shield components).

2. Pull apart PTO telescoping shaft ends and measure lengths "T" & "C" (Figure 4-44)

Add "T" + "C" measurements together

Enter total here: _____ (2)

3. Calculate maximum recommended extended length:

- a. Subtract line 1 from line 2

Enter here: _____ (a)

- b. Divide line (a) by 2

Enter here: _____ (b)

- c. Add line (b) to line 1.

Enter here: _____ (c)

- d. Subtract 3 inches from line (c)

Enter here: _____ (d)




Fig. 4-43






Fig. 4-44

This is the maximum recommended extended length.

Verify Telescoping PTO Shaft Length (continued)

4. Hitch tractor drawbar to cart, ensuring that tractor and cart are on level ground and coupled as straight as practical.
5. Connect PTO shaft to tractor, and measure length “L” from same points as used in step 1. Ensure that this measurement does not exceed the maximum recommended extended length calculated in step 3 above. If necessary, choose a shorter drawbar position, or obtain a longer PTO shaft assembly before operating cart.
6. Position the tractor to obtain the tightest turning angle, relative to the cart (Figure 4-45).
7. Measure the length “L” from the same points as used in step 1. **This distance must be at least 1.5 inches greater than the distance measured in step 1.** If necessary, adjust the length of the PTO shaft by cutting the inner and outer plastic guard tubes and inner and outer sliding profiles by the same length. Round off all sharp edges and remove burrs before greasing and reassembling shaft halves. (FIG. 4-46)







PTO Shaft Length Adjustment

WARNING

- CHECK THE LENGTH OF THE TELESCOPING MEMBERS TO ENSURE THE DRIVELINE WILL NOT BOTTOM OUT OR SEPARATE WHEN TURNING AND/OR GOING OVER ROUGH TERRAIN.

NOTE: Maximum operating length LB. (Refer to “Verify Telescoping PTO Shaft Length” in this section for LB length.)





1. To adjust length, hold the half-shafts next to each other in the shortest working position and mark them.
2. Shorten inner and outer guard tubes equally.
3. Shorten inner and outer sliding profiles by the same length as the guard tubes.
4. Round off all sharp edges and remove burrs. Grease sliding profiles.



PTO Shaft and Clutch

To Dismantle Guard (Figs. J1 - J4)






1. Remove locking screw.
2. Align bearing tabs with cone pockets.
3. Remove half-guard.
4. Remove bearing ring.



PTO Shaft and Clutch (continued)




To Assemble Guard (Figs. K1 - K5)

1. Grease yoke groove and inner profile tube.
2. Fit bearing ring in groove with recesses facing profile tube.
3. Slip on half-guard.
4. Turn cone until it engages correctly.
5. Install locking screw.



To Assemble Cone (Figs. L1 - L3)

1. Dismantle guard (Figs. J1 - J3). Remove old cone (e.g. cut open with knife). Take off chain. Place neck of new cone in hot water (approx 80° C / 180° F) and pull onto bearing housing (Fig. L1).
2. Turn guard cone into assembly position (Fig. L2). Further assembly instructions for guard (Figs. K1 - K5).
3. Reconnect chain if required (Fig. L3).




Hydraulic Jack Cylinder Replacement

WARNING

- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. LEAKS OF HIGH-PRESSURE FLUIDS MAY NOT BE VISIBLE. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 100 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

1. Park the empty unit on a firm, level surface. Block tractor and machine to keep it from moving. Set the tractor parking brake, shut off the engine and remove the ignition key. Completely disconnect the PTO from the cart and tractor.

2. Attach hydraulic jack hoses to tractor SCV.



3. Open valve and lower jack leg to ground. DO NOT raise tongue.


4. Relieve pressure on hydraulic jack circuit. See tractor operator manual for procedure.

5. Close valve.

6. Support the hydraulic jack assembly with a safe lifting device rated for a minimum of 100 lbs.


7. Remove hydraulic jack hoses from tractor SCV.

8. Remove cylinder pin (272587) and snap rings (91192) from the base end of the cylinder at the lug on top of the tongue. (FIG. 4-47)



Hydraulic Jack Cylinder Replacement (continued)

9. Remove hydraulic jack assembly from the tongue. (FIG. 4-48)
10. On new hydraulic assembly (296288B), attach hoses (9006068) and fittings to cylinder (9009047) as shown in FIG. 4-48. The valve needs to be assembled to the hose on the base end of the cylinder. Assemble the fittings on the cylinder so they face each other, then store the hydraulic hoses on the hose caddy.
11. To reassemble hydraulic jack, see “Install Hydraulic Jack (Optional)” in SET UP section.



Horizontal Auger Removal and Replacement

WARNING

- TO PREVENT PERSONAL INJURY OR DEATH WHILE SERVICING, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE ARE RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL INJURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 1,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

NOTE: Open the flow gates all the way.

1. Park the unit on a firm, level surface. Block the machine to keep it from moving. Set the vehicle parking brake, shut off the engine and remove the ignition key and disconnect the PTO shaft from the tractor.




NOTE: For SN B44410099 & lower, skip to step 4.

2. Remove 4 rear ladder capscrews attached to the cart. Keep capscrews. (FIG. 4-49)
3. Remove rear ladder from the cart. (FIG. 4-49)



NOTE: For SN B44410100 & higher, skip to step 5.

NOTE: Keep all hardware for re-assembly.



Horizontal Auger Removal and Replacement (continued)

4. For SN B44410099 & lower, remove the SMV bracket located on the rear auger cover. (Fig. 4-50)
5. Remove the capscrews from the auger cover. (Fig. 4-50)
6. Pry the auger from the auger tube. (Fig. 4-51)
7. Using a safe lifting device rated for a minimum 1,000 lbs., pull the rear auger out of the cart. (Fig. 4-52)




Horizontal Auger Removal and Replacement (continued)


NOTE: If only servicing rear auger, skip to step 23. For 5-pin driver replacement, continue to step 8.

8. Remove the flange screws in both middle grates inside the cart. Remove the grates. (Fig. 4-53)


NOTE: Retain all hardware for reassembly.



9. Remove locknuts, baffle weldments and cover plates from the middle tent. (Fig. 4-54)
10. Disconnect grease line. (Fig. 4-54)
11. Remove the bearing mount bar bolts on each side of the auger.
12. Remove capscrews and lock washers holding bearing onto the bearing mount bar.




13. Remove bearing mount bar to allow access to work on the bearing and shaft. Remove two center tube connecting capscrews, spacer bushings (283895B) and locknuts from the horizontal auger. (Fig. 4-55)




Horizontal Auger Removal and Replacement (continued)

14. Remove the original 5-pin driver, bearing and the bushing insert. (Figure 4-56 & Figure 4-57)
15. Discard 5-pin driver.




16. Substantially coat bushing insert with anti-seize.
17. Slide bushing insert into front auger and ensure tube holes are aligned. (Figure 4-57 & Figure 4-58)




NOTE: Make sure the set screws on bearing are towards the front of the cart. (Figure 4-59)

18. Slide bearing onto 5-pin driver. (Figure 4-59)
19. Insert new 5-pin driver into front auger and ensure tube holes are aligned.
20. Install front capscrews, spacer bushings and locknuts 180 degrees from each other and assemble spacer bushings on threaded side of capscrews. Hand tighten hardware. (Figure 4-59)



Horizontal Auger Removal and Replacement (continued)

21. Install hanger bracket. Leave the capscrews loose attaching hanger bracket to the cart. Attach hanger bracket to the bearing. (Figure 4-60)
22. Reattach grease line components. (Figure 4-60)




NOTE: Rear auger flighting should lead the front auger flighting.

23. Slide the rear auger forward. Align the pins and holes with the rear auger pipe. (Figure 4-61)




24. Extend a string tightly from front to rear to check horizontal auger alignment. Measure the string to the auger tube either in front or behind the hanger bearing. If this dimension is 1/8" greater than the measurement taken in the front and rear, shims (8GA - 286419B or 12GA - 286424B) are required on top of the center hanger bearing. Ideally the center measurement should be equal to or 1/8" lower than the measurements on the ends of the augers. (Figure 4-62)





NOTE: The shims are 1/8" thick each. Add as needed. See "Auger System - Horizontal Auger" in MAINTENANCE section for more details.

25. Torque hanger bracket capscrews to 130 ft.-lbs. See Figure 4-60.
26. Torque auger capscrews to 200 ft.-lbs. (Figure 4-63)



Horizontal Auger Removal and Replacement (continued)

- 27. Torque hardware for the rear auger cover. (Fig. 4-64)
- 28. For SN B44410100 & higher, torque hardware for the rear ladder. (Fig. 4-65)
- 29. For SN B44410099 & lower, torque SMV bracket back onto the cart. (Figure 4-64)
- 30. Reinstall ALL the grates.



Troubleshooting

Problem Possible Cause Corrective Action

No Manual Override (EOH / SCV Contolled) functions work	Not getting 12 Volt power supply to the power harness in the tractor	Check the connections to the main power harness in the tractor cab, and check the 5 AMP fuse in the fuse holder of the main power harness. Replace fuse if necessary.
	Not getting good connection at Deutch connectors in the harnesses	Unplug the Deutsch connectors at the hitch point and in the extension harness (if used). Clean up the connectors with electrical contact cleaner. Make sure the connectors are aligned correctly and re-connect them.
	Not pressurizing the correct hydraulic hose	Make sure the quick couplers are properly connected to the tractor SCV and the Hydraulic Pressure line is being pressurized when engaging the tractor SCV.
Auger unfolds, but won't fold back into a transport position	Rotating Spout is not in the folding position	Rotate the spout so it is positioned straight down or forward in order to fold the auger into a transport position.
	Rotating spout switch is faulty or out of adjustment	Make sure the spout is in the centered position. Refer to the manual override sections in order to fold the auger back into a transport position. Inspect the switch assembly near the rotating spout cylinder. The clearance between the end of the proximity switch and the barrel of the rotating spout cylinder must not exceed 1/4".
Auger unfolds part way and stops	Debris in the EOH block on the auger fold cylinder	Fold auger, remove the Coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil.
	Rotating Spout switch is out of adjustment or has been activated.	With the auger folded in to the road transport rest, have someone depress and hold the switch at the vertical auger hinge plate. Use any means necessary to depress the switch without placing your hands or other body parts near the pinch points. With the switch depressed, rotate the spout to the folding postion.

Troubleshooting (continued)

Problem	Possible Cause	Corrective Action
Rotating spout will not function	7 pin connector is not plugged into tractor.	Plug in 7 pin connector to same power source as the 5 function controller.
	Proximity Switch at the auger hinge is not getting Power or Ground.	Check power and ground to the proximity switch harness on the vertical auger. Make sure the center pin on the 7 pin plug has +12V key switch power.
	Proximity switch located at the hinge plate is not adjusted correctly.	This proximity switch has a 1/4" effective operating range. The upper auger hinge plate needs to be within that range when it is unfolded in to the operating position. Adjust the proximity switch in or out in order for the sensor to activate when it is in the operating position.
	Switch located at the hinge plate of the vertical auger is not getting power, ground or is defective	Check the ground wire located near the hydraulic valve at the base of the vertical auger and on the left hand standard just behind the front plate of the harness. Unplug the 3 pin connector on the hinge plate proximity switch. With a multi-meter or test light, confirm that the pin in socket B has +12V constant power and socket A has +12V when the sensor is activated.
One single function will not work	Defective coil on the EOH valve for that function	Loosen the cap for the coils associated with that function on the EOH valve. Depress the button on the remote, and determine if the coils are getting magnetized. Inspect the wiring connectors to these coils, and replace the coil if necessary.
	Defective valve on the EOH valve for that function	Remove the coil and the cartridge valve on the EOH valve block for that function. Replace the valve if it doesn't operate when the coil is magnetized.
	Debris in the EOH block at the base of the vertical auger	Remove the coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil.
Functions continue to operate after the button on the remote is released	Tractor hydraulic flow is set too high	Turn tractor hydraulic flow down so that flow doesn't exceed 6 gallons per minute.
	Defective valve on the EOH valve for that function	Remove the Coil and the cartridge valve on the EOH valve block for that function, and replace the cartridge.

Tarp Troubleshooting Inspection & Maintenance

PROBLEM	SOLUTION
TARP SAGS IN MIDDLE AREAS	<ol style="list-style-type: none"> 1. BOWS MAY BE BENT OR ADJUSTED TOO LOW 2. MISSING OR LOOSE RIDGE STRAP REPLACE OR RETIGHTEN 3. TENSION MAY BE TOO LOOSE. U-JOINT MAY NEED TO BE ADJUSTED ON SPLINED SHAFT TO PROVIDE MORE TENSION
HOLES OR TEARS IN TARP	<ol style="list-style-type: none"> 1. CONSULT YOUR LOCAL DEALER FOR REPAIRS 2. ORDER TARP REPAIR KIT (9005581) FROM DEALER 3. WHEN NEW TARP OR PARTS ARE NEEDED ALWAYS REPLACE WITH ORIGINAL PARTS

Inspection and Maintenance

⚠ WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.

IMPORTANT

- *Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.*
- *Tarp should not be used if it is torn or the bungee cords are frayed or show damage. Fully close tarp with tension on the latch plate to prevent water from pooling.*

Periodic preventive maintenance should be practiced. Inspect tarp and hardware often for abrasions or loosened bolts that may need adjustment and/or repair. Check bungee cords for wear and adjust tension at the beginning of the season and again half way through the season.

Tears in tarp should be addressed before further tarp operation. If water pools on tarp, adjust tension of tarp cables and/or crank handle tension.


If installed correctly, tarp should always operate as well as when first installed. If tarp does not pass this simple inspection, make all appropriate repairs or adjustments immediately before serious damage occurs.

Electrical System Schematic


GRAIN CART WIRES

White -- Ground
Green -- Right amber flashing lamp
Yellow -- Left amber flashing lamp
Brown -- Amber Clearance and
Red Tail Lights (Low Filament)
Red -- Red Brake Lights (High Filament)
Black -- Work Lights
Blue -- 12V Key Switch Power

SAE SEVEN-POINT
CONNECTOR PLUG



Electrical System Schematic




- MOTOR REVERSING RELAY MOUNTING INSTRUCTIONS:**
1. SELECT A DESIRED MOUNTING LOCATION AS CLOSE TO THE BATTERY AS POSSIBLE.
 2. USING THE RELAY AS A TEMPLATE, MARK THE CENTERS OF THE MOUNTING HOLES.
 3. USING A 1/4" DRILL BIT, DRILL THE HOLES MARKED IN THE PREVIOUS STEP.
 4. MOUNT THE RELAY USING THE PROVIDED BOLTS AND NUTS.
 5. WIRE THE RELAY ACCORDING TO THE WIRING DIAGRAM.
 6. APPLY DIELECTRIC GREASE TO ALL ELECTRICAL CONNECTIONS.


NOTE: See separate electric tarp manual for additional information.

11/1398 ELECTRIC TARP


Electrical System Schematic - Front Harness #9009547




Electrical System Schematic - Rear Harness #9009586




**Electrical System Schematic
Clearance Light Harnesses #9006481**



Electrical Diagram — Work Light Wiring Harness #9008969




Electrical System Schematic - Proximity Switch #9007223




METRI-PACK 150 WIRING CHART		
WIRE COLOR	PIN NO.	FUNCTION
BLACK	A	SIGNAL
BROWN	B	+12 V DC
BLUE	C	GROUND


Electrical System Schematic - Main Harness #9007290 (Opt.)



NOTE: For Optional Electric Over Hydraulic 5 Function Valve.




Electrical System Schematic - Diverter Harness #9007266



CONNECTOR TYPE: 2 PIN DEUTSCH PLUG

PIN #	WIRE COLOR	FUNCTION
1	RED	+12V POWER
2	WHITE	GROUND


Electrical System Schematic - Work Flood Lamp #9008957



2 PIN INTEGRATED
DEUTSCH CONNECTOR

POWER (PIN #1)
GROUND (PIN #2)


Electrical System Schematic - Amber Lamp #9005142



YELLOW - TURN AND FLASHER AMBER LIGHT

WHITE - GROUND


Electrical System Schematic - Micro Dot, LED Light #9006107




MALE BULLET
CONNECTORS

AMBER LED LIGHT

Electrical System Schematic - Auger Harness #9009531




Electrical System Schematic - Adapter Harness, AG to RV #9009843 (Optional)




Electrical System Schematic — Red Lamp #9006282



**Electrical Over Hydraulic (EOH) System Schematic
 5 Function Optional**




Optional Electric Over Hydraulic Valve Electric Schematic 5 Function




PORT	END OF CYLINDER	FUNCTION
A	BUTT END	FLOW DOOR
B	RAM END	FLOW DOOR
C	RAM END	AUGER FOLD
D	BUTT END	AUGER FOLD
E	RAM END	SPOUT TILT
F	BUTT END	SPOUT TILT
G	ORBIT MOTOR LEFT-HAND PORT	JOYSTICK / SPOUT ROTATE
H	ORBIT MOTOR RIGHT-HAND PORT	JOYSTICK / SPOUT ROTATE
I	BUTT END	AUGER PIVOT
J	RAM END	AUGER PIVOT
P		JOYSTICK / TRACTOR PRESSURE
T		JOYSTICK / TRACTOR RETURN

SCV Controlled Inline Valve Assemblies - Electric Schematic

AUGER FOLD



SPOUT ROTATE



NOTE: For hydraulic connections chart, refer to “Hitching to Tractor - Hydraulic Connections” in the MAINTENANCE section.

Complete Torque Chart

Capscrews - Grade 5

NOTE:

- Grade 5 capscrews can be identified by three radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.



SIZE	FOOT POUNDS	NEWTON METERS
1/4-20	8-10	11-13
1/4-28	9-11	12-15
5/16-18	15-17	20-23
5/16-24	17-19	23-26
3/8-16	25-28	34-38
3/8-24	28-31	38-42
7/16-14	40-45	54-61
7/16-20	45-50	61-68
1/2-13	62-68	84-92
1/2-20	68-75	92-102
9/16-12	90-98	122-133
9/16-18	100-110	134-148
5/8-11	120-135	162-183
5/8-18	124-137	168-186
3/4-10	200-220	270-300
3/4-16	210-230	285-310
7/8-9	330-350	425-475
7/8-14	360-380	460-515
1-8	500-525	675-710
1-14	540-560	730-760
1 1/8-7	600-635	815-860
1 1/8-12	665-700	920-950
1 1/4-7	850-895	1150-1215
1 1/4-12	940-990	1275-1340
1 3/8-6	1125-1175	1525-1590
1 3/8-12	1280-1335	1735-1810
1 1/2-6	1500-1560	2035-2115
1 1/2-12	1685-1755	2285-2380

IMPORTANT

- Follow these torque recommendations except when specified in text.

Complete Torque Chart

Capscrews - Grade 8



NOTE:

- Grade 8 capscrews can be identified by six radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

SIZE	FOOT POUNDS	NEWTON METERS
5/16-18	20-22	27-30
5/16-24	21-23	28-31
3/8-16	35-39	47-53
3/8-24	36-41	49-55
7/16-14	54-58	73-78
7/16-20	55-60	75-80
1/2-13	82-88	110-120
1/2-20	94-99	125-135
9/16-12	127-134	170-180
9/16-18	147-155	199-210
5/8-11	160-170	215-230
5/8-18	165-175	225-235
3/4-10	280-295	380-400
3/4-16	330-365	445-495
7/8-9	410-430	555-580
7/8-14	420-440	570-595
1-8	630-650	850-880
1-14	680-700	920-950
1 1/8-7	900-930	1220-1260
1 1/8-12	930-950	1260-1290
1 1/4-7	1250-1300	1695-1760
1 1/4-12	1280-1320	1735-1790


IMPORTANT

- Follow these torque recommendations except when specified in text.

Hydraulic Fittings - Torque and Installation


SAE Flare Connection (J. I. C.)

1. Tighten nut with finger until it bottoms the seat.
2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



SAE Straight Thread O-Ring Seal

1. Ensure jam nut and washer are backed up to the back side of smooth portion of elbow adapter.
2. Lubricate o-ring.
3. Thread into port until washer bottoms onto spot face.
4. Position elbows by backing up adapter.
5. Tighten jam nut.



Section V Parts

Please visit www.unverferth.com/parts/ for the most current parts listing.

Decals.....	5-2
Touch-Up Paint.....	5-5
Vertical Auger Flighting Components.....	5-6
Horizontal Auger Components.....	5-8
Hopper Cross Brace & Cleanout Door Components.....	5-10
Hopper Flow Door Components.....	5-12
Front and Rear Flow Door Components.....	5-14
Flow Door Indicator Assembly.....	5-16
Side Ladder Components.....	5-18
Front End Components.....	5-20
Sideboards - Model 1198.....	5-22
Sideboards - Model 1398.....	5-23
Axle & Hub Components - Model 1198 Single Wheels.....	5-24
Axle & Hub Components - Model 1398 Single Wheels.....	5-26
Walking Tandem Assembly Components.....	5-28
Walking Tandem Mounting Components.....	5-30
Wheels & Tires.....	5-31
Dual Wheels & Tires.....	5-31
Track Axle Components - Model 1198 & 1398 w/36x148, 42x131, 42x148, & 50x148.....	5-32
Track Axle Components - Models 1198 w/36x112 & 36x131.....	5-34
Track Panel Kit Components.....	5-35
Rear Drop Hitch Components (Optional) - For SN B44410100 & Higher.....	5-36
Rear Ladder Components - For SN B44410100 & Higher.....	5-37
Rear Access Door Components - For SN B44410100 & Higher.....	5-38
Lower Auger Cleanout Door, Covers & Rest Components.....	5-40
Lower Auger Linkage Components.....	5-42
Idler Assembly Components.....	5-44
Lower Auger Retaining Components.....	5-46
Auger Fold Linkage Components.....	5-48
EOH Valve Functions & Wire Locations 5 Spool (Optional).....	5-51
EOH Valve Assembly Components 5 Spool (Optional).....	5-52
EOH Tractor Circuit Hydraulic Components (Optional).....	5-54
EOH Spout Rotate and Tilt Hydraulic Components (Optional).....	5-56
Auger Pivot Hydraulic Components.....	5-58
Auger Fold Hydraulic Components.....	5-59
Flow Door Circuit Hydraulic Components.....	5-60
SCV Controlled Inline Valve Assemblies - Valve Functions & Wire Locations.....	5-61
SCV Controlled Inline Valve Assembly Components.....	5-62
SCV Controlled Inline Valve - Auger Fold Hydraulic Components.....	5-63
SCV Controlled Inline Valve - Spout Rotate Hydraulic Components.....	5-64
Cylinders.....	5-65
Auger Grease Bank Components.....	5-66
Switch Assembly Components for Rotating Spout.....	5-68
Downspout Components.....	5-70
Cut Out Clutch PTO Assembly.....	5-72
Cut Out Clutch Components.....	5-73
Gearbox Components.....	5-74
Hopper Rear Electrical Components.....	5-76
Electrical Components.....	5-78
Weather Guard Tarp.....	5-80
Hydraulic Jack - Kit #296288B (Optional).....	5-82
Video System (Optional).....	5-84

FOR SCALE, TRACK, UHARVEST, ELECTRIC TARP, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE INDIVIDUAL MANUALS.


Decals

Please visit www.unverferth.com/parts/ for the most current parts listing.

Front & Tongue View

LEFT-HAND AUGER SHOWN
RIGHT-HAND AUGER SIMILAR


NOTE: Decals also on back side of the lower auger.



Decals (continued)

Please visit www.unverferth.com/parts/ for the most current parts listing.


Rear View




UM
unverferth
Wheel Products
unverferth.com

Always consult your operator's manual for correct tire pressure and wheel hardware torque specifications.

Left-Hand Side View



**LEFT-HAND AUGER SHOWN
RIGHT-HAND AUGER SIMILAR**




Decals (continued)

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9003127	Reflector 2x9 =AMBER=	8	
2	9003126	Reflector 2x9 =RED=	2	
3	9003125	Reflector 2x9 =FLUORESCENT=	2	
4	9003474	Decal, DANGER (Electrical Lines)	2	
5	9003475	Decal, WARNING (Cut & Crush)	4	
6	9003476	Decal, WARNING (No Riders)	3	
7	9003477	Decal, IMPORTANT (Operation)	1	
8	9006588	Decal, Brent Logo	4	
9	9008947	Decal, IMPORTANT (Grease)	7	
10	9004966	Decal, IMPORTANT (Cart Loading)	2	
11	9006589	Decal, Stripe	14	
12	9009168	Decal, WARNING (Ladder Lock Pin)	1	
13	94094	Decal, WARNING (Tongue Rise)	1	
14	9009650	Decal, Hose Legend	1	
15	900024	Decal, WARNING (High Pressure Oil)	2	
16	9009631	Decal, Avalanche	1	
17	94754	Decal, UM Wheel Systems	1	
18	95839	Decal, WARNING (Pinch Point)	6	
19	95046	Decal, DANGER (Entanglement)	2	
20	97961	Decal, WARNING (Read Manual)	2	
21	TA1-906109-0	Decal, WARNING (Moving Parts Crush/Cut)	2	
22	97575	Decal, CAUTION (Transport Chain)	1	
23	95445	Decal, DANGER (Do Not Use Hands)	1	
24	9005971	Decal, WARNING (Suspension)	2	
25	91605	Decal, FEMA	2	
26	95008	Decal, CAUTION (Slippery Surface)	1	
27	98229	Decal, WARNING (Falling Equipment)	2	
28	9003478	Decal, DANGER (Never Play)	1	
29	TA510514	SMV Emblem	1	
30	9008151	Decal, IMPORTANT (PTO Engagement)	1	
31	9008714	Decal, Rear SIS 20MPH	1	
32	9008715	Decal, Front SIS 20MPH	1	
33	9008720	Decal, Rear SIS 30KPH	1	
34	9008721	Decal, Front SIS 30KPH	1	
35	9009499	Decal, 1198	4	
36	9009500	Decal, 1398		
37	9009646	Decal, WARNING (Towing Capacity)	1	
38	9008543	Decal, IMPORTANT (Spout Rotate)	2	
39	9008626	Decal, Flow Door Control Indicator RH	1	For Right-Hand Unload
40	9006601	Decal, Flow Door Control Indicator LH	1	For Left-Hand Unload

Touch-Up Paint


Please visit www.unverferth.com/parts/ for the most current parts listing.



PAINT	SPRAY
Black	97013
Green	97015
Red	97301
Primer, Gray	9500082
Silver Mist	97012
Black Metallic	9504382

Vertical Auger Fighting Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Vertical Auger Flighting Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9007366	Gearbox 1 3/4"-20 Spline Input Shaft 2 1/4"-17 Spline Output Shaft	1	See "Gearbox" in this section for parts.
2	9404-030	Lock Washer, 5/8"	8	
3	9390-124	Capscrew, 5/8"-11UNC x 2" G5	6	
4	289898B	Bearing Bracket Replacement Kit (Black)	1	Includes Items 6 and 7
5	9388-102	Carriage Bolt, 1/2"-13UNC x 1" G5	4	
6	9405-088	Flat Washer, 1/2" USS	4	
7	9390-101	Carriage Bolt, 1/2"-13UNC x 1 1/2" G5	4	
8	9390-122	Capscrew, 5/8"-11UNC x 1 1/2" G5	2	
9	9004731	Pillow Block Bearing, 2 1/2" Bore	1	
10	284636	Grease Pipe	1	
11	9003397	Lock Nut/Top, 1/2"-13UNC	4	
12	9004764	90° Elbow, 1/8" NPTF Female	1	
13	9002492	Bearing 2" Dia. Flanged	1	
14	9004899	Spring - 10 Coils	4	
15	9390-136	Capscrew, 5/8"-11UNC x 6" G5	4	
16	9801	Lock Nut, 5/8"-11UNC	4	
17	9404-025	Lock Washer, 1/2"	5	
18	283515	Auger Tube Adapter	1	
19	288813	Drive Dog, Double Lobe	1	
20	9390-159	Capscrew, 3/4"-10UNC x 7" G5	2	
21	9802	Lock Nut, 3/4"-10UNC	2	
22	9007377B	Dust Cover =Black=	1	
23	407699	Washer Plate, 2 1/2" Dia.	1	
24	9390-100	Capscrew, 1/2"-13UNC x 1 1/4" G5	1	
25	9405-098	Flat Washer, 5/8" SAE	6	
26	296316B	Lower Auger Replacement Kit (Black)	1	Includes Items 27-29 Fits 2 1/4"-17 Spline Gearbox Output Shaft
27	287802	Auger Drive Plate Assembly	1	Includes Items 28 & 29
28	9007000	Drive Head Pin	5	
29	902614-238	Spiral Pin, 1/2" Dia. x 2 3/4"	1	
30	297405B	Upper Auger Replacement Kit (Black)	1	Includes Items 31-38 For SN B44120100 & Higher
	295510B	Upper Auger Weldment =Black=		Includes Items 31-37 For SN B44120099 & Lower
31	284626	Flex Coupler Bushing Assembly	1	Includes End Ring and Self Lubricating Bushing
32	281912	Soft Start Replacement Kit	1	Includes Items 33-37 and Self Lubricating Bushing
33	9004878	Self Lubricating Washer	1	
34	9390-119	Capscrew, 1/2"-13UNC x 8" G5	1	
35	410511	Spacer Bushing	1	
36	9800	Locknut, 1/2"-13UNC	1	
37	281283	Soft Start Assembly	1	
38	297221B	Hanger Bearing Weldment =Black=	1	For SN B44120100 & Higher
	288246B			For SN B44120099 & Lower

Horizontal Auger Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Horizontal Auger Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	283097G	Cover Plate =Green=	1	
	283097R	Cover Plate =Red=		
2	283895	Spacer Bushing, 1 1/4" OD x 0.813" ID x 1 1/8"	2	
3	286282	Adapter/Shaft Bushing Weldment =Primed=	1	
4	286381B	Bearing Mounting Bar =Black=	1	
5	286424B	Bearing Shim Plate =Black=	2	As Required
6	294130B	Front Drag Auger Replacement Kit (Black)	1	includes Items 7 - 11
7	283537	Auger Shaft 2.25" Dia.	1	
8	283535	Auger Tube Adapter	1	
9	294136B	Front Auger Weldment =Black=	1	
10	91299-157	Capscrew, 3/4"-10UNC x 6" Grade 8	2	
11	9802	Lock Nut, 3/4"-10UNC	2	
12	293954B	Rear Auger Weldment =Black=	1	
13	293957	Auger Coupler Shaft Weldment	1	
14	9002479	Adapter 1/8"-27 NPTF Male x 1/8"-27 NPSM Female Swivel Nut	1	
15	9002492	Bearing/Flanged 2" Dia.	1	
16	9002689	Grease Hose 1/8" x 12", 3000 PSI	1	
17	9004731	Pillow Block Bearing with 2 1/2" Bore	1	
18	9004764	90° Elbow 1/8" Female NPTF x 1/8" Female NPTF	1	
19	9005072	90° Elbow 1/4" Tube x 1/8"-27 NPTF Swivel Nut	1	
20	9006964	Nipple 1/8" NPT Male x 1/8" NPT Male	1	
21	91262	Capscrew, 3/8"-16UNC x 1" G5	9	
22	91267	Lock Nut, 1/2"-13UNC	2	
23	9388-104	Carriage Bolt, 1/2"-13UNC x 1 1/2" G5	2	
24	9390-124	Capscrew, 5/8"-11UNC x 2" G5	4	
25	9390-160	Capscrew, 3/4"-10UNC x 7 1/2" G5	2	
26	9394-014	Hex Nut, 5/8"-11UNC Grade 5	4	
27	9404-029	Lock Washer, 5/8"	6	
28	9802	Lock Nut, 3/4"-10UNC	2	

Hopper Cross Brace & Cleanout Door Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	271566B	Stop Bushing =Black=	1	
2	271664B	Cleanout Door Weldment =Black=	6	(Walking Tandem)
			5	(Single Axle & Tracks)


Hopper Cross Brace & Cleanout Door Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
3	271700B	Front Link Arm Weldment =Black=	1	
4	271568B	Rear Link Arm Weldment =Black=	1	(Walking Tandem)
	271702B	Rear Link Arm Weldment =Black=	1	(Single Axle)
5	286417	Door Link Spring =Black=	12	(Walking Tandem)
		Door Link Spring =Black=	10	(Single Axle & Tracks)
6	286414B	Pivot Door =Black=	6	
7	273753B	Door Latch Weldment =Black=	1	
8	284401B	Top Wheel Well Brace Plate =Black=	1	(Walking Tandem) Not Used on Tracks
	283444B	Top Wheel Well Brace Plate =Black=	1	(Single Axle)
9	271765B	Wheel Well Brace Plate =Black=	2	(Single Axle Only)
10	296630B	Cross Tube Weldment =Black=	1	For SN B44120100 & Higher Model 1198
	296638B	Cross Tube Weldment =Black=	1	For SN B44130100 & Higher For Model 1398
11	284435B	Cross Tube Weldment =Black=	1	For SN B44120099 & Lower Model 1198
	284392B	Cross Tube Weldment =Black=	1	For SN B44130099 & Lower Model 1398
12	296639B	Cross Tube Weldment (Inside) =Black=	2	For SN B44120100 & Higher Model 1198
	296637B	Cross Tube Weldment (Inside) =Black= (SHOWN)	2	For SN B44130100 & Higher For Model 1398
13	284407B	Cross Tube Weldment (Inside) =Black=	2	For SN B44120099 & Lower Model 1198
	284393B	Cross Tube Weldment (Inside) =Black=	2	For SN B44130099 & Lower Model 1398
14	9002058	Center Lock Flange Nut, 1/2"-13UNC Grade 5	36	For SN B44120100 & Higher
			24	For SN B44120099 & Lower
15	9003396	Locknut, 3/8"-16UNC Grade 5	10	
16	9003397	Locking Flange Nut, 1/2"-13UNC Grade 5	1	
17	9005305	Lynch Pin, 3/8" Dia. x 3"	1	
18	9006351	Clamp	6	
19	9006352	Top Plate	6	
20	91262	Large Flange Screw, 3/8"-16UNC x 1" Grade 5	30	
21	91263	Large Flange Nut, 3/8"-16UNC Grade 5	30	
22	91266	Flange Screw, 1/2"-13UNC x 1 1/4" Grade5	36	For SN B44120100 & Higher
			24	For SN B44120099 & Lower
23	9390-015	Capscrew, 1/4"-20UNC x 3 1/2" Grade 5	12	
24	9390-056	Capscrew, 3/8"-16UNC x 1 1/4" Grade 5	10	
25	9390-108	Capscrew, 1/2"-13UNC x 3 1/4" Grade 5	1	
26	97189	Large Flange Hex Nut, 1/4"-20UNC Grade 5	12	
27	9007108	Gasket	26 Ft.	(Single Axle, Tracks)
			32 Ft.	(Walking Tandem)
28	TA8B95	Cotter Pin, 1/8" Dia. x 1 15/16"	10	(Single Axle, Tracks)
			12	(Walking Tandem)
29	9405-076	Flat Washer, 3/8"	10	
30	286418B	Cleanout Door Doubler Plate =Black=	10	(Single Axle, Tracks)
			12	(Walking Tandem)
31	903171-660	Flat Head Phillips Screw, 5/16"-18UNC x 1"	20	(Single Axle, Tracks)
			24	(Walking Tandem)
32	9405-070	Flat Washer, 5/16" USS	20	(Single Axle, Tracks)
			24	(Walking Tandem)
33	91257	Large Flange Hex Nut, 5/16"-18 UNC	20	(Single Axle, Tracks)
			24	(Walking Tandem)
34	296827B	Cross Pipe Weldment =Black=	1	For SN B44120100 & Higher (Tracks Only)
35	295870B	Middle Cross Tube Weldment =Black=	1	For SN B44120099 & Lower (Tracks Only)
36	9390-113	Capscrew, 1/2"-13UNC x 5" Grade 5	2	(Tracks Only)
37	9800	Locknut, 1/2"-13UNC	2	
38	296665B	Brace Bar =Black=	6	For SN B44130100 & Higher

Hopper Flow Door Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Hopper Flow Door Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	294155B	Flow Door Linkage Replacement Kit =Black=	1	Includes Items 2 - 4
	2	294153B	Flow Door Linkage Weldment =Black=	1
	3	271331*	Seal Plate	4 *Not for individual sale, see Item 1
	4	282187B	Tent Hole Cover Plate =Black=	2
5	284187B	Cover Plate =Black=	1	
6	284723B	Center Door Weldment Left-Hand =Black=	1	
7	284724B	Center Door Weldment Right-Hand =Black=	1	
8	266285	Idler Pin 1" Dia. x 4 1/2"	1	
9	271112	Idler Pin 1" Dia. x 4"	1	
10	294080B	Front Tent (Service Kit) (Black)	1	Refer to "Front and Rear Flow Door Components" for parts list.
11	294081B	Rear Tent (Service Kit) (SHOWN) (Black)	1	(For Single Axle & Tracks) Refer to "Front and Rear Flow Door Components" for parts list.
	294082B	Rear Tent (Service Kit) (Black)	1	(For Walking Tandem) Refer to "Front and Rear Flow Door Components" for parts list.
12	284887B	Flow Door (Service Kit)	1	Refer to "Front and Rear Flow Door Components" for parts list.
13	804572	Pin 1" Dia. x 3 1/2"	1	
14	9002575	Hydraulic Cylinder 3" x 16"	1	
15	9390-103	Capscrew 1/2"-13UNC x 2" Grade 5	4	
16	9391-046	Cotter Pin 3/16" Dia. x 2"	6	
17	9394-010	Hex Nut 1/2"-13UNC Grade 5	4	
18	9404-025	Lock Washer 1/2"	4	
19	95585	Capscrew/Large Flange 3/8"-16UNC x 3/4" Gr.5	60	
20	9874	90° Elbow 9/16"-18 JICM x 3/4"-16 Adj ORMB	2	
21	93426	Grease Zerk	1	
22	9005073	Quicklinc Fitting 1/4" Tube x 1/8" NPT Straight	1	
23	9005074	Tube, Nylon 1/4" OD	3	Specify in Feet
24	9002538	Coupling-Pipe 1/8" NPT	1	
25	9005072	Quicklinc Fitting 1/4" Tube x 1/8" NPT Elbow	1	
26	9008159	Large Flange Locknut 3/8"-16UNC	64	
27	91263	Locknut 3/8"-16UNC	20	
28	91262	Nut/Large Flange 3/8"-16UNC x 1" Grade 5	4	

Front and Rear Flow Door Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Front and Rear Flow Door Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES	
1	294080B	Front Tent Service Kit (Black)	1	Includes Items 2-5	
	2	294076B	Front Tent Weldment =Black=	1	
	3	283135B	Front LH Baffle =Black=	1	
	4	283136B	Front RH Baffle =Black=	1	
	5	271054*	Cylinder Mount Plate	-	*Not for individual sale, see Item 1
6	294081B	Rear Tent Service Kit (Black) (Shown)	1	For Single Axle & Tracks Includes Items 7-9	
	294082B	Rear Tent Service Kit (Black)	1	For Walking Tandem Includes Items 7-9	
	7	294077B	Rear Tent Weldment =Black= (Shown)	1	For Single Axle
		294079B	Rear Tent Weldment =Black=	1	For Walking Tandem
	8	282139B	Rear LH Baffle =Black=	1	
9	283138B	Rear RH Baffle =Black=	1		
10	284887B	Flow Door Service Kit (Black)	1	Includes Items 11-19	
	11	284848B	Front Door Weldment Left-Hand =Black=	1	
	12	284847B	Front Door Weldment Right-Hand =Black=	1	
	13	284850B	Rear Door Weldment Left-Hand =Black=	1	
	14	284849B	Rear Door Weldment Right-Hand =Black=	1	
	15	9003396	Locknut 3/8"-16UNC	14	
	16	284168	Spacer Bushing, 2 1/4" OD x 1/2"	14	
	17	284169	Roller Bushing, 1/4" OD x 7/16" ID	14	
	18	9005471	Flat Washer, 3/8"	14	
19	91299-057	Capscrew, 3/8"-16UNC x 1 1/2"	14		
20	91263	Locknut, 3/8"-16UNC Gr.5	16		
21	284721B	Baffle Weldment =Black=	8		

Flow Door Indicator Assembly

Please visit www.unverferth.com/parts/ for the most current parts listing.




Flow Door Indicator Assembly**Please visit www.unverferth.com/parts/ for the most current parts listing.**

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	293760R	Complete Indicator Assembly	1	Includes Items 1 through 17
1	271582	Push Rod Indicator	1	
2	271585	Bushing - Coupler	1	
3	271589	Cable Tube (Push Rod)	1	
4	271593	Reducer Bushing	1	
5	271595R	Flow Door Indicator =Red=	1	
6	9006610	Seal (Wiper)	1	
7	9008593	Inner Cable (Conduit) - 3/16" Dia. x 112 1/2"	1	
8	9008612	Seal (Shaft)	1	
9	9006630	Rod End, 3/8"	1	
10	9006634	Connector Fitting	1	
11	9006635	Quad Ring	1	
12	9006636	Wear Ring	1	
13	271597	Wire Stop	1	
14	9006640	Hose Fitting	1	
15	9006641	Snap Ring	1	
16	9006644	Retaining Ring - Internal	1	
17	293759	Plastic Tubing - 92"	1	

Side Ladder Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Side Ladder Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2003029	Nylon Bushing, .625" OD x .406" ID x .380"	6	
2	289294B	Plate-Bracket, Ladder =Black=	1	
3	2003030	Nylon Bushing, .875" OD x .531" ID x .563"	4	
4	9405-088	Flat Washer, 1/2" USS	6	
5	9390-107	Capscrew, 1/2"-13UNC x 3" G5	4	
6	9003397	Lock Nut/Top, 1/2"-13UNC	4	
7	TA620384	Plastic Stop, 1" Dia. x .250"	8	
8	9005305	Lynch Pin 3/8" Dia. x 3"	1	
9	99985	Button Head Socket, 3/8"-16UNC x 1 1/4"	2	
10	9008159	Lock Nut/Top, 3/8"-16UNC	6	
11	9003503	Rivet 3/16 X 1/4	8	
12	289284B	Ladder Link Weldment =Black=	1	
13	9390-057	Capscrew, 3/8"-16UNC x 1 1/2" G5	4	
14	289328B	Ladder Extension Weldment =Black=	1	
15	289326B	Ladder Weldment =Black=	1	
16	289715B	Step Weldment =Black=	1	
17	289707B	Ladder Extension Weldment =Black=	1	
18	289840B	Ladder Bracket =Black=	1	
19	289844B	Ladder Weldment =Black=	1	
20	9388-029	Carriage Bolt, 5/16"-18UNC x 2" G5	4	
21	9405-064	Flat Washer, 5/16" ID USS	9	
22	901527	Lock Nut/Center, 5/16"-18UNC	9	
23	9388-024	Carriage Bolt, 5/16"-18UNC x 3/4" G5	4	
24	9388-102	Carriage Bolt, 1/2"-13UNC x 1" G5	4	
25	91267	Flange Nut 1/2-13 UNC G5	4	
26	9004998	Rivet Burr, 3/16"	4	
27	9390-027	Capscrew, 5/16"-18UNC x 5/8" G5	1	
28	97879	Nylon Lanyard	1	

Front End Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9004898	Transport Chain 41,000#	1	Standard
	PF1238-19	Transport Chain 61,000#	1	Replaces Standard Grain Cart Transport Chain
2	271687B	Spring Retainer Plate =Black=	2	
3	9390-053	Capscrew, 3/8"-16UNC x 3/4" Grade 5	3	
4	271800G	Tongue Weldment =Green=	1	
	271800R	Tongue Weldment =Red=		
	271800BM	Tongue Weldment =Black Metallic=		
5	273237	Nylon Pad	2	
6	273368	Tongue Pin, 2" Dia. x 7 3/4"	2	
7	295799B	Hose Caddy Weldment =Black=	1	

Brent 1198/1398 — Parts


Front End Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
8	294085B	Hose Caddy Cover =Black=	1	
9	296159	Hose Retainer	1	
10	9003849	Hose Wrap 3"	3	Specify in Feet
11	91256	Large Flange Capscrew 5/16"-18UNC x 3/4" Grade 5	6	
12	91257	Large Flange Hex Nut, 5/16"-18UNC Grade 5	14	
13	282875B	CAT 4 Hitch =Black=	1	Standard 1198 & 1398
14	271887B	CAT 5 Conversion Kit =Black=	1	1398 Optional - Includes Items CAT 5 Hitch, 19, 39, 58
15	282876	CAT 4 Hitch Pin, 1" Dia. x 5 1/2"	1	
16	281691	CAT 5 Hitch Pin, 1" Dia. x 7 3/8"	1	
17	284780	Hitch Bar CAT 4	1	Non-Scale
18	9004910	Load Bar 3 3/4" Dia. with 16 ft. Cable CAT 4	1	Standard 1198 & 1398
19	9008119	Load Bar 3 3/4" Dia. with 16 ft. Cable CAT 5	1	1398 Optional
20	296155Y	PTO Bracket =Yellow=	2	
21	91267	Flange Nut, 1/2"-13UNC Grade 5	2	
22	296156	PTO Holder Bushing, 1 3/8" ID	1	
23	295840	Driveline Storage Rod	1	
24	9405-088	Flat Washer 1/2"	1	
25	9001498	Rubber Pad	1	
26	9008857	Window & Trim Assembly 14 15/32" x 19 21/32"	2	
27	9008933	Pan Head Screw 8"-18UNC x 1/2"	26	
28	9001917	Tension Bushing	1	
29	9001968	Trailer Connector Holder	1	
30	9002130	Split Tension Bushing, 2" Dia.	1	
31	9009602	Rubber Grommet, 1 3/8" OD x 3/4" ID	2	
32	9005230	PTO Assembly Complete	1	1 3/4"-20 Spline, W2500
33	9005259	O-Ring 2" Dia.	4	
34	9005473	Split Tension Bushing, 2 3/8" Dia.	4	
35	9008634	Toolbox	1	
36	9006456	Spring, 4.75" Thick	2	
37	9006457	Spring, 2.50" Thick	2	
38	91192	Retaining Ring, 1"	2	item 14
39	9005376	U-Nut 3/8"-16UNC	3	
40	271891B	Shield Tube =Black=	1	
41	91299-191	Capscrew, 1"-8UNC x 4" Grade 8	1	
42	92199	Center Locknut, 1"-8UNC	2	
43	9390-003	Capscrew, 1/4"-20UNC x 3/4" Grade 5	2	
44	9390-006	Capscrew, 1/4"-20UNC x 1 1/4" Grade 5	2	
45	9390-130	Capscrew, 5/8"-11UNC x 3 1/2" Grade 5	2	
46	91299-195	Capscrew, 1"-8UNC x 6" Grade 8	1	
47	9390-464	Capscrew, 1"-8UNC x 10" Grade 5	4	
48	9936	Locknut, 1/4"-20UNC Grade 5	4	
49	903171-663	Phillips Head Machine Screw, 5/16"-18UNC x 1 1/2"	8	
50	9405-064	Flat Washer, 5/16" ID	4	
51	94763	Fender Washer, 2" Dia.	2	
52	95905	Center Locknut, 5/8"-11UNC	2	
53	9663	Locknut, 1"-8UNC Grade 5	4	
54	281663	Poly Wear Shoe For CAT 3	1	Optional
55	281898	Poly Wear Shoe For CAT 4	1	Standard 1198 & 1398
56	281899	Poly Wear Shoe For CAT 5	1	1398 Optional
57	296421B	GCM Mounting Bracket =Black=	1	
58	97420	Flange Screw 1/4"-20UNC x 3/4" Grade 5	4	
59	97189	Large Flange Hex Nut, 1/4"-20UNC	4	
60	9000104	Cable Tie, 21 1/2"	2	
61	902875	Center Locknut, 3/8"-16UNC	1	
62	9390-062	Capscrew, 3/8"-16UNC x 2 3/4" Grade 5	1	
63	9005011	Jack	1	
64	9007632	Jack Pin, 7/8" Dia. x 4 7/8" with Chain	1	Standard
65	295491G	Scale Display Cover Plate =Green=	1	
	295491R	Scale Display Cover Plate =Red=		
	295491BM	Scale Display Cover Plate =Black Metallic=		

Sideboards - Model 1198


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	220032B	Angle Brace Tube =Black=	2	
2	295755B	Board Weldment Front, Right-Hand =Black=	1	
3	295756B	Board Weldment Rear, Right-Hand =Black=	1	
4	295757B	Board Weldment Front, Left-Hand =Black=	1	
5	295758B	Board Weldment Rear, Left-Hand =Black=	1	
6	295941B	Front Board Replacement Kit (Black)	1	Includes Front Board, Items 8 & 20
7	295942B	Rear Board Replacement Kit (Black)	1	Includes Rear Board, Items 8 & 20
8	250431	Window Moulding	2	
9	295761B	RH Front Sideboard Corner Plate =Black=	1	
10	295762B	RH Rear Sideboard Corner Plate =Black=	1	
11	295759B	LH Front Sideboard Corner Plate =Black=	1	
12	295760B	LH Rear Sideboard Corner Plate =Black=	1	
13	295763B	RH Sideboard Bracket =Black=	1	
14	295764B	LH Sideboard Bracket =Black=	1	
15	295667B	Sideboard Cover Bracket =Black=	4	
16	295691B	Sideboard Cover Plate =Black=	2	
17	9388-051	Carriage Bolt 3/8"-16UNC x 1" G5	26	
18	91262	Screw/Large Flange 3/8"-16UNC x 1"	4	
19	91263	Hex Nut/Large Flange 3/8"-16UNC G5	45	
20	92403	Window (Clear Tempered)	2	
21	95585	Capscrew/Large Flange 3/8"-16UNC x 3/4" G5	16	
22	9008957	LED Work Light	1	
23	271574B	Lamp Mount Bracket =Black=	1	

Sideboards - Model 1398


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	220032B	Angle Brace Tube =Black=	4	
2	282319B	Brace Bracket Weldment =Black=	2	
3	295653B	Board Weldment Front RH =Black=	1	
4	295654B	Board Weldment Rear RH =Black=	1	
5	295655B	Board Weldment Front LH =Black=	1	
6	295656B	Board Weldment Rear LH =Black=	1	
7	295943B	Front Board Replacement Kit (Black)	1	Includes Front Board, Items 9 & 10
8	295944B	Rear Board Replacement Kit (Black)	1	Includes Rear Board, Items 9 & 10
9	9008857	Window & Trim Assembly	2	
10	9008933	Pan Head Screw #8-18UNC x 1/2"	24	
11	295659B	RH Front Sideboard Corner Plate =Black=	1	
12	295660B	RH Rear Sideboard Corner Plate =Black=	1	
13	295657B	LH Front Sideboard Corner Plate =Black=	1	
14	295658B	LH Rear Sideboard Corner Plate =Black=	1	
15	295661B	RH Sideboard Bracket =Black=	1	
16	295662B	LH Sideboard Bracket =Black=	1	
17	295667B	Sideboard Cover Bracket =Black=	4	
18	295691B	Sideboard Cover Plate =Black=	2	
19	9388-051	Carriage Bolt 3/8"-16UNC x 1" G5	42	
20	91262	Screw/Large Flange, 3/8"-16UNC x 1"	8	
21	91263	Hex Nut/Large Flange, 3/8"-16UNC G5	73	
22	95585	Capscrew/Large Flange, 3/8"-16UNC x 3/4" G5	41	
23	9008957	LED Work Light	1	
24	271574B	Lamp Mount Bracket =Black=	1	

Axle & Hub Components - Model 1198 Single Wheels

Please visit www.unverferth.com/parts/ for the most current parts listing.





Axle & Hub Components - Model 1198 Single Wheels

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	252389B	Axle Assembly 119" (Black)	1	For Scale Units
	252388B			For Non-Scale Units
1	250843	Scale Hitch Pin, 1" Dia x 4 9/16"	4	
2	252398B	Axle Weldment - 120 1/2" =Black=	1	For 4 1/2" Spindle
3	268836B	Axle Mount Weldment =Black=	4	
4	284268B	Hub & Spindle Asy (Black)	2	Includes Items: 5-20
5	265390G	Hub Sub-Assembly =Green=	2	Model 881 Hub Includes Items: 6-8
	265390R	Hub Sub-Assembly =Red=		
6	92462	Outer Bearing Cup	2	Ref #HM212011
7	92476	Inner Bearing Cup	2	Ref #HM218210
8	9007001	Stud Bolt, M22 x 1.5 x 4	20	
9	286172	Spindle 4 1/2" Dia. x 19 7/8" 2"-12UNF Threaded End	2	
10	92455	Seal	2	Ref #43605SA
11	92464	Outer Bearing Cone	2	Ref #HM212049
12	286171B	Hub Cap "Bolt-On Type" =Black=	2	
13	91160	Grease Zerk	2	
14	92470	Slotted Hex Nut 2"-12UNF Grade 5	2	
15	92472	Spindle Washer, Hardened	2	
16	92545	Inner Bearing Cone	2	Ref #HM218248
17	9390-026	Capscrew 5/16"-18UNC x 1/2" Grade 5	8	
18	9390-064	Capscrew, 3/8-16UNC x 3 1/4" Grade 5	2	
19	284230	Gasket	2	
20	902875	Locknut, 3/8"-16UNC	2	
21	9004903	Load Bar - Scale 2.875" Dia.	4	
22	268289	Bar - Non-Scale 2 7/8" Dia x 18"	4	
23	91192	Retaining Ring 1"	8	
24	92199	Center Locknut, 1"-8UNC	4	
25	9390-138	Capscrew, 5/8"-11UNC x 7" Grade 5	2	
26	91299-1457	Capscrew 1"-14UNS x 3 1/4" Grade 8	12	
27	9390-193	Capscrew, 1"-8UNC x 5" Grade 5	4	
28	9008440	Center Locknut, 5/8"-11UNC Grade 8	2	
29	97319	Flange Nut, M22x1.5	20	
30	272754B	Runner Support Weldment =Black=	1	
31	288789B	Spacer Bushing	2	
32	804685	Washer 2"	32	
33	91299-1461	Capscrew 1"-14UNS x 4 1/2" Grade 8	4	
34	9008441	Elastic Locknut, 1"-14UNS Grade 8	16	

Axle & Hub Components - Model 1398 Single Wheels

Please visit www.unverferth.com/parts/ for the most current parts listing.




Axle & Hub Components - Model 1398 Single Wheels

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	271630B	Axle Bundle 119" (Black)	1	For Scale Units Only Includes Items: 2-31
2	9008442	Center Locknut, 3/4"-10UNC Grade 8	2	
3	271628B	Axle Weldment =Black=	1	For 6" Spindle
4	250843	Scale Hitch Pin, 1" Dia x 4 9/16"	4	
5	91192	Retaining Ring 1"	8	
6	9390-193	Capscrew, 1"-8UNC x 5" Grade 5	4	
7	91299-1457	Capscrew, 1"-14UNS x 3 1/4" Grade 8	12	
8	92199	Center Locknut, 1"-8UNC	4	
9	268836B	Axle Mount Weldment =Black=	4	
10	282310B	Hub & Spindle Assembly (Black)	2	Includes Items: 11-23
	272926G	12 Bolt Hub Assembly Less Spindle =Green=		Includes Items: 11-21, 23
	272926R	12 Bolt Hub Assembly Less Spindle =Red=		
11	282312G	12 Bolt Hub Sub-Assembly =Green=	2	Model 881 Hub Includes Items: 12 & 13
	282312R	12 Bolt Hub Sub-Assembly =Red=		
12	9006996	Bearing Cup 7.5" DIA. x 1.3125"	4	Ref #48320
13	9007001	Stud, M22x1.5 x 4	24	
14	282316	Spindle Nut	2	
15	9007854	Capscrew, 1/2"-13UNC x 5 3/4" Grade 5	2	
16	9007007	Bearing Cone	2	Ref #48385
17	282315	Gasket	2	
18	9007010	Seal	2	
19	282314G	Hub Cap "Bolt-On Type" =Green=	2	
	282314R	Hub Cap "Bolt-On Type" =Red=		
20	91160	Grease Zerk	4	
21	9390-028	Capscrew 5/16"-18UNC x 3/4" Grade 5	12	
22	282311	Spindle 6" Dia. x 23 3/4"	2	
23	94981	Locknut, 1/2"-13UNC	2	
24	9004903	Load Bar - Scale 2.875" Dia.	4	
25	272754B	Runner Support Weldment =Black=	1	
26	91299-1461	Capscrew, 1"-14UNS x 4 1/2" Grade 8	4	
27	804685	Washer 2"	32	
28	91299-256	Capscrew 3/4"-10UNC x 9" Grade 8	2	
29	97319	Flange Nut, M22x1.5	24	
30	283895B	Spacer Bushing	2	
31	9008441	Elastic Locknut, 1"-14UNS Grade 8	16	

Walking Tandem Assembly Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	282882G	Walking Tandem Weldment =Green=	2	
	282882R	Walking Tandem Weldment =Red=		
	282882BM	Walking Tandem Weldment =Black Metallic=		
2	285682B	Tandem Axle Weldment RH =Black= (Shown)	1	For 650/65R42 WH/TI
	282794B	Tandem Axle Weldment RH =Black=		For All WH/TI except 650/65R42
	285683B	Tandem Axle Weldment LH =Black=	1	For 650/65R42 WH/TI
	282793B	Tandem Axle Weldment LH =Black=		For All WH/TI except 650/65R42


Walking Tandem Assembly Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
3	9405-088	Flat Washer 1/2"	v	
4	93426	Grease Zerk	2	
5	9002538	Coupling-Pipe 1/8" NPT	2	
6	9005475	Pipe Nipple 1/8"-27NPT x 3 1/2" Threaded Ends	2	
7	282842	Axle Pin Weldment	2	
8	9001297	Flat Washer, 3"	4	
9	92470	Castle Nut, 2"-12UNF Grade 5	2	
10	92472	Spindle Washer	2	
11	9390-100	Capscrew, 1/2"-13UNC x 1 1/4" Grade 5	4	
12	9390-136	Capscrew, 5/8"-11UNC x 6" Grade 5	4	
13	9390-065	Capscrew, 3/8"-16UNC x 3 1/2" Grade 5	2	
14	95905	LockNut, 5/8"-11UNC	4	
15	9404-025	Lock Washer, 1/2"	4	
16	267276G	Hub & Spindle Kit Non-Scale =Green=	1	For 1198 Only
	267276R	Hub & Spindle Kit Non-Scale =Red=		
17	267203B	Hub & Spindle Assembly With Scale =Black=	4	Includes Items 18-21, 23-34
	266520G	Hub & Spindle Assembly Non-Scale =Green=		Includes Items 18-22, 24-34 For 1198 Only
	266520R	Hub & Spindle Assembly Non-Scale =Red=		
	266520B	Hub & Spindle Assembly Non-Scale =Black=		
18	265390G	Hub Sub-Assembly =Green=	2	Model 881 Hub Includes Items 20-22
	265390R	Hub Sub-Assembly =Red=		
19	92462	Outer Bearing Cup	2	Ref. #HM212011
20	92476	Inner Bearing Cup	2	Ref. #HM218210
21	9007001	Stud Bolt, M22 x 1.5 x 4	20	
22	266521	Non-Scale Complete Spindle Asy, 3 3/4" Dia.	2	Includes Items 28, 29, 32, 33 For 1198 Only
23	9006347	Scale Spindle, 3 3/4" Dia.		
24	92565	Seal	2	Ref. #37605SA
25	92464	Outer Bearing Cone	2	Ref. #HM212049
26	286171B	Hub Cap "Bolt-On Type" =Black=	2	
27	284230	Gasket	2	
28	92470	Slotted Hex Nut, 2-12UNF Grade 5	2	
29	92472	Spindle Washer, Hardened	2	
30	92545	Inner Bearing Cone	2	Ref. #HM218248
31	9390-026	Capscrew, 5/16-18UNC x 1/2 Grade 5	8	
32	9390-064	Capscrew, 3/8-16UNC x 3 1/4 Grade 5	2	
33	902875	Locknut, 3/8-16UNC	2	
34	91160	Grease Zerk	2	
35	267500	Wheel Nut Kit, M22 x 1.5 Threaded	1	
36	97319	Flanged Cap Nut, M22 x 1.5 Grade 10	10	
37	91160	Grease Zerk	2	
38	9928	Locknut 3/8-16UNC Grade 5	2	
39	282784B	Axle Assembly, Left-Hand For 650/65R42 WH/TI	1	Includes: Tandem Axle, 41 thru 46
	282788B	Axle Assembly, Left-Hand For All WH/TI except 650/65R42		
40	282785B	Axle Assembly, Right-Hand For 650/65R42 WH/TI	1	Includes: Tandem Axle, 41 thru 46
	282789B	Axle Assembly, Right-Hand For All WH/TI except 650/65R42		
41	9005072	Quicklinc Fitting, 90° Swivel	1	
42	9005073	Quicklinc Fitting, Straight	1	
43	9005074	Tube	1	
44	9005474	Tension Bushing	2	
45	93426	Grease Zerk	1	
46	9002538	Coupling-Pipe 1/8" NPT	1	

Walking Tandem Mounting Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9390-422	Capscrew 1 1/8"-7UNC x 2 1/2" Grade 5	2	
2	9404-045	Lock Washer 1 1/8"	2	
3	9405-122	Flat Washer 1 1/8" SAE	2	
4	9404-030	Lock Washer 5/8"	4	
5	9394-014	Hex Nut 5/8"-11UNC Grade 5	4	
6	9394-020	Hex Nut 1"-8UNC Grade 5	8	
7	9404-042	Lock Washer 1"	8	
8	804685	Flat Washer Hardened 2" OD x 1 1/16" ID	8	
9	9390-189	Capscrew 1"-8UNC x 3 1/2" Grade 5	8	
10	268521	Axle Pivot Pin Weldment	2	
11	282815G	Axle Extension Weldment =Green=	2	
	282815R	Axle Extension Weldment =Red=		
	282815BM	Axle Extension Weldment =Black Metallic=		
12	9005290	Jam Nut 1 3/4"-5UNC W/Set Screw Grade 5	2	
13	284185G	Clamp Weldment =Green=	2	
	284185R	Clamp Weldment =Red=		
	284185BM	Clamp Weldment =Black Metallic=		
14	9390-442	Capscrew 5/8"-11UNC x 9" Grade 5	4	

Wheels & Tires

Please visit www.unverferth.com/parts/ for the most current parts listing.



TIRES

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Tire manufacturers' phone numbers and websites are listed in Maintenance Section for your convenience.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	110825SM/99478	Wheel & Tire Asy (10 Bolt)	2	36 x 32 / 1050/50R32 R-1W (178A8 LI)
	110825SM	Wheel Only	2	36 x 32
2	93300	Valve Stem	2	
	95365	Plug	2	
1	17939SM/9500848	Wheel & Tire Assembly (10 Bolt)	2	30 x 32 / 35.5LR32 R-3 (193A8 LI)
	110803SM/9500992	Wheel & Tire Assembly (10 Bolt)	2	44 x 32 / TL1250/50R32 R-1W (194A8 LI)
	110803SM/9500943	Wheel & Tire Assembly (10 Bolt)	2	44 x 32 / IF1250/50R32 R-1W (201A8 LI)
	110598SM/9500943	Wheel & Tire Assembly (12 Bolt)	2	Model 1398 Only 44 x 32/1250/50R32 R-1W
1	110803SM/9501414	Wheel & Tire Assembly (10 Bolt)	2	44x32/IF1250/50R32 CFO R-1W
	110803SM	Wheel Only	2	44 x 32
1	17939SM	Wheel Only	2	30 x 32
1	110598SM	Wheel Only (12 Bolt)	2	Model 1398 Only 44 x 32

Dual Wheels & Tires


Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	14680SM	Wheel & Tire Assembly - 1/2" Inset	4	18 x 38 / 520/85R38 R-1
	14678SM	Wheel Only	4	18 x 38
1	17418SM	Wheel & Tire Assembly - 1/2" Inset	4	18 x 38 / 520/85D38 R-1
	17704SM	Wheel Only	4	18 x 38
1	18739SM	Wheel & Tire Assembly - 1/2" Inset	4	18 x 42 / TL520/85R42F R-1
	18624SM/9503775	Wheel & Tire Assembly	4	18 x 42 / TLVF520/85R42CFO R-1W
	18624SM	Wheel Only	4	18 x 42
1	18051SM	Wheel & Tire Assembly	4	20 x 42 / 650/65R42 R1W
	17877SM	Wheel Only	4	20 x 42
2	93300	Valve Stem	4	
	901207	Valve Stem Adapter	-	

Track Axle Components

Models 1198 & 1398 with 36x148, 42x131, 42x148 & 50x148 Tracks

Please visit www.unverferth.com/parts/ for the most current parts listing.



Track Axle Components


Models 1198 & 1398 with 36x148, 42x131, 42x148 & 50x148 Tracks

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	250843	Pin 1" Dia. x 4 9/16"	4	
2	268764B	Axle Weldment =Black=	1	(Standard Tracks 36"x148" & Equalizer Tracks 50"x148") (Long Axle Option for Equalizer Tracks 42"x131" & 42"x148")
	282054B	Axle Weldment =Black=	1	Short Axle Option for Equalizer Tracks 42"x131" & 42"x148"
3	268836B	Axle Mount Weldment =Black=	4	
4	9004903	Load Bar, 2.875" Dia.	4	With Scales
	268289	Hitch Bar, 2.875" Dia.		Without Scales
5	91192	Retaining Ring 1"	8	
6	92199	Locknut, 1"-8UNC	6	
7	91299-1457	Capscrew 1"-14UNS x 3 1/4" Grade 8	12	
8	9390-193	Capscrew 1"-8UNC x 5" Grade 5	4	
9	9390-462	Capscrew 1"-8UNC x 8 1/2" Grade 5	2	
10	282395	Track Pivot Shaft 7" Dia. x 19 3/16"	2	Standard Tracks Only
	282026	Track Pivot Shaft 7" Dia. x 19 1/8"		Equalizer Tracks Only
	282397	Washer 8 1/2" OD x 6 1/16" ID	2	
12	282689B	Cover Plate =Black=	2	
13	282690	Washer, 8 1/2" OD x 7 1/16" ID	2	
14	93426	Grease Zerk	2	
15	9390-184	Capscrew 1"-8UNC x 2 1/4" Grade 5	8	
16	9404-041	Lockwasher 1"	8	
17	272754B	Runner Support Weldment =Black=	1	
18	804685	Washer 2"	32	
19	91299-1461	Capscrew 1"-14UNS x 4 1/2" Grade 8	4	
20	9008441	Elastic Locknut, 1"-14UNS Grade 8	16	
21	9006785	90° Adapter 1/8"NPT	1	
22	9006816	Adapter 1/8"NPT	1	
23	268063	Tensioner Hose Assembly	1	

Track Axle Components Model 1198 with 36x112 & 36x131


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	250843	Pin 1" Dia. x 4 9/16"	4	
2	268764B	Axle Weldment =Black=	1	
3	268836B	Axle Mount Weldment =Black=	4	
4	9004903	Load Bar, 2.875" Dia.	4	With Scales
	268289	Hitch Bar, 2.875" Dia.		Without Scales
5	91192	Retaining Ring 1"	8	
6	92199	Locknut, 1"-8UNC	6	
7	91299-1457	Capscrew 1"-14UNS x 3 1/4" Grade 8	12	
8	9390-193	Capscrew 1"-8UNC x 5" Grade 5	4	
9	9390-462	Capscrew 1"-8UNC x 8 1/2" Grade 5	2	
10	268121B	Cover Plate =Black=	2	
11	268619	Washer 7 1/2" OD	4	
	268640	Track Pivot Shaft 6" Dia. x 16 5/8"		36" x 131"
	267124	Track Pivot Shaft 6" Dia. x 18 3/8"	2	36" x 112"
13	93426	Grease Zerk	2	
14	9390-145	Capscrew 3/4"-10UNC x 2" Grade 5	8	
	9404-033	Lockwasher 3/4"		
15	804685	Washer 2" OD	8	
16	9008441	Elastic Locknut, 1"-14UNS Grade 8	16	
17	272754B	Runner Support Weldment =Black=	1	
18	91299-1461	Capscrew 1"-14UNS x 4 1/2" Grade 8	4	
19	9006785	90° Adapter 1/8"NPT	1	
20	9006816	Adapter 1/8"NPT	1	
21	268063	Tensioner Hose Assembly	1	

Track Panel Kit Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	271374G	Track Panel Kit =Green=	-	Includes Items 1 through 5
	271374R	Track Panel Kit =Red=		
	271374BM	Track Panel Kit =Black Metallic=		
1	271373G	Track Panel Plate =Green=	2	
	271373R	Track Panel Plate =Red=		
	271373BM	Track Panel Plate =Black Metallic=		
2	9005376	U-Nut, 3/8"-16UNC	16	
3	95585	Capscrew, 3/8"-16UNC x 3/4" G5	16	
4	97189	Hex Nut, 1/4"-20UNC	14	
5	97420	Flange Screw, 1/4"-20UNC x 3/4" G5	14	

Rear Drop Hitch Components (Optional) For SN B44410100 and Higher

Please visit www.unverferth.com/parts/ for the most current parts listing.




NOTE: Item 10 Replaces Standard Grain Cart Transport Chain

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	296960B	Rear Drop Hitch Kit (Black)	-	Includes Items 1-15
1	91268	Tension Bushing	1	
2	9398-021	Lock Nut 3/4"-10UNC	2	
3	9405-104	Flat Washer 3/4" SAE	4	
4	9405-128	Flat Washer 1 1/4" SAE	2	
5	9404-049	Lock Washer 1 1/4"	1	
6	9394-024	Hex Nut 1 1/4"-7UNC Grade 5	1	
7	9390-225	Capscrew 1 1/4"-7UNC x 8" Grade 5	1	
8	91160	Grease Zerk	2	
9	903172-133	Phillips Head Screw #10-24 x 1/2"	4	
10	PF1238-19	Transport Chain 61,000#	2	Replaces Standard Grain Cart Transport Chain
11	9009843	7-Pin Connector	1	
12	9390-159	Capscrew 3/4"-10UNC x 7" Grade 5	2	
13	9009656	Hitch Pin	1	
14	295978B	Rear Hitch Tang =Black=	1	
15	9000936	Lynch Pin	1	

Rear Ladder Components For SN B44410100 and Higher


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	296417B	Upper Ladder Assembly =Black=	1	
2	296429B	Lower Ladder Assembly =Black=	1	
3	900059	Draw Latch Keeper	1	
4	900060	Draw Latch Handle	1	
5	900066	Stud Pin 3/16" x 1 1/2"	1	
6	900067	Washer 1/2"	1	
7	900068	E-Ring	1	
8	9928	Lock Nut 3/8-16UNC"	2	
9	9405-076	Flat Washer 3/8" USS	2	
10	TA0-908386-0	3/16" Stainless Rivet	4	
11	9390-062	Capscrew 3/8"-16UNC x 2 3/4" Grade 5	2	
12	91262	Flange Screw 3/8"-16UNC x 1" Grade 5	4	
13	91263	Flange Nut 3/8"-16UNC	4	
14	295137	Pivot Bushing	2	
15	9003850	Bumper	2	
16	296585B	Ladder Bolt Plate =Black=	1	
17	9003259	Flange Screw 3/8"-16UNC x 1 1/4" Grade 5	2	

Rear Access Door Components For SN B44410100 and Higher

Please visit www.unverferth.com/parts/ for the most current parts listing.




ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	256527R	Rear Access Door Weldment =Red=	1	
	256527G	Rear Access Door Weldment =Green=		
	256527BM	Rear Access Door Weldment =Black Metallic=		
2	256670B	Rear Access Door Hinge =Black=	2	
3	9008680	Window and Trim Assembly	1	
4	294121B	Window Bracket =Black=	2	
5	9390-003	Capscrew 1/4"-20UNC x 3/4" Grade 5	8	
6	9008933	Phillips Head Screw #8-18 x 1/2"	10	
7	9405-064	Flat Washer 1/4"USS	12	
8	9936	Locknut 1/4"-20UNC	8	
9	296534B	Handle Weldment =Black=	1	
10	91262	Flange Screw 3/8"-16UNC x 1" Grade 5	4	
11	91263	Flange Nut 3/8"-16UNC	4	
12	9009768	Compression Draw Latch	2	

Notes

Please visit www.unverferth.com/parts/ for the most current parts listing.

Lower Auger Cleanout Door, Covers & Rest Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	283518G	Cover Plate 14 1/4" x 15" =Green=	1	
	283518R	Cover Plate 14 1/4" x 15" =Red=		
	283518BM	Cover Plate 14 1/4" x 15" =Black Metallic=		
2	2001446B	Cover Plate 4 1/2" x 4 1/2" =Black=	1	
3	9008700	PTO Bell Cover	1	
4	9004718	Belt Cover/Shield	3	


Lower Auger Cleanout Door, Covers & Rest Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
5	900060	Handle for Draw Latch	3	
6	900068	Retainer for Draw Latch	3	
7	900066	Stud Pin for Draw Latch	3	
8	900067	Washer for Draw Latch	3	
9	900059	Flexible Draw Latch Asy w/Style R Keeper	3	
10	9004940	Pop Rivet	6	
11	9004998	Rivet Washer/Burr 3/16"	6	
12	91263	Large Flange Nut 3/8"-16UNC (Grade 5)	3	
13	95585	Capscrew/Large Flange 3/8"-16UNC x 3/4" Grade 5	3	
14	9007108	Gasket w/Adhesive Backing for Cleanout Door	A/R	Specify in Feet
15	9006497	Plate - Latch	2	
16	289854B	Cleanout Door Weldment =Black=	1	
17	903171-574	Countersunk Screw #10-24 UNC	4	
18	902331	Flange Hex Nut #10-24 (Serrated)	4	
19	9005705	Flange Screw 1/2"-13UNC x 1 1/2" Grade 5	4	
20	91267	Flange Nut 1/2"-13UNC	2	
21	295991B	Auger Tire Guard Weldment =Black=	1	
22	296086G	Transport Rest Weldment =Green=	1	
	296086R	Transport Rest Weldment =Red=		
	296086BM	Transport Rest Weldment =Black Metallic=		
23	295556G	Field Rest Weldment =Green=	1	
	295556R	Field Rest Weldment =Red=		
	295556BM	Field Rest Weldment =Black Metallic=		
24	97420	Flange Screw 1/4"-20UNC x 3/4" G5	10	
25	9003412	Split Output Bushing 1" ID	2	
26	9000787	Trim Lock	1.25	Specify in Feet
27	9392-136	Roll Pin, 1/4" Dia. x 1 1/2"	1	
28	9007843	Socket Head Bolt, 5/16"-18UNC x 1" (3/8" Dia.)	2	
29	901527	Locknut 5/16"-18UNC	6	
30	92424	Hairpin Cotter	1	
31	272583	Bushing, 3/4" Dia. x 7/8"	1	
32	9001868	Locking Collar W/Set Screw 3/4"	1	
33	9004772	Spring 2 1/2"	1	
34	272376	Lock Pin 6 3/4"	1	
35	9392-182	Roll Pin, 3/8" Dia. x 2 1/2"	1	
36	284549	Pivot Pin, 13 1/16"	1	
37	9003397	Locking Flange Nut 1/2"-13UNC	1	
38	9390-102	Capscrew, 1/2-13UNC x 1 3/4" G5	1	
39	9405-088	Flat Washer 1/2"	1	
40	9390-030	Capscrew 5/16"-18UNC x 1" G5	6	
41	9388-003	Carriage Bolt, 1/4"-20UNC x 1" G5	4	
42	97189	Hex Nut/Large Flange 1/4"-20UNC	4	

Lower Auger Linkage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



Lower Auger Linkage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	256030G	Front Cover Junction Box Weldment =Green=	1	
	256030R	Front Cover Junction Box Weldment =Red=		
	256030BM	Front Cover Junction Box Weldment =Black Metallic=		
2	9004590	Pulley, 15" Dia. x 5 13/16"	1	
3	9004591	Pulley, 7 1/2" Dia. x 5 13/16"	1	
4	9004813	Split Bushing Hardware Kit	1	Includes Items: 6, 7 & 30
5	9006669	Capscrew, 3/8"-16UNC x 2" Grade 5	1	
6	9404-027	Lock Washer, 9/16"	3	
7	9399-107	Set Screw, 1/2"-13UNC x 5/8"	1	
8	9005565	Flanged Bearing 2 1/4" ID	2	Includes Set Screw & Zerk
9	93426	Grease Zerk	1	
10	9002562	Keystock 1/2" x 1/2" x 2 1/2"	2	
11	9006849	Grease Zerk Cap	4	
12	281675	Drive Belt Set, 4 Strand (5V750)	1	Included As Matched Pair
13	9005074	Hose/Type Nylon, 1/4" OD	2.5	Specify in Feet
14	9003949	Hex Pipe Coupling	2	
15	93426	Grease Zerk 1/8" NPT	2	
16	94981	Locknut 1/2"-13UNC	3	
17	9007376	Bushing, 4 5/8" OD x 2 1/4" ID x 2 1/16" w/ 1/2" Keyway & Capscrews	1	Includes Items: 5, 18 & 19
18	9399-059	Set Screw, 1/4"-20UNC x 3/8"	1	
19	9404-021	Lockwasher, 3/8"	3	
20	902875	Center Locknut 3/8"-16UNC	1	
21	9390-062	Capscrew, 3/8"-16UNC x 2 3/4" Grade 5	1	
22	95905	Center Locknut 5/8"-11UNC	18	
23	9390-123	Capscrew, 5/8"-16UNC x 3/4"	8	
24	9390-122	Capscrew, 5/8"-11UNC x 1 1/2"	10	
25	9005073	Quickline Fitting	4	
26	9405-076	Flat Washer 3/8" USS	2	
27	9388-103	Carriage Bolt, 1/2"-13UNC x 1 1/4"	2	
28	-	Hose Caddy	1	Refer to Page 5-20 & 5-21 for Components
29	295565B	Idler Assembly (Black)	1	Refer to "Idler Assembly Components" Section
30	9006263	Bolt, 9/16"-12UNC x 3 5/8" Grade 5	3	
31	296738B	Belt Cover Bracket =Black=	2	
32	91256	Flange Screw, 5/16"-18UNC x 3/4" Grade 5	2	
33	97604	Flange Screw, 5/16"-18UNC x 1" Grade 5	2	


Idler Assembly Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	295565B	Idler Assembly (Black)	1	Includes Items 1-26
1	295566B	Idler Mount Weldment =Black=	1	
2	283602B	Idler Arm Weldment =Black=	1	
3	283603B	Idler Arm Weldment =Black=	1	
4	283604B	Tensioner Weldment =Black=	1	
5	283605	Tensioner Rod Weldment	2	
6	283619B	Idler Brace Plate =Black=	1	
7	284703	Tensioner Bushing Weldment	1	
8	9003635	Self-Lubricating Bushing, 1.4" OD x 1.25" ID x 3/4"	6	
9	9003810	Snap Ring, 3/4"	2	
10	9005447	Spring, 1.415" Dia. x 2 1/2"	2	
11	9005684	Idler Pulley	2	Single Piece Item
	296744B	Idler Pulley Assembly =Black=		Includes Ball Bearing W/Retaining Ring 2"
12	9005685	Machine Washer, 3/4"	4	
13	9390-101	Capscrew 1/2"-13UNC x 1 1/2" Grade 5	1	
14	9390-104	Capscrew, 1/2"-13UNC x 2 1/4" Grade 5	1	
15	9390-149	Capscrew, 3/4"-10UNC x 3" Grade 5	2	
16	9390-003	Capscrew, 1/4"-20UNC x 3/4" Grade 5	2	
17	9395-010	Hex Jam Nut, 1/2"-13UNC Grade 5	1	
18	9404-033	Lock Washer, 3/4"	2	
19	9405-104	Flat Washer, 3/4"	4	
20	9405-106	Flat Washer, 3/4"	2	
21	94144	Retaining Ring, 1 1/4"	4	
22	94981	Locknut, 1/2"-13UNC	1	
23	TA500397	Bushing, 1.875" Dia. x .074"	2	
24	9404-017	Lock Washer, 1/4"	2	
25	9405-062	Flat Washer, 1/4" SAE	4	
26	9405-066	Flat Fender Washer, 1/4"	2	

Lower Auger Retaining Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Lower Auger Retaining Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	278019G	Slide Plate Weldment =Green=	1	
	278019R	Slide Plate Weldment =Red=		
	278019BM	Slide Plate Weldment =Black Metallic=		
2	278061G	Cylinder Lug Weldment =Green=	1	
	278061R	Cylinder Lug Weldment =Red=		
	278061BM	Cylinder Lug Weldment =Black Metallic=		
3	284711B	Locking Pipe Weldment =Black=	1	
4	9392-208	Roll Pin 1/2" Dia. x 2"	1	
5	9388-134	Carriage Bolt, 5/8"-11UNC x 1 3/4" Grade 5	16	
6	9003398	Locknut 5/8"-11UNC	16	
7	295605B	Auger Slide Mount =Black=	1	
8	271124	Nylon Fold Slide 2" x 8"	4	
9	295962B	Slide Shim Plate =Black=	2	
10	295642B	Upper Bolt Plate Weldment =Black=	1	
11	295643B	Lower Bolt Plate Weldment =Black=	1	
12	271119B	Fold Plate 6 1/2 x 8 =Black=	1	
13	284518B	Fold Plate 6" x 8" =Black=	1	
14	9390-123	Capscrew, 5/8"-11UNC x 1 3/4" G5	14	
15	9404-030	Lock Washer, 5/8"	10	
16	9802	Top Locknut 3/4"-10UNC	5	
17	9390-145	Capscrew, 3/4"-10UNC x 2" G5	5	
18	9001688	Capscrew/Flat Head, 5/16"-18UNC x 3/4"	12	
19	9000933	Hydraulic Cylinder, 3 1/2" x 20" - 3000 PSI	1	
20	250104	Cylinder Pin W/Holes, 1" Dia. x 4"	1	
21	804572	Pin, 1" Dia. x 3 1/2"	1	
22	9002155	Tee, 9/16"-18 JIC Male x 3/4"-16 OR ADJ Male	1	
23	9002719	Accumulator - 1800 PSI	1	
24	9002720	Adapter, 3/4"-16 OR Male x 9/16"-18 JIC Female	1	
25	9391-046	Cotter Pin, 3/16" Dia. x 2"	4	
26	9874	90° Elbow, 9/16"-18 JIC Male x 3/4"-16 O-R Male	1	
27	289852B	Pivot Retainer Plate, 4 3/8" x 15 1/16"	5	
28	256011B	Junction Box Mount =Black=	1	
29	9009518	Cable Clamp 1 1/4"	1	
30	9007556	Cable Clamp 1 1/8"	1	
31	95905	Center Locknut 5/8"-11UNC	10	
32	9390-126	Capscrew, 5/8"-11UNC x 2 1/2" G5	10	
33	9390-120	Capscrew, 5/8"-11UNC x 1" G5	2	
34	91256	Flange Screw, 5/16"-18UNC x 3/4" G5	2	
35	9006785	90° Adapter 1/8" NPT	6	
36	9002538	Pipe Coupling, 1/8" NPT	1	

Auger Fold Linkage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



Auger Fold Linkage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	296406G	Upper Auger Housing Replacement Kit =Green=	1	
	296406R	Upper Auger Housing Replacement Kit =Red=		
	296406BM	Upper Auger Housing Replacement Kit =Black Metallic=		
2	296402G	Lower Auger Housing Replacement Kit =Green=	1	
	296402R	Lower Auger Housing Replacement Kit =Red=		
	296402BM	Lower Auger Housing Replacement Kit =Black Metallic=		
3	284493G	Middle Pivot Tube, 2 1/2" OD x 1 3/4" ID x 7 5/8" =Green=	1	
	284493R	Middle Pivot Tube, 2 1/2" OD x 1 3/4" ID x 7 5/8" =Red=		
	284493BM	Middle Pivot Tube, 2 1/2" OD x 1 3/4" ID x 7 5/8" =Black Metallic=		
4	295958	Auger Pivot Pin 1.735" OD x 25 1/4"	1	
5	295540G	Auger Fold Linkage Weldment =Green=	1	
	295540R	Auger Fold Linkage Weldment =Red=		
	295540BM	Auger Fold Linkage Weldment =Black Metallic=		
6	293663B	Pin Retainer Plate, 3" x 5 11/32" =Black=	1	
7	9003398	Lock Nut/Top 5/8"-11UNC	2	
8	9405-098	Flat Washer 5/8" SAE	2	
9	9390-125	Capscrew, 5/8"-11UNC x 2 1/4" G5	2	
10	295957B	Pin Retainer Plate, 2 5/8" x 5 5/32" =Black=	1	
11	9003440	Self Lube Bushing 1.1275" OD x 1" ID x 1.25"	4	
12	9006491	Clevis	2	
13	295551	Fold Linkage Weldment	2	
14	9003636	Self Lube Bushing 1 1/8" OD x 1" ID x 3/4"	2	
15	272587	Pin, 1" Dia. x 3 1/8"	2	
16	91192	Retaining Ring, 1" Dia.	4	
17	295559	Linkage Pin Weldment, 1" Dia. x 6"	2	
18	9390-057	Capscrew, 3/8"-16UNC x 1 1/2" Grade 5	3	
19	9003396	Lock Nut/Top 3/8"-16UNC	3	
20	295793	Cylinder Pin Weldment, 1 1/4" Dia. x 5 1/8"	1	
21	9009659	Hydraulic Cylinder 3 1/2" x 20" (3000 PSI)	1	
22	266285	Cylinder Pin 1" Dia. x 4 1/2"	1	
23	9391-046	Cotter Pin, 3/16" Dia. x 2"	2	
24	295549	Auger Linkage Pin Weldment, 2 1/2" Washer OD x 5 13/32"	2	
25	9004741	Self Lubricating Bushing, 1 3/4" OD x 1 1/2" ID x 1 1/2"	2	
26	9390-063	Capscrew, 3/8"-16UNC x 3" G5	2	
27	902875	Center Locknut 3/8"-16UNC	2	
28	296290	Lower Auger Seal Kit	1	Includes Instruction Sheet
29	289857G	Auger Hinge Weldment =Green=	2	
	289857R	Auger Hinge Weldment =Red=		
	289857BM	Auger Hinge Weldment =Black Metallic=		
30	9006785	90° Adapter 1/8" NPT	2	
31	91299-146	Capscrew, 3/4"-10UNC x 2 1/4" Grade 8	6	
32	9404-034	Lock Washer, 3/4"	6	
33	9234PL	Flat Washer, 13/16" (Hardened)	6	
34	9394-016	Hex Nut 3/4"-10UNC	2	
35	94733	Capscrew 3/4"-10UNC x 3" Full Threaded	2	

(Continued on next page)


Auger Fold Linkage Components (continued)

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
36	272553G	Auger Rest Weldment =Green=	1	
	272553R	Auger Rest Weldment =Red=		
	272553BM	Auger Rest Weldment =Black Metallic=		
37	272574	Pad, 1/2" x 3" x 6 1/2"	2	
38	903171-662	Flat Head Machine Screw, 5/16"-18UNC x 1 1/4"	4	
39	91257	Large Hex Flange Nut, 5/16"-18UNC Grade 5	4	
40	91266	Flange Screw, 1/2"-13UNC x 1 1/4" Grade 5	4	
41	91267	Flange Nut, 1/2"-13UNC	4	
42	272645B	Switch Bracket =Black=	1	
43	9007223	Proximity Sensor with Connector	1	
44	91263	Flange Nut, 3/8"-16UNC	2	
45	91262	Flange Screw, 3/8"-16UNC x 1" Grade 5	2	
46	95585	Capscrew/Large Flange 3/8"-16UNC x 3/4" (Grade 5)	2	
47	284141G	Strike Plate =Green=	1	
	284141R	Strike Plate =Red=		
	284141BM	Strike Plate =Black Metallic=		

**Electric Over Hydraulic (EOH) Valve Functions & Wire Locations
5 Spool (Optional)**



Please visit www.unverferth.com/parts/ for the most current parts listing.




PORT	END OF CYLINDER	FUNCTION
A	BUTT END	Flow Door
B	RAM END	Flow Door
C	RAM END	Auger Fold
D	BUTT END	Auger Fold
E	RAM END	Spout Tilt Out
F	BUTT END	Spout Tilt In
G	ORBIT MOTOR LEFT-HAND PORT	Joystick / Spout Rotate
H	ORBIT MOTOR RIGHT-HAND PORT	Joystick / Spout Rotate
I	BUTT END	Auger Pivot Down
J	RAM END	Auger Pivot Up
P		Joystick / Tractor Pressure
T		Joystick / Tractor Return

EOH Valve Assembly Components 5 Spool (Optional)

Please visit www.unverferth.com/parts/ for the most current parts listing.



Cartridge Valve (9008416) & (9008463)
Middle Detent Position



PUSH BUTTON
AND HOLD
WHILE OPERATING
INDIVIDUAL FUNCTIONS

Cartridge Valve (9008438)

FOR MANUAL OVERRIDE



NOTE: Refer to “Manual Override for Optional Electric Over Hydraulic System” in MAINTENANCE section.


EOH Valve Assembly Components 5 Spool (Optional)

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	293416	EOH Block Assembly - 5 Spool Replacement Kit	1	Includes Items 2-7 and Instruction Sheet
2	9003856	Pilot Check Valve	4	
3	9005769	Coil - 12 VDC DN-40	11	
4	9008667	Manifold Block - 5 Spool	1	
5	9008416	Cartridge Valve - 4 Way, 3 Position - Closed Center w/Detented Manual Override	3	Includes Retaining Cap
	9003906	Seal Kit	-	
6	9008463	Cartridge Valve - 4 Way, 3 Position - Open Center w/Detented Manual Override	2	Includes Retaining Cap
	9003906	Seal Kit	-	
7	9008438	Cartridge Valve - 2 Way, 2 Position w/Push Type Manual Override	1	
	9003904	Seal Kit	-	

EOH Tractor Circuit Hydraulic Components (Optional)

Please visit www.unverferth.com/parts/ for the most current parts listing.



EOH Tractor Circuit Hydraulic Components (Optional)


Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	95802	Hydraulic Hose, 1/2 x 205" - 3000 PSI	1	
2	9005574	Hydraulic Hose, 1/4 x 208" - 3000 PSI	1	
3	9009766	Hose Grips - Tan (- Cylinder Retract)	1	Spout Rotate Front (Joystick)
4	9009765	Hose Grips - Tan (+ Cylinder Extend)	1	Spout Rotate Back (Joystick)
5	9006527	JIC Tube Reducer 9/16-18 UNF Male x 9/16-UNF Female	1	
6	901568	Elbow, 90° Extra Long 3/4-16 JIC x 3/4-16 Male O-Ring	1	
7	91257	Large Flange Hex Nut, 5/16-18UNC Gr.5	3	
8	91383	Male Tip Coupling, 3/4-16	2	
9	98508	Adapter 3/4-16 O-Ring Male x 3/4-16 O-Ring Male	4	
10	9006994	Check Line Valve 145 PSI	1	
11	9390-043	Capscrew, 5/16-18UNC x 4 Gr.5	3	
12	9874	Elbow, 90° 9/16-18 JIC Male x 3/4-16 OR ADJ Male	1	
13	295569B	Valve Cover Plate =Black=	1	Also Order Item #15
14	9005403	120 Micron Hydraulic Filter	1	
15	9008564	Decal, CAUTION (Valve Block)	1	Located Inside Cover Plate #13
16	9003848	Velcro Hose Wrap, 2" ID x 127"	1	


EOH Spout Rotate and Tilt Hydraulic Components (Optional)

Please visit www.unverferth.com/parts/ for the most current parts listing.

SPOUT ROTATE



SPOUT TILT




EOH Spout Rotate and Tilt Hydraulic Components (Optional)

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9001495	Adapter, 9/16"-18 JIC Male x 9/16"-18 O-Ring Male	5	
2	9003814	Clamp Top Plate, 1/4" x 1 1/8" x 2 1/16"	10	
3	9003816	Clamp, Polypropylene	18	
4	97445	Elbow, 90° 9/16"-18 JIC Male x 9/16"-18 O-Ring ADJ Male	1	
5	9008152	Hydraulic Cylinder, 1 1/2" x 6" - 3000 PSI	1	
6	9009759	Hose Grips - Yellow (+ Cylinder Extend)	1	Spout Out
7	9009730	Hydraulic Hose, 1/4" x 238" - 3000 PSI	2	
8	9007626	Hydraulic Motor	1	
9	9006695	Hydraulic Hose, 1/4" x 324 1/2" - 3000 PSI	1	
10	9009489	Hydraulic Hose, 1/4" x 334" - 3000 PSI	1	
11	9390-031	Capscrew, 5/16"-18UNC x 1 1/4" G5	6	
12	9390-035	Capscrew, 5/16"-18UNC x 2 1/4" G5	4	
13	95193	Adapter, 9/16"-18 JIC Female x 9/16"-18 JIC Male	2	
14	9009760	Hose Grips - Yellow (- Cylinder Retract)	1	Spout In
15	98435	Adapter, 9/16"-18 JIC Male x 9/16"-18 O-Ring Male	2	Optional (Includes 0.030" Red Restrictor)
16	9897	Elbow, 90° 9/16"-18 JIC Male x 9/16"-18 JIC Male	2	
17	91383	Male Tip Coupling, 3/4"-16 O-Ring Female	2	
18	9006587	Hydraulic Hose, 1/4" x 186" - 3000 PSI	2	
19	98508	Adapter, 3/4"-16 OR Male x 3/4"-16 OR Male	2	

Auger Pivot Hydraulic Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9000925	Hydraulic Hose, 1/4" x 78" - 3000 PSI	2	
2	9000933	Hydraulic Cylinder, 3 1/2" x 20" - 3000 PSI	1	
3	98435	Adapter, 9/16"-18 JIC Male x 9/16"-18 OR Male	2	Optional (Includes 0.030" Red Restrictor)
4	9002155	Tee, 9/16"-18 JIC Male x 3/4"-16 OR ADJ Male	1	
5	9002719	Accumulator - 1800 PSI	1	
6	9002720	Adapter, 3/4"-16 OR Male x 9/16"-18 JIC Female	1	
7	9874	Elbow, 90° 9/16"-18 JIC Male x 3/4"-16 OR ADJ Male	1	
8	9897	Elbow, 90° 9/16"-18 JIC Male x 9/16"-18 JIC Male	2	
9	91383	Male Tip Coupling, 3/4"-16 OR Female	2	
10	9006587	Hydraulic Hose, 1/4" x 186" - 3000 PSI	2	
11	9009761	Hose Grips - Orange (+ Cylinder Extend)	1	Auger Pivot Up
12	9008603	Hose Grips - Orange (- Cylinder Retract)	1	Auger Pivot Down
13	98508	Adapter, 3/4"-16 OR Male x 3/4"-16 OR Male	2	

Auger Fold Hydraulic Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9001495	Adapter, 9/16"-18 JIC Male x 9/16"-18 OR Male	2	Optional
2	9002199	Reducer, 9/16"-18 JIC Female x 9/16"-18 JIC Male	1	0.060" Yellow Restrictor
3	9009659	Hydraulic Cylinder, 3 1/2" x 20" - 3000 PSI	1	
	9006942	Seal Kit	-	
4	9006608	Hydraulic Hose, 1/4" x 84" - 3000 PSI	2	
5	9002446	Adapter, 9/16"-18 Male O-Ring x 9/16"-18 JIC Female	1	
6	93472	Hydraulic Hose, 1/4" x 16" - 3000 PSI	1	
7	9874	Elbow, 90° 9/16"-18 JIC Male x 3/4"-16 OR ADJ Male	2	
8	9897	Elbow, 90° 9/16"-18 JIC Male x 9/16"-18 JIC Male	2	
9	91383	Male Tip Coupling, 3/4"-16 OR Female	2	
10	9006587	Hydraulic Hose, 1/4" x 186" - 3000 PSI	2	
11	97445	Elbow, 90° 9/16"-18 JIC Male x 9/16"-18 O-Ring ADJ Male	1	
12	9003990	Pilot Operated Check Valve with 3 Ports	1	
13	9001710	Tee 9/16"-18 JIC Male x 9/16"-18 JIC Male x 9/16"-18 O-Ring Male	1	
14	9006166	Reducer, 9/16"-18 JIC Female x 9/16"-18 JIC Male	1	0.090" Green Restrictor
15	9009751	Hose Grips - Green (+ Cylinder Extend)	1	Auger Raise
16	9009752	Hose Grips - Green (- Cylinder Retract)	1	Auger Lower
17	98508	Adapter, 3/4"-16 OR Male x 3/4"-16 OR Male	2	

Flow Door Circuit Hydraulic Components

Please visit www.unverferth.com/parts/ for the most current parts listing.





ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9001495	Adapter, 9/16" -18 JIC Male x 9/16" -18 OR Male	2	Optional
2	9002575	Hydraulic Cylinder, 3" x 16" - 3000 PSI	1	
3	9004442	Hydraulic Hose, 1/4" x 54" - 3000 PSI	2	
4	93472	Hydraulic Hose, 1/4" x 16" - 3000 PSI	1	
5	9002888	Hydraulic Hose, 1/4" x 27" - 3000 PSI	1	
6	95192	Bulkhead Union, 9/16" -18 JIC Male x 9/16" -18 JIC Male	2	
7	9874	Elbow, 90° 9/16" -18 JIC Male x 3/4" -16 OR ADJ Male	2	
8	9897	Elbow, 90° 9/16" -18 JIC Male x 9/16" -18 JIC Male	2	
9	91383	Male Tip Coupling, 3/4" -16 OR Female	2	
10	9006587	Hydraulic Hose, 1/4" x 186" - 3000 PSI	2	
11	9009754	Hose Grips - Red (+ Cylinder Extend)	1	Flow Door Open
12	9009755	Hose Grips - Red (- Cylinder Retract)	1	Flow Door Close
13	98508	Adapter, 3/4" -16 OR Male x 3/4" -16 OR Male	2	

**SCV Controlled Inline Valve Assemblies -
Valve Functions and Wire Locations**

Please visit www.unverferth.com/parts/ for the most current parts listing.

AUGER FOLD




SPOUT ROTATE


NOTE: Refer to “SCV Controlled Inline Valve Assembly Components” in the next section for Parts Listing.

SCV Controlled Inline Valve Assembly Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




NOTE: Refer to “Manual Override for SCV Controlled Spout Rotate & Auger Fold” in MAINTENANCE section.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9009184	Inline Valve Assembly	2	Includes Items 2-4
2	9009185	Coil - 12 VDC, w/ DT04-2P Connector	1	
3	9009186	Cartridge Valve - 4 Way, 2 Position - Normally Closed w/Pull Type Manual Override	1	
4	9009187	Inline Valve Block - 4 Port	1	

SCV Controlled Inline Valve - Auger Fold Hydraulic Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9001495	Adapter, 9/16"-18 JIC Male x 9/16"-18 OR Male	2	
2	9002199	Reducer, 9/16"-18 JIC Female x 9/16"-18 JIC Male	1	0.060" Yellow Restrictor
3	9009659	Hydraulic Cylinder, 3 1/2" x 20" - 3000 PSI	1	
	9006942	Seal Kit	-	
4	9006608	Hydraulic Hose, 1/4" x 84" - 3000 PSI	2	
5	9002446	Adapter, 9/16"-18 Male O-Ring x 9/16"-18 JIC Female	1	
6	93472	Hydraulic Hose, 1/4" x 16" - 3000 PSI	1	
7	9874	Elbow, 90° 9/16"-18 JIC Male x 3/4"-16 OR ADJ Male	2	
8	97445	Elbow, 90° 9/16"-18 JIC Male x 9/16"-18 O-Ring ADJ Male	3	
9	91383	Male Tip Coupling, 3/4"-16 OR Female	2	
10	9006587	Hydraulic Hose, 1/4" x 186" - 3000 PSI	2	
11	9003990	Pilot Operated Check Valve with 3 Ports	1	
12	9001710	Tee 9/16"-18 JIC Male x 9/16"-18 JIC Male x 9/16"-18 O-Ring Male	1	
13	9006166	Reducer, 9/16"-18 JIC Female x 9/16"-18 JIC Male	1	0.090" Green Restrictor
14	9009751	Hose Grips - Green (+ Cylinder Extend)	1	Auger Raise
15	9009752	Hose Grips - Green (- Cylinder Retract)	1	Auger Lower
16	98508	Adapter, 3/4"-16 OR Male x 3/4"-16 OR Male	2	

**SCV Controlled Inline Valve -
Spout Rotate Hydraulic Components**


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9001495	Adapter, 9/16"-18 JIC Male x 9/16"-18 OR Male	4	
2	9003814	Clamp Top Plate, 1/4" x 1 1/8" x 2 1/16"	10	
3	9003816	Clamp, Polypropylene	18	
4	97445	Elbow, 90°9/16"-18JICM x 9/16"-18 OR Male	2	
5	9009765	Hose Grips - Tan (+ Cylinder Extend)	1	Spout Rotate Back
6	9009766	Hose Grips - Tan (- Cylinder Retract)	1	Spout Rotate Front
7	91383	Male Tip Coupling, 3/4"-16 OR Female	2	
8	9009730	Hydraulic Hose, 1/4" x 238" - 3000 PSI	2	
9	9007626	Hydraulic Motor	1	
10	9006587	Hydraulic Hose, 1/4" x 186" - 3000 PSI	2	
11	9390-031	Capscrew, 5/16"-18UNC x 1 1/4" G5	6	
12	9390-035	Capscrew, 5/16"-18UNC x 2 1/4" G5	4	
13	98508	Adapter, 3/4"-16 OR Male x 3/4"-16 OR Male	2	

Cylinders

Please visit www.unverferth.com/parts/ for the most current parts listing.



Auger Fold Cylinder - 3" x 20"

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
	9009659	Cylinder, Complete	1	
1	9006942	Seal Kit	1	

Auger Flow Door Cylinder - 3" x 16"

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
	9002575	Cylinder, Complete	1	
1	9003772	Seal Kit	1	

Auger Pivot Cylinder - 3 1/2" x 20"

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
	9000933	Cylinder, Complete	1	
1	9001081	Seal Kit	1	

Spout Tilt Cylinder - 1 1/2" x 6"


ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
	9008152	Cylinder, Complete	2	#6 9/16-18 O-Ring Ports (3000 PSI)
1	9008341	Seal Kit	2	

Optional Jack Cylinder - 3 1/2" x 8"

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
	9009047	Cylinder, Complete	1	
1	9007880	Seal Kit	1	

Auger Grease Bank Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Auger Grease Bank Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9009493	Grease Hose 3/16" x 94" (1/8" NPT)	1	Lower Vertical Auger Hanger Bearing
2	9008185	Grease Hose 3/16" x 135" (1/8" NPT)	2	Upper Auger Pivot Pin
3	9008961	Grease Hose 3/16" x 48" (1/8" NPT)	1	Vertical Auger Tilt Pivot Rings
4	9008960	Grease Hose 3/16" x 44" (1/8" NPT)	1	
5	9008958	Grease Hose 3/16" x 30" (1/8" NPT)	1	
6	9008959	Grease Hose 3/16" x 38" (1/8" NPT)	1	
7	9008962	Grease Hose 3/16" x 55" (1/8" NPT)	1	
8	9008964	Grease Hose 3/16" x 70" (1/8" NPT)	1	
9	9008963	Grease Hose 3/16" x 58" (1/8" NPT)	1	
10	9008968	Grease Hose 3/16" x 134" (1/8" NPT) (LEFT-HAND)	1	Drag Auger Center Bearing
11	9008184	Grease Hose 3/16" x 166" (1/8" NPT) (RIGHT-HAND)		
12	9003949	Coupler 1/8" NPT	11	
13	93426	Grease Zerk	11	
14	9006849	Grease Zerk Cap	11	
15	295596B	Grease Bank Plate =Black=	1	
16	9001529	Flange Screw 1/2"-13UNC x 1 Grade 5	2	
17	295645B	Hose Bracket Plate =Black=	1	
18	91256	Flange Screw 5/16"-18UNC x 3/4" Grade 5	2	
19	9008925	Decal, Grease Bank	1	

Switch Assembly Components for Rotating Spout

Please visit www.unverferth.com/parts/ for the most current parts listing.




Switch Assembly Components for Rotating Spout

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	272618	Hydraulic Valve Assembly	1	Optional
2	295720B	Switch Bracket =Black=	1	
3	276457B	Spout Motor Assembly =Black=	1	Refer to "Downspout Components" for Parts List
4	295693B	Sensor Plate =Black=	1	
5	9007223	Proximity Sensor with Connector	1	
6	9009184	Inline Valve Assembly	2	
7	91257	Hex Nut/Large Flange 5/16"-18UNC	3	Optional
8	91262	Flange Screw 3/8"-16UNC x 1" G5	2	
9	9390-043	Capscrew, 5/16"-18UNC x 4 1/2" G5	3	Optional
10	295569B	Valve Cover Plate =Black=	1	Also Order Item #11
11	9009341	Decal, CAUTION (Valve Block)	1	Located Inside Cover Plate #10
12	9405-086	Flat Washer 1/2" SAE	1	
13	97189	Hex Nut/Large Flange 1/4"-20UNC	3	
14	9390-017	Capscrew, 5/16"-18UNC x 4 1/2" G5	2	
15	9405-064	Flat Washer 5/16" ID	2	
16	294614B	Spacer Plate =Black=	1	
17	91263	Nut/Large Flange 3/8"-16UNC	2	
18	9390-101	Capscrew 1/2"-13UNC x 1 1/2" G5	1	
19	9003397	Locknut/Top 1/2"-13UNC	1	
20	9390-056	Capscrew 3/8"-16UNC x 1 1/4" G5	1	
21	9003396	Locknut/Top 3/8"-16UNC	2	
22	9388-052	Carriage Bolt 3/8"-16UNC x 1 1/4" G5	1	

Downspout Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	293729	Gear Rack Plate	1	
2	288184	Pivot Pad	6	
3	288186B	Spout Pivot Plate =Black=	2	
4	293640B	Spout Assembly =Black=	1	
5	293641B	Upper Spout Weldment =Black=	1	
6	293670B	Lower Spout Weldment =Black=	1	
7	9405-088	Flat Washer 1/2" USS	2	


Downspout Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
8	9404-025	Lock Washer 1/2"	2	
9	9003810	Snap Ring 3/4"	3	
10	9007847	Rubber Chute	1	
11	9388-003	Carriage Bolt 1/4"-20UNC x 1" G5	8	
12	9388-004	Carriage Bolt 1/4"-20UNC x 1 1/4" G5	2	
13	9405-066	Flat Washer 1/4"	8	
14	97189	Hex Nut/Large Flange 1/4"-20UNC	14	
15	9008957	LED Work Light	3	
16	94763	Fender Washer, 2" OD x 5/16" ID x .08"	12	
17	9390-005	Capscrew 1/4"-20UNC x 1" G5	6	
18	9003127	Reflector 2" x 9" =AMBER=	2	
19	9390-107	Capscrew 1/2"-13UNC x 3" G5	2	
20	95193	Adapter 9/16"-18 JIC Female x 9/16"-18 JIC Male	2	0.030" Red Restrictor
21	285290	Sleeve Bushing .75" OD x .532" ID x 1.938"	2	
22	288293B	Chute Strap =Black=	2	
23	272646B	Light Bracket =Black=	1	
24	272841B	Light Bracket =Black=	1	
25	9004457	Plug 3/8" Dia.	2	
26	288292	Pivot Shaft 3/4" Dia. x 25 5/16"	1	
27	288683B	Spacer Pivot Plate =Black=	3	
28	276577B	Hose Bracket =Black=	1	
29	9003814	Clamp Top Plate	4	
30	9003816	Double Hose Clamp (Pair)	4	
31	9007837	Shoulder Bolt 3/8" Dia. Socket Head, 5/16"-18UNC x 1 1/4"	4	
32	9007838	Sholder Bolt 3/8" Dia. Socket Head, 5/16"-18UNC x 7/8"	8	
33	9008110	Zerk 1/8"-27 with Cap	2	
34	91160	Zerk 1/4"-28 STT	4	
35	91257	Hex Nut/Large Flange 5/16"-18UNC	2	
36	9003259	Flange Screw 3/8"-16UNC x 1 1/4"	2	
37	91263	Nut/Large Flange 3/8"-16UNC	2	
38	9390-034	Capscrew 5/16"-18UNC x 2" G5	2	
39	9405-064	Flat Washer 5/16 ID" USS	16	
40	9807	Lock Nut/Top 5/16"-18UNC	12	
41	9390-031	Capscrew 5/16"-18UNC x 1 1/4" G5	4	
42	265384	Checker Decal	4	
43	9008152	Cylinder 1 1/2" x 6" (3000 PSI)	1	
44	9001041	45° Elbow 9/16"-18 JIC Female x 9/16"-18 JIC Male	1	
45	9876	90° Elbow 9/16"-18 JIC Female x 9/16"-18 JIC Male	1	
46	276457B	Spout Motor Assembly (Black)	1	
47	272840	Gear Weldment w/ 1/4"-20UNC x 1/4" Set Screws	1	
48	276451	Gear and Shaft Weldment	1	
49	276456B	Panel-Cover =BLACK=	1	
50	276453B	Gear Drive Mount Weldment =BLACK=	1	
51	9003809	Self-Lubricating Bushing	2	
52	9001495	Adapter 9/16"-18 JIC Male x 9/16"-18 OR Male	2	
53	9007626	Motor-Hydraulic 3.07" CID, 5.28 GPM, 2 Bolt Flange Mount	1	
54	9394-004	Hex Nut 5/16"-18UNC	2	
55	9404-019	Lock Washer 5/16"	2	
56	9405-068	Flat Washer 5/16" SAE	2	
57	97420	Flange Screw 1/4"-20UNC x 3/4"	2	
58	TA500309	Washer 3/4"	2	
59	9390-056	Capscrew 3/8"-16UNC x 1 1/4" G5	1	
60	9388-052	Carriage Bolt 3/8"-16UNC x 1 1/4" G5	1	
61	9390-101	Capscrew 1/2"-13UNC x 1 1/2" G5	1	
62	9405-086	Flat Washer 1/2" SAE	1	
63	9003396	Locknut/Top 3/8"-16UNC	2	
64	9003397	Locknut/Top 1/2"-13UNC	1	

Cut Out Clutch PTO Assembly


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	9005230	PTO Assembly Complete		Includes Items 19 & 20
1	9005234	Over-Running PTO Clutch Assembly	1	1 3/4"-20 Spline 1000RPM
2	92529	Cross & Bearing Kit	2	
3	9002609	Spring Pin 10x90	2	
4	9002610	Inboard Yoke S4	1	
5	9004840	Inner Profile	1	
6	9004841	Outer Profile	1	
7	9002613	Inboard Yoke S5	1	
8	9005235	Cut Out Clutch (3200 N-m Setting)	1	1 3/4"-20 Spline 1000RPM
9	9002615	Shield Cone 7 Rib	1	
10	9004843	Outer Shield Tube Oval	1	
11	9004844	Inner Shield Tube Oval	1	
12	92373	Bearing Ring	2	
13	92374	Safety Chain	1	
14	92372	Screw	2	
15	92377	Decal Out	1	
16	92378	Decal In	1	
17	93866	Shield Cone 6 Rib	1	
18	9005233	Decal K64	1	"Tighten to 75 Ft.-Lbs."
19	93856	Quick-Disconnect Kit	1	1 3/4"-20 Spline w/Metal Collar
20	9005253	Cut Out Clutch Lock Assembly	1	
21	9005231	PTO Front Half Assembly 1 3/4-20 Spline	1	
22	9005232	PTO Rear Half Assembly 1 3/4-20 Spline	1	
23	9002513	Reinforcing Collar	1	NOT SHOWN

Cut Out Clutch Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




NOTE: Cut Out Clutch (9005235) must be used with the Complete PTO Assembly (9005230). This will not work with the Friction Clutch PTO Assembly (9005245).

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	9005235	Cut Out Clutch (3500 N*m Setting)		Includes Items 1-8
1	9005247	Clutch Housing	1	
2	9005248	Clutch Hub 1 3/4"-20 Spline	1	
3	9005249	Spring Pack	1	
4	9005250	Washer	1	
5	9005251	Retaining Ring	1	
6	9005252	Sealing Ring	1	
7	9005253	Clutch Clamp Cone Assembly	1	
8	9005254	Clutch Cam	4	

Gearbox Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Gearbox Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	9007366	Gearbox Complete	1	Includes Items 1 through 20
1	9006381	Glass Sight Plug	2	
2	9007492	Gearbox Housing Q800 w/Taped Holes	1	
3	9007493	Gearbox Housing Q800 w/Through Holes	1	
4	9007494	Gearbox Shaft 2 1/4" Dia.	1	
5	9007495	Gear Shaft Assembly 29 Tooth, 2 1/4"-17 Spline	1	
6	9007496	Gear 16 Tooth Splined	1	
7	9007497	Bearing Cup & Cone Set, 3.740" OD x 1 1/4"	1	
8	9007498	Bearing Cone 2 1/4" ID x 1"	2	
9	9007499	Bearing Cup 3.8437" OD x 0.7812"	2	
10	9007500	Bearing Cone 2" ID x 1.5312"	1	
11	9007501	Bearing Cup 4.125" OD	1	
12	9007502	End Cap	1	
13	9007503	Retaining Ring - External 2" Nominal Shaft Dia.	1	
14	9007504	Shim - 0.025"	1	
15	9007505	Shim - 0.030"	1	
16	9007508	Shaft Seal	2	
17	9007511	Shim - 0.005"	2	
18	9007512	Shim - 0.003"	1	
19	903161-060	Flange Screw 1/2"-13UNC x 2 1/2"	12	
20	95283	Plug	3	

Hopper Rear Electrical Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Hopper Rear Electrical Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	282305G	Upper Harness Cover =Green=	2	
	282305R	Upper Harness Cover =Red=		
	282305BM	Upper Harness Cover =Black Metallic=		
2	282308G	Harness Cover Plate RH =Green=	1	
	282308R	Harness Cover Plate RH =Red=		
	282308BM	Harness Cover Plate RH =Black Metallic=		
3	282309G	Harness Cover Plate LH =Green=	1	
	282309R	Harness Cover Plate LH =Red=		
	282309BM	Harness Cover Plate LH =Black Metallic=		
4	284358B	Lamp Assembly LH =Black=	1	
5	284359B	Lamp Assembly RH =Black=	1	
6	9390-003	Capscrew 1/4"-20UNC x 3/4" Grade 5	4	
7	9390-005	Capscrew 1/4"-20UNC x 1" Grade 5	12	
8	97189	Lrg. Flange Hex Nut 1/4"-20UNC Grade 5	4	
9	9936	Locknut 1/4"-20UNC	12	
10	9405-064	Flat Washer 5/16" ID	12	
11	TA510514	SMV Emblem	1	

Electrical Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Electrical Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	272645B	Switch Plate Bracket =Black=	1	
2	252386	Plug Assembly, 2 Pin Shroud	2	
3	9008969	Wiring Harness - 226"	1	
4	9005618	Relay - 12VDC	4	
5	271574B	Lamp Mount Plate =Black=	1	
6	9830-016	Hex Nut, #10-32 Grade 2	4	
7	9008957	Work Light (LED)	4	
8	9009531	Auger Wiring Harness (w/2-Pin Shroud Connectors)	1	
9	9007223	Proximity Switch	2	
10	9008252	Joystick Controller Extension Harness	1	
11	903172-350	Phillips Pan Head Screw, #10-32UNF x 1-1/4"	4	
12	9009547	Front Harness - 296"	1	
13	9006282	LED Lamp - Red	2	
14	232170	LED Lamp - Red - Replacement Kit	2	Includes Lamp, & Items 6, 11, 13 & 21
15	9005142	LED Lamp - Amber	2	
16	9006107	Micro Dot, LED Amber Light	6	
17	293416	EOH Block Assembly - 5 Spool Replacement Kit	1	
18	9008265	L-Series Control Grip - 5 Function	1	
19	9009586	Rear Harness	1	
20	9006481	Clearance Harness	2	
21	9404-013	Lock Washer, #10	4	
22	9006907	Power Harness, 2-Pin	1	
23	9007290	"T" Main Wiring Harness - 189"	1	
24	91262	Large Flange Screw, 3/8"-16 x 1" Grade 5	2	
25	91263	Large Flange Nut, 3/8"-16UNC Grade 5	2	
26	92450	7-Way Plug	1	
27	284358B	Lamp Assembly Left-Hand =Black=	1	Includes items 14, 15, 28, 29, 30, 31
28	284370B	Lamp Mount Weldment Left-Hand =Black=	1	
29	9003125	Reflector 2" x 9" Fluorescent - Red / Orange	2	
30	9003126	Reflector 2" x 9" =Red=	2	
31	9003127	Reflector 2" x 9" = Amber=	2	
32	284359B	Lamp Assembly Right-Hand =Black=	1	Includes Items 14, 15, 29, 30, 31, 33
33	284371B	Lamp Mount Weldment Right-Hand =Black=	1	
34	9008251	Harness - Joystick Power	1	
35	9007266	Wire Harness, 218 5/16" (2 Pin Diverter)	1	
36	97189	Lrg. Flange Hex Nut 1/4"-20UNC Grade 5	1	
37	9004981	External Tooth Lock Washer 1/4"	1	
38	9390-005	Capscrew 1/4-20UNC x 1" Grade 5	1	
39	9009184	SCV Controlled Inline Valve Assembly	2	
40	9009843	Adapter Harness, AG to RV	1	Optional For SN B44410100 & Higher

Weather Guard Tarp

Please visit www.unverferth.com/parts/ for the most current parts listing.



For SN B44410099 & Lower

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	255001-MOD	Tarp Kit	-	
1	9004355	Screw 1/4"-20UNC x 1" Self-Threading	6	Model 1198 Only
2	221788	Roll Tube Weldment	1	
3	221614	Fixed Tube Weldment	1	
4	221668	Pipe - 180"	1	
5	296832	Plate - Latch 129 1/2" (Front)	1	
6	296833	Plate - Latch 129 1/2" (Rear)	1	

Weather Guard Tarp

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
7	296423B	Handle Bracket Weldment =Black=	1	SN B44410100 & Higher
	221696B		1	SN B44410099 & Lower
8	221722	Bungee 3/8" Dia. x 204"	1	
9	97189	Hex Nut/Large Flange 1/4"-20UNC	6	Model 1198 Only
10	297234	Tarp Handle Weldment 123 7/16"	1	SN B44410100 & Higher (1398)
	221749	Tarp Handle Weldment 117 7/16"	1	SN B44410099 & Lower (1398) All SN Model 1198
11	266689B	Tarp Short Stop Plate =Black=	8	
12	295183B	Tarp Stop Spacer Plate =Black=	8	
13	9009089	Torx Head Machine Screw 3/8"-16UNC x 1 1/4" Grade 5	8	
14	9009729	Torx Head Machine Screw 3/8"-16UNC x 1 1/2" Grade 5	1	
15	295259B	Tarp Spacer Plate =Black=	8	
16	9005305	Lynch Pin 3/8" x 3"	1	
17	9003078	Cap - Plastic (2" x 3")	8	
18	9005676	Cable Assembly 242"	4	
19	9005307	Poly Deflector 8"	3	Model 1198 Only
20	91262	Flange Screw 3/8"-16UNC x 1" Grade 5	2	SN B44410100 & Higher
21	9004548	Eye Bolt 3/8"-16UNC x 1 3/4"	1	
22	9004947	Plug 2"	1	
23	221770B	Handle Retainer Weldment =Black=	1	
24	9004949	U-Clamp	8	
25	9004969	Handle	1	
26	9004977	U-Joint w/ 1 3/8"-21 Spline	1	
27	9005045	Tarp 164" x 253"	1	
28	9005088	Plug 1 1/8"	2	
29	9005089	Plug 1 1/4"	1	
30	9001396	Pan Head Screw #10-16 x 1/2"	1	
31	TA806225	Hose 1/2" EPDM	1	
32	9005197	Screw/Self Drilling #10-16 x 3/4" Pan Head	10	
33	295668B	Sideboard Cover Plate =Black=	4	
34	91263	Nut/Large Flange 3/8"-16UNC Grade 5	34	SN B44410100 & Higher
			32	SN B44410099 & Lower
35	283427B	Tarp Bow Bracket =Black= (Left Hand Side)	6	
36	9390-055	Capscrew 3/8"-16UNC x 1" Grade 5	1	
37	9392-180	Roll Pin 3/8" Dia. x 2"	1	
38	903172-450	Phillips Machine Screw Pan Head 3/8"-16UNC x 4 1/2"	1	
39	9405-074	Flat Washer 3/8"	3	
40	9398-012	Elastic Stop Nut 3/8"-16UNC	1	
41	283425B	Tarp Bow Bracket =Black= (Right Hand Side)	6	
42	295997B	End Cap Weldment =Black=	2	
43	283424B	Tarp Bow Weldment =Black=	6	
44	9009504	Endcap Vent Cover	2	
45	9003259	Flange Screw 3/8"-16UNC x 1 1/4" Grade 5	8	SN B44410100 & Higher
			10	SN B44410099 & Lower
46	902703-046	Flat Socket Capscrew 3/8"-16UNC x 3" (RH Thread) Gr. 5	12	
47	9512	Screw/Self Drilling 1/4"-14 x 1"	14	
48	95585	Capscrew/Large Flange 3/8"-16UNC x 3/4" Grade 5	8	
49	9928	Locknut 3/8"-16UNC	1	
50	9005581	Tarp Patch Kit	1	Not Shown
51	281712B	Bracket and U-Nut Asy =Black=	4	
52	9005688	Star Washer 3/8"	4	
53	9005696	Fender Washer 3/8"	4	
54	9005727	Plug 7/16"	4	
55	TA0-907131-0	Capscrew 3/8"-16UNC x 4 1/2" (Full Threaded)	4	
56	97604	Flange Screw 5/16"-18UNC x 1" Grade 5	24	
57	91257	Hex Nut/Large Flange 5/16"-18UNC	24	
58	9008948	Hurricane Strap For 12 FT Wide Hopper	2	
59	96972	Screw/Self Tapping 3/8"-16UNC x 1"	2	
60	9008972	Flat Washer, 3/8" Aluminum	4	
61	9008949	Tarp Strap Spacer Bushing	4	
62	294660B	Sideboard Doubler =Black=	12	



Hydraulic Jack - Kit #296288B (Optional)

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9390-197	Capscrew, 1"-8UNC x 7" Grade 5	3	
2	92199	Center Locknut, 1"-8UNC	3	
3	272587	Pin, 1" Dia. x 3 1/8"	1	
4	91192	Retaining Ring, 1"	2	
5	9006068	Hydraulic Hose, 1/4" x 92" - 3000 PSI	2	
6	91383	Male Tip Coupling 3/4"-16	2	
7	271712B	Jack Weldment =Black=	1	
8	271723B	Jack Foot Weldment =Black=	1	
9	9006173	Elbow, 90°	2	
10	9005426	High Pressure Ball Valve	1	
11	98508	Adapter, 3/4"-16 OR Male x 3/4"-16 OR Male	3	
12	9009047	Hydraulic Cylinder, 3 1/2" x 8" - 3000 PSI	1	
13	9009757	Hose Grips - Black (+ Raise Jack)	1	For SN B44410100 & Higher
14	9009758	Hose Grips - Black (- Lower Jack)	1	

Video System (Optional)



Please visit www.unverferth.com/parts/ for the most current parts listing.



9004510 CABLE W/FUSE WIRES

- Red -- Key Switched Power
- Black -- Ground
- Green -- NOT USED
- White -- NOT USED

IMPORTANT ! Do not operate Video System below 15° F.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	265770	Video System Kit with Single Camera	1	Includes Items 1 - 8 and own Instruction Sheet
	9004506	Additional Video System Kit	1	Includes Items 6 & 7
1	TAAU14007	Snap Clip, Adhesive	10	
2	9512	Self-Drilling Screw 1/4-14 x 1	10	
3	9006273	Monitor, 7" LCD/LED	1	
4	9004510	Cable w/Fuse	1	
5	9006274	Camera	1	
6	265771B	Bracket	1	
7	9004513	Cable, 65'	1	
8	9000106	Cable Tie	AR	
9	9004506	Camera Kit for Rear View with 65' Cable	1	
10	9007174	Extension Cable 16 ft. For CH Series Camera	1	

Notes

Please visit www.unverferth.com/parts/ for the most current parts listing.



Unverferth[®]
Manufacturing Company, Inc.

www.unverferth.com