

Grain Cart Maintenance

MODEL 1319 & 1519 X-TREME CART PG.2

MODEL 1019 & 1119 X-TREME CART PG.67





Grain Handling

FRONT FOLDING X-TREME® GRAIN CART MODELS 1319 & 1519


Serial Number B37680100 and Higher

292860

SECTION IV Maintenance

Lubrication	4-2
Gearbox Lubrication	4-5
Hydraulic System	4-6
Manual Override for Optional Electric Over Hydraulic System	4-7
Auger System	4-9
Lower Auger	4-10
Lower Auger Removal	4-10
Lower Auger Assembly	4-11
Hanger Bearing Centering	4-12
Lower Auger Timing	4-12
U-Joint Spline Gap	4-14
Upper Auger	4-15
Upper Auger Removal	4-15
Soft Start Replacement	4-16
Upper Auger Timing	4-17
Upper Auger Height	4-17
Upper Auger Bearing Gap	4-19
Flow Door Cylinder Stop	4-20
Auger Driveline	4-21
Bearings	4-21
Driveline Replacement	4-21
Verify Telescoping PTO Shaft Length	4-24
PTO Shaft and Clutch	4-26
PTO Quick Disconnect	4-30
Wheel, Hub and Spindle Disassembly and Assembly	4-31
Wheels & Tires	4-33
Wheel Nut Torque Requirements	4-33
Tire Pressure	4-34
Tire Warranty	4-36
Adjusting Cleanout Door	4-37
Hydraulic Jack Cylinder Replacement	4-39
Seasonal Storage	4-41
EOH Troubleshooting	4-42
Scale Troubleshooting	
Tarp - Troubleshooting Inspection and Maintenance	4-44
Electrical System Diagram - Overall	4-45
Electrical Over Hydraulic System Schematic 4 Function (Optional)	4-47
Electrical System Schematic - Electric Tarp (Optional)	
Wireless Electric Tarp - For SN B43320100 & Higher	
Electric Tarp - For SN B43320099 & Lower	4-59
Complete Torque Chart - Capscrews - Grade 5	
Complete Torque Chart - Capscrews - Grade 8	
Hydraulic Fittings - Torque and Installation	4-62

FOR SCALE, TRACK, UHARVEST, HYDRAULIC DRIVE, ELECTRIC TARP, VIDEO SYSTEM OPTIONS, AND / OR WATER DELIVERY SYSTEM INFORMATION, PLEASE REFER TO THE SPECIFIC MANUAL.



Lubrication (continued)

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.

Unverferth Mfg. recommends use of NLGI #2 Extreme Presure grease.

The lubrication locations and recommended schedule are as follows:


DESCRIPTION	POINT	LUBRICANT	QTY.	HOURS
PTO Driveshaft	7	EP-2	1 Shot	See Next Page
Gearbox - Check oil level every 2 weeks. Replace oil every season. Refer to Gearbox in MAINTENANCE section for instructions.	1	EP80W90	73 oz. Or 55 oz.	Once Every Season
U-Joint Cross Bearing - Driveline	1	EP-2	1 Shots	Weekly
Splined Yoke - Driveline U-Joint	1	EP-2	3 Shots	Weekly
Grease Bank Hanger Bearing - Lower Auger *See note below.	1	EP-2	3 Shots*	Daily
U-Joint Cross Bearing - Lower Auger	1	EP-2 Lithium Base w/o Moly	2 Shots	Weekly
Splined Yoke - Lower Auger	1	EP-2	1 Shot	Weekly
Top Bearing - Upper Auger	1	EP-2	1 Shot	Each Season
Pivot Rings - Upper Auger	4	EP-2	2 Shots	Weekly
Grease Bank Auger Pivot Pins - Front and Rear	2	EP-2	3 Shots	Daily
Hubs	2	EP-2	Repack	2 Years


*NOTE: Hanger bearing contains hydraulic shut-off grease zerk (9005240) with pressure relief to prevent over-greasing that could push bearing seals out. If grease is coming out of the relief on the zerk this is normal and the bearing contains enough grease.

Lubrication (continued)

Lubricate with quality grease before starting work and every 8 operating hours. Clean and grease PTO drive shaft before each prolonged period of non-use. Molded nipples on the shield near each shield bearing are intended as grease fittings and should be lubricated every 8 hours of operation! Check and grease the guard tubes in winter to prevent freezing.

<u>NOTE:</u> Telescoping members must have lubrication to operate successfully regardless of whether a grease fitting is provided for that purpose! Telescoping members without fittings should be pulled apart and grease should be added manually.





Gearbox Lubrication


For SN B42550100 & higher with gearbox (9008711), the check/fill plug is located on the right-hand front side of the housing. To check oil fluid level, place cart on a level surface with the tongue elevated to hitch height and remove the plug. Oil level should be at the bottom thread. (FIG. 4-1)


For Maximum gearbox life:

Check oil level every 2 weeks.

Replace oil every season with a minimum of 73 fl. oz. of 80W90 EP gear lubricant.

For SN B41330100 & B42550099 with gearbox (9009053), the fill plug is located on the left-hand front side of the housing. To check oil fluid level, place cart on a level surface with the tongue elevated to hitch height. Oil level should be visible in the sight glass. Fill with oil to the sight glass only. (FIG. 4-2)






For SN B41330099 & lower with gearbox (9002812), the check/fill plug is located on the right-hand front side of the housing. To check oil fluid level, place cart on a level surface with the tongue elevated to hitch height and remove the plug. Oil level should be at the bottom thread or approximately 5/8" below the outside gearbox surface. (FIG. 4-3)

For Maximum gearbox life:

Check oil level every 2 weeks.

Replace oil every season with a minimum of 55 fl. oz. of 80W90 EP gear lubricant.



Hydraulic System

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the grain cart requires little maintenance.

Replacing Hoses/Fittings/Cylinders:

- 1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3000 psi.
- 2. Do not use hoses, fittings and cylinders that have pipe threads.
- 3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings according to "Torque Chart Hydraulic Fittings" in this section.
- 4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
- 5. Always purge the hydraulic system after servicing.

Purge Hydraulic System

WARNING

- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING.
 SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. LEAKS OF HIGH-PRESSURE FLUIDS MAY NOT BE VISIBLE. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.



KEEP CLEAR OF PINCH POINT AREAS.



Purge air from system as follows:

- A. Clear all personnel and objects from the area, including where the machine will have full range of motion during the hydraulic movement. Remove transport locks from the machine.
- B. Pressurize the system and maintain the system at full pressure for at least 5 seconds after the cylinder rods stop moving, or hydraulic motors have completed the required movement. Check that all movements are fully completed.
- C. Check oil reservoir in the hydraulic power source and refill as needed.
- D. Pressurize the system again to reverse the motion of step B. Maintain pressure on the system for at least 5 seconds after the cylinder rods stop moving, or hydraulic motors have completed the required movement. Check that all movements are fully completed.
- E. Check for hydraulic oil leaks using cardboard or wood. Tighten connections according to directions in the Torque Specifications in the MAINTENANCE section.
- F. Repeat steps in B, C, D, and E 10-12 times.

IMPORTANT

Machine damage will occur if the cylinder is incorrectly installed.

Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.


Manual Override for Optional Electric Over Hydraulic System

A WARNING

- MOVING OR ROTATING AUGER COMPONENTS CAN CAUSE SERIOUS INJURY OR MA-CHINE DAMAGE. BEFORE OPERATING MANUAL OVERRIDE(S), ENSURE EVERYONE IS AWAY FROM THE SPOUT AND THAT THE SPOUT WILL NOT CONTACT ANY OTHER PARTS OF THE GRAIN CART.
- MOVING OR ROTATING PTO COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT OPERATE PTO WHILE UTILIZING MANUAL OVERRIDE(S).
- ALL SAFETY SWITCHES ARE DEACTIVATED WHILE UTILIZING MANUAL OVERRIDE(S).

NOTE: It is recommended the joystick and 7-pin connector be plugged into the same power source.

<u>NOTE</u>: Manual override operation is intended for emergency use **ONLY** and is not intended for continuous operation.




- 1. Park the empty grain cart on a firm and level surface. Block the machine to keep it from moving. Set the tractor's parking brake.
- 2. Connect the Hydraulic Pressure and Return hoses to the tractor SCV remote so that the Pressure line is able to be put in continuous detent.
- 3. To operate the manual override functions, place the tractor SCV remote in continuous detent so that the Hydraulic Pressure hose is pressurized.


Manual Override for Optional Electric Over Hydraulic System (continued)


NOTE: Only one cartridge valve (9008416) may be in the top or bottom detent position at a time to function properly. All other valves must be in the middle detent postion. (FIG 4-5 & 4-6)

- 4. Locate desired function on valve (9008416) and move cartridge to top/bottom detent, as desired, and lock in position. (FIG. 4-7)
- 5. Push and hold the power cartridge on valve (9008438). (FIG. 4-7)
- 6. Once the desired position is reached, release manual override button on valve (9008438).
- 7. Return cartridge to center and lock valve (9008416) in position. (FIG. 4-5 & 4-6)
- 8. Turn off hydraulic circuit when done. Correct electric/hydraulic system before continued use. Consult your dealer for service and parts.

NOTE: Refer to "Troubleshooting" for EOH and auger issues in the MAINTENANCE section.







Auger System



- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- NEVER ENTER CART WITH AUGER OR TRACTOR RUNNING. SERIOUS OR FATAL IN-JURY CAN OCCUR DUE TO ENTANGLEMENT WITH ROTATING COMPONENTS. ALWAYS STOP ENGINE AND REMOVE KEY BEFORE ENTERING CART.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 2,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING MACHINE.



• SHARP EDGES ON THE MACHINE CAN CAUSE INJURY. BE CAREFUL WHEN WORKING AROUND THE MACHINE.

Auger System (continued)


Lower Auger

 Hitch cart to tractor, connect hoses for flow door and upper auger hydraulic cylinders and fully open flow door. Keep upper auger in the folded position. Park the empty grain cart on a firm, level surface. Set the tractor's parking brake, shut-off the engine and remove the ignition key. Block the machine to keep it from moving.



Lower Auger Removal

2. Remove the three 5/8"-11UNC x 2" capscrews (9390-124), 5/8" flat washers (9405-098), 5/8"-11UNC lock nuts (9003398) and shims that secure the hanger bearing bracket to the auger tube. (FIG. 4-8)




3. Using a safe lifting device rated at a minimum of 1000 lbs., support the lower auger. Remove the hanger bearing assembly. Then remove the lower auger through the auger hinge opening.

Auger System (continued)


Lower Auger Assembly

4. The replacement auger is factory balanced. Remove entire auger from shipping crate and secure from rolling. The lower auger assembly is pictured in FIG. 4-9 for reference.




 Attach the u-joint assembly to the lower auger flighting by placing 3/4"-10UNC x 7 1/2" capscrews (9008114) and 3/4"-10UNC lock nuts (9802) into the auger from opposite directions as shown in FIG. 4-10.

NOTE: If reusing flighting extension, replace with new hardware and apply anti-seize to hardware before installing to auger flighting. Do not reuse old flighting extension hardware.




- Using a safe lifting device rated at a minimum of 1000 lbs., lift the auger and assembly. Slowly lower the auger down through the auger plate opening to intersect with the drive bushing.
- 7. Align auger end with the five pin auger drive plate assembly and securely engage together, see FIG. 4-11.



Auger System (continued)

Hanger Bearing Centering

 Once the lower auger is inserted into the auger tube, center the lower auger in the tube and support with two 5/8" thick bars/wedges near the auger hinge plate. (FIG. 4-12)




Lower Auger Timing

9. Apply anti-seize to the splines before sliding the drive dog into the u-joint. Time the drive dog (as in FIG. 4-13) with the finished edge of the flighting at 12:00. Position the drive dog at 1:30.


NOTE: When looking down at the lower flighting (FIG. 4-13) the auger rotation will be clockwise.

<u>NOTE</u>: For additional auger timing assistance, refer to your dealer for an auger timing fixture (293329Y).



Auger System (continued)

10. Loosely secure the hanger bearing using two 3" x 3 9/16" shims (292423B), one 2" x 3 5/16" shim (292886), three 5/8"-11UNC x 2" capscrews (9390-124), three 5/8" flat washers (9405-098), and three 5/8"-11UNC lock nuts (9003398) as shown in FIG. 4-14.




Auger System (continued)

U-Joint Spline Gap

11. Verify spline gap before tightening hanger bearing hardware. Spline gap should be a minimum of 3/16". Using a lifting device rated for 250 pounds, raise the hanger bearing in the holes so the proper minimum spline gap is achieved. (FIG. 4-15)

NOTE: When auger components have been replaced or serviced, proper spline gap MUST be verified. It may be necessary to loosen the hanger bearing hardware and use the lifting device to achieve the proper spline gap.

- 12. Tighten the retaining hardware to the appropriate torque values listed in the MAINTENANCE section.
- 13. Grease the spline and hanger bearing grease zerks. (FIG. 4-15)
- 14. Fold upper auger to unload position and have a second user visually check for auger engagement. Test run augers at slow speed.



Upper Auger


 Hitch cart to tractor, connect hoses for flow door and upper auger hydraulic cylinders and fully open flow door. Keep upper auger in the folded position. Park the empty grain cart on a firm, level surface. Set the tractor's parking brake, shut-off the engine and remove the ignition key. Block the machine to keep it from moving.



Upper Auger Removal

- 2. Loosen the two bearing set screws.
- 3. Remove and save the 5/16"-18UNC x 2 3/4" capscrew (9390-037), four 5/16" SAE flat washers (9405-068), 5/16"-18UNC lock nut (901527), and 2" flat washers (93974). (FIG. 4-16)
- 4. Use a safe lifting device rated at a minimum of 2,000 lbs. to support the upper auger, remove auger from tube.

NOTE: If replacing the soft start, continue to step 5. If replacing the upper auger, continue to step 9.





Soft Start Replacement

Remove the 5/8-11UNC x 9" capscrew (9390-442 - SN B38910100 and higher), 5/8"-11UNC x 8" capscrew (9390-140 - SN B38910099 and lower), spacer bushing (405402B), 5/8"-11UNC lock nut (9801), soft start assembly, thrust washer (9004878), and bushing (9004877). Discard 5/8" hardware and spacer bushing. (FIG. 4-17 and 4-18)

NOTE: If reusing flighting extension, replace with new hardware and apply anti-seize to hardware before installing to auger flighting. Do not reuse old flighting extension hardware.

6. Insert the bushing (9004877) into the end of the upper auger. Attach the thrust washer (9004878) and apply anti-seize to the soft start and insert into the auger tube. (FIG. 4-17 and 4-18)





Upper Auger Timing

7. Time the drive pin (as in FIG. 4-19) with the finished edge of the flighting at 12:00. Position the drive pin at 6:00.

NOTE: Looking up at the upper flighting (FIG. 4-19) the auger rotation will be counter clockwise.

NOTE: There is only one way the soft-start will go in.


NOTE: For additional auger timing assistance, refer to your dealer for a timing fixture kit (293329Y).


NOTE: Before soft start reassembly, ensure the spacer bushing (405402B) is on the same side as the lock nut (9801). (FIG. 4-17 and FIG. 4-18)

Retain the soft start into position with the 5/8-11UNC x 9" capscrew (9390-442 - SN B38910100 and higher), 5/8"-11UNC x 8" capscrew (9390-140 - SN B38910099 and lower), spacer bushing (405402B), 5/8"-11UNC lock nut (9801). (FIG. 4-17 and FIG. 4-18)

NOTE: The replacement auger is factory balanced. Remove entire auger from shipping crate and secure from rolling. The upper auger assembly is pictured in FIG. 4-20 for reference.

 Using an adequate hoist and slings with a minimum capacity of 2,000 lbs. to support the upper auger, install upper auger into the tube. (FIG. 4-20)






10. If only installing upper auger, refer to "Upper Auger Timing" and position soft start accordingly.

Upper Auger Height


11. Place a flat bar across the center of the auger housing tube. Measure the distance between the center of the face of the soft start bushing that sits on the top of the drive dog and the center of the flat bar. Verify the upper auger in-set of approximately 7 5/8". With the upper auger folded back, ensure the height of the upper auger is set correctly. If this dimension is not correct, loosen the set screws in the flange bearing at the top of the upper auger and slide the auger through the bearing to this correct position. Tighten set screws. (FIG. 4-21)

(Continued on next page.)



Auger System (continued)

12. Make sure the 4 bolt flange bearing is sitting tight against the mounting plate and then tighten the two bearing set screws. Attach the upper auger with the 5/16"-18UNC x 2 3/4" capscrew (9390-037), four 5/16" SAE flat washers (9405-068), 5/16"-18UNC lock nut (901527), and as many 2" flat washers (93974) as required to fill the gap between the bearing and the cross bolt. (FIG. 4-22)




Upper Auger Bearing Gap


- 13. Unfold the auger to the operating position.
- 14. Engage PTO and test run augers to ensure drive dogs are engaged. Stop PTO, shut off tractor and remove key.



- 15. Remove upper auger tube plug and visually verify upper and lower auger engagement. (Fig. 4-25)
- 16. Verify the upper auger bearing height by inspecting the upper auger bearing in operating position. There should be minimum 1/16" to 1/8" gap between the bearing and mount plate with the upper auger in operating position and the drive dog completely engaged. If gap is present, no action is needed, go to step 3. If no gap or gap is too large, Re-adjust the upper auger placement to achieve a 1/16-1/8" gap. If there is no gap, the upper auger will need to be moved ahead. If there is too large of a gap, move it backwards in the upper auger housing. The number of washers (93974) will also need to be adjusted to eliminate any gap between the bearing and the cross bolt. (FIG. 4-23 and 4-24)
- 17. Place upper auger in the folded/transport position.
- 18. Once the upper auger height has been verified, remove the upper bearing set screws one at a time, and dimple the stud shaft with a 1/4" diameter drill bit. Apply TL-42 blue thread locker to the set screws, and reinstall the set screws into the flange bearing and into the dimples on the stud shaft. Tighten set screws. Tighten all hardware.
- 19. If upper and lower auger engagment is good, install upper auger tube plug. (FIG. 4-23)
- 20. Test run auger driveline to verify smooth driveline operation. Check for noise and/or vibration and address immediately.







Flow Door Cylinder Stop

▲ DANGER

ELECTROCUTION WILL CAUSE SERIOUS INJURY OR DEATH. ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT. KEEP AWAY FROM ALL ELECTRICAL LINES AND DEVICES.



ENTANGLEMENT WITH THE DRIVELINE WILL CAUSE SERIOUS INJURY OR DEATH.
KEEP ALL GUARDS AND SHIELDS IN GOOD CONDITION AND PROPERLY INSTALLED
AT ALL TIMES. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOE
STRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC. THAT CAN BECOME ENTANGLED IN A ROTATING DRIVELINE.

The floor door has been set with a stop to limit the maximum opening. The factory stop position provides full auger fill in most crops and conditions. For extra-difficult flowing crops, more auger opening may be required.


NOTE: Opening the auger flow door past the factory setting will increase power consumption, auger wear, and shorten driveline life. (FIG. 4-26)

- 1. Park the empty grain cart on a firm and level surface. Block the machine to keep it from moving. Set the tractor's parking brake. Leave the tractor on throughout procedure.
- 2. Before loading cart or operating auger, verify that the flow control door is closed.
- 3. Choose an area free from obstructions and unfold the auger into the unloading position. Allow sufficient time for the cylinder to fully engage the two augers.

4. Rotate spout to the most forward position to engage the spout cylinder stroke bracket, then rotate the spout to the desired operating position.

NOTE: In order to increase grain flow to the maximum bushels per minute, cylinder stop (293781B) can be removed from the flow door cylinder. (FIG. 4-26)

- 5. Locate the cylinder stop on the end of the flow door cylinder. (FIG. 4-26)
- 6. Remove the capscrew and lock nut retaining the cylinder stop.
- 7. Remove the cylinder stop from the flow door cylinder rod and keep for future use.



<u>NOTE</u>: Upon removal of the cylinder stop, a minimum of 1000 PTO RPM MUST be maintained when operating the flow door at the maximum setting.

IMPORTANT


• Operating the PTO at less than 1,000 RPM can result in damage to the PTO and driveline components in addition to excessive auger wear and cart vibration.

Auger Driveline


Bearings

It is important to periodically check setscrews in all bearings of the driveline for tightness.

Driveline Replacement



- Park the empty cart on a firm, level surface. Block the machine to keep it from moving. Set the tractor parking brake, shut off the engine, and remove the ignition key from the tractor. Completely disconnect driveline assembly and bearing hardware.
- 2. Loosen the setscrews (9399-071) on all flangette bearings (9003920) (Fig. 4-27).
- 3. Remove the 1/2" carriage bolts (9388-103), flange nuts (9394-010), and lock washers (9404-025) holding the flangette bearings. Keep hardware. (Fig. 4-28).
- Remove paint on driveshaft to allow for easier movement. Slide driveshaft forward until the rear spline is out of the universal joint connected to the gearbox.




5. Drop the gearbox end of drive shaft down and slide driveshaft out of the flangette bearing on the hitch end of the driveshaft.

Auger Driveline (continued)


Driveline Replacement (continued)

- Remove bearings, bearing mounts, universal joint cover, driveshaft lock collars (if lock collars are attached to driveshaft), PVC driveshaft covers, and driveline cover off the current driveshaft.
- 7. Slide new 1 3/4" dia. two-piece lock collars (9008674) to both sides of new bearing (9005061) closest to the U-Joint.
- When installing new bearings (9005061) onto new 1 3/4" dia. driveshaft, assemble new PVC driveshaft covers (292590) between bearings near the gearbox and between bearings behind the hitch driveline cover. (FIG. 4-29)



NOTE: Ends of driveshaft are symmetrical.

- 9. Slide the hitch end of the driveshaft, bearing and hitch driveline cover into the bearing near hitch of the cart. (FIG. 4-29)
- 10. Raise the gearbox end of the drive shaft up and insert the original 1/2" carriage bolts, flange nuts, and lock washers into the mounting flanges making sure that the bearing flanges are both on the front side of the mounting brackets. Only loosely tighten the hardware.
- 11. Slide driveshaft down into the universal joint attached to the gearbox until the end of the shaft extends into the universal joint about 2 3/8". Ensure universal joint and driveshaft splines completely engage. Verify the hitch end for adequate length for driveline assembly to connect. (FIG. 4-30)




Auger Driveline (continued)


Driveline Replacement (continued)

- 12. Tighten all flangette mounting hardware.
- 13. With bearing mounting hardware completely tightened, drill a setscrew dimple in the driveshaft by going through the bearing setscrew threaded hole to dimple the driveshaft being careful to not damage threads. Drill the dimple to a depth that setscrews are flush with the bearing prior to applying thread locker and installing setscrews. (FIG. 4-31)
- 14. For alignment of the yoke, the orientation of the universal joint at the gearbox must be in line with the driveshaft drill dimple when the driveline assembly is attached. (FIG. 4-31 and 4-32)
- 15. Apply blue thread locker on bearing setscrews and tighten.
- 16. Torque lock collars to 170 inch-lbs.

NOTE: Check/fill gearbox oil and grease universal joint before installing new universal joint cover. See "Gearbox Lubrication" for oil specifications.

- 17. Attach new universal joint cover (292875B) to the bearing mount in front of the gearbox using original 3/8"-16UNC capscrews and 5/16"-18UNC weld nuts. Review to ensure PVC driveshaft covers and driveline cover are in place and hardware tightened prior to operation.
- Test run driveline. Verify smooth driveline operation.





Verify Telescoping PTO Shaft Length

PROPER EXTENDED AND COLLAPSED LENGTHS OF THE TELESCOPING PTO SHAFT MUST BE VERIFIED BEFORE FIRST OPERATION WITH EACH AND EVERY TRACTOR. IF THE EXTENDED LENGTH OF THE PTO SHAFT IS NOT SUFFICIENT, IT MAY BECOME UNCOUPLED IN OPERATION AND CAUSE SERIOUS INJURY OR DEATH FROM CON-TACT WITH UNCONTROLLED FLAILING OF PTO SHAFT ASSEMBLY COMPONENTS.

IMPORTANT

Check the length of the telescoping members to insure the driveline will not bottom out or separate when turning and/or going over rough terrain.

Consult your OEM dealer for recommended drawbar and PTO set up.

An excessive collapsed length can result in damage to the PTO driveline and attached components. This is most likely to occur during extreme turning angles and/or travel over rough terrain. Conditions are amplified on tractors with tracks operating in uneven terrain, particularly rice levies. Damaged driveline components can result in unsafe operation and severely reduced driveline component life.

NOTE: Do not exceed 10 degrees beyond a straight pull line while operating the PTO. To verify proper extended and collapsed lengths, use the following procedure:

1. Fully collapse PTO shaft and measure length "L" (Fig. 4-33).

Enter here:____(1)


(Verify that outer tube does not bottom out on surrounding plastic shield components).


2. Pull apart PTO telescoping shaft ends and measure lengths "T" & "C" (Fig. 4-34)

Add "T" + "C" measurments together Enter total here: (2)

- 3. Calculate maximum recommended extended length:
 - a. Subtract line 1 from line 2 Enter here:
 - b. Divide line (a) by 2
 - Enter here:____(b)
 - c. Add line (b) to line 1. Enter here:____(c)
 - d. Subtract 3 inches from line (c)

Enter here:____(d)







This is the maximum recommended extended length.

Verify Telescoping PTO Shaft Length (continued)

- 4. Hitch tractor drawbar to cart, ensuring that tractor and cart are on level ground and coupled as straight as practical.
- 5. Connect PTO shaft to tractor, and measure length "L" from same points as used in step 1. Ensure that this measurement does not exceed the maximum recommended extended length calculated in step 3 above. If necessary, choose a shorter drawbar position, or obtain a longer PTO shaft assembly before operating cart.
- 6. Position the tractor to obtain tightest turning angle, relative to the cart. (Fig. 4-35)
- 7. Measure length "L" from same points as used in step 1. This distance must be at least 1.5 inches greater than the distance measured in step 1 If necessary, adjust length of PTO shaft by cutting inner and outer plastic guard tubes and inner and outer sliding profiles by the same length. Round off all sharp edges and remove burrs before greasing and reassembling shaft halves. (Fig. 4-36)






PTO Shaft and Clutch

Lubrication (Figs. D1 - D6)

Lubricate with quality grease before starting work and every 8 operating hours. Clean and grease PTO drive shaft before each prolonged period of non-use. Molded nipples on the shield near each shield bearing are intended as grease fittings and should be lubricated every 8 hours of operation! Telescoping members must have lubrication to operate successfully regardless of whether a grease fitting is provided for that purpose! Telescoping members without fittings should be pulled apart and grease should be added manually. Check and grease the guard tubes in winter to prevent seizing.



PTO Shaft and Clutch (continued)

Coupling the PTO drive shaft (Figs. E1 - E2)


Clean and grease the PTO and implement input connection (IIC)

AS-Lock

 Pull locking collar and simultaneously push PTO drive shaft onto PTO shaft until the locking device engages.

Push-Pull Lock

2. Pull locking collar and simultaneously push PTO drive shaft onto PTO shaft until the locking device engages.







CHECK TO INSURE ALL THE LOCKS ARE SECURELY ENGAGED BEFORE STARTING WORK WITH THE PTO DRIVESHAFT.


Length Adjustment (Figs. F1 - F4)

NOTE: Maximum operating length LB.

- 1. To adjust length, hold the half-shafts next to each other in the shortest working position and mark them.
- 2. Shorten inner and outer guard tubes equally.
- 3. Shorten inner and outer sliding profiles by the same length as the guard tubes.
- 4. Round off all sharp edges and remove burrs. Grease sliding profiles.












CHECK THE LENGTH OF THE TELESCOPING MEMBERS TO INSURE THE DRIVELINE WILL NOT BOTTOM OUT OR SEPARATE WHEN TURNING AND/OR GOING OVER ROUGH TERRAIN.

PTO Shaft and Clutch (continued)

Chains (Figs. G1 - G3)


NOTE: The chain is intended to prevent the shield from rotating against non-moving parts and thereby preventing shield damage. A properly installed chain will increase the service life of the shield.

- Chains must be fitted so as to allow sufficient articulation of the shaft in all working positions.
 Care must be taken to be sure that chain does not become entangled with drawbar hitch or other restrictions during operation or transport of machine.
- 2. The PTO drive shaft must not be suspended from the chain.



To Dismantle Guard (Figs. J1 - J4)


- 1. Remove locking screw.
- 2. Align bearing tabs with cone pockets.
- 3. Remove half-guard.
- 4. Remove bearing ring.





PTO Shaft and Clutch (continued)


To Assemble Guard (Figs. K1 - K5)


- 1. Grease yoke groove and inner profile tube.
- 2. Fit bearing ring in groove with recesses facing profile tube.
- 3. Slip on half-guard.
- 4. Turn cone until it engages correctly.
- 5. Install locking screw.














To Assemble Cone

- Dismantle guard (Figs. J1 J3). Remove old cone (e.g. cut open with knife). Take off chain. Place neck of new cone in hot water (approx80°C/180°F)andpullontobearinghousing (Fig. L1).
- 2. Turn guard cone into assembly position (Fig. L2). Further assembly instructions for guard (Figs. K1 K5).
- 3. Reconnect chain if required (Fig. L3).









PTO Quick Disconnect


Coupling

Slide clamp yoke or clutch onto connecting shaft. Make sure the location hole for the clamping cone is positioned above the annular groove of the connecting shaft. Screw appropriate clamping cone into the location hole. Slightly moving the clamp yoke or clutch to and from in the axial direction will help drive in the clamping cone. Check the clamp yoke or clutch for a tight and safe fit and continue to check at regular intervals. Retighten the clamping cone as necessary. Torque clamping cone down to 75 ft.-lbs.

When over loading occurs, the clutch disengages and will repeatedly attempt to reset. The clutch will create a repeated "clicking" noise when resetting. Torque demand must decrease for clutch to reset.








Uncoupling

First dislodge the clamping cone with a punch and hammer from its current position. Unscrew the clamping cone a partial turn. Use the punch and hammer to help alleviate the torque resistance on the wrench if necessary. After a few cycles the clamping cone will move freely with low torque resistance for the removal process.



Wheel, Hub and Spindle Disassembly and Assembly

A WARNING

- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 32,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

A CAUTION

IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

- Remove only one wheel and tire from a side at any given time using the following procedure.
- 1. Hitch cart to tractor. Park the empty cart on a firm, level surface. Set the tractor's parking brake, shut off engine and remove key.




- 2. With cart empty, place 32,000 lbs. safe lifting and load holding devices rated at 32,000 lbs. to support the weight of your grain cart. Place the safe lifting device under the axle closest to the tire/track.
- 3. Use a 3,000 lbs. safe lifting device to support the wheel and tire then remove hardware.
- 4. Remove the hardware retaining the hubcap. Next, remove the hubcap, gasket, cotter pin, castle nut and spindle washer. Remove hub with bearings from old spindle using a 250 lb. lifting device.
- 5. Inspect the spindle and replace if necessary. If spindle does not need to be replaced, skip to Step 6; otherwise continue.

Remove the capscrew and lock nut that retains the spindle to the axle. Using a safe lifting device rated for 200 lbs., replace the old spindle with a new spindle. Coat axle contact length of spindle shaft (scale or non-scale) with anti-seize lubricant prior to installation. If installing scale spindle, install with 'top' decal facing upwards. Reuse capscrew and lock nut to retain spindle to axle. Torque as outlined in MAINTENANCE section.

Wheel, Hub and Spindle Disassembly and Assembly (continued)

6. For Hub disassembly: Remove seal and inspect bearings, spindle washer, castle nut and cotter pin. Replace if necessary. Pack both bearings with approved grease and reinstall inner bearing. Install new seal in hub with garter spring facing the hub by tapping on flat plate that completely covers seal while driving it square to hub. (FIG. 4-37) Install until flush with back face of hub. Using a 250 lb. rated lifting device, install hub assembly onto spindle. Install outer bearing, spindle washer and castle nut.



- 7. For Hub adjustment: Slowly tighten castle nut while spinning the hub until drag causes the hub to stop freely spinning. Do not use an impact! Turn castle nut counterclockwise until the hole in the spindle aligns with the next notch in castle nut. Hub should spin smoothly with little drag and no end play. If play exists, tighten to next notch of castle nut. If drag exists, then back castle nut to next notch of castle nut. Spin and check again. Install cotter pin. Clean face for hub cap gasket and install gasket, grease-filled hub cap and retain hub cap with hardware removed. Tighten hubcap hardware in alternating pattern.
- 8. Attach the wheel(s) and tire(s) to the hub using the same rated lifting device for removal. Tighten wheel nuts to appropriate requirements and recheck as outlined in "Wheel and Tire" in the MAIN-TENANCE section.
- 9. Raise cart, remove load holding devices and lower cart to the ground.

Wheels and Tires

Wheel Nut Torque Requirements




CAUTION

IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagram 1.

WHEEL HARDWARE					
SIZE	FOOT-POUNDS				
7/8-14 (UNF)	440 ftlbs.				
M22x1.5	475 ftlbs.				

Note: Do not use anti-seize on wheel hardware.



Wheels and Tires (continued)

Tire Pressure

The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. It is important that tires are inspected after unit is loaded. Start with minimum pressure. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. Do not exceed maximum recommended tire pressure. Each tire must be inflated to 35 PSI max to seat the beads, deflated to 5-10 PSI, then reinflated to to recommended minimum pressure.

Tire Pressure for Grain Carts

		Load Index / Ply		
Tire Make	Tire Size	Rating	Max. PSI	
Firestone	23.1x26 R-3	12	32	
	23.1x26 R-1	12	32	
	28Lx26 R-3	12	26	
	24.5x32 R-3	12	32	
	24.5x32 R-1	12	32	
	30.5x32 R-1	14	28	
	30.5x32 R-3	14	28	
	30.5x32 R-3	16	34	
	30.5x32 R-1	16	26	
	35.5x32 R-3	20	36	
	76x50.00x32 HF-3	16	40	
	76x50.00x32 HF-3	20	50	
	800/65R32 R-1W	172D	41	
	800/60R32 R-3	181B	46	
	900/65R32 R-3	191B	46	
	900/60R32 R-1	176A8	44	
	1250/50R32F IF/CFO R-1WNP	201D	46	
	1250/50R32F IF/CFO R-1W	188B	30	
	520/85R38 R-1	155A8	29	
	520/85R38 R-1	173A8	64	
	480/80R42 R-1	151A8	36	
	520/85R42 R-1	157A8	29	
	520/85R42 R-1	165A8	51	
	520/85R42 IF/CFO R-1	169A8/B	35	
	IF520/85R42 R-1W	169B	35	
	VF520/85R42 R-1W	177B	35	
	420/80R46 R-1	151A8	44	
	480/80R46 R-1	158A8	44	
	380/90R46 R-1	152B	51	

Wheels and Tires (continued)

Tire Pressure (continued)

Tire Make	Tire Size	Load Index / Ply Rating	Max. PS
Titan/Goodyear	23.1x26 R-3	10	26
	23.1x26 R-1	10	26
	24.5R32 R-1	169A8/B (5-Star)	48
	24.5x32 R-3	12	32
	24.5x32 R-1	12	32
	30.5x32 R-3	16	26
	30.5x32 R-3	14	22
	30.5x32 R-1	14	22
	480/80x42 R-1	166A8	23
	900/60R32 R-1W	185A	49
	1050/50R32 R-1	196D	52
	1100/45R46 R-1W	195D	35
	IF1250/50R32 R-1W	201D	46
Mitas	650/75R32 R-1W	172A8	58
wiitas	650/75R32 R-1	176A8	41
	800/65R32 R-1W	172A8	46
	900/60x32 R-1W	181A8	58
	900/60x32 CHO R-1W	181A8	46
	900/70R32 R-1W	188A8	53
	1050/50x32 R-1W	178A8	41
	1250/50R32 R-1W	188A8	41
	900/60x38 R-1W	181A8	44
	520/85x42 R-1W	162A8	44
A 111	650/65x42 R-1W	168A8	44
Alliance	30.5B32 35.5LR32	18-Ply 193A8	36 44
	900/60R32 R-1W	192D	46
	1050/50R32 R-1W	185A8	52
	1250/50R32 R-1W	201B	46
Trelleborg	VF1050/50R32 R-1	198D	52
-	900/50R32 R-1W	181A8	55
	900/60x32	176LI	44
	850/55R42 R-1W	161A8	32

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. **USED TIRES CARRY NO WARRANTY**. Following are phone numbers and Websites for your convenience:

<u>Firestone</u> www.firestoneag.com

Phone 800-847-3364

<u>Titan</u> www.titan-intl.com

or Phone 800-USA-BEAR

Goodyear Fax 515-265-9301

<u>Trelleborg</u> www.trelleborg.com

Phone 866-633-8473

Continental/Mitas www.mitas-tires.com

Phone 704-542-3422 Fax 704-542-3474

<u>Alliance</u> www.atgtire.com

Phone 781-325-3801


Adjusting Cleanout Door

A WARNING


- MOVING PARTS CAN CRUSH AND CUT. KEEP AWAY FROM MOVING PARTS.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.
- 1. Park the empty grain cart on a firm and level surface. Block the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.



2. Inspect and verify that all the grain dust and filings are removed that may prevent the door from shutting completely. Completely close cleanout door. (FIG. 4-38)




- 3. Engage the locking plate (268313B). (FIG. 4-39)
- 4. Loosen mounting hardware. (FIG. 4-39)




Adjusting Cleanout Door (continued)

5. Push the gear assembly toward bottom of auger to remove excess movement and prevent the door from moving upward when unloading the cart. (FIG. 4-40)




- 6. Tighten hardware loosened in step 4. (FIG. 4-41)
- 7. Check door operation. Lock the handle weldment into position. (FIG. 4-41)




Hydraulic Jack Cylinder Replacement

A WARNING

- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. LEAKS OF HIGH-PRESSURE FLUIDS MAY NOT BE VISIBLE. USE CARD-BOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH.
 ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING UNIT.
- UNHITCHING A LOADED CART CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED CART ATTACHED TO A TRACTOR. THE JACK IS INTENDED TO SUPPORT AN EMPTY CART ONLY.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER
 THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES
 AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY
 INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 100 LBS. SPECIFIC
 LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME
 IN THE INSTRUCTIONS.
- 1. Park the empty unit on a firm, level surface. Block tractor and machine to keep it from moving. Set the tractor parking brake, shut off the engine and remove the ignition key. Completely disconnect the PTO from the cart and tractor.
- 2. Attach hydraulic jack hoses to tractor SCV.
- Open valve and lower jack leg to ground. DO NOT raise tongue.




- 4. Relieve pressure on hydraulic jack circuit. See tractor operator manual for procedure.
- 5. Close valve.
- 6. Support the hydraulic jack assembly with a safe lifting device rated for a minimum of 100 lbs.
- 7. Remove hydraulic jack hoses from tractor SCV.
- 8. Remove cylinder pin (272587) and snap rings (91192) from the base end of the cylinder at the lug on top of the tongue. (Fig. 4-42)




Hydraulic Jack Cylinder Replacement (continued)

- Remove two 7/8"-9UNC x 2 1/4" capscrews (9390-165) and 7/8" lock washers (9404-037) from mounting bracket (273808B). (Fig. 4-43)
- 10. Remove hydraulic jack assembly from the tongue. (Fig. 4-43)



- 11. On new hydraulic assembly (294143B), attach hoses (9006068) and fittings to cylinder (9009047). (Fig. 4-53) The valve needs to be assembled to the hose on the base end of the cylinder. Assemble the fittings on the cylinder so they face each other, then store the hydraulic hoses on the hose caddy.
- 12. To reassemble hydraulic jack, see "Optional Hydraulic Jack" in SET UP section.



Seasonal Storage

Your cart is an important investment. Spend a little time to protect it from destructive rust and corrosion. You will be repaid in longer service life and better performance.

Do the following before placing the cart in storage:

- Wash machine inside and out before storing to remove dirt and debris that can draw and collect moisture. When using pressure washers, maintain an adequate distance so not to force water into bearings.
- 2. Using safe lifting device rated at 100 lbs., store PTO on the rest brackets at the rear of the cart.
- Repaint all areas where paint has been removed to keep rust from developing. Rust will affect grain flow.
- 4. Coat exposed cylinder piston rods with rust preventative material if applicable.
- 5. Lubricate machine at all points outlined.
- 6. Inspect for damage or worn parts, replace before next season.
- 7. Store cart inside, away from livestock.
- 8. Replace all worn, torn or faded decals and reflectors.
- 9. If unit is equipped with a scale indicator or electric hydraulic controls, store these indoors in a dry location.
- 10. Fully open flow door and auger cleanout door to remove any remaining grain and to allow moisture to dry.
- 11. Close the tarp to keep debris out of the hopper.




EOH Troubleshooting

Problem Possible Cause Corrective Action

	7 Pin connector not supplying good ground to cart.	Check the connections to the main power harness in the tractor cab, and check the 5 AMP fuse in the fuse holder of the main power harness. Replace fuse if necessary.
No Electric Over Hydraulic (EOH) Functions work	Not getting good connection at Deutch connectors in the harnesses	Unplug the Deutsch connectors at the hitch point and in the extension harness (if used). Clean up the connectors with electrical contact cleaner. Make sure the connectors are aligned correctly and re-connect them.
	Not pressurizing the correct hydraulic hose	Make sure the quick couplers are properly connected to the tractor SCV and the Hydraulic Pressure line is being pressurized when engaging the tractor SCV.
Auger unfolds part way and stops	Debris in the EOH block on the auger fold cylinder	Fold auger, remove the Coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil.
	Defective coil on the EOH valve for that function	Loosen the cap for the coils associated with that function on the EOH valve. Depress the button on the remote, and determine if the coils are getting magnetized. Inspect the wiring connectors to these coils, and replace the coil if necessary.
One single function will not work	Defective valve on the EOH valve for that function	Remove the coil and the cartridge valve on the EOH valve block for that function. Replace the valve if it doesn't operate when the coil is magnetized.
	Debris in the EOH block at the base of the vertical auger	Remove the coil and the cartridge valve on the EOH valve block. Remove any debris and reinstall cartridge and coil.
Functions continue to operate after the button on the remote is released	Tractor hydraulic flow is set too high	Turn tractor hydraulic flow down so that flow doesn't exceed 6 gallons per minute.
	Defective valve on the EOH valve for that function	Remove the coil and the cartridge valve on the EOH valve block for that function, and replace the cartridge.

Scale Troubleshooting



Tarp - Troubleshooting Inspection and Maintenance

PROBABLE CAUSE	CORRECTION	
Tarp sags in middle areas	1. Bows may be bent or adjusted too low.	
	2. Missing or loose ridge strap. Replace or retighten.	
	U-joint may need to be adjusted 3. on splinded shaft to provide more tension.	
Holes or tears in tarp	Consult your local dealer for repairs.	
	2. Order tarp repart kit from dealer.	
	3. When new tarp or parts are needed always replace with original parts.	

Inspection and Maintenance

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.


IMPORTANT

- Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.
- Tarp should not be used if it is torn or the bungee cords are frayed or show damage. Fully close tarp with tension on the latch plate to prevent water from pooling.

Periodic preventive maintenance should be practiced. Inspect tarp and hardware often for abrasions or loosened bolts that may need adjustment and/or repair. Check bungee cords for wear and adjust tension at the beginning of the season and again half way through the season.

Tears in tarp should addressed before further tarp operation. If water pools on tarp, adjust tension of tarp cables and/or arm springs.

If installed correctly, tarp should always operate as well as when first installed. If tarp does not pass this simple inspection, make all appropriate repairs or adjustments immediately before serious damage occurs.



Electrical System Diagram — Plug #92450

GRAIN CART WIRES

White -- Ground

Green -- Right amber flashing lamp

Yellow -- Left amber flashing lamp


Brown -- Tail Lights

Black/White -- Interior & Auger Lights


Black -- Side/Work Lights


Red -- Brake Lights


Blue -- NOT USED





SAE SEVEN-POINT CONNECTOR PLUG

























3 PIN FEMALE CONNECTOR BLACK - SIGNAL (PIN #A) BROWN - +12 V DC (PIN #B) BLUE - GROUND (PIN #C)














Optional Electric Over Hydraulic Valve Electric Schematic 4 Spool




PORT	END OF CYLINDER	FUNCTION
А	BUTT END	FLOW DOOR CLOSE
В	RAM END	FLOW DOOR OPEN
С	RAM END	AUGER FOLD LOWER
D	BUTT END	AUGER FOLD RAISE
E	RAM END	SPOUT TILT OUT
F	BUTT END	SPOUT TILT IN
G	ORBIT MOTOR PORT B	SPOUT ROTATE OUT
Н	ORBIT MOTOR PORT A	SPOUT ROTATE IN
Р		TRACTOR PRESSURE
Т		TRACTOR RETURN





Electrical System Schematic - Optional Electric Tarp For SN B43320099 & Lower



Complete Torque Chart

Capscrews - Grade 5

NOTE:

- Grade 5 capscrews can be identified by three radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

SIZE	FOOT NEWTON POUNDS METERS	
1/4-20	8-10	11-13
1/4-28	9-11	12-15
5/16-18	15-17	20-23
5/16-24	17-19	23-26
3/8-16	25-28	34-38
3/8-24	28-31	38-42
7/16-14	40-45	54-61
7/16-20	45-50	61-68
1/2-13	62-68	84-92
1/2-20	68-75	92-102
9/16-12	90-98	122-133
9/16-18	100-110	134-148
5/8-11	120-135	162-183
5/8-18	124-137	168-186
3/4-10	200-220	270-300
3/4-16	210-230	285-310
7/8-9	330-350	425-475
7/8-14	360-380	460-515
1-8	500-525	675-710
1-14	540-560	730-760
1 1/8-7	600-635	815-860
1 1/8-12	665-700	920-950
1 1/4-7	850-895	1150-1215
1 1/4-12	940-990	1275-1340
1 3/8-6	1125-1175	1525-1590
1 3/8-12	1280-1335	1735-1810
1 1/2-6	1500-1560	2035-2115
1 1/2-12	1685-1755	2285-2380

IMPORTANT

• Follow these torque recommendations except when specified in text.

Complete Torque Chart

Capscrews - Grade 8

NOTE:

- Grade 8 capscrews can be identified by six radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.





SIZE	FOOT POUNDS	NEWTON METERS
5/16-18	20-22	27-30
5/16-24	21-23	28-31
3/8-16	35-39	47-53
3/8-24	36-41	49-55
7/16-14	54-58	73-78
7/16-20	55-60	75-80
1/2-13	82-88	110-120
1/2-20	94-99	125-135
9/16-12	127-134	170-180
9/16-18	147-155	199-210
5/8-11	160-170	215-230
5/8-18	165-175	225-235
3/4-10	280-295	380-400
3/4-16	330-365	445-495
7/8-9	410-430	555-580
7/8-14	420-440	570-595
1-8	630-650	850-880
1-14	680-700	920-950
1 1/8-7	900-930	1220-1260
1 1/8-12	930-950	1260-1290
1 1/4-7	1250-1300	1695-1760
1 1/4-12	1280-1320	1735-1790

IMPORTANT

• Follow these torque recommendations except when specified in text.

Hydraulic Fittings - Torque and Installation


Tightening O-Ring Fittings

- Inspect components for damage or contamination. Do not connect any other type of fitting to an O-ring fitting.
- 2. For adjustable fittings, insure the jam nut and washer are fully backed up.
- 3. Lubricate the O-ring and threads on the fitting.
- 4. Turn the fitting into the port until it is finger tight.
- 5. For adjustable fittings, set in the desired position.
- 6. Using a wrench, torque the fitting to the value in the below table. For adjustable fittings the jam nut will be tightened.

NOTE: Never use a power tool to install a fitting.

Dash Size	Thread Size	Straight Stud Torque (Ft-Lbs)	Adjustable Stud Torque (Ft-Lbs)
-5	1/2-20	14-19	10-14
-6	9/16-18	18-24	12-16
-8	3/4-16	27-43	20-30
-10	7/8-14	36-48	30-36
-12	1-1/16-12	65-75	44-54
-14	1-3/16-12	75-99	53-70
-16	1-5/16-12	85-123	59-80
-20	1-5/8"-12	115-161	75-100
-24	1-7/8"-12	125-170	105-125






Hydraulic Fittings - Torque and Installation

Tightening JIC Fittings

- Inspect all components for damage or contamination. Do not connect any other type of fitting to a JIC fitting.
- 2. Lubricate the threads.
- 3. Turn the fitting into the port until it bottoms out.
- Use one wrench on the fixed hex on the hose to prevent twisting and a second on the swivel. Tighten the fitting another 60 degrees (or one flat)

NOTE: Never use a power tool to install a fitting.





Notes	





Grain Handling

FRONT FOLDING X-TREME® GRAIN CART MODELS 1019 & 1119

1019 Serial Number B37660100 and Higher 1119 Serial Number B37660100 and Higher

Part No. 292499


SECTION IV Maintenance


Lubrication	4-2
Seasonal Storage	4-5
Gearbox Lubrication	4-6
Hydraulic System	4-7
Purging Procedure for Braking System (Optional)	4-9
Adjusting Cleanout Door	. 4-10
Auger System	. 4-12
Lower Auger Removal	. 4-12
Lower Auger Assembly	. 4-13
Hanger Bearing Centering	. 4-14
Lower Auger Timing	. 4-15
U-Joint Spline Gap	. 4-16
Upper Auger Removal	. 4-17
Soft Start Replacement	. 4-18
Upper Auger Timing	
Soft Start Replacement (Continued)	
Upper Auger Assembly	. 4-20
Upper Auger Height	
Upper Auger Assembly (Continued)	
Upper Auger Bearing Gap	
Auger Driveline - Bearings	
Auger Driveline - Driveline Replacement	
Verify Telescoping PTO Shaft Length	
PTO Shaft and Clutch	
PTO Quick Disconnect	
Scale Troubleshooting	
Weather Guard Tarp Troubleshooting	
Inspection and Maintenance	
Electrical System Diagram	
Electrical Over Hydraulic (EOH) System Schematic 4 Function Optional	
Braking System Schematic (Optional)	
Hydraulic System	
Wheel, Hub and Spindle Disassembly and Assembly	. 4-41
Wheels & Tires	
Wheel Nut Torque Requirements	
Tire Pressure	
Tire Warranty	
Complete Torque Chart - Capscrews - Grade 5	
Complete Torque Chart - Capscrews - Grade 8	
Hydraulic Fittings - Torque and Installation	. 4-49

FOR TRACK INFORMATION, PLEASE REFER TO YOUR TRACK MANUAL.
FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR ELECTRIC ROLL TARP INFORMATION, PLEASE REFER TO YOUR ELECTRIC ROLL TARP MANUAL.
FOR HYDRAULIC DRIVE INFORMATION, PLEASE REFER TO YOUR HYDRAULIC DRIVE MANUAL.

Lubrication

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.





Lubrication (continued)

To keep your grain cart in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.

Unverferth Mfg. recommends use of NLGI #2 Extreme Pressure grease.

The lubrication locations and recommended schedule are as follows:

DESCRIPTION	POINT	LUBRICANT	QTY.	HOURS
PTO Driveshaft	7	EP-2	1 Shot	See Previous Page
Gearbox Remove Cover - Check oil level every 2 weeks. Replace oil every season. Refer to Gearbox in MAINTENANCE section for instructions.	1	EP80W90	55oz	Once Every Season
U-Joint Cross Bearing - Driveline	1	EP-2	1 Shots	Weekly
Splined Yoke - Driveline U-Joint	1	EP-2	3 Shots	Weekly
Grease Bank Hanger Bearing - Vertical Lower Auger *See note below.	1	EP-2	3 Shots*	Daily
Auger Hanger Bearing - U-Joint Cross Bearing	1	EP-2	2 Shots	Weekly
Splined Yoke - Vertical Lower Auger	1	EP-2	1 Shot	Weekly
Top Bearing - Vertical Upper Auger	1	EP-2	1 Shot	Each Season
Auger Pivot Rings	4	EP-2	2 Shots	Weekly
Grease Bank Auger Pivot Pins - Front and Rear	2	EP-2	3 Shots	Daily
Hubs	2	EP-2	Repack	2 Years

*NOTE: Hanger bearing contains hydraulic shut-off grease zerk (9005240) with pressure relief to prevent over-greasing that could push bearing seals out. If grease is coming out of the relief on the zerk this is normal and the bearing contains enough grease.

Seasonal Storage

Your cart is an important investment. Spend a little time to protect it from destructive rust and corrosion. You will be repaid in longer service life and better performance.

Do the following before placing the cart in storage:

- 1. Remove dirt and trash which could cause rusting.
- 2. Repaint any chipped or scraped areas.
- 3. Lubricate points, refer to lubrication pages in the MAINTENANCE section.
- 4. Inspect for damage or worn parts, replace before next season.
- 5. Store cart inside, away from livestock.
- Replace all worn, torn or faded decals and reflectors.
- 7. Fully open flow door and auger cleanout door to remove any remaining grain and to allow moisture to drain. See Fig. 4-1.
- 8. If unit is equipped with a scale indicator, electric hydraulic controls, store these indoors in a dry location.





Gearbox Lubrication

IMPORTANT

• For 45° gearbox (9009053), the fill plug is inaccessible. Add oil at the vent plug on the left-hand side of the housing.

For 45° gearbox with 20 spline input shaft (SN B42720100 and higher), (9008711), the fill plug is located on the left-hand front side of the housing for reference. See figure 4-2.

For 45° gearbox with 20 spline input shaft (SN B41340100 - B42720099), (9009053), the fill plug is located on the right-hand front side of the housing for reference. See figure 4-3.


To check oil fluid level, place cart on a level surface with the tongue elevated to hitch height. Oil level should be visible in the sight glass. Fill with oil to the sight glass only.


Maximum gearbox life for (9009053, 9002812, and 9008711):


Check oil level every 2 weeks.


Replace oil every season starting with a minimum of 55 fl. oz. of 80W90 EP gear lubricant.

For 45° gearbox with 6 spline input shaft (SN B41340099 & lower), (9002812), the check/ fill plug is located on the right-hand front side of the housing. To check oil fluid level, place cart on a level surface with the tongue elevated to hitch height and remove the plug. Oil level should be at the bottom thread or approximately 5/8" below the outside gearbox surface. See figures 4-4 and 4-5.









Hydraulic System

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the grain cart requires little maintenance.

Replacing Hoses/Fittings/Cylinders:

- 1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3000 psi.
- 2. Do not use hoses, fittings and cylinders that have pipe threads.
- 3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings according to "Torque Chart" in this section.
- 4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
- 5. Always purge the hydraulic system after servicing.

Purge Hydraulic System

A WARNING

- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING.
 SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SE-RIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.



KEEP CLEAR OF PINCH POINT AREAS.



Purge air from system as follows:

- A. Disconnect the rod end of all cylinders in a circuit and block up cylinders so the rod can completely extend and retract without contacting any other component.
- B. Pressurize the system and maintain system at full pressure for at least 5 seconds after cylinder rods stop moving. Check that all cylinders have fully extended or retracted.
- C. Check oil reservoir in hydraulic power source and refill as needed.
- D. Pressurize system again to reverse the motion of step B. Maintain pressure on system for at least 5 seconds after cylinder rods stop moving. Check that cylinders have fully extended or retracted.
- E. Check for hydraulic leaks using cardboard or wood. Tighten connections according to directions in Torque Chart.
- F. Repeat steps B, C, D, and E 3-4 times.
- G. Depressurize hydraulic system and connect cylinder rod clevises to their mating lugs.

IMPORTANT

• Machine damage will occur if the cylinder is incorrectly installed.

Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.

Hydraulic System (continued)

Relieving Hydraulic Pressure

To relieve hydraulic pressure in the system, be sure hydraulic motor is disengaged and/or hydraulic cylinder is not exerting force on the system. Next, consult tractor operators manual for procedure to relieve pressure.

Bleeding Procedure For EOH System

A WARNING

- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

Open and close the flow door. Unfold and fold the vertical auger. Operate the spout tilt, spout rotate, and auger tilt. Perform these functions several times.

Purging Procedure For Braking System (Optional)


A WARNING

- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY
 OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC
 SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE
 FLUIDS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

<u>NOTE</u>: System is intended for tractors with hydraulic trailer brakes. If your tractor does not have hydraulic trailer brakes, contact your dealer for support.

Connector should comply with ISO:5676 standards. Brake hydraulic hose is designated with blue color band. See tractor's operators manual for connection location.


- 1. Set the tractor parking brake, but leave tractor engine on throughout the procedure. Attach hydraulic brake coupler on the cart to the implement brake port at the rear of the tractor.
- 2. Apply and hold pressure to brake pedal.
- Loosen the bleeder screw, at the top of the brake caliper and allow air bubbles to escape. Close bleeder screw when oil flow is free of bubble interruptions and flowing steady. If necessary, pump the brake pedal to build circuit pressure. See Fig. 4-6.
- 4. Repeat steps 2 and 3 to the next brake caliper in the brake circuit. Repeat until all brakes are bled.
- 5. Perform a final tightness check of all caliper bleed screws before beginning cart operation. Check that both brakes actuate and release properly with tractor brake pedal.




Adjusting Cleanout Door

A WARNING

- MOVING PARTS CAN CRUSH AND CUT. KEEP AWAY FROM MOVING PARTS.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.
- 1. Park the empty grain cart on a firm and level surface. Block the tires/tracks on the machine to keep it from moving. Set the tractor's parking brake, shut-off the engine, remove the ignition key and disconnect the PTO shaft.
- Inspect and verify that all the grain dust and filings are removed that may prevent the door from shutting completely. Completely close cleanout door. (Fig. 4-7)




- 3. Engage the locking plate (268313B). (Fig. 4-8)
- 4. Loosen mounting hardware. (Fig. 4-8)




Adjusting Cleanout Door (continued)

5. Push the gear assembly toward bottom of auger to remove excess movement and prevent the door from moving upward when unloading the cart. (Fig. 4-9)



- 6. Tighten hardware loosened in step 4. (Fig. 4-10)
- 7. Check door operation. Lock the handle weldment into position. (Fig. 4-10)



Auger System


A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, ALWAYS ENSURE THAT THERE ARE PEOPLE WHO REMAIN OUTSIDE THE CART TO ASSIST THE PERSON WORKING INSIDE, AND THAT ALL SAFE WORKPLACE PRACTICES ARE FOLLOWED. THERE IS RESTRICTED MOBILITY AND LIMITED EXIT PATHS WHEN WORKING INSIDE THE IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 4,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS IN-JURY OR DEATH. ALWAYS DISCONNECT POWER SOURCE BEFORE SERVICING. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING MACHINE.



Lower Auger Removal

- 1. Hitch cart to tractor, connect hoses for flow door and upper auger hydraulic cylinders and fully open flow door. Keep upper auger in the folded position. Park the empty grain cart on a firm, level surface. Set the tractor's parking brake, shut-off the engine and remove the ignition key. Block the tires on the machine to keep it from moving.
- 2. Remove the three 5/8"-11UNC x 2" capscrews (9390-124), 5/8" flat washers (9405-098), 5/8"-11UNC lock nuts (9003398) and shims that secure the hanger bearing bracket to the auger tube. (Fig. 4-11).
- Using a safe lifting device rated at a minimum of 1000 lbs., support the lower auger. Remove the hanger bearing assembly. Then remove the lower auger through the auger hinge opening.



Lower Auger Assembly


 The replacement auger is factory balanced. Remove entire auger from shipping crate and secure from rolling. The lower auger assembly is pictured in Fig. 4-12 for reference.


Attach the u-joint assembly to the lower auger flighting by placing capscrews into the auger from opposite directions as shown in Fig. 4-13.


Models 1019/1119 5/8"-11UNC x 6" capscrews (9390-136) and 5/8"-11UNC lock nuts (9801)

<u>NOTE:</u> If removing flighting extension hardware, replace with new hardware. Do not reuse old flighting extension hardware.

- Using a safe lifting device rated at a minimum of 1000 lbs., lift the auger and assembly. Slowly lower the auger down through the auger plate opening to intersect with the drive bushing.
- 4. Align auger end with the five pin drive bushing and securely engage together, see Fig. 4-14.








Auger System (continued)

Hanger Bearing Centering

1. Once the lower auger is inserted into the auger tube, center the lower auger in the tube and support with two 5/8" thick bars/wedges near the auger hinge plate. (Fig. 4-15)




Lower Auger Timing

 Apply anti-seize to the splines before sliding the drive dog into the u-joint. Time the splined connection as follows:


Time the drive dog (as in Fig. 4-16) with the finished edge of the flighting at 12:00. Position the drive dog at 11:00.

NOTE: When looking down at the lower flighting (Fig. 4-16) the auger rotation will be clockwise.



2. Loosely attach the hanger bearing as follows to ensure all the feet are shimmed evenly:

Loosely secure using one 3" \times 3 9/16" left-hand shim (292423B), one 3" \times 3 9/16" right-hand shim (292424B), three 5/8"-11UNC \times 2" capscrews (9390-124), three 5/8" flat washers (9405-098), and three 5/8"-11UNC lock nuts (9003398) as shown in Fig. 4-17.




U-Joint Spline Gap

A WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED.
- 1. Verify spline gap before tightening hanger bearing hardware. Spline gap should be a minimum of 3/16". Using a safe lifting device rated for 250 pounds, raise the hanger bearing in the holes so the proper minimum spline gap is achieved. (Fig. 4-18)

<u>NOTE:</u> When auger components have been replaced or serviced, proper spline gap MUST be verified. It may be necessary to loosen the hanger bearing hardware and use the lifting device to achieve the proper spline gap.

- Tighten the retaining hardware to the appropriate torque values listed in this section of the operators manual.
- 3. Grease the spline grease zerk. (Fig. 4-18)




NOTE: If no further changes are required, continue with the "Upper Auger" section.

Auger System (continued)

Upper Auger Removal

- 1. Keep upper auger in the folded position.
- 2. Loosen the two bearing set screws. Remove and save the 5/16"-18UNC x 2 3/4" capscrew (9390-037), four 5/16" SAE flat washers (9405-068) 5/16"-18UNC lock nut (901527) and 2" flat washers (93974). (Fig. 4-19)




Soft Start Replacement

A WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 2,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- 1. Use safe lifting devices rated at a minimum of 2,000 lbs. to support the upper auger, remove auger from tube.
- 2. Remove the 1/2"-13UNC capscrew (9390-140), 1/2"-13UNC lock nut (9801), soft start assembly, thrust washer (9004878), and bushing (9004877). Discard 1/2"-13UNC capscrew (9390-140). (Fig. 4-20)

<u>NOTE</u>: If removing flighting extension hardware, replace with new hardware. Do not reuse old flighting extension hardware.



3. Insert the bushing (9004877) into the end of the upper auger. Attach the thrust washer (9004878) and apply anti-seize to the soft start and insert into the auger tube.

Upper Auger Timing


1. Time the drive pin as follows:

Time the drive pin (as in Fig. 4-21) with the finished edge of the flighting at 12:00. Position the drive pin at 9:30.

NOTE: Looking up at the upper flighting (Fig. 4-21) the auger rotation will be counter clockwise.

NOTE: There is only one way the soft-start will go in.


<u>NOTE</u>: For additional auger timing assitance, refer to your dealer for an auger timing fixture (293329Y).



Soft Start Replacement (continued)

NOTE: Before soft start reassembly, ensure the spacer bushing (405402) is on the same side as the lock nut (9801). (Fig. 4-22)


1. Retain the soft start into position with 1/2"-13UNC capscrew (9390-140), spacer bushing (405402), and 1/2"-13UNC lock nut (9801). (Fig. 4-22)



Upper Auger Assembly

A WARNING


- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 2,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- The replacement auger is factory balanced. Remove entire auger from shipping crate and secure from rolling. The upper auger assembly is pictured in Fig. 4-23 for reference.
- 2. Using a safe lifting device and slings with a minimum capacity of 2,000 lbs. to support the upper auger, install upper auger into the tube.



3. Refer to "Upper Auger Timing" and position soft start accordingly.

Upper Auger Height


 Place a flat bar across the center of the auger housing tube. Measure the distance between the center of the face of the soft start bushing that sits on the top of the drive dog and the center of the flat bar. Verify the upper auger in-set of approximately 8 1/8". With the upper auger folded back, ensure the height of the upper auger is set correctly. If this dimension is not correct, loosen the set screws in the flange bearing at the top of the upper auger and slide the auger through the bearing to this correct position. Tighten set screws. (Fig. 4-24)



Auger System (continued)

Upper Auger Assembly (continued)

1. Make sure that the 4 bolt flange bearing is sitting tight against the mounting plate and then tighten the two bearing set screws. Attach the upper auger with the 5/16"-18UNC x 2 3/4" capscrew (9390-037), four 5/16" SAE flat washers (9405-068) 5/16"-18UNC lock nut (901527) and as many 2" flat washers (93974) as required to fill the gap between the bearing and the cross bolt. (Fig. 4-25)



Upper Auger Bearing Gap

- 1. Verify the upper auger bearing height by inspecting the upper auger bearing in operating position. There should be minimum 1/16" to 1/8" gap between the bearing and mount plate with the upper auger in operating position and the drive dog completely engaged. If gap is present, no action is needed, go to step 2. If no gap or gap is too large, Re-adjust the upper auger placement to achieve a 1/16-1/8" gap. If there is no gap, the upper auger will need to be moved ahead. If there is too large of a gap, move it backwards in the upper auger housing. The number of washers (93974) will also need to be adjusted to eliminate any gap between the bearing and the cross bolt. (Fig. 4-26 and 4-27)
- 2. Place upper auger in the folded/transport position.
- 3. Once the upper auger height has been verified, remove the upper bearing set screws one at a time, and dimple the stud shaft with a 1/4" diameter drill bit. Apply medium strength blue thread locker to the set screws, and reinstall the set screws into the flange bearing and into the dimples on the stud shaft. Tighten set screws. Tighten all hardware.
- 4. Test run auger driveline. Verify smooth driveline operation.






Auger Driveline

Bearings

It is important to periodically check set screws in all bearings at either end of the driveline for tightness.


Driveline Replacement



- 1. Park the empty cart on a firm, level surface. Block the wheels or tracks on the cart to keep it from moving. Set the tractor parking brake, shut off the engine, and remove the ignition key from the tractor before disconnecting driveline assembly and bearing hardware.
- 2. Loosen the setscrews on the three flangette bearings (9005061) (Fig. 4-28).
- 3. Remove the 1/2" carriage bolts (9388-103), flange nuts (9394-010), and lock washers (9404-025) holding the flangette bearings. Keep hardware. (Fig. 4-28).

Auger Driveline (continued)

- Remove paint on driveshaft to allow for easier movement. Slide driveshaft forward until the rear spline is out of the universal joint connected to the gearbox.
- 5. Drop the gearbox end of driveshaft down and slide driveshaft out of the flangette bearing on the hitch end of the driveshaft.
- Remove bearings, bearing mounts, universal joint cover, driveshaft lock collars (if lock collars are attached to driveshaft), PVC driveshaft covers, and driveline cover off the current driveshaft.
- 7. Slide new 1 3/4" dia. two-piece lock collars (9008674) to both sides of new bearing (9005061) closest to the U-joint.



- 8. Torque lock collars to 325 Inch-Lbs.
- 9. When installing new bearings onto new driveshaft (9008138), assemble new 20 1/2" PVC driveshaft cover (292448) between bearings near the gearbox, and new 33 1/2" PVC driveshaft cover (292449) between bearings behind the hitch driveline cover. (Fig. 4-29)

NOTE: Ends of driveshaft are symmetrical.

- 10. Slide the hitch end of the driveshaft, bearing and hitch driveline cover into the bearing near hitch of the cart. (Fig. 4-29)
- 11. Raise the gearbox end of the driveshaft up and insert the original 1/2" carriage bolts, flange nuts, and lock washers into the mounting flanges making sure that the bearing flanges are both on the front side of the mounting brackets. Only loosely tighten the hardware.

Auger Driveline (continued)

12. Slide driveshaft down into the gearbox universal joint attached to the gearbox until the end of the shaft extends into the universal joint about 2 3/8". Ensure universal joint and driveshaft splines completely engage. Verify the hitch end for adequate length for driveline assembly to connect.


(Fig. 4-32)


- 13. Tighten all flangette mounting hardware.
- 14. For alignment of the yoke, the orientation of the universal joint at the gearbox MUST be in line with the driveshaft drill dimple when the driveline assembly is attached.


 (Fig. 4-30, 4-31, and 4-32)
- 15. With bearing mounting hardware completely tightened, drill a setscrew dimple in the driveshaft by going through the bearing setscrew threaded hole to dimple the driveshaft being careful to not damage threads. Drill the dimple to a depth that setscrews are flush with the bearing prior to applying thread locker and installing setscrews. (Fig. 4-30)

NOTE: Check gearbox oil level and grease universal joint before installing universal joint cover.

- 16. Attach new universal joint cover (290720B) to the bearing mount in front of the gearbox using original 3/8"-16UNC capscrews and 5/16"-18UNC weld nuts. Review to ensure PVC driveshaft covers and driveline cover, located behind the ladder, are in place and hardware tightened prior to operation.
- 17. Apply thread lock on bearing setscrews and tighten.
- Test run driveline. Verify smooth driveline operation.







Verify Telescoping PTO Shaft Length

A WARNING

PROPERLY EXTENDED AND COLLAPSED LENGTHS OF THE TELESCOPING PTO SHAFT
MUST BE VERIFIED BEFORE FIRST OPERATION WITH EACH AND EVERY DIFFERENT
TRACTOR. IF THE EXTENDED LENGTH OF THE PTO SHAFT IS NOT SUFFICIENT, IT
MAY BECOME UNCOUPLED IN OPERATION AND CAUSE SERIOUS INJURY OR DEATH
FROM CONTACT WITH UNCONTROLLED FLAILING OF PTO SHAFT ASSEMBLY COMPONENTS.


An excessive collapsed length can result in damage to the PTO driveline and attached components. This is most likely to occur during extreme turning angles and/or travel over rough terrain. Conditions are amplified on tractors with tracks operating in uneven terrain, particularly rice levies. Damaged driveline components can result in unsafe operation and severely reduced driveline component life.

NOTE: Do not exceed 10 degrees beyond a straight pull line while operating the PTO.

To verify proper extended and collapsed lengths, use the following procedure:


1. Fully collapse PTO shaft and measure length "L" (Fig. 4-33).

Enter here:_____(1) (Verify that outer tube does not bottom out on surrounding plastic shield components).



2. Pull apart PTO telescoping shaft ends and measure lengths "T" & "C" (Fig. 4-34).

Add "T" &"C" measurements together
Enter total here:_____(2)




- 3. Calculate maximum recommended extended length:
 - a. Subtract line 1 from line 2. Enter here:_____(a)
 - b. Divide line (a) by 2. Enter here:_____(b)
 - c. Add line (b) to line 1. Enter here:_____(c)
 - d. Subtract 3 inches from line (c). Enter here:_____(d)


This is the maximum recommended extended length (LB).

Verify Telescoping PTO Shaft Length (continued)

- 4. Hitch tractor drawbar to cart, ensuring that tractor and cart are on level ground and coupled as straight as practical.
- 5. Connect PTO shaft to tractor, and measure length "L" from same points as used in step 1. Ensure that this measurement does not exceed the maximum recommended extended length calculated in step 3 above. If necessary, choose a shorter drawbar position, or obtain a longer PTO shaft assembly before operating cart.
- 6. Position the tractor to obtain tightest turning angle, relative to the cart. (Fig. 4-35)




7. Measure length "L" from same points as used in step 1. This distance must be at least 1.5 inches greater than the distance measured in step 1. If necessary, adjust length of PTO shaft by cutting inner and outer plastic guard tubes and inner and outer sliding profiles by the same length. Round off all sharp edges and remove burrs before greasing and reassembling shaft halves. (Fig. 4-36)



PTO Shaft and Clutch

Lubrication (Figs. D1 - D6)

Lubricate with quality grease before starting work and every 8 operating hours. Clean and grease PTO drive shaft before each prolonged period of non-use. Molded nipples on the shield near each shield bearing are intended as grease fittings and should be lubricated every 8 hours of operation! Telescoping members must have lubrication to operate successfully regardless of whether a grease fitting is provided for that purpose! Telescoping members without fittings should be pulled apart and grease should be added manually. Check and grease the guard tubes in winter to prevent seizing.



PTO Shaft and Clutch (continued)

Coupling the PTO drive shaft (Figs. E1 - E2)


Clean and grease the PTO and implement input connection (IIC)


AS-Lock

 Pull locking collar and simultaneously push PTO drive shaft onto PTO shaft until the locking device engages.

Push-Pull Lock

2. Pull locking collar and simultaneously push PTO drive shaft onto PTO shaft until the locking device engages.






A WARNING


• CHECK TO INSURE ALL THE LOCKS ARE SECURELY ENGAGED BEFORE STARTING WORK WITH THE PTO DRIVESHAFT.


Length Adjustment (Figs. F1 - F4)

NOTE: Maximum operating length LB.

- 1. To adjust length, hold the half-shafts next to each other in the shortest working position and mark them.
- 2. Shorten inner and outer guard tubes equally.
- 3. Shorten inner and outer sliding profiles by the same length as the guard tubes.
- 4. Round off all sharp edges and remove burrs. Grease sliding profiles.









A WARNING


 CHECK THE LENGTH OF THE TELESCOPING MEMBERS TO INSURE THE DRIVELINE WILL NOT BOTTOM OUT OR SEPARATE WHEN TURNING AND/OR GOING OVER ROUGH TERRAIN.

PTO Shaft and Clutch (continued)

Chains (Figs. G1 - G3)


NOTE: The chain is intended to prevent the shield from rotating against non-moving parts and thereby preventing shield damage. A properly installed chain will increase the service life of the shield.

- Chains must be fitted so as to allow sufficient articulation of the shaft in all working positions.
 Care must be taken to be sure that chain does not become entangled with drawbar hitch or other restrictions during operation or transport of machine.
- 2. The PTO drive shaft must not be suspended from the chain.



To Dismantle Guard (Figs. J1 - J4)


- 1. Remove locking screw.
- 2. Align bearing tabs with cone pockets.
- 3. Remove half-guard.
- 4. Remove bearing ring.





PTO Shaft and Clutch (continued)


To Assemble Guard (Figs. K1 - K5)


- 1. Grease yoke groove and inner profile tube.
- 2. Fit bearing ring in groove with recesses facing profile tube.
- 3. Slip on half-guard.
- 4. Turn cone until it engages correctly.
- 5. Install locking screw.














To Assemble Cone

- Dismantle guard (Figs. J1 J3). Remove old cone (e.g. cut open with knife). Take off chain. Place neck of new cone in hot water (approx 80° C / 180° F) and pull onto bearing housing (Fig. L1).
- 2. Turn guard cone into assembly position (Fig. L2). Further assembly instructions for guard (Figs. K1 K5).
- 3. Reconnect chain if required (Fig. L3).









PTO Quick Disconnect


Coupling

Slide clamp yoke or clutch onto connecting shaft. Make sure the location hole for the clamping cone is positioned above the annular groove of the connecting shaft. Screw appropriate clamping cone into the location hole. Slightly moving the clamp yoke or clutch to and from in the axial direction will help drive in the clamping cone. Check the clamp yoke or clutch for a tight and safe fit and continue to check at regular intervals. Retighten the clamping cone as necessary. Torque clamping cone down to 75 ft.-lbs.

When over loading occurs, the clutch disengages and will repeatedly attempt to reset. The clutch will create a repeated "clicking" noise when resetting. Torque demand must decrease for clutch to reset.









Uncoupling

Unscrew the clamping cone a partial turn. Use the punch and hammer to help alleviate the torque resistance on the wrench if necessary. After a few cycles the clamping cone will move freely with low torque resistance for the removal process.



Scale Troubleshooting



Weather Guard Tarp Troubleshooting

PROBABLE CAUSE	CORRECTION
Tarp sags in middle areas	1. Bows may be bent or adjusted too low.
	2. Missing or loose ridge strap. Replace or retighten.
	U-joint may need to be adjusted 3. on splinded shaft to provide more tension.
Holes or tears in tarp	1. Consult your local dealer for repairs.
	2. Order tarp repart kit from dealer.
	3. When new tarp or parts are needed always replace with original parts.

Inspection and Maintenance

A WARNING

- TO PREVENT PERSONAL INJURY OR DEATH, DO NOT ALLOW ANYONE ON A CLOSED TARP. TARP SYSTEM IS NOT DESIGNED TO SUPPORT A PERSON.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. REMOVE ACCUMULATED WATER/SNOW/ICE OR ANY OTHER OBJECTS FROM TARP BEFORE OPENING TARP.


IMPORTANT

- Do not open or close tarp while moving or in high wind conditions. Damage to the tarp may occur.
- Tarp should not be used if it is torn or the bungee cords are frayed or show damage. If water pools on the tarp adjust tension of tarp cables and/or arm springs as required.


Periodic preventive maintenance should be practiced. Inspect tarp and hardware often for abrasions or loosened bolts that may need adjustment and/or repair. Check bungee cords for wear and adjust tension at the beginning of the season and again half way through the season.


Tears in tarp should addressed before further tarp operation. If water pools on tarp, adjust tension of tarp cables and/or arm springs.

If installed correctly, tarp should always operate as well as when first installed. If tarp does not pass this simple inspection, make all appropriate repairs or adjustments immediately before serious damage occurs.



Electrical System Diagram — Plug #92450





GRAIN CART WIRES


White -- Ground

Green -- Right amber flashing lamp Yellow -- Left amber flashing lamp

Brown -- Tail light


Black -- Interior & Auger Lights

Red -- Brake Lights Blue -- NOT USED





Electrical Over Hydraulic (EOH) System Schematic 4 Function Optional 4-WAY HAT SWITCH MEMBRANE STYLE KEYPAD WITH ILLUMINATED TEXT POWER HARNESS DOUBLE TRIGGER SEE NOTE FOR SOFTWARE LOGIC FUSE HOLDER 5 AMP BLADE STYLE ATC FUSE STRAIN +12 VDC - RED WIRE +12 VDC - RED WIRE AUGER FOLD - BLUE WIRE -- AUGER FOLD - BLUE WIRE -AUGER LINFOLD - GREEN WIRE -3 - AUGER LINEOLD - GREEN WIRE NOT USED - PLUGGED - NOT USED - PLUGGED +12VDC FROM DIODES - RED W/ WHITE STRIPE WIRE 5 - +12VDC FROM DIODES - RED W/WHITE STRIPE - FLOW DOOR OPEN - ORANGE WIRE-FLOW DOOR OPEN - ORANGE WIRE 6 - FLOW DOOR CLOSE - PINK WIRE FLOW DOOR CLOSE - PINK WIRE -7 - SPOUT IN - BROWN WIRE SPOUT IN - BROWN WIRE -- SPOUT OUT - YELLOW WIRE SPOUT OUT - YELLOW WIRE-10 - SPOUT REAR - TAN WIRE SPOUT REAR - TAN WIRE -10 - SPOUT FRONT - BLACK WIRE SPOUT FRONT - BLACK WIRE 11 12 GROUND - WHITE WIRE GROUND - WHITE WIRE 12 골 UGGED 12 1 1 0 00 7 00 5 4 4 2 1 SPST MONLATCHING SWITCH SPOUT FROMT HAT SWITCH RIGHT SPST MONLATCHING SWITCH HAT SWITCH LETT SPST MONLATCHING SWITCH HAT SWITCH LETT SPST MONLATCHING SWITCH SPOUT OF SWITCH HAT SWITCH DOWN PAT SWITCH DOWN SPST MONLATCHING SWITCH FLOW DOOR CLOSE TRIGGER PULL STST NCHATCHING SWITCH TRIGGER PULL STST NCHATCHING SWITCH TRIGGER PUSH TRIGGER FUSH TRIGGER FUSH TRIGGER FUSH HAT SWITCH SWITCH TRIGGER FUSH HAT SWITCH SWITCH SWITCH SWITCH TRIGGER FUSH HAT SWITCH SWITCH SWITCH SWITCH SWITCH SWITCH TRIGGER FUSH HAT SWITCH SWITC PIN 12 - GROUND - WHITE WIRE SPOUT FLOW FLOW PIVOT PIVOT PIN 11 - SPOUT FRONT FUNCTION - BLACK WIRE PIN 10 - SPOUT REAR FUNCTION - TAN WIRE PIN 9 - SPOUT OUT FUNCTION - YELLOW WIRE DOOR CLOSE -DOOR OPEN -두 1 ŝ IN - BROWN PIN 8 - SPOUT IN FUNCTION - BROWN WIRE PIN 7 - FLOW DOOR CLOSE FUNCTION - PINK WIRE PIN 6 - FLOW DOOR OPEN FUNCTION - ORANGE WIRE * * * * * * - GRAY PURPLE WIRE **YELLOW** Ā PIN 5 - +12 VDC FROM DIODES - RED W/ WHITE STRIPE WIRE BLACK PIN 4 - NOT USED - PLUG ¥IRE ORANGE SPST LOGIC CONTROLLED SWITCH AUGER UNFOLD (SEE NOTE FOR SOFTWARE LOGIC) PIN 3 - AUGER UNFOLD FUNCTION - GREEN WIRE PIN 2 - AUGER FOLD FUNCTION - BLUE WIRE PIX VIRE ¥IRE ¥IRE (NOT PIN 1 -+12 VDC - RED WIRE ¥IRE NOT SPST LOGIC CONTROLLED SWITCH AUGER FOLD (SEE NOTE FOR SOFTWARE LOGIC) ¥IRE USED) USED) HYDRAULIC VALVE -GROUND - WHITE WIRE - AUGER FOLD - BLUE WIRE -BLUE AUGER UNFOLD - GREEN WIRE-AUGER FOLD WHITE NOT USED - PLUGGED -GREEN +12VDC FROM DIODES - RED W/WHITE STRIPE -AUGER UNFOLD WHITE - FLOW DOOR OPEN - ORANGE WIRE -RED W/WHITE STRIPE - FLOW DOOR CLOSE - PINK WIRE-+12VDC FROM DIODES WHITE - SPOUT IN - BROWN WIRE -8 ORANGE -SPOUT OUT - YELLOW WIRE -9 FLOW DOOR OPEN WHITE - SPOUT REAR - TAN WIRE-10 PINK SPOUT FRONT - BLACK WIRE -FLOW DOOR CLOSE WHITE NOT USED - PLUGGED 12 BROWN SPOUT IN Main Harness YELLOW (9008403) SPOUT OUT TAN -SPOUT REAR BLACK SPOUT FRONT

Optional Electric Over Hydraulic Valve Electric Schematic 4 Spool



PORT	END OF CYLINDER	FUNCTION
Α	BUTT END	FLOW DOOR CLOSE
В	RAM END	FLOW DOOR OPEN
С	RAM END	AUGER FOLD LOWER
D	BUTT END	AUGER FOLD RAISE
E	RAM END	SPOUT TILT OUT
F	BUTT END	SPOUT TILT IN
G	RAM END	SPOUT ROTATE OUT
Н	BUTT END	SPOUT ROTATE IN
Р		TRACTOR PRESSURE
Т		TRACTOR RETURN





Wheel, Hub and Spindle Disassembly and Assembly

WARNING

- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 20,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

A CAUTION

• IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

- Remove only one wheel and tire from a side at any given time in the following procedure.
- 1. Hitch cart to tractor. Park the empty cart on a firm, level surface. Set the tractor's parking brake, shut off engine and remove key.
- 2. With cart empty, use 20,000 lbs. safe lifting and load holding devices rated at 20,000 lbs. to support the weight of your grain cart. Place the safe lifting device under the axle closest to the tire.
- 3. Use a 3,000 lbs. safe lifting device to support the wheel and tire during removal.

A WARNING

- INNER WHEEL AND TIRE MAY FALL FROM HUB CAUSING SERIOUS INJURY OR DEATH. ALWAYS SUPPORT INNER WHEEL WHEN REMOVING OUTER WHEEL.
- 4. If only changing wheel and tire, skip to Step 8; otherwise continue with Step 4.
- 5. Remove the hardware retaining the hubcap. Next, remove the hubcap, gasket, cotter pin, castle nut and spindle washer. Using a 200 lbs. safe lifting device, remove hub with bearings from old spindle.

Wheel, Hub and Spindle Disassembly and Assembly (continued)

6. Inspect the spindle and replace if necessary. If spindle does not need to be replaced, skip to Step 7; otherwise continue with Step 6.

Remove the bolt and lock nut that retains the spindle to the axle. Using a safe lifting device rated for 150 lbs., replace the old spindle with a new spindle. Coat axle contact length of spindle shaft (scale or non-scale) with anti-seize lubricant prior to installation. If installing scale spindle, install with 'top' decal facing upwards. Reuse bolt and lock nut to retain spindle to axle. Tighten as outlined in "Wheel and Tire" in the MAINTENANCE section.

- 7. Remove seal and inspect bearings, spindle washer, castle nut and cotter pin. Replace if necessary. Pack both bearings with approved grease and reinstall inner bearing. Install new seal in hub with garter spring facing the hub by tapping on flat plate that completely covers seal while driving it square to hub. Install until flush with back face of hub. Using a 200 lbs. rated lifting device, install hub assembly onto spindle. Install outer bearing, spindle washer and castle nut.
- 8. Slowly tighten castle nut while spinning the hub until drag causes the hub to stop freely spinning. Do not use an impact! Turn castle nut counterclockwise until the hole in the spindle aligns with the next notch in castle nut. Hub should spin smoothly with little drag and no end play. If play exists, tighten to next notch of castle nut. If drag exists, then back castle nut to next notch of castle nut. Spin and check again. Install cotter pin. Clean face for hub cap gasket and install gasket, grease filled hub cap and retain hubcap with hardware removed. Tighten hubcap hardware in alternating pattern.
- 9. Attach the wheel(s) and tire(s) to the hub using the same rated lifting device for removal. Tighten wheel nuts to appropriate requirements and recheck as outlined in "Wheel and Tire" in the MAINTE-NANCE section
- 10. Raise cart, remove safe load holding devices and lower tire to the ground.

Wheels and Tires

Wheel Nut Torque Requirements



CAUTION

• IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagram 1.

NOTE: Do not use anti-seize on wheel hardware.

WHEEL HARDWARE		
SIZE FOOT-POUND		
7/8-14 (UNF)	440 ftlbs.	
M22x1.5	475 ftlbs.	




DIAGRAM 1

Wheels and Tires (continued)

Tire Pressure

The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. It is important that tires are inspected after unit is loaded. Start with minimum pressure indicated. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. Do not exceed maximum recommended tire pressure. Each tire must be inflated to 35 PSI max to seat the beads, deflated to 5-10 PSI, then reinflated to the tire's max PSI when mounting.

Tire Pressure for Grain Carts			
		Load Index / Ply	
Tire Make	Tire Size	Rating	Max. PSI
Firestone	23.1x26 R-3	12	32
	23.1x26 R-1	12	32
	28Lx26 R-3	12	26
	24.5x32 R-3	12	32
	24.5x32 R-1	12	32
	30.5x32 R-1	14	28
	30.5x32 R-3	14	28
	30.5x32 R-3	16	34
	30.5x32 R-1	16	26
	35.5x32 R-3	20	36
	76x50.00x32 HF-3	16	40
	76x50.00x32 HF-3	20	50
	800/65R32 R-1W	172D	41
	800/60R32 R-3	181B	46
	900/65R32 R-3	191B	46
	900/60R32 R-1	176A8	44
	1250/50R32F IF/CFO R-1WNP	201D	46
	1250/50R32F IF/CFO R-1W	188B	30
	520/85R38 R-1	155A8	29
	520/85R38 R-1	173A8	64
	480/80R42 R-1	151A8	36
	520/85R42 R-1	157A8	29
	520/85R42 R-1	165A8	51
	520/85R42 IF/CFO R-1	169A8/B	35
	IF520/85R42 R-1W	169B	35
	VF520/85R42 R-1W	177B	35
	420/80R46 R-1	151A8	44
	480/80R46 R-1	158A8	44
	380/90R46 R-1	152B	51

Wheels and Tires (continued)

Tire Pressure (continued)

Tire Pressure for Grain Carts		
Tivo Circo	Load Index / Ply	May DS
		Max. PS
23.1x26 R-3	10	26
23.1x26 R-1	10	26
24.5R32 R-1	169A8/B (5-Star)	48
24.5x32 R-3	12	32
24.5x32 R-1	12	32
30.5x32 R-3	16	26
30.5x32 R-3	14	22
30.5x32 R-1	14	22
480/80x42 R-1	166A8	23
1100/45R46 F-1W	195D	35
650/75R32 R-1W	172A8	58
650/75R32 R-1	176A8	41
800/65R32 R-1W	172A8	46
900/60x32 R-1W	176A8	41
900/70R32 R-1W	188A8	53
1050/50x32 R-1W	178A8	41
1250/50R32 R-1W	188A8	41
900/60x38 R-1W	181A8	44
520/85x42 R-1W	162A8	44
650/65x42 R-1W	168A8	44
30.5B32	18-Ply	36
35.5LR32	193A8	44
		46
1050/50R32 R-1W	185A8	52
1250/50R32 R-1W	201B	46
VF1050/50R32 R-1	198D	52
		55
		44 32
	Tire Size 23.1x26 R-3 23.1x26 R-1 24.5R32 R-1 24.5x32 R-3 24.5x32 R-1 30.5x32 R-3 30.5x32 R-3 30.5x32 R-1 480/80x42 R-1 1100/45R46 F-1W 650/75R32 R-1W 650/75R32 R-1W 900/60x32 R-1W 900/70R32 R-1W 1050/50x32 R-1W 1250/50R32 R-1W 900/60x38 R-1W 520/85x42 R-1W 30.5B32 35.5LR32 900/60R32 R-1W 1050/50R32 R-1W 1050/50R32 R-1W	Tire Size Load Index / Ply Rating 23.1x26 R-3 10 23.1x26 R-1 10 24.5R32 R-1 169A8/B (5-Star) 24.5x32 R-3 12 24.5x32 R-1 12 30.5x32 R-3 16 30.5x32 R-3 14 30.5x32 R-1 14 480/80x42 R-1 166A8 1100/45R46 F-1W 195D 650/75R32 R-1W 172A8 650/75R32 R-1W 176A8 800/65R32 R-1W 176A8 900/60x32 R-1W 178A8 1250/50R32 R-1W 178A8 1250/50R32 R-1W 188A8 900/60x38 R-1W 181A8 520/85x42 R-1W 162A8 650/65x42 R-1W 162A8 650/65x32 R-1W 192D 1050/50R32 R-1W 192D 1050/50R32 R-1W 192D 1050/50R32 R-1W 198D 900/50R32 R-1W 198D 900/50R32 R-1W 181A8 900/60x32 176LI

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. **USED TIRES CARRY NO WARRANTY**. Following are phone numbers and Websites for your convenience:

<u>Firestone</u> www.firestoneag.com

Phone 800-847-3364

Titan www.titan-intl.com or Phone 800-USA-BEAR

Goodyear Fax 515-265-9301

<u>Trelleborg</u> www.trelleborg.com

Phone 866-633-8473

Continental/Mitas www.mitas-tires.com

Phone 704-542-3422 Fax 704-542-3474

Alliance www.atgtire.com

Phone 781-325-3801

Complete Torque Chart

Capscrews - Grade 5

NOTE:

- Grade 5 capscrews can be identified by three radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

SIZE	FOOT POUNDS	NEWTON METERS
1/4-20	8-10	11-13
1/4-28	9-11	12-15
5/16-18	15-17	20-23
5/16-24	17-19	23-26
3/8-16	25-28	34-38
3/8-24	28-31	38-42
7/16-14	40-45	54-61
7/16-20	45-50	61-68
1/2-13	62-68	84-92
1/2-20	68-75	92-102
9/16-12	90-98	122-133
9/16-18	100-110	134-148
5/8-11	120-135	162-183
5/8-18	124-137	168-186
3/4-10	200-220	270-300
3/4-16	210-230	285-310
7/8-9	330-350	425-475
7/8-14	360-380	460-515
1-8	500-525	675-710
1-14	540-560	730-760
1 1/8-7	600-635	815-860
1 1/8-12	665-700	920-950
1 1/4-7	850-895	1150-1215
1 1/4-12	940-990	1275-1340
1 3/8-6	1125-1175	1525-1590
1 3/8-12	1280-1335	1735-1810
1 1/2-6	1500-1560	2035-2115
1 1/2-12	1685-1755	2285-2380

IMPORTANT

• Follow these torque recommendations except when specified in text.

Complete Torque Chart

Capscrews - Grade 8

NOTE:

- Grade 8 capscrews can be identified by six radial dashes on the head.
- For wheel torque requirements, refer to Wheels and Tires.





SIZE	FOOT POUNDS	NEWTON METERS
5/16-18	20-22	27-30
5/16-24	21-23	28-31
3/8-16	35-39	47-53
3/8-24	36-41	49-55
7/16-14	54-58	73-78
7/16-20	55-60	75-80
1/2-13	82-88	110-120
1/2-20	94-99	125-135
9/16-12	127-134	170-180
9/16-18	147-155	199-210
5/8-11	160-170	215-230
5/8-18	165-175	225-235
3/4-10	280-295	380-400
3/4-16	330-365	445-495
7/8-9	410-430	555-580
7/8-14	420-440	570-595
1-8	630-650	850-880
1-14	680-700	920-950
1 1/8-7	900-930	1220-1260
1 1/8-12	930-950	1260-1290
1 1/4-7	1250-1300	1695-1760
1 1/4-12	1280-1320	1735-1790


IMPORTANT

• Follow these torque recommendations except when specified in text.

Hydraulic Fittings - Torque and Installation


SAE Flare Connection (J. I. C.)

- 1. Tighten nut with finger until it bottoms the seat.
- 2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



SAE Straight Thread O-Ring Seal

- 1. Insure jam nut and washer are backed up to the back side of smooth portion of elbow adapter.
- 2. Lubricate o-ring.
- 3. Thread into port until washer bottoms onto spot face.
- 4. Position elbows by backing up adapter.
- 5. Tighten jam nut.



Notes	