



**UM** Bulk Seed Handling

**PLANTER TUBE-CONVEYOR**

Fits JD 1790/1795 CCS - 12/23, 12/24,  
16/31, 16/32 Row - 30/15" Row Spacing &  
JD 1790 1795 CCS - 24 Row - 20" Row Spacing

Beginning With Serial #A59530100

Part No. 29987

## Foreword



This symbol identifies important safety messages. When you see it, read the message that follows and be alert to the possibility of personal injury.

Remember, safety instructions stated in this manual are for your protection. Read them carefully and follow them closely when working around or using this machine.

Read and study this manual completely before attempting to operate this implement. Take this manual to the field for handy reference when operating, adjusting, or servicing your machine.

When referenced, “Right-Hand” (RH) and “Left-Hand” (LH) side of the machine are determined by standing behind the machine and facing in the direction of travel.

## Product Information

When ordering parts or when requesting further information or assistance, always give the following information:

- Machine name
- Serial number

All products manufactured by Unverferth Mfg. Co., Inc. are warranted to be free from material and workmanship defects for one full year from time of consumer delivery. Your local dealer will gladly assist you with any warranty questions.


Please fill out and retain this portion for your records. The serial number plate is located on the discharge end of the conveyor (Fig. 1).

Purchase Date \_\_\_\_\_ Model \_\_\_\_\_ Serial No. \_\_\_\_\_

Installed On Planter Make \_\_\_\_\_ Model Number \_\_\_\_\_

Dealer \_\_\_\_\_ City \_\_\_\_\_

Dealer Contact \_\_\_\_\_ Phone \_\_\_\_\_



## IMPORTANT

*The information, specifications, and illustrations in the manual are on the basis of information available at the time it was written. Due to continuing improvements in the design and manufacture of Unverferth products, all specifications and information contained herein are subject to change without notice.*

**Table of Contents**

Foreword.....2  
Product Information.....3

**SECTION I  
Safety**

General Hazard Information.....1-2  
Safety Decals.....1-3  
Following Safety Instructions .....1-4  
Before Servicing.....1-4  
Before Operating.....1-4  
During Operation.....1-5  
Before Transporting .....1-5  
Pressurized Oil.....1-6  
Preparing for Emergencies .....1-7  
Wearing Protective Equipment.....1-7

**SECTION II  
Set Up**

General.....2-2  
Hopper .....2-4  
Tube Conveyor.....2-8  
Handrails.....2-10  
Vertical Mounting Post.....2-11  
Horizontal Mounting Arm.....2-13  
Overhead Layout  
    JD1790/1795 CCS - 12/23, 12/24, 16/31, 16/32 Row - 30/15" .....2-14  
    JD1790/1795 CCS - 24 Row - 20" Row Spacing.....2-15  
Pivot Car/Sliding Rail.....2-16  
Attaching The Conveyor .....2-17  
Telescopic Spout Assembly.....2-19  
Hydraulics .....2-20  
Relocating SMV .....2-22  
Hydraulic Flow Control Valve Kit #23669 (Optional).....2-24  
Hopper Lift Stand Bundle #26588B (Optional) .....2-26  
Planter Fill-Conveyor Belt Stretcher (Optional)  
    For Replacement of Cleated Belts.....2-28

**Table of Contents**

**SECTION III**  
**Operation**

Preparing Planter .....3-2  
Operating Procedures.....3-2  
Transporting.....3-6  
Hydraulics .....3-7  
Clean-Out Doors .....3-8

**SECTION IV**  
**Maintenance**

Lubrication .....4-2  
    Conveyor Bearings.....4-2  
    Miscellaneous Lube Points .....4-2  
Storage/Maintenance .....4-2  
Hydraulic System.....4-3  
Conveyor Belt .....4-4  
    Belt Tension.....4-4  
    Belt Tracking.....4-5  
    Belt Change Procedures .....4-6  
Trouble Shooting.....4-7  
Torque Chart .....4-9  
Hydraulic Fittings.....4-9

**SECTION V**  
**Parts**

Idler End Components .....5-2  
Hopper Components .....5-6  
Mounting Brackets & Pivot Cart/Slide Rail Components .....5-10  
Extension, Horizontal, & Vertical.....5-12  
Discharge Spout Components .....5-14  
Telescopic Spout Components.....5-14  
Hydraulic Components .....5-18  
Optional Flow Control Valve Kit Components .....5-19  
Belt Stretcher (Optional) .....5-20

**Notes**

# **SECTION I**

# **Safety**

General Hazard Information.....	1-2
Safety Decals.....	1-3
Following Safety Instructions.....	1-4
Before Servicing.....	1-4
Before Operating.....	1-4
During Operation.....	1-5
Before Transporting.....	1-5
Pressurized Oil.....	1-6
Preparing for Emergencies.....	1-7
Wearing Protective Equipment.....	1-7

## General Hazard Information

No accident-prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

A large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the field, or in the industrial plant, can be safer than the person who is at the controls. If accidents are to be prevented--and they can be prevented--it will be done by the operators who accept the full measure of their responsibility.

It is true that the designer, the manufacturer, and the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that, "the best kind of a safety device is a careful operator." We, at Unverferth Mfg. Co., Inc. ask that you be that kind of operator.



**REMEMBER:**  
**THINK SAFETY**  
A CAREFUL OPERATOR IS THE  
BEST INSURANCE AGAINST AN  
ACCIDENT!

### SIGNAL WORDS

 **DANGER**

INDICATES AN EXTREMELY HAZARDOUS SITUATION OR ACTION THAT WILL RESULT IN SERIOUS INJURY OR DEATH.

---

 **WARNING**

INDICATES A HAZARDOUS SITUATION OR ACTION THAT COULD RESULT IN SERIOUS INJURY OR DEATH.

---

 **CAUTION**

INDICATES AN UNSAFE SITUATION OR ACTION THAT MAY RESULT IN PERSONAL INJURY.

---

**IMPORTANT**



*Is used for instruction on operating, adjusting, or servicing a machine.*




**Safety Decals**

**⚠ WARNING**

- **REPLACE LOST, DAMAGED, PAINTED, OR UNREADABLE DECALS IMMEDIATELY. IF PARTS THAT HAVE DECALS ARE REPLACED, ALSO MAKE SURE TO INSTALL NEW DECALS. THESE DECALS INFORM AND REMIND THE OPERATOR WITH OPERATIONAL INFORMATION AND SAFETY MESSAGES.**



Part #9003125  
Fluorescent Reflector



Part #9003126  
Red Reflector



Part #9003127  
Amber Reflector

## Following Safety Instructions

- Read and understand this operator's manual before operating.



- All machinery should be operated only by trained and authorized personnel.

- To prevent machine damage, use only attachments and service parts approved by the manufacturer.

- Always shut tractor engine off and remove key before servicing.



- Avoid personal attire such as loose fitting clothing, shoestrings, drawstrings, pants cuffs, long hair, etc., that may become entangled in moving parts.

- Do not allow anyone to ride on the implement. Make sure everyone is clear before operating machine or towing vehicle.



## Before Servicing

- Avoid working under the unit; however, if it becomes absolutely unavoidable, make sure the implement is safely blocked.



- Ensure that all applicable safety decals are installed and legible.

## Before Operating

- Always make certain everyone and everything is clear of the machine before beginning operation.

- Verify that all safety shields are in place and properly secured.

- Ensure that all applicable safety decals are installed and legible.

### During Operation

- Regulate speed to field conditions. Maintain complete control at all times.

---
- Never service or lubricate equipment when in operation.

---
- Keep away from overhead power lines. Electrical shock can cause serious injury or death.

---
- Use extreme care when operating close to ditches, fences, or on hillsides.

---
- Do not leave towing vehicle or unattended with engine running.


### Before Transporting

- Install transport locks before transporting.

## Pressurized Oil

- Relieve pressure before disconnecting hydraulic lines, loosening any hydraulic fittings or servicing hydraulic system. See the maintenance section of this manual for the procedure to relieve pressure.

---

- High-pressure fluids can penetrate the skin and cause serious injury or death. Use cardboard or wood to detect leaks in the hydraulic system. Seek medical treatment immediately if injured by high-pressure fluids. 

---

- Hydraulic system must be purged of air before operating to prevent serious injury or death.

---

- Do not bend or strike high-pressure lines. Do not install bent or damaged tubes or hoses.

---

- Repair all oil leaks. Leaks can cause fires, personal injury, and environmental damage.

---

- Route hoses and lines carefully to prevent premature failure due to kinking and rubbing against other parts. Make sure that all clamps, guards and shields are installed correctly.

---

- Check hydraulic hoses and tubes carefully. Replace components as necessary if any of the following conditions are found:
  - o End fittings damaged, displaced, or leaking.
  - o Outer covering chafed/cut or wire reinforcing exposed.
  - o Outer covering ballooning locally.
  - o Evidence of kinking or crushing of the flexible part of a hose.

## Preparing for Emergencies

- Keep a first aid kit and properly rated fire extinguisher nearby.



- Keep emergency numbers for fire, rescue, and poison control personnel near the phone.



## Wearing Protective Equipment

- Wear clothing and personal protective equipment appropriate for the job.



- Wear steel-toed shoes when operating.



- Wear hearing protection when exposed to loud noises.



- Do not wear additional hearing impairing devices such as radio headphones, etc.



**Notes**

# **SECTION II**

# **Set Up**

General.....	2-2
Hopper .....	2-4
Tube Conveyor.....	2-8
Handrails.....	2-10
Vertical Mounting Post.....	2-11
Horizontal Mounting Arm.....	2-13
Overhead Layout	
JD1790/1795 CCS - 12/23, 12/24, 16/31, 16/32 Row - 30/15" .....	2-14
JD1790/1795 CCS - 24 Row - 20" Row Spacing.....	2-15
Pivot Car/Sliding Rail.....	2-16
Attaching The Conveyor .....	2-17
Telescopic Spout Assembly.....	2-19
Hydraulics .....	2-20
Relocating SMV .....	2-22
Hydraulic Flow Control Valve Kit #23669 (Optional).....	2-24
Hopper Lift Stand Bundle #26588B (Optional) .....	2-26
Planter Fill-Conveyor Belt Stretcher (Optional)	
For Replacement of Cleated Belts.....	2-28

# PLANTER TUBE-CONVEYOR — Set Up

## General

This section contains all of the instructions required for the complete assembly of the CONVEYOR to your planter.


For your safety, and the safety of others, use proper tools and equipment and always use safe working procedures. Refer to these instructions before starting any work on your machine.

### IMPORTANT

- The procedures for assembling this unit are intended for two or more people.
- Planters with the ExactEmerge Planting System may have two battery access doors located on the platform between the two seed tanks. The conveyor mounts over these doors and will prevent access to the battery


For ease of assembly, install all hardware loosely until assembly is complete and then tighten according to "Torque Chart".

Place planter on a solid, level surface with sufficient clear space to unfold the wings of the planter. Unfold wings, lower unit to the ground, block from moving, set the tractor brakes, shut-off the engine, and remove the ignition key.




You should receive the following bundles:

**VERTICAL POST  
WELDMENT  
PART #23707B**




**HORIZONTAL ARM  
WELDMENT  
PART #23710B**




**HOPPER BUNDLE  
PART #27717B**



**HAND RAIL  
WELDMENT  
PART #23730G**




**TELESCOPIC SPOUT  
PART #27629**




**CONVEYOR ASSEMBLY 6x18  
PART #25150B**



**FLOW CONTROL  
VALVE BUNDLE  
PART #23669**



**PARTS BOX  
PART #25177**






## General (continued)

### **WARNING**

- **KNOW AND UNDERSTAND SAFETY RULES BEFORE ASSEMBLING, OPERATING OR SERVICING THIS MACHINE. REVIEW "SAFETY" SECTION IN THIS MANUAL, TRACTOR AND PLANTER OPERATOR MANUALS IF NECESSARY.**
- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.**
- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**
- **MOVING PARTS CAN CRUSH AND CUT. KEEP AWAY FROM MOVING PARTS.**
- **KEEP HANDS CLEAR OF PINCH POINT AREAS.**
- **EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.**
- **FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 500 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.**


### **IMPORTANT**

- *Attach the reflectors to the tube conveyor hopper end as shown below.*





## Hopper

1. Attach the pivot weldment (24554B) to the tube conveyor using pin weldment (24578), 3/8"-16UNC x 1" capscrew (9390-055), and 3/8"-16UNC lock nut (9928) (FIG. 2-1).
2. Attach the shim plate (25434B) to the pivot weldment (24554B) using 5/16"-18UNC x 1" screws/small flange (901044) and 5/16"-18UNC hex nuts/large flange (91257) (FIG. 2-1).
3. Push the grips (92928) onto the ends of the handle weldment (24576B). Attach the handle weldment (24576B) to the tube conveyor using 1/2"-13UNC x 1-1/2" capscrews (9390-101), bushings (24550), flat washers (9405-088) and 1/2"-13UNC lock nuts (9800) (FIG. 2-1).




4. Insert the formed tube (26918B) into the vinyl hopper (902421) as shown in FIG. 2-2. Attach the formed tube (26918B) ends to the pivot weldment (24554B) using 5/16"-18UNC x 1-1/2" capscrews (9390-032) and 5/16"-18UNC lock nuts (9807).





**Hopper (continued)**

5. Remove the 5/16"-18UNC hex nuts (91257), 5/16"-18UNC x 3/4" screw/large flange (91256), straps (24620B), and grate (28400B). Also remove the 5/16"-18UNC hex nuts (91257), 5/16"-18UNC x 1" capscrews (9390-030), strap (28486B), brush holder (24964) with nylon brush (901111), and seal (26865). See FIG. 2-3.



## Hopper (continued)

6. Attach the vinyl hopper (902421) to the bottom of the tube conveyor with the previously removed parts (capscrews - 9390-030; strap - 28486B; brush holder - 24964 & nylon brush - 901111; seal - 26865; and nuts - 91257) and two poly strips (24986) as shown in FIG. 2-4 & FIG. 2-5.



## Hopper (continued)

7. Attach the sides of the vinyl hopper to the tube conveyor with the previously removed parts (screws/lrg flg - 91256; straps - 24620B; grate - 28400B; and nuts - 91257) as shown in FIG. 2-6.




FIG. 2-6

8. Secure the hopper lid/cover with bungee cord (27715) to the conveyor (FIG. 2-7).





FIG. 2-7


## Tube Conveyor

1. Raise tube conveyor using a hoist or lifting device rated for 500 lbs. min.
2. Place tube conveyor on properly rated jack stands.
3. Adjust the channel weldment to the upper holes for increased spout height, but with decreased bushel flow. Adjust the channel weldment in the lower holes for increased bushel flow, but decreased spout height.
4. Insert tube/bushing (25307) into pivot weldment (25160B). Attach the pivot weldment and tube/bushing to the channel weldment (26564B) using 3/4"-10UNC x 9" capscrew (9390-449) and 3/4"-10UNC lock nut (96732) as shown in FIG. 2-8.



### Tube Conveyor (continued)

5. Attach the transport mount weldments (25155B) to tube conveyor in the standard position using 3/8"-16UNC x 1" screw/large flange (91262) as shown in FIG. 2-9.



**NOTE:** On planters with a refuge tank, the 6" extension post will need to be installed. Refer to "Assembly" Section for procedures.



### IMPORTANT

- Planters which have the optional fertilizer tanks will have to position the conveyor transport plates as shown in Fig 2-8 and will increase the overall length when the conveyor is in the transport position by approximately 24".
6. Using 3/8"-16UNC x 1" capscrews (9390-055) and 3/8"-16UNC lock nuts (9928) attach the formed bar (25156B) (Fig. 2-8).
  7. Insert the formed pin (25157) through the transport mount weldments (25155B) and retain into position using hairpin cotter (95959) (FIG. 2-8).

## Handrails

The railing located at the top of the planter has to be replaced with the new hand rail weldment (23730G).

1. Detach work light from hand rail. Save all the components because they will be reinstalled later.
2. Remove the top railing as shown in FIG. 2-10. Loosely attach the new hand rail weldment (23730G) using the existing hardware in the **LOWEST POSITION POSSIBLE**. The bolts located on the left-hand side will be installed with the nut closest to the tractor and as shown in FIG. 2-11.



3. Remove the left-hand railing from the planter as shown in FIG. 2-10.



## CAUTION

- THE CONVEYOR MUST BE INSTALLED WHEN USING THE PLANTER REAR STEPS TO PREVENT FALLING.



## Vertical Mounting Post

JD 1790/1795 CCS - 30/15" ROW SPACING ONLY

ROWS	ROW SPACING
12/23	30/15"
12/24	30/15"
16/31	30/15"
16/32	30/15"

1. JD 1790/1795 CCS Planters with 30/15" row spacings require the vertical post weldment to be installed on the outside of planter wheels as shown in FIG. 2-12 & FIG. 2-13 and Overhead Layouts.
  - a. The vertical post weldment (23707B) will be located on the outside of the planter wheel. The plate (23512B) will be located on the opposite side of the planter wheel.

**NOTE:** 1795 planters beginning in 2019 have a welded hose bracket on the wheel arm. Position vertical support arm forward of welded bracket. Install offset bracket (2009884B) on top of vertical support.

- b. Attach the vertical post weldment (23707B) and plate (23512B) to the planter wheel using 5/8"-11UNC x 4" capscrews (9390-132) and 5/8"-11UNC lock nuts (9801).
- c. Tighten hardware according to "Torque Chart".

FIG. 2-12

FOR 30/15" ROW SPACING ONLY








FIG. 2-13

**Vertical Mounting Post (continued)**

**JD 1790/1795 CCS - 20" ROW SPACING ONLY**

ROWS	ROW SPACING
24	20"


2. JD 1790/1795 CCS Planters with 20" row spacings require the vertical post weldment to be installed on the outside of planter wheels as shown in FIG. 2-14 & FIG. 2-15 and Overhead Layouts.
  - a. The vertical post weldment (23707B) and strap (23639B) will be located on the inside of the planter wheel. The strap (23639B) and plate (23512B) will be located on the opposite side of the planter wheel.
  - b. Attach the vertical post weldment (23707B), straps (23639B), and plate (23512B) to the planter wheel with 5/8"-11UNC x 7" capscrews (9390-138) and 5/8"-11UNC lock nuts (9801).
  - c. Tighten hardware according to "Torque Chart".



**Horizontal Mounting Arm**


**JD 1790/1795 CCS - 30/15" & 20" ROW SPACINGS**

1. Loosely attach the horizontal arm weldment (23710B) to the vertical post weldment (23707B) using U-bolts (900076), flat washers (9405-074), locknuts (9928) as shown in FIG. 2-16 & FIG. 2-17 and Overhead Layouts.



# PLANTER TUBE-CONVEYOR — Set Up


**Overhead Layout — JD 1790/1795 CCS - 12/23, 12/24,  
16/31, 16/32 Row - 30/15" Row Spacing**



OM04219

# PLANTER TUBE-CONVEYOR — Set Up


## Overhead Layout — JD 1790/1795 CCS - 24 Row - 20" Row Spacing



OM04219


## Pivot Car/Sliding Rail

1. Remove and save the three platform screws on the left-hand side (FIG. 2-18).



**NOTE:** Beginning with the 2015 model year, JD Planters have 2 access doors on the planter platform providing access to batteries for the ExactEmerge Row Unit system. ExactEmerge customers will have limited access to the batteries unless they modify/cut the doors. Contact Unverferth Mfg. for additional planter fill options.

The two arrows indicate the bolts that need to be replaced with 1/4"-20UNC x 3/4" capscrews (9390-003) and flange nuts (97189).



2. Attach the pivot car/sliding rail assembly (2003135B) to platform using the three flat washers and 8mm bolts provided. Once the rail is secure, add one 8mm jam nut to each of the three bolts on the underside of the platform (FIG. 2-20).




## Pivot Car/Sliding Rail (Continued)

3. Attach the pivot car/sliding rail assembly (2003135B) to the offset channel bracket (2009884B) and post weldment (24413B) using capscrews (9390-030 & 9390-031) and locknuts (9807) as shown in FIG. 2-21. Attach the post weldment (24413B) to the horizontal arm weldment (23710B) using U-bolts (900077), flat washers (9405-074), locknuts (9928) as shown in FIG. 2-21.



**NOTE:** On units with 20" row spacing, the post weldment (24413B) will have to be shortened to clear the steps.

4. Double check all hardware and tighten according to Torque Chart.



## Attaching The Conveyor


1. Using a safe lifting device rated at 500 lbs. minimum, lift the conveyor assembly into the mounting position as shown in FIG. 2-22 & FIG. 2-23.
  - a. The conveyor assembly will rest in the pivot car/slide rail assembly (2003135B).
  - b. Place collar (25376B) onto the bottom of the pivot car/slide rail assembly (2003135B). Secure collar (25376B) with 3/8"-16UNC x 3-1/2" capscrew (9390-065). Tighten hardware according to "Torque Chart".



## Attaching The Conveyor (continued)

If using a refuge tank, a pivot tube weldment is needed for additional height to clear the refuge tank while in transport. Attach conveyor as follows:

2. Attach pivot tube weldment (26563B) to the pivot car/slide rail assembly (2003135B) by placing the collar (25376B) onto the bottom of the pivot car/slide rail assembly (2003135B). Secure collar (25376B) with 3/8"-16UNC x 3-1/2" capscrew (9390-065). Tighten hardware according to "Torque Chart". See FIG. 3-24.
3. Using a hoist and lifting devices rated at 500 lbs. minimum, lift the conveyor assembly into the mounting position as shown in FIG. 2-22 & FIG. 2-24.
  - a. The conveyor assembly will rest in the pivot tube weldment (26563B).
  - b. Secure using 3/8"-16UNC x 3-1/2" capscrews (9390-065) and lock nuts (9928).







**Telescopic Spout Assembly**

1. Remove the spout weldment with metal latch (26620B) and attach it to the discharge end/upper conveyor end.
2. Attach the telescopic spout assembly (27629) to the discharge end/upper conveyor using clamp (98060). Slide the spout on until it connects with the main conveyor and secure. Place spout on the spout hanger when not in use.

Spout holder may need to be readjusted to securely hold the telescopic spout. Adjust holder as needed and retighten hardware.




## Hydraulics

### **WARNING**

- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.


1. Route the hydraulic hoses around the slide rail arms as shown in FIG. 2-27 & FIG. 2-28. Be sure the hoses are not kinked or rubbing any sharp edges. Secure with 32" cable ties (94038).

**NOTE:** The supply line comes from the top end of the control valve, the return line comes from the side of the motor with the in-line check valve.



### Hydraulics (continued)

2. Attach the adapters (9864) to the opposite ends of the hoses (96758) (FIG. 2-29). Attach the hoses to the side of the conveyor using the hose retainers.
3. Thread the hoses through the loop on the dust cap (91511) (FIG. 2-29).
4. Attach the male tip couplings (91383) to the adapter end of the hoses (FIG. 2-29). Tighten all the fittings completely.






5. Insert the coupling end of the hoses into the planter auxiliary valve with a maximum 12 GPM. If not using an auxiliary valve, attach additional lines directly to the tractor ports.

### IMPORTANT

- *Hoses are provided to the optional John Deere auxiliary ports on the rear of the planter. It is not recommended that you tie into the planter hydraulics without this option. Contact your JD dealer for more information. Hoses may be lengthened to tie directly into the tractor ports (these hoses are not provided).*


## Relocating SMV

1. The SMV Emblem and bracket have to be moved for optimum visibility. Move the SMV bracket from the original mounting position at the top of the railing steps and reattach it to the new mounting position on the vertical post weldment as shown in FIG. 2-30 & FIG. 2-32.
2. Drill a 13/32" hole in the SMV mounting bracket as shown in FIG. 2-31.
3. Using the SMV bracket as a template, mark the position for the additional holes as shown in FIG. 2-31.
4. Drill 3/16" holes at the marked location and secure using self-drilling screws (96972) as shown in FIG. 2-31.



## Relocating SMV (continued)

5. Planters which have the optional fertilizer tanks will have to reposition the conveyor transport plates as shown in Fig 3-33.



### IMPORTANT

- *Repositioning the conveyor will increase the overall length when the conveyor is in the transport position by approximately 24".*
6. Be certain clearance to rafters, walls, machinery, etc. exists before lowering the conveyor. With a tractor hooked to the unit, activate the conveyor to make sure everything moves freely. Do not pinch or kink hoses.
  7. Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.

## Hydraulic Flow Control Valve Kit #23669

Tractors having high-capacity hydraulic systems with 12 to 20 GPM flow, may cause your conveyor or auger to run too fast, resulting in:

- A. Excess Vibration
- B. Excess Wear
- C. Loss of Performance

To eliminate these problems, an adjustable flow control valve is offered for installation into the auger/conveyor hydraulic system. This valve will allow the operator to adjust the flow to obtain the proper speed for your application.


**NOTE:** The speed control valve may be ordered through your Unverferth dealer.

### **⚠ WARNING**


- **EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.**
- **RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.**
- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**

### OPEN CENTER SYSTEM

OM23857




### CLOSED CENTER SYSTEM




\* Parts are included with auger/conveyor.

## Hydraulic Flow Control Valve Kit #23669 (continued)



**NOTE:** Use a piece of cardboard or wood to detect leaks of hydraulic fluid under pressure.

1. Determine the type of hydraulic system and plumb according to the diagrams below. Contact your local dealer to identify which system your tractor is equipped with.
2. Once hydraulics are assembled, position valve on outside of stairs and mark holes for drilling. Drill two 9/32" holes.
3. Mount valve and secure using two 1/4" bolts and locknuts provided.
4. Install handle onto valve as shown.
5. Once the control valve is installed, the auger/conveyor speed can be set as follows:
  - A. Set flow control valve approximately 1/2 way on flow indicator (lock into position).
  - B. Start oil flow and run auger/conveyor to check speed. Flighting/belt should run smooth, not lag or fluctuate in speed, adjust speed control valve if necessary.





**NOTE:** When conveyor is loaded with material, it should not stall. Adjust speed to allow for smooth, even feeding of material through the unit.

**Optional Hopper Lift Stand Bundle #26588B**

**⚠ WARNING**

- EXCESSIVE WEIGHT ON HOPPER LIFT STAND CAN CAUSE LIFT STAND TO COLLAPSE RESULTING IN SERIOUS INJURY OR DEATH. DO NOT PLACE BULK SEED BAGS OR CONTAINERS DIRECTLY ON OR IN HOPPER.

1. Raise hopper end of tube conveyor using a hoist or lifting device rated for 200 lbs. min.
2. Place tube conveyor on properly rated jack stands.
3. Attach the hopper lift stand using four 3/8"-16UNC x 3/4" capscrews (9390-053) and four 3/8"-16UNC lock nuts (9928). See FIG. 2-34.







**Optional Hopper Lift Stand Bundle (continued)**

4. Bent pin (900803) location:


Place bent pin (900803) into bottom hole of plate (26586B) when conveyor is in use. See FIG. 2-36.



Place bent pin (900803) into upper hole of plate 26586B) when conveyor is in transport position. See FIG. 2-37.



**Belt Stretcher (Optional)**






INSTALL BOTTOM BARS ACROSS UNDERSIDE OF BELT, AND SECURE WITH FOUR 5/8NC X 1-1/2" BOLTS THROUGH TOP BARS AS SHOWN.

REF	PART NO.	QTY	DESCRIPTION
1	TA0-907235-0	4	BOLT, HEX 5/8NC X 1/2" GRADE 5
2	TA0-903118-0	2	BEARING, BALL THRUST, 5/8" I.D.
3	TA1-114401-0	2	BOTTOM BAR, 6" & 12" BELT STRETCHER
4	TA2-114404-0	2	PLAIN TOP BAR WELDMENT, 6" & 12" BELT STRETCHER
5	TA2-114406-0	2	THREADED TOP BAR WELDMENT, 6" & 12" BELT STRETCHER
6	TA1-114408-0	2	THREADED ROD WELDMENT, 6" & 12" BELT STRETCHER

**Belt Stretcher (Optional) (Continued)**

**Stretcher Assembled to Belt**

FOR ILLUSTRATION ONLY



**Notes**

# **SECTION III**

# **Operation**

Preparing Planter .....	3-2
Operating Procedures.....	3-2
Transporting.....	3-6
Hydraulics .....	3-7
Clean-Out Doors .....	3-8

## Preparing Planter

### **WARNING**

- READ AND UNDERSTAND SAFETY RULES BEFORE OPERATING OR SERVICING THIS MACHINE. REVIEW "SAFETY" SECTION IN THIS MANUAL IF NECESSARY.

Read this operation section thoroughly. Acquaint yourself with the adjustments required to obtain efficient and trouble-free operations.

## Preparing Planter

### **IMPORTANT**


- Before attempting to attach the planter to the tractor, familiarize yourself with operations and adjustments of the unit. To insure safe operating conditions, obey all "Safety" and "Cautions" outlined in the planter's operator's manual.

## Operating Procedures

### **CAUTION**

- KEEP ALL UNAUTHORIZED PEOPLE CLEAR OF WORK AREA.

1. Pull tractor and planter into position, shift tractor into park (or neutral) and lock brakes on tractor. Planter must be lowered to the ground to fill.
2. Open the lid on the planter tanks to allow the conveyor to be positioned.
3. Remove the lynch pin (9951) from the transport bracket as shown in FIG. 3-1.
4. Lift up on the transport handle to release the hooks retaining the conveyor.




**Operating Procedures (continued)**

5. Lower the conveyor into operating position as shown in FIG. 3-2.



## Operating Procedures (continued)


**NOTE:** Adjust the position of the conveyor using the hole settings in the conveyor channel to determine the spout height and bushel flow (reference FIG. 3-3).



### IMPORTANT

- Do not let telescoping spout rest in bottom of seed box. Seed will rapidly build up and plug conveyor, resulting in potential damage to belt.
- Be sure shims are assembled to minimize gap between channel and side plates. Do not draw bolts to minimize gaps, else premature belt wear might occur. Refer to SET UP section for details.

6. Engage the tractor hydraulic system to allow the hydraulic oil to flow to the conveyor. Turn on conveyor by sliding manual control lever to on position. Make sure the conveyor belt is moving in a forward direction. If the belt is moving in a backward direction, either reverse the hoses going into the tractor or move the tractor control hydraulic lever in the opposite direction to reverse the flow.





### Operating Procedures (continued)

#### **WARNING**

- SEED MAY BE TREATED WITH HAZARDOUS MATERIAL. AVOID CONTACTING SEED WITH SKIN, EYES, AND AVOID BREATHING DUST. FOLLOW MANUFACTURER'S RECOMMENDATIONS.

7. Begin the flow of seed into the conveyor. Adjust the seed flow for a smooth, even flow of seed through the conveyor.
8. Fill the tank evenly by moving the adjustable spout from side-to-side while the conveyor is running. When the desired level is reached in the tank(s), close the transfer wagon door and empty out the conveyor.

#### **IMPORTANT**

- *When rotating conveyor from side-to-side, be sure to not over-rotate. Gas shock may be bent resulting in loss of pressure.*

## Transporting



1. Remove the lynch pin from the transport latch bracket. Place the conveyor back into the transport latch bracket. Lift the latch handle. Place the hooks on the conveyor bracket. Lower the latch handle and replace the lynch pin to keep the conveyor in place. (FIG. 3-5)



2. Place the spout in the spout holder as shown in FIG. 3-6.

### IMPORTANT

- Always position the conveyor in transport position when not filling the planter.




## Hydraulics

### **WARNING**

- **HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.**
- **RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.**
- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**

Check routing of all hydraulic hoses. Hoses should not be kinked, twisted, or rubbing against sharp edges. Hoses should be secured with tie straps. Check hose fittings for hydraulic leaks. Tighten and/or repair or replace as required (FIG. 3-8).

Hoses are shown connected to the optional John Deere rear remote package. Contact John Deere dealer for information on this option.




**FIG. 3-8**

**Clean-Out Doors**

**⚠ WARNING**

- **MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. ALWAYS STOP THE ENGINE, REMOVE THE KEY BEFORE SERVICING. ENSURE SERVICE COVERS, CHAIN/BELT COVERS AND CLEAN-OUT DOOR(S) ARE IN PLACE AND SECURELY FASTENED BEFORE OPERATING THE MACHINE.**

The hopper end of the conveyor can be cleaned by releasing the latch and opening the clean-out door (FIG. 3-9). The conveyor discharge head can be cleaned by releasing the latch and opening the clean-out door (FIG. 3-9).



**FIG. 3-9**

# **SECTION IV**

# **Maintenance**

Lubrication .....	4-2
Conveyor Bearings.....	4-2
Miscellaneous Lube Points .....	4-2
Storage/Maintenance .....	4-2
Hydraulic System.....	4-3
Conveyor Belt .....	4-4
Belt Tension.....	4-4
Belt Tracking.....	4-5
Belt Change Procedures .....	4-6
Trouble Shooting.....	4-7
Torque Chart .....	4-9
Hydraulic Fittings.....	4-9

### Lubrication

Lubricate with an SAE multi-purpose grease. All fittings must be free from dirt and paint to insure entry of lubricant inside bearing.

### Conveyor Bearings

Lubricate this bearing every 100 hours of operation and at the end of each season before storage. Use only one stroke of grease per bearing.



### CAUTION

- DO NOT USE A HIGH-PRESSURE GREASE GUN TO LUBRICATE THIS BEARING, AS DAMAGE TO BEARING SEAL COULD OCCUR.

NOTE: Excessive lubrication of these bearings will result in premature failure.

### Miscellaneous Lube Points

Oil or grease periodically (or as needed) the following:

- Hinge for clean-out door.
- Swivel base on conveyor.
- Latch pin housing.
- Pivot bracket and arm.
- On/Off control rod.

### Storage/Maintenance

Your conveyor is an important investment. Spend a little time to protect it from destructive rust and corrosion. You will be repaid in longer service life and better performance.

#### DO THE FOLLOWING AFTER USE:

1. Clean out conveyor/hopper. Use pressurized water to wash out conveyor and hopper after use.
2. Wipe off the following:
  - Hydraulic valve, motor, hoses, and fittings.
  - Swivel base, cradle.
  - Reflectors and warning/caution decals.
3. Check the following:
  - Mounting bolts for tightness.
  - Cable ties for tightness.
  - Valve, motor, hoses, and fittings for leaks, etc.
  - Hydraulic hoses for wear-abuse.

#### DO THE FOLLOWING BEFORE PLACING THE CONVEYOR IN STORAGE:

- Repaint any chipped or scraped areas.
- Inspect for damaged or worn parts. Replace before next season.
- Store unit inside, away from livestock.

### Hydraulic System

#### **WARNING**

- RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the conveyor requires little maintenance.

#### Replacing Hoses/Fittings/Cylinders:

1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3000 psi.
2. Do not use hoses, fittings and cylinders that have pipe threads.
3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings per "Torque Chart".
4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
5. Always purge the hydraulic system after servicing.

## Conveyor Belt


Proper belt tension and correct 'tracking' of the belt are critical to maintaining the belt for years of worry-free use. Belt tension and tracking should be checked at the beginning of each season. Belt alignment should be checked after the very first initial use then after the first 2 hours of initial use or after every adjustment of belt tension/alignment. Once belt tracking is set, it will be necessary to check alignment after every 8 hours of use.

### **WARNING**

- **AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOESTRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC., THAT MAY BECOME ENTANGLED IN MOVING PARTS.**
- **MOVING OR ROTATING COMPONENTS CAN CAUSE SERIOUS INJURY OR DEATH. USE EXTREME CARE WHEN INSPECTING AND ADJUSTING BELT TRACKING.**


## Belt Tension

Belt tension is inspected by removing lower intake panel/guard from conveyor, and gently pull on the conveyor belt. The belt should have approximately 1 1/2-2" of slack at the center.



Belt tension is adjusted at the discharge end of the conveyor. Loosen, **DO NOT REMOVE**, the four 3/8" bolts on each side of the conveyor. Use the two adjusting bolts to adjust the belt to the proper tension.

It is important to move both sides the same distance. Too much tension on the belt will stretch the splice link and greatly reduce belt life. Too little tension on the belt could result in belt slipping on drive pulley. Replace the bottom cover panel and continue to check belt tracking before re-tightening the four bolts on each side of the conveyor.



### **IMPORTANT**

- *Belt tracking must be done every time tension is adjusted.*




## Conveyor Belt (continued)

### Belt Tracking

Conveyor belt must always run at the center of the pulley on both the intake and discharge end. Improper tracking of the belt will result in excessive wear to the edge of the belt, and will greatly reduce belt life. Check belt tracking every 8 hours of use, and every time belt tension is adjusted.


Inspect tracking of belt at discharge end by removing lower spout, pivoting deflector up, and looking up at the belt and pulley. Belt should be in center of pulley.



Adjust by loosening, **DO NOT REMOVE**, the four bolts on the side of the conveyor. Operate conveyor at slow speed, and tighten or loosen the adjustment bolt until belt is running in the center of the pulley.

Tighten all bolts on side of conveyor, and lock adjustment bolts into place.


Inspect tracking of belt at intake end by opening bottom inspection door on conveyor. Belt should be in the center of the pulley.



### Conveyor Belt (continued)

#### Belt Tracking (continued)

Adjust by loosening (Do Not Remove) the four bolts (two on each side) on the adjusting plate.



Operate conveyor at slow speed, and tighten or loosen adjustment bolt until belt is running in the center of the pulley.

Tighten the two bolts on the adjustment plate, and lock the adjustment bolt into place.

### Belt Change Procedures

1. Remove the access panel from the underside near the center of the conveyor housing.
2. Run the conveyor belt until the splice is positioned in the access opening.
3. Reduce tension from the belt by turning the tensioning bolts on the end of the conveyor.
4. Attach the belt stretcher to the belt to remove tension on the belt splice. Remove connecting wire from the splice.
5. Attach the new belt to the original belt splice using a length of small diameter wire.
6. Pull the original belt out of the conveyor. When finished, the new belt should be routed through the conveyor, remove the temporary splice wire and discard.
7. Reinstall the belt stretcher to the new belt to draw the splice together. Insert the vinyl coated cable through the splice, attach the small bent washers on each end of the cable by crimping tight with a pliers. Remove the belt stretcher from the new belt.
8. Increase tension on the new belt by adjusting the tensioning bolts on the end of the conveyor housing, making sure the belt tracking is centered.
9. Install access panel door removed in step 1.

**Troubleshooting**

Occasionally when a conveyor has been connected into an auxiliary hydraulic system, it may not operate or convey the material being handled. When hydraulic pressure and flow gauges are not available, it may be difficult to determine if there is a fault in the source, hydraulic system, or the conveyor. A convenient method of determining this is to connect the conveyor hydraulic hoses to another tractor system and check the operation. If, for example, the conveyor operates from the other tractor system but not from the original tractor there is a fault in the original tractor connection, or the original tractor system is not adequate. If the conveyor fails to operate; however, there is probably a fault with the conveyor control valve, motor, or the conveyor itself. In this case, refer to the trouble shooting guide.

**PROBABLE CAUSE**

**CORRECTION**

**Conveyor Will Not Turn Over or Develop Proper Speed/Torque**

Pump does not deliver sufficient pressure or volume	Check output and delivery-repair if necessary
Conveyor mechanism binding	Check for cause and correct
Wrong hose hook-up to tractor control levers	Refer to Tractor Operator's Manual for valve and control lever arrangement
Insufficient tractor hydraulic pressure	See the following: A. Check hydraulic reservoir oil level B. See assembly section "Hydraulic Hook-Up Recommendations"
Hydraulic components leaking oil	Find cause and correct
Hydraulic hoses kinked or twisted	Find cause and correct
Malfunction of hydraulic components	Isolate problem area-repair as necessary

**Conveyor Runs Too Slow**

Pump is worn	Repair or replace pump
Internal leak in controls or motor	Replace seals; repair or replace valves or motors
Air in system	Bleed system and tighten connections
If conveyor starts slowly and speed increases after oil heats up; oil is too heavy weight. If conveyor slows down after oil heats up; oil is too light weight	Use proper weight hydraulic oil

**Troubleshooting (continued)**

**PROBABLE CAUSE**

**CORRECTION**

**Conveyor is Turning in Wrong Direction**

Incorrect piping between source and control valve

Reverse piping connections

Improperly installed check valve plate

Reposition (As shown in SET-UP section)

**Oil Heat Excessively**

Too light weight in hot climate

Drain and refill with proper weight oil.

Oil too heavy weight

Use recommended weight oil.

Dirty oil

Drain, flush, and refill with clean oil and filter

Oil level too low

Fill to proper level

Relief valve pressure too high or low; does not operate

Adjust and repair or replace relief valve

Oil slipping through worn pump

Repair or replace pump

Hoses or valves too small

Use larger hoses or valves

Restricted lines or piping

Reroute lines to eliminate restrictions

Reservoir too small to provide adequate cooling

Replace with larger reservoir or install oil cooler

**Pump/Motors/Seals Blow - Shaft/Housing Breaks - Hose Burst**

When a standard control valve is returned to neutral to stop or start a motor, sudden excess pressure is created which will break seals, tear off motor shafts, burst housing or hoses, (Especially at speed under load.) This sudden shock cannot be relieved through the primary relief valve in the system.

Avoid sudden rapid starting and stopping

**Belt Edges Showing Excessive Wear**

Belt tracking incorrect

Adjust tracking as detailed in MAINTENANCE section

Poly seals on intake and/or discharge end worn

Replace poly seals

**Complete Torque Chart - Capscrews - Grade 5**

**IMPORTANT**


- Grade 5 capscrews can be identified by three radial dashes on head.
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

SIZE	FOOT POUNDS	NEWTON METERS	SIZE	FOOT POUNDS	NEWTON METERS
1/4-20	8-10	11-13	3/4-10	200-220	270-300
1/4-28	9-11	12-15	3/4-16	210-230	285-310
5/16-18	15-17	20-23	7/8-9	330-350	425-475
5/16-24	17-19	23-26	7/8-14	360-380	460-515
3/8-16	25-28	34-38	1-8	500-525	675-710
3/8-24	28-31	38-42	1-14	540-560	730-760
7/16-14	40-45	54-61	1 1/8-7	600-635	815-860
7/16-20	45-50	61-68	1 1/8-12	665-700	920-950
1/2-13	62-68	84-92	1 1/4-7	850-895	1150-1215
1/2-20	68-75	92-102	1 1/4-12	940-990	1275-1340
9/16-12	90-98	22-133	1 3/8-6	1125-1175	1525-1590
9/16-18	100-110	134-148	1 3/8-12	1280-1335	1735-1810
5/8-11	120-135	162-183	1 1/2-6	1500-1560	2035-2115
5/8-18	124-137	168-186	1 1/2-12	1685-1755	2285-2380

**Hydraulic Fittings - Torque and Installation**


**SAE FLARE CONNECTION (J. I. C.)**

1. Tighten nut with finger until it bottoms the seat.
2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



**SAE STRAIGHT THREAD O-RING SEAL**

1. Insure jam nut and washer are backed up to the back side of smooth portion of elbow adapter.
2. Lubricate o-ring -- VERY IMPORTANT!
3. Thread into port until washer bottoms onto spot face.
4. Position elbows by backing up adapter.
5. Tighten jam nut.



**Notes**


# **SECTION V**

# **Parts**

Idler End Components .....5-2  
Hopper Components .....5-6  
Mounting Brackets & Pivot Cart/Slide Rail Components .....5-10  
Extension, Horizontal, & Vertical.....5-12  
Discharge Spout Components .....5-14  
Telescopic Spout Components.....5-14  
Hydraulic Components .....5-18  
Optional Flow Control Valve Kit Components .....5-19  
Belt Stretcher (Optional) .....5-20

**Idler End Components**

Beginning with Serial #A59530100






## PLANTER TUBE-CONVEYOR — Parts

### Idler End Components

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	900608	Idler Pulley	1	
2	TA0-903088-0	Bearing w/Zerk	4	
3	23912B	Adjustment Plate	1	
4	9388-024	Carriage Bolt, 5/16-18UNC x 3/4	4	Grade 5
5	9394-004	Hex Nut, 5/16-18	16	Grade 5
6	9404-019	Lock Washer, 5/16	20	
7	9500310	Idler Cover	3	
8	9394-006	Hex Nut, 3/8-16UNC	10	Grade 5
9	24756	Poly Strip	2	
10	97420	Flange Screw, 1/4-20UNC x 3/4	20	Grade 5
11	97189	Hex Nut/Large Flange, 1/4-20UNC	20	
12	TA0-907104-0	Capscrew, 3/8-16UNC x 1 3/4 (Full Threaded)	1	Grade 5
13	900779	Conveyor Belt 8" Wide x 37'-1" Long	1	
	9501506	Splice Kit	-	
14	23923B	Cleanout Door Weldment	1	
15	TA0-908335-0	Rivet, 3/16 x 3/8	5	
16	TA1-906109-0	Decal, "Warning (Moving Parts)"	2	
17	9388-027	Carriage Bolt, 5/16-18UNC x 1 1/2	8	Grade 5
18	27165B	Bottom Shield	1	
19	902340	Rivet Nut 1/4-20UNC	8	
20	91257	Flange Nut 5/16-18UNC	24	

**Idler End Components**

Serial #A59530099 and Below




# PLANTER TUBE-CONVEYOR — Parts

## Idler End Components

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2005362B	Conveyor Weldment	1	
2	TA1-906109-0	Decal, WARNING (Moving Parts)	2	
3	95839	Decal, WARNING (Pinch Point)	2	
4	900608	Idler Pulley	1	
5	TA0-903088-0	Bearing w/Zerk	4	
6	93415	Grease Zerk 90°	2	
7	23912B	Adjustment Plate	1	
8	9388-024	Carriage Bolt 5/16-18UNC x 3/4	4	
9	9388-027	Carriage Bolt 5/16-18UNC x 1 1/2	8	
10	9394-004	Hex Nut 5/16-18UNC	16	
11	9404-019	Lock Washer 5/16"	16	
12A	23735B	Idler Cover (Square Style)	3	
	9500310	Idler Cover (Rounded Style)		
	91257	Large Flange Hex Nut 5/16-18UNC		
13	9394-006	Hex Nut 3/8-16UNC	10	
14	24756	Poly Strip	2	
15	97420	Flange Screw 1/4-20UNC x 3/4	14	
16	97189	Large Flange Hex Nut 1/4-20UNC	18	
17	TA0-907104-0	Capscrew 3/8-16UNC x 1 3/4	1	Full Threaded-Grade 5
18	9405-064	Flat Washer 1/4 USS	4	
19	9936	Locknut 1/4-20UNC	19	
20	900779	Conveyor Belt	1	
21	24048B	Bottom Shield	1	
22	9390-001	Capscrew 1/4-20UNC x 1/2	16	Grade 5
23	24077	Control Rod Weldment	1	
24	23698	Control Rod	1	
25	23701	Coupler 5/8 OD x .313 ID x 1 1/4	1	
26	24266	Friction Block	2	
27	9388-004	Carriage Bolt 1/4-20UNC x 1 1/4	1	
28	901056	Wing Nut Nylon 1/4-20UNC	1	
29	TA0-914793-0	Knob	1	
30	23923B	Cleanout Door Weldment	1	
31	TA0-908335-0	Rivet 3/16 x 3/8	5	

Hopper Components

Beginning with Serial #A59530100




# PLANTER TUBE-CONVEYOR — Parts

## Hopper Components

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	91256	Screw/Large Flange, 5/16-18UNC x 3/4	12	GRADE 5
2	24964	Brush Holder	1	
3	901111	Nylon Brush	1	
4	24620B	Strap 3/4 x 17 1/2	2	
5	91257	Hex Nut/ Large Flange, 5/16-18UNC	14	GRADE 5
6	9090-030	Capscrew, 5/16-18UNC x 1	2	GRADE 5
7	26865	Seal	1	
8	28400B	Guard	1	
9	28486B	Strap 3/4 x 7 1/2	1	
10	24554B	Pivot Weldment	1	
11	24576B	Handle Weldment	1	
12	24578	Pin Weldment	1	
13	25434B	Shim Plate	2	
14	9807	Locknut, 5/16-18UNC	2	
15	9800	Locknut, 1/2-13UNC	2	
16	24550	Bushing	2	
17	24986	Poly Strip	2	
18	901044	Screw/Small Flange, 5/16-18UNC x 1	4	GRADE 5
19	9390-055	Capscrew, 3/8-16UNC x 1	6	GRADE 5
20	9928	Locknut, 3/8-16UNC	3	
21	26918B	Upper Hopper Frame Tube	1	S/N A53950100 & Up
	24549B	Upper Hopper Frame Tube	1	S/N A53950100 & Below
22	9390-032	Capscrew, 5/16-16UNC x 1 1/2	2	GRADE 5
23	92928	Grip/Handle Bar, 3/4 ID x 4.8	2	
24	9390-101	Capscrew, 1/2-13UNC x 1 1/2	2	GRADE 5
25	9405-088	Flat Washer, 1/2 USS Plt	2	
26	27715	Hopper Cover, Vinyl w/Bungee Cord	1	S/N A53950100 & Up
	901472	Hopper Cover, Vinyl		S/N A53950100 & Below
27	902421	Hopper, Vinyl	1	S/N A53950100 & Up
	901058	Hopper, Vinyl		S/N A53950100 & Below
28	26588B	Hopper Lift Stand Bundle (Optional)	1	
29	26574B	Post Weldment	1	
30	900803	Bent Pin w/Hairpin Cotter	2	
31	26587	Bushing	1	
32	9405-104	Flat Washer, 3/4	2	
33	9390-109	Capscrew, 1/2-13UNC x 3 1/2	1	
34	9800	Locknut, 1/2-13UNC	1	
35	9928	Locknut, 3/8-16UNC	5	
36	9390-064	Capscrew, 3/8-16UNC x 3 1/4	1	
37	9390-053	Capscrew, 3/8-16UNC x 3/4	4	
38	26572B	Tube w/Holes	1	
39	26586B	Bracket w/Holes	2	
40	27717B	Hopper Bundle	-	Includes Items 21, 26, 27

Hopper Components

Serial #A59530099 & Below




# PLANTER TUBE-CONVEYOR — Parts

## Hopper Components

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	91256	Screw/Large Flange, 5/16-18UNC x 3/4	12	GRADE 5
2	24964	Brush Holder	1	
3	901111	Nylon Brush	1	
4	24620B	Strap 3/4 x 17 1/2	2	
5	91257	Hex Nut/ Large Flange, 5/16-18UNC	14	GRADE 5
6	9090-030	Capscrew, 5/16-18UNC x 1	2	GRADE 5
7	26865	Seal	1	
8	28400B	Guard	1	
9	28486B	Strap 3/4 x 7 1/2	1	
10	24554B	Pivot Weldment	1	
11	24576B	Handle Weldment	1	
12	24578	Pin Weldment	1	
13	24646TS	Plate 14GAx3 1/4x11 3/4	1	
14	25434B	Shim Plate	2	
15	9807	Locknut, 5/16-18UNC	2	
16	9800	Locknut, 1/2-13UNC	2	
17	24550	Bushing	2	
18	24986	Poly Strip	2	
19	901044	Screw/Small Flange, 5/16-18UNC x 1	4	GRADE 5
20	9390-055	Capscrew, 3/8-16UNC x 1	6	GRADE 5
21	9928	Locknut, 3/8-16UNC	3	
22	26918B	Upper Hopper Frame Tube	1	S/N A53950100 & Up
	24549B	Upper Hopper Frame Tube	1	S/N A53950100 & Below
23	9390-032	Capscrew, 5/16-16UNC x 1 1/2	2	GRADE 5
24	97189	Hex Nut/Large Flange 1/4-20UNC	2	GRADE 5
	97420	Flange Screw 1/4-20UNC x 3/4	2	GRADE 5
25	92928	Grip/Handle Bar, 3/4 ID x 4.8	2	
26	9390-101	Capscrew, 1/2-13UNC x 1 1/2	2	GRADE 5
27	9405-088	Flat Washer, 1/2 USS Plt	2	
28	27715	Hopper Cover, Vinyl w/Bungee Cord	1	S/N A53950100 & Up
	901472	Hopper Cover, Vinyl		S/N A53950100 & Below
29	902421	Hopper, Vinyl	1	S/N A53950100 & Up
	901058	Hopper, Vinyl		S/N A53950100 & Below
30	26588B	Hopper Lift Stand Bundle (Optional)	1	
31	26574B	Post Weldment	1	
32	900803	Bent Pin w/Hairpin Cotter	2	
33	26587	Bushing	1	
34	9405-104	Flat Washer, 3/4	2	
35	9390-109	Capscrew, 1/2-13UNC x 3 1/2	1	
36	9800	Locknut, 1/2-13UNC	1	
37	9928	Locknut, 3/8-16UNC	5	
38	9390-064	Capscrew, 3/8-16UNC x 3 1/4	1	
39	9390-053	Capscrew, 3/8-16UNC x 3/4	4	
40	26572B	Tube w/Holes	1	
41	26586B	Bracket w/Holes	2	
42	27717B	Hopper Bundle	-	Includes Items 21, 26, 27

# PLANTER TUBE-CONVEYOR — Parts

## Mounting Brackets & Pivot Cart/Slide Rail Components





## PLANTER TUBE-CONVEYOR — Parts


### Mounting Brackets & Pivot Cart/Slide Rail Components

ITEM	DESCRIPTION	PART NO.
1	Decal, WARNING (Pinch Point)	95839
2	Decal UM Oval	901607
3	Decal UNVERFERTH Logo	901725
4	Post Weldment 14 3/4" Lg.	24413B
5	Bracket/Bent Bar	25156B
6	Bent Pin 3/4" Dia.	25157
7	Pivot Tube Weldment	25160B
8	Tube 7 3/4" Lg.	25307
9	Pivot Collar Weldment	25376B
10	Channel Weldment	26564B
11	Transport Mount Weldment	25155B
12A	Rail Assembly Includes Items: 13A, 14 through 33	26579B
12B	Rail Assembly With Latch Handle Includes Items: 13B, 14 through 28, 32, 33, 51 through 59	2003135B
13A	Slide Rail Weldment	23545B
13B	Slide Rail Weldment	2003115B
14	Pivot Car Weldment with Decal	26566B
15	Grease Zerk	91160
16	Decal WARNING (Pinch Point)	97048
17	Roller & Bearing Assembly Includes Items: 18 & 21 NOT SHOWN	27178
18	Roller	24254
19	Retaining Ring	900161
20	Roller	24246
21	Bearing	95789
22	Capscrew (Grade 5) 5/8-11 x 8" Lg.	9390-140
23	Locknut 5/8-11	9801
24	Capscrew (Grade 5) 5/8-11 x 2" Lg.	9390-124
25	Rubber Wheel with Bearing	99918
26	Capscrew (Grade 5) 3/8-16 x 2 1/4" Lg.	9390-060
27	Flat Washer 3/8" USS	9405-076
28	Locknut 3/8-16	9928
29	S-Hook	98054
30	Sash Chain	23660
31	Hitch Pin 1/2" Dia. x 2 3/4"	99836
32	Decal WARNING (Pinch Point)	97048
33	Locknut 5/8-11	95905

ITEM	DESCRIPTION	PART NO.
34	Capscrew (Grade 5) 5/16-18 x 1" Lg.	9390-030
35	Locknut 5/16-18	9807
36	Capscrew (Grade 5) 3/8-16UNC x 1	9390-055
37	Locknut 3/8-16	9928
38	Capscrew (Grade 5) 3/8-16 x 3 1/2" Lg.	9390-065
39	Hairpin Cotter 3" Lg.	95959
40	Flange Capscrew (Grade 5) 5/8-11 x 1 1/2" Lg.	9390-122
41	Capscrew (Grade 5) 3/4-10 x 8" Lg.	9390-449
42	Locknut 3/4-10	96732
43	Locknut 5/8-11UNC	9801
44	Hand Rail Weldment	23730G
45	Screw/Large Flange (Grade 5) 3/8-16UNC x 1	91262
46	Capscrew M8-1.25Px30 For Securing Slide Rail	94917-073
47	Hex Nut M8-1.25P For Securing Slide Rail	97692
48	Refuge Tank Post Kit Includes Pivot Tube Weldment & Items: 10, 37, 38	26618B
	Pivot Tube Weldment	26563B
49	Capscrew 1/4-20UNC x 3/4 For Battery Access Door Hinge	9390-003
50	Large Flange Hex Nut 1/4-20UNC For Battery Access Door Hinge	97189
51	Shaft 3/4" Dia. x 6 1/4	2003128
52	Roll Pin 5/16" Dia. x 1 1/4	9392-153
53	Shaft 1 1/4" Dia. x 8 1/2	2003119
54	Draw Hook 5/8" Dia.	2003118
55	Hex Jam Nut 5/8-18UNF	9395-013
56	Latch Handle Weldment	2003123B
57	Lynch/Klik Pin 7/16" Dia.	901170
58	Bushing 1 5/8" Dia.	2003138
59	Split Ring 15/16" Dia.	9501116
60	Shim	2005843B
	Shim Kit	2006141B
61	Channel Bracket	2009884B
62	Capscrew (Grade 5) 5/16-18 x 1 1/4" Lg.	9390-031

# PLANTER TUBE-CONVEYOR — Parts

## Extension, Horizontal, & Vertical Post




**Extension, Horizontal, & Vertical Post**

<b>ITEM</b>	<b>DESCRIPTION</b>	<b>PART NO.</b>
1	Capscrew 5/16-18 x 1"	9390-030
2	Capscrew 5/16-18 x 1 1/4"	9390-031
3	Capscrew 5/8-11 x 7" (For 20" Row Spacing)	9390-138
	Capscrew 5/8-11 x 4" (For 30/15" Row Spacing)	9390-132
4	Flat Washer 3/8" SAE	9405-074
5	Locknut 5/8-11	9801
6	Locknut 5/16-18	9807
7	Locknut 3/8-16	9928
8	Mounting Plate	23512B
9	Strap w/Holes	23639B
10	Vertical Post Weldment	23707B
11	Horizontal Arm Weldment	23710B
12	Post Weldment 14 3/4"	24413B
13	Self Drilling Screw 3/8-16 x 1"	96972
14	U-Bolt 3/8-16 x 4" Lg.	900076
15	U-Bolt 3/8-16 x 3" Lg.	900077
16	Channel Bracket	2009884B

# PLANTER TUBE-CONVEYOR — Parts


## Discharge Spout Components

Beginning with Serial #A59530100



OM04426

## Telescopic Spout Components



ITEM	PART NO.	DESCRIPTION
1	27629	4-6' x 6" Diameter Telescopic Spout w/Sock
2	98060	Clamp
3	22577	Sock, 5 3/4" Dia. x 8" Lg


# PLANTER TUBE-CONVEYOR — Parts

## Discharge Spout Components

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2005362B	Conveyor Weldment	1	
2	TA1-906109-0	Decal, "WARNING (Moving Parts)"	2	
3	TA0-903088-0	Bearing w/Zerk	4	
4	93415	Grease Zerk 90°	2	
5	9388-027	Carriage Bolt, 5/16-18UNC x 1 1/2 (Gr. 5)	8	
6	9394-004	Hex Nut, 5/16-18UNC (Gr. 5)	16	
7	9404-019	Lock Washer, 5/16	16	
8	9500310	Idler Cover	3	
9	9394-006	Hex Nut, 3/8-16UNC (Gr. 5)	10	
10	97420	Flange Screw, 1/4-20UNC x 3/4 (Gr. 5)	14	
11	97189	Large Flange Hex Nut, 1/4-20UNC (Gr. 5)	18	
12	9388-051	Carriage Bolt, 3/8-16 x 1 (Gr. 5)	8	
13	9404-021	Lock Washer, 3/8	16	
14	9405-076	Flat Washer, 3/8 USS PLT	12	
15	23994B	Adjustment Plate	1	
16	24091B	Bracket Weldment	1	
17	93400	Capscrew, 1/2-13UNC x 4 1/2 (Gr. 5)	2	
18	9394-010	Hex Nut, 1/2-12UNC (Gr. 5)	2	
19	901077	Drive Pulley	1	
20	24755	Poly Strip	2	
21	24260	Seal	2	
22	901101	Flange Screw, 1/4-20UNC x 1 (Gr. 5)	4	
23	23918B	Top Shield	1	
24	91256	Large Flange Screw, 5/16-18UNC x 3/4	14	
25	22018	Bushing	2	
26	9390-003	Capscrew, 1/4-20UNC x 3/4 (Gr. 5)	3	
27	9405-064	Flat Washer, 1/4 USS	4	
28	9936	Locknut, 1/4-20UNC	19	
29	901046	Knob	2	
30	26215B	Deflector Weldment	1	
31	9001501	Keystock, 1/4 x 1/4 x 1	1	
32	23690	Coupler	1	
33	91604B	Hydraulic Motor	1	
34	9390-055	Capscrew, 3/8-16UNC x 1 (Gr. 5)	6	
35	9390-059	Capscrew, 3/8-16UNC x 2 (Gr. 5)	1	
36	9928	Locknut, 3/8-16UNC	3	
37	9473	Self-Drilling Screw, 1/4-20UNC x 3/4	4	
38	24399B	Shield	2	
39	95488	Hydraulic Valve Control	1	
40	9390-034	Capscrew, 5/16-18UNC x 2 (Gr. 5)	4	
41	23693	Handle, 3/8" Dia.	1	
42	9392-056	Roll Pin, 1/8D x 3/4	2	
43	24077	Control Rod Weldment	1	
44	900209	Cap/Vinyl Handle	1	
45	24414B	Bracket	1	
46	26673B	Spout Weldment	1	
47	91306	O-Rings	2	
48	91257	Flange Nut 5/16-18UNC	24	

**Discharge Spout Components**

Serial #A59530099 & Below




# PLANTER TUBE-CONVEYOR — Parts

## Discharge Spout Components

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2005362B	Conveyor Weldment	1	
2	TA1-906109-0	Decal, "WARNING (Moving Parts)"	2	
3	TA0-903088-0	Bearing w/Zerk	4	
4	93415	Grease Zerk 90°	2	
5	9388-027	Carriage Bolt, 5/16-18UNC x 1 1/2 (Gr. 5)	8	
6	9394-004	Hex Nut, 5/16-18UNC (Gr. 5)	16	
7	9404-019	Lock Washer, 5/16	16	
8	23735B	Idler Cover	3	
9	9394-006	Hex Nut, 3/8-16UNC (Gr. 5)	10	
10	97420	Flange Screw, 1/4-20UNC x 3/4 (Gr. 5)	14	
11	97189	Large Flange Hex Nut, 1/4-20UNC (Gr. 5)	18	
12	9388-051	Carriage Bolt, 3/8-16 x 1 (Gr. 5)	8	
13	9404-021	Lock Washer, 3/8	16	
14	9405-076	Flat Washer, 3/8 USS PLT	12	
15	23994B	Adjustment Plate	1	
16	24091B	Bracket Weldment	1	
17	93400	Capscrew, 1/2-13UNC x 4 1/2 (Gr. 5)	2	
18	9394-010	Hex Nut, 1/2-12UNC (Gr. 5)	2	
19	901077	Drive Pulley	1	
20	24755	Poly Strip	2	
21	24260	Seal	2	
22	901101	Flange Screw, 1/4-20UNC x 1 (Gr. 5)	4	
23	23918B	Top Shield	1	
24	91256	Large Flange Screw, 5/16-18UNC x 3/4	14	
25	22018	Bushing	2	
26	9390-003	Capscrew, 1/4-20UNC x 3/4 (Gr. 5)	3	
27	9405-064	Flat Washer, 1/4 USS	4	
28	9936	Locknut, 1/4-20UNC	19	
29	901046	Knob	2	
30	26215B	Deflector Weldment	1	
31	9001501	Keystock, 1/4 x 1/4 x 1	1	
32	23690	Coupler	1	
33	91604B	Hydraulic Motor	1	
34	9390-055	Capscrew, 3/8-16UNC x 1 (Gr. 5)	6	
35	9390-059	Capscrew, 3/8-16UNC x 2 (Gr. 5)	1	
36	9928	Locknut, 3/8-16UNC	3	
37	9473	Self-Drilling Screw, 1/4-20UNC x 3/4	4	
38	24399B	Shield	2	
39	95488	Hydraulic Valve Control	1	
40	9390-034	Capscrew, 5/16-18UNC x 2 (Gr. 5)	4	
41	23693	Handle, 3/8" Dia.	1	
42	9392-056	Roll Pin, 1/8D x 3/4	2	
43	24077	Control Rod Weldment	1	
44	900209	Cap/Vinyl Handle	1	
45	24414B	Bracket	1	
46	26673B	Spout Weldment	1	
47	91306	O-Rings	2	

# PLANTER TUBE-CONVEYOR — Parts

## Hydraulic Components



ITEM	PART NO.	DESCRIPTION
1	9404-019	Lock Washer, 5/16"
2	9405-076	Flat Washer 3/8 USS
3	9390-055	Capscrew (Grade 5) 3/8-16UNC x 1
4	9928	Locknut 3/8-16UNC
5	9390-034	Capscrew (Grade 5) 5/16-18UNC x 2"
6	23693	Handle
7	9392-056	Roll Pin 1/8" Dia. x 3/4"
8	23698	Control Rod 92 3/16" Long
9	23701	Coupler 1 1/4" Long
10	24266	Friction Block
11	TA0-914793-0	Knob 1" Dia. Plastic, 5/16-18 Threaded
12	91604B	Hydraulic Motor 6 CU. IN.
	91687	Seal Kit for Hyd Motor
13	91511	Dust Cap


ITEM	PART NO.	DESCRIPTION
14	91383	Coupling 3/4-16 O-Ring Female
15	9864	Adapter 3/4-16 JIC Male x 3/4-16 O-Ring Male
16	94909	In-Line Check Valve with 3/4-16 O-Ring Ports
17	9863	Elbow 90°
18	23851	Hose 1/2 x 240" Long
19	901056	Wing Nut Nylon 1/4-20UNC
20	900209	Vinyl Handle
21	25755	Control Rod Weldment
22	9388-005	Carriage Bolt (Grade 5) 1/4-20UNC x 1 1/2
23	95488	Hyd Control Valve with 3/4-16 Ports
	96918	Seal Kit for Hyd Control Valve
24	93586	Elbow 45°
25	24414B	Telescopic Spout Bracket




**Flow Control Valve Kit Components**

**OPEN CENTER SYSTEM**

OM23886




**CLOSED CENTER SYSTEM**



ITEM	PART NO.	DESCRIPTION
	23669	Flow-Control Valve Kit For Open-Center Systems & Closed-Center Systems
1	9000832	Flow Control Valve Less Handle
2	900241	Handle
3	93588	Tee
4	93683	Elbow 90°
5	9390-011	Capscrew 1/4-20 x 2 1/2" Lg.
6	95144	Hose 1/2 x 20" Lg.
7	97742	Hose 1/2 x 18" Lg.
8	9864	Adapter
9	9936	Locknut 1/4-20

**Conveyor Options**

**Belt Stretcher**  
**(Part No. TA4-114400-0)**



**Notes**



***Unverferth***<sup>®</sup>

***Manufacturing Company, Inc.***

[www.unverferth.com](http://www.unverferth.com)