



Fertilizer Applicator

NutriMax® Liquid Applicator
1800 & 2600 Models

Serial Number B40640100 & Higher

Operator's Manual
Part No. 415257

Refer to Part No. 415258 for Parts Catalog

Foreword



This symbol identifies important safety messages. When you see it, read the message that follows and be alert to the possibility of personal injury.

Remember, safety instructions stated in this manual are for your protection. Read them carefully and follow them closely when working around or using this machine.

Read and study this manual completely before attempting to operate this implement. Take this manual to the field for handy reference when operating, adjusting, or servicing your machine.

When referenced, “Right-Hand” (RH) and “Left-Hand” (LH) side of the machine are determined by standing behind the machine and facing in the direction of travel.



Product Information

When ordering parts or when requesting further information or assistance, always give the following information:

- Machine name
- Model
- Serial number


All products manufactured by Unverferth Mfg. Co., Inc. are warranted to be free from material and workmanship defects for one full year from time of consumer delivery. Your local dealer will gladly assist you with any warranty questions.

Please fill out and retain this portion for your records.

Purchase Date _____ Model _____ Serial Number _____

Dealer _____ City _____

Dealer Contact _____ Phone _____



IMPORTANT

- *The information, specifications, and illustrations in the manual are based on information available at the time it was written. Due to continuing improvements in the design and manufacture of Unverferth products, all specifications and information contained herein are subject to change without notice.*

Table of Contents

Introduction

| | |
|--------------------------|---|
| Foreword..... | 2 |
| Product Information..... | 3 |

Section I Safety

| | |
|------------------------------------|------|
| General Hazard Information..... | 1-2 |
| Safety Decals..... | 1-3 |
| Following Safety Instructions..... | 1-4 |
| Before Operating..... | 1-5 |
| Before Servicing..... | 1-6 |
| During Operation..... | 1-7 |
| Before Transporting..... | 1-7 |
| During Transport..... | 1-7 |
| Pressurized Oil..... | 1-8 |
| Chemical Hazards..... | 1-9 |
| Clean Water Tank..... | 1-9 |
| Preparing for Emergencies..... | 1-10 |
| Wearing Protective Equipment..... | 1-10 |

Table of Contents

**Section II
Set Up**

Pre-Delivery Checklist..... 2-2

Dealer Set Up 2-3

Closer Wheel Tank Guard Installation (Optional)..... 2-11

Tongue Adjustment 2-14

 Units with Fixed Position Hitch (80'/88'/90' Units) 2-14

 Units Equipped with Steerable Hitch 2-14

Axle Tread Settings 2-15

 Wheel Spacing Combinations 2-15

 Adjustment 2-16

 Tracks Toe In Adjustment..... 2-19

Belt Conditioning 2-21

Toolbar Functions 2-22

Controller Calibration Settings..... 2-22

 “BOOM CAL” Monitor Settings 2-22

Pump Set Up 2-23

 Setting the Pump Pressure (PWM Pump)..... 2-23

RCM Set Up 2-24

 PWM Pump Start Up Procedure (Rate Control Module)..... 2-30

Applicator Calibration..... 2-31

 Determine Required Nozzle Size 2-31

Overhead Layouts

 Legend 2-32

 40' Toolbar - 20" Row Spacing For 1800 NutriMax 2-33

 44' Toolbar - 22" Row Spacing For 1800 NutriMax 2-34

 40' Toolbar - 30" Row Spacing For 1800 NutriMax 2-35

 40' Toolbar - Double Coulter 30" Row Spacing For 1800 NutriMax 2-36

 40' Toolbar - 36" Row Spacing For 1800 NutriMax 2-37

 40' Toolbar - 38" Row Spacing For 1800 NutriMax 2-38

 60' Toolbar - 20" Row Spacing Offset Coulter Post 2-39

 60' Toolbar - 20" Row Spacing Straight Coulter Post 2-40

 66' Toolbar - 22" Row Spacing Offset Coulter Post 2-41

 66' Toolbar - 22" Row Spacing Straight Coulter Post 2-42

 60' Toolbar - 30" Row Spacing Offset Coulter Post 2-43

 60' Toolbar - 30" Row Spacing Straight Coulter Post 2-44

 60' Toolbar - 30" Row Spacing Double Coulter Post..... 2-45

 80' Toolbar - 20" Row Spacing Straight Coulter Post 2-46

 80' Toolbar - 30" Row Spacing Offset Coulter Post 2-47

 80' Toolbar - 30" Row Spacing Straight Coulter Post 2-48

 88' Toolbar - 22" Row Spacing Offset Coulter Post 2-49

 88' Toolbar - 22" Row Spacing Straight Coulter Post 2-50

 90' Toolbar - 30" Row Spacing Offset Coulter Post 2-51

 90' Toolbar - 30" Row Spacing Straight Coulter Post 2-52

FOR INDUCTOR INFORMATION, PLEASE REFER TO YOUR INDUCTOR MANUAL.

Table of Contents

**Section III
Operation**

| | |
|--|------|
| Preparing Tractor | 3-2 |
| Preparing Applicator | 3-2 |
| Hardware..... | 3-2 |
| Pivot Pins | 3-2 |
| Hitch | 3-2 |
| Hydraulic System..... | 3-2 |
| Tires/Wheels..... | 3-3 |
| Lubrication | 3-3 |
| Hitching to the Tractor..... | 3-4 |
| Drawbar Hitching (60'/66'/80'/88'/90' Toolbars) | 3-4 |
| Drawbar Hitching (1800 - 40'/44' Toolbars) | 3-5 |
| Transport Chain | 3-6 |
| Hydraulic Connections..... | 3-7 |
| Applicator Solution Pump Hydraulics..... | 3-7 |
| Toolbar Hydraulics..... | 3-9 |
| Electrical Connection..... | 3-9 |
| Steerable Hitch..... | 3-9 |
| Jack Usage..... | 3-10 |
| Parked Position (60'/66'/80'/88'/90' Toolbars) | 3-10 |
| Transport Position (60'/66'/80'/88'/90' Toolbars)..... | 3-10 |
| Parked Position (1800 - 40'/44' Toolbars) | 3-11 |
| Transport Position (1800 - 40'/44' Toolbars)..... | 3-11 |
| Transporting | 3-12 |
| Drawbar Connection | 3-12 |
| Toolbar Operation (60'/66'/80'/88'/90' Toolbars)..... | 3-13 |
| Unfolding..... | 3-13 |
| Folding | 3-13 |
| Raising/Lowering in the Field | 3-14 |
| Wing Fold Stops..... | 3-14 |
| Toolbar Operation (1800 - 40'/44' Toolbars)..... | 3-15 |
| Unfolding..... | 3-15 |
| Folding | 3-15 |
| Raising/Lowering in the Field | 3-16 |
| Depth Stop/Bushings | 3-16 |
| Dual Width Toolbar | 3-17 |
| Filling Applicator..... | 3-18 |
| Quick Fill | 3-18 |
| Inductor..... | 3-19 |
| Basic Operation | 3-19 |
| Tank Mixing..... | 3-19 |
| Jug and Inductor Tank Rinsing..... | 3-20 |
| Orifice and Nozzle Installation | 3-21 |
| Flow Ball Indicator | 3-22 |

Table of Contents

**Section IV
Maintenance**

Lubrication (60'/66'/80'/88'/90' Toolbars).....4-2
 Lubrication (1800 - 40'/44' Toolbars).....4-4
 Applicator Maintenance.....4-5
 Seasonal Storage.....4-5
 Purging A Hydraulic System.....4-6
 Hydraulically Driven Centrifugal Pump4-7
 Tracks4-8
 Toolbar & Wing Adjustments4-8
 Main Wing & Wing Mast Adjustment.....4-9
 Stop Bolts.....4-9
 Slider Adjustment4-9
 Diverter Valve (60'/66'/80'/88'/90' Toolbars)4-10
 Diverter Valve (40' Toolbar / 1800 Model)4-10
 Center Toolbar & Main Wing Down Pressure.....4-11
 Pivoting Coulter Tube Adjustment.....4-12
 Shim Adjustment4-12
 Stop Bolt Adjustment4-12
 Outer Wing Adjustment.....4-12
 Wing Stop & Shim Adjustment.....4-12
 Outer Wing Down Pressure.....4-13
 Sequence Valve Adjustment (40' Toolbar / 1800 Model).....4-14
 Unfolding to Working Position.....4-14
 Folding to Transport Position4-14
 Sequence Valve Adjustment (60'/66'/80'/88'/90' Toolbars).....4-15
 Unfolding to Working Position.....4-15
 Folding to Transport Position4-15
 Center Toolbar & Wing Mast Cylinder End Replacement (80'/88'/90' Toolbars).....4-16
 Coulter Hub Adjustment and Replacement4-19
 Coulter Spring Replacement.....4-21
 Coulter Post Mount Bracket Adjustment.....4-22
 Closer Wheel Adjustment & Replacement (Optional)4-23
 Filters (1800 - 40'/44' Toolbars)4-25
 Primary Filter.....4-25
 Secondary Filter.....4-26
 Filters (60'/66'/80'/88'/90' Toolbars)4-27
 Primary Filter.....4-27
 Secondary Filter.....4-28
 Winterizing4-29
 Schematics.....4-30
 Troubleshooting4-42
 Wheel, Hub and Spindle Disassembly and Assembly.....4-43
 Wheels and Tires.....4-45
 Wheel Nut Torque Requirements.....4-45
 Tire Pressure4-46
 Tire Warranty4-47
 Tracks4-47
 Equalizer Track System4-47
 Track Warranty.....4-47
 Complete Torque Chart.....4-48
 Hydraulic Fittings - Torque and Installation4-49

Notes

Section I Safety

| | |
|-------------------------------------|------|
| General Hazard Information | 1-2 |
| Safety Decals | 1-3 |
| Following Safety Instructions | 1-4 |
| Before Operating | 1-5 |
| Before Servicing | 1-6 |
| During Operation | 1-7 |
| Before Transporting | 1-7 |
| During Transport | 1-7 |
| Pressurized Oil | 1-8 |
| Chemical Hazards | 1-9 |
| Clean Water Tank | 1-9 |
| Preparing for Emergencies | 1-10 |
| Wearing Protective Equipment | 1-10 |

General Hazard Information

No accident-prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

A large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the field, or in the industrial plant, can be safer than the person who is at the controls. If accidents are to be prevented--and they can be prevented--it will be done by the operators who accept the full measure of their responsibility.

It is true that the designer, the manufacturer, and the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that, "the best kind of a safety device is a careful operator." We, at Unverferth Mfg. Co., Inc. ask that you be that kind of operator.



REMEMBER:
THINK SAFETY
A CAREFUL OPERATOR IS THE
BEST INSURANCE AGAINST AN
ACCIDENT!

SIGNAL WORDS



INDICATES AN EXTREMELY HAZARDOUS SITUATION OR ACTION THAT WILL RESULT IN SERIOUS INJURY OR DEATH.



INDICATES A HAZARDOUS SITUATION OR ACTION THAT COULD RESULT IN SERIOUS INJURY OR DEATH.



INDICATES AN UNSAFE SITUATION OR ACTION THAT MAY RESULT IN PERSONAL INJURY.




Is used for instruction on operating, adjusting, or servicing a machine.

Safety Decals

WARNING

- REPLACE LOST, DAMAGED, PAINTED, OR UNREADABLE DECALS IMMEDIATELY. IF PARTS THAT HAVE DECALS ARE REPLACED, ALSO MAKE SURE TO INSTALL NEW DECALS. THESE DECALS INFORM AND REMIND THE OPERATOR WITH OPERATIONAL INFORMATION AND SAFETY MESSAGES.



Following Safety Instructions


- Read and understand this operator's manual before operating.



- All machinery should be operated only by trained and authorized personnel.

- To prevent machine damage, use only attachments and service parts approved by the manufacturer.

- Always shut tractor engine off and remove key before servicing.



- Avoid personal attire such as loose fitting clothing, shoestrings, drawstrings, pants cuffs, long hair, etc., that may become entangled in moving parts.


- Do not allow anyone to ride on the implement. Make sure everyone is clear before operating machine or towing vehicle.




- Never attempt to operate implement unless you are in driver's seat.



Before Operating

- Do not stand between towing vehicle and implement during hitching.

- Always make certain everyone and everything is clear of the machine before beginning operation.
- Ensure that all applicable safety decals are installed and legible.
- When working around the implement, be careful not to be cut by sharp edges.
- Secure drawbar pin with safety lock and lock tractor drawbar in fixed position.
- This applicator is intended to apply only agricultural fertilizers. Attempting to apply other liquids may cause equipment damage and introduce unexpected personal hazards.
- When operating applicators on sidehill conditions, it is recommended that the wheel spacing be set as wide as possible for stability.
- Ensure that the towing vehicle drawbar has sufficient strength to support the draft and vertical tongue load of a fully-loaded applicator.
- Hitch applicator to towing vehicle and clear all personnel from the surrounding area before folding and unfolding wings.
- Ensure tank access covers are fully closed before beginning or resuming operation.
- Residual pressure may exist in applicator plumbing even when unit is not in use. Remove pressure before servicing any plumbing.

Before Servicing

- Avoid working under an implement; however, if it becomes absolutely unavoidable, make sure the implement is safely blocked. 

- Ensure that all applicable safety decals are installed and legible.

- When working around the implement, be careful not to be cut by sharp edges.

- To prevent personal injury or death, always ensure that there are people who remain outside the applicator to assist the person working inside, and that all safe workplace practices are followed. There are restricted mobility and limited exit paths when working inside the implement.

- Secure drawbar pin with safety lock and lock tractor drawbar in fixed position.

- Explosive separation of a tire and rim can cause serious injury or death. Only properly trained personnel should attempt to service a tire and wheel assembly.

- Add sufficient ballast to tractor to maintain steering and braking control at all times. Do not exceed tractor's lift capacity or ballast capacity.

- Check equipment for leaks. Repair any leaks before beginning or resuming operation.

During Operation

- Comply with all laws and product label directions governing safe product application.
- Regulate speed to field conditions. Maintain complete control at all times.
- Never service or lubricate equipment when in operation.
- Keep away from overhead power lines. Electrical shock can cause serious injury or death.
- Use extreme care when operating close to ditches, waterways, fences, or on hillsides.
- Do not leave towing vehicle unattended with engine running.

Before Transporting

- Secure transport chain to towing vehicle before transporting. **DO NOT** transport without chain.
- Check for proper function of all available transport lights. Make sure that all reflectors are clean and in place on machine. Make sure the SMV emblem and SIS decals are visible to approaching traffic.
- This applicator is not equipped with brakes. Ensure that the towing vehicle has adequate weight and braking capacity to tow this unit.

During Transport

- Comply with all laws governing highway safety when moving machinery.
- Use transport lights as required by all laws to adequately warn operators of other vehicles.
- Use good judgment when transporting equipment on highways. Regulate speed to road conditions and maintain complete control.
- Maximum on road speed of applicator should never exceed 20 m.p.h. with wheels or 15 m.p.h. with tracks as indicated on the machine. Maximum transport speed of any combination of implements must not exceed the lowest specified speed of the implements in combination. Do not exceed 10 m.p.h. during off-highway travel.
- Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.
- It is probable that this implement is taller, wider and longer than the towing vehicle. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Pressurized Oil

- Relieve pressure before disconnecting hydraulic lines from tractor, loosening any hydraulic fittings or servicing hydraulic system. See hydraulic power unit manual for procedure to relieve pressure.
- High-pressure fluids can penetrate the skin and cause serious injury or death. Seek medical treatment immediately if injured by high-pressure fluids. Use cardboard or wood to detect leaks of hydraulic fluid under pressure.
- Hydraulic system must be purged of air before operating to prevent serious injury or death.
- Do not bend or strike high-pressure lines. Do not install bent or damaged tubes or hoses.
- Repair all oil leaks. Leaks can cause fires, personal injury, and environmental damage.
- Route hoses and lines carefully to prevent premature failure due to kinking and rubbing against other parts. Make sure that all clamps, guards and shields are installed correctly.
- Check hydraulic hoses and tubes carefully. Replace components as necessary if any of the following conditions are found:
 - End fittings damaged, displaced, or leaking.
 - Outer covering chafed/cut or wire reinforcing exposed.
 - Outer covering ballooning locally.
 - Evidence of kinking or crushing of the flexible part of a hose.



Chemical Hazards

- Always wear personal protective equipment when working with or near chemicals. This equipment includes, but is not limited to: protective eye wear, gloves, shoes, socks, long-sleeved shirt, and long pants. Additional protection may be required for many types of chemicals.

- Applicator tanks may contain residual toxic chemicals. **DO NOT ENTER APPLICATOR TANK FOR ANY REASON WITHOUT WEARING PROPER VENTILATION EQUIPMENT.** Failure to do so may result in asphyxiation and death.

- Seek and receive chemical product training prior to using agricultural chemicals.

- Read and understand the entire label of every chemical being applied with this applicator.

- Avoid breathing spray mist or vapor.

- Wash hands before eating, drinking, chewing gum, or using the toilet.

- Remove clothing immediately if chemicals penetrate clothing and contact skin. Wash thoroughly and put on clean clothing.

- Dispose of unused chemical in accordance with chemical label directions and local/national regulations.

Clean Water Tank

- A clean water tank is provided as standard equipment. It is equipped with a spigot for general washing and a hose for emergency eye washing.

- Always keep clean water in tank. Water in clean water tank is not suitable for human consumption.

- For emergency eyewash, pull hose off of the top fitting and flush affected area.



Preparing for Emergencies

- Keep a first aid kit and properly rated fire extinguisher nearby.



- Keep emergency numbers for fire, rescue, and poison control personnel near the phone.



Wearing Protective Equipment

- Wear clothing and personal protective equipment appropriate for the job.



- Wear steel-toed shoes when operating.



- Wear hearing protection when exposed to loud noises.



- Do not wear additional hearing impairing devices such as radio headphones, etc.



Section II Set Up

| | |
|---|------|
| Pre-Delivery Checklist..... | 2-2 |
| Dealer Set Up..... | 2-3 |
| Closer Wheel Tank Guard Installation (Optional)..... | 2-11 |
| Tongue Adjustment..... | 2-14 |
| Units with Fixed Position Hitch (80'/88'/90' Units)..... | 2-14 |
| Units Equipped with Steerable Hitch..... | 2-14 |
| Axle Tread Settings..... | 2-15 |
| Wheel Spacing Combinations..... | 2-15 |
| Adjustment..... | 2-16 |
| Tracks Toe In Adjustment..... | 2-19 |
| Belt Conditioning..... | 2-21 |
| Toolbar Functions..... | 2-22 |
| Controller Calibration Settings..... | 2-22 |
| “BOOM CAL” Monitor Settings..... | 2-22 |
| Pump Set Up..... | 2-23 |
| Setting the Pump Pressure (PWM Pump)..... | 2-23 |
| RCM Set Up..... | 2-24 |
| PWM Pump Start Up Procedure (Rate Control Module)..... | 2-30 |
| Applicator Calibration..... | 2-31 |
| Determine Required Nozzle Size..... | 2-31 |
| Overhead Layouts | |
| Legend..... | 2-32 |
| 40' Toolbar - 20" Row Spacing For 1800 NutriMax..... | 2-33 |
| 44' Toolbar - 22" Row Spacing For 1800 NutriMax..... | 2-34 |
| 40' Toolbar - 30" Row Spacing For 1800 NutriMax..... | 2-35 |
| 40' Toolbar - Double Coulter 30" Row Spacing For 1800 NutriMax..... | 2-36 |
| 40' Toolbar - 36" Row Spacing For 1800 NutriMax..... | 2-37 |
| 40' Toolbar - 38" Row Spacing For 1800 NutriMax..... | 2-38 |
| 60' Toolbar - 20" Row Spacing Offset Coulter Post..... | 2-39 |
| 60' Toolbar - 20" Row Spacing Straight Coulter Post..... | 2-40 |
| 66' Toolbar - 22" Row Spacing Offset Coulter Post..... | 2-41 |
| 66' Toolbar - 22" Row Spacing Straight Coulter Post..... | 2-42 |
| 60' Toolbar - 30" Row Spacing Offset Coulter Post..... | 2-43 |
| 60' Toolbar - 30" Row Spacing Straight Coulter Post..... | 2-44 |
| 60' Toolbar - 30" Row Spacing Double Coulter Post..... | 2-45 |
| 80' Toolbar - 20" Row Spacing Straight Coulter Post..... | 2-46 |
| 80' Toolbar - 30" Row Spacing Offset Coulter Post..... | 2-47 |
| 80' Toolbar - 30" Row Spacing Straight Coulter Post..... | 2-48 |
| 88' Toolbar - 22" Row Spacing Offset Coulter Post..... | 2-49 |
| 88' Toolbar - 22" Row Spacing Straight Coulter Post..... | 2-50 |
| 90' Toolbar - 30" Row Spacing Offset Coulter Post..... | 2-51 |
| 90' Toolbar - 30" Row Spacing Straight Coulter Post..... | 2-52 |

FOR INDUCTOR INFORMATION, PLEASE REFER TO YOUR INDUCTOR MANUAL.

Pre-Delivery Checklist

- For units equipped with single wheels, ensure wheel offset is outward.
- Torque wheel nuts as as specified in MAINTENANCE section.
- Check tire pressure as specified in MAINTENANCE section.
- Check track alignment. Refer to 14” Wide x 80” Long Equalizer® Track manual (411200) for adjustment and alignment procedure.
- Axles are adjusted from shipping position to desired operating width.
- All grease fittings have been lubricated.
- Check to be sure all safety decals are correctly located and legible. Replace if damaged.
- Check to be sure all reflective decals are correctly located.
- Check to be sure SMV emblem and SIS decals are in place and shipping film is removed.
- Check to be sure transport lights are working properly.
- Transport chains are properly installed and hardware is torqued to specification. See “Transport Chain Connection” in OPERATION section.
- Check hydraulic components for leaks.
- Check all plumbing components for leaks.
- Paint all parts scratched during shipment and dealer set up.

Dealer Set Up



WARNING

- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- FALLING COULTERS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT REMOVE PIVOTING COULTER TUBE SHIPPING RETAINERS UNTIL INSTRUCTED.

There are 4 hydraulic circuits on this unit and an optional steerable hitch circuit if equipped.

- 1/2" hydraulic hose (Marked Red) – main lift and main wing tilt
- 3/8" hydraulic hose (Marked Blue) – outer wing extend and retract
- 1/4" hydraulic hose (Marked Gray) – fold and unfold wings
- 1/2" hydraulic hose (Marked Yellow) – product centrifugal pump
- Optional – 3/8" hydraulic hose (Marked Green) – steerable hitch

1. Attach empty applicator to tractor. Refer to "Hitching to the Tractor" in OPERATION section.
2. Applicators with tracks, continue on with step 4.
Applicators with wheels, adjust transport brackets to working height. Engage the toolbar lift hydraulic circuit to fully raise the toolbar up out of the wing transport brackets. Unfold the wings and rest them on the ground. Raise the transport brackets into the recommended transport position (see FIG. 2-2) reusing the existing hardware.



Dealer Set Up (continued)

3. After the transport brackets have been relocated, remove the safe lifting device and lower the toolbar into the wing transport brackets.


4. UNITS WITH TRACKS

The tracks are shipped in the narrowest setting. Refer to “Axle Tread Setting” in this section for proper spacing. Refer to “Belt Conditioning” in this section for conditioning procedures.

UNITS WITH WHEELS

The wheels are shipped less duals and in the narrowest setting. Using a safe lifting device rated at a minimum of 30,000 lbs., support the applicator. Attach the dual wheels and torque nuts according to the “Wheel Torque Requirements” in the MAINTENANCE section. Refer to “Axle Tread Setting” in this section for proper spacing.

5. Remove the safe lifting device.
6. Place a set of depth stop collars on each toolbar parallel lift cylinder. (FIG. 2-3)




Dealer Set Up (continued)

7. Unfold the applicator to access the toolbar.


8. 80'/88'/90' TOOLBARS ONLY

Attach the front wing hook plates (411390G or 411390R) as shown in FIG. 2-4 with 3/4"-10UNC x 3 1/4" grade 8 capscrews (91299-150), 3/4" SAE flat washers (9405-104), and 3/4"-10UNC flange locknuts (9003399). Torque hardware to 290 ft.-lbs.



9. 80'/88'/90' TOOLBARS ONLY


Attach the rear wing hook plates (411391G or 411391R) as shown in FIG. 2-5 with 3/4"-10UNC x 3 1/4" grade 8 capscrews (91299-150), 3/4" SAE flat washers (9405-104), and 3/4"-10UNC flange locknuts (9003399). Torque hardware to 290 ft.-lbs.



Dealer Set Up (continued)

10. Engage toolbar main lift circuit to raise center section and main wings fully out of the transport rest.
11. Engage the main wing unfold circuit. The toolbar transport latch will unlatch and then swing the main wings forward. Stop the wings before they become fully unfolded. (FIG. 2-6)
12. Using a safe lifting device rated at a minimum of 3,000 lbs., support each wing at the end of the main wing. (FIG. 2-6)

FIG. 2-6



13. Remove and discard the pivoting coulter tube retainers located behind the main wing. (FIG. 2-6)
14. Remove the safe lifting devices.

Dealer Set Up (continued)




15. Re-engage the main wing unfold circuit. Finish unfolding the wings. Then the pivoting coulters will rotate down and the outer wings will unfold.
16. Using safe stands rated at a minimum of 3,000 lbs. per side, position safe stands at the ends of the main wings. Ensure transport stands are in shipping position on both sides as shown in (FIG. 2-7). Then lower the main wing masts into the saddle area of the center toolbar. If the wings do not sequence properly, the unfold sequence valve on the hydraulic manifold will need to be adjusted, refer to MAINTENANCE section.
17. With wings unfolded and toolbar in cradle, remove and discard the shipping boards from the pivoting coulters blades. Repeat the process on the opposite side of the applicator. (FIG. 2-7)

NOTE: Offset coulters bracket (414902B) positions the straight post coulters 6" forward. (FIG. 2-8)

18. Mount the straight post coulters with offset bracket (414902B) onto the first row on the main wing as shown in (Figure 2-8). Using 5/8"-11UNC x 7 1/2" capscrews (9501438-139) and 5/8"-11UNC locknuts (9501438-036), attach the straight post coulters. Be sure to mount the straight post coulters assembly to provide the most amount of clearance to the unit when folded. Repeat this step for the other main wing.

IMPORTANT

- When installing the coulters mount weldments, ensure the double set of holes are at the top and single set of holes are located at the bottom, see (Figure 2-9).



Dealer Set Up (continued)

19. Pivot the coulters into working position. Secure into position by placing the roll pin (9501441-210) into the retaining hole. Then install the spiral pin (9501442-209) inside the roll pin. Refer to the “Overhead Layouts” in this section to determine the proper positioning of the coulters. Use a safe lifting device rated at a minimum of 100 lbs., to support coulters post assembly while repositioning.




Note: All but the center coulters post allows for four height settings, all of the mounted coulters posts are in the shortest position from the factory. The center coulters post allows for three height settings. The height difference between each position is 1 3/4". (FIG. 2-10)

Note: Coulters post hole 3 and 4 also requires 480/80R50 R-1W (159A8) tires. (FIG. 2-10)

Note: All hole settings are only recommended. Any combination of coulters hole settings and depth stop collars on each cylinder can be used to achieve the desired depth setting.

20. Pivot the transport stand up to the working position by removing the upper capscrew and reinstalling it in the upper set of holes. See (FIG. 2-11). Repeat for opposite side. Refer to “Overhead Layouts” for proper positioning.

21. Attach the outer wing gauge wheel/tire assembly (FIG. 2-12). Using safe lifting device rated at a minimum of 50 lbs., position the outer wing gauge wheel assembly with the gauge wheel tire in-line with the coulters blade. Refer to the “Overhead Layouts” in this section for proper positioning. Torque nuts according to the “Wheel Torque Requirements” in the MAINTENANCE section.



Dealer Set Up (continued)

22. Using a safe lifting device rated at a minimum of 125 lbs., install the main wing gauge wheel assembly with the pin handle to the outside of the post (FIG. 2-13 and 2-14). Verify the gauge wheel tire is directly in-line with the coulter blade. Refer to “Overhead Layouts” in this section for proper positioning.
23. Rotate amber flasher bracket to be perpendicular to the front toolbar tube (FIG. 2-14). The amber light should be visible to the front and rear of the unit and the amber reflector should face forward when the wings are folded in the transport position.
24. After transport lights have been adjusted, coulter post assemblies have been relocated and gauge wheels installed, remove the safe lifting devices.

FIG. 2-13





FIG. 2-14




Dealer Set Up (continued)

25. Remove the SMV emblem film and make sure the SMV emblem is visible from the rear of the unit. (FIG. 2-15)

NOTE: Ensure front and rear SIS decals are clean and visible after shipping.



26. To set toolbar working depth for the center section adjust the number of depth stop collars on each parallel lift cylinder. Adjust each gauge wheel position for adjustment of each wing section. (FIG. 2-16)



Closer Wheel Tank Guard Installation (Opt.)

⚠ WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.

⚠ CAUTION

- SHARP EDGES ON COULTER BLADES CAN CAUSE SERIOUS INJURY. BE CAREFUL WHEN WORKING AROUND COULTER BLADES.



1. Park the empty unit on a firm, level surface. Block the tires or tracks to keep the machine from moving. Ensure the wings are folded into transport position. Set the vehicle parking brake. Relieve hydraulic system pressure, see “Purging A Hydraulic System” in this section. Shut off the engine and remove the ignition key. Completely disconnect the unit from the towing vehicle.



2. Remove 3/8” hardware retaining the bottom of the rear sight gauge bracket. Keep flange nuts and discard capscrews. (FIG. 2-17).

NOTE: For steps 2 through 8, loosely attach all hardware.


3. Attach bottom of left-hand tank guard (415412G/R) to the bottom of left-hand wing mast and retain the rear sight gauge bracket reusing 3/8”-16UNC flange nuts (91263) and provided 3/8”-16UNC x 1 1/4” capscrews (9390-056). (FIG. 2-17)
4. Install top of left-hand tank guard to the mount bracket using 5/16”-18UNC x 2 3/4” u-bolts (9002713), 5/16” flat washers (9405-070) and 5/16”-18UNC lock nuts (9807). (FIG. 2-18).




Closer Wheel Tank Guard Installation (Opt.) (continued)

NOTE: Closer wheel assembly (69386B) removed from coulter assembly for clarity. (FIG. 2-19)

5. Attach the tank guard bracket (415414G/R) to the right-hand wing mast using 1/2"-13UNC x 4 1/8" u-bolt (901897) and two 1/2"-13UNC lock nuts (9003397). (FIG. 2-19).




6. Install the right-hand tank guard (415413G/R) to the bottom of right-hand wing mast using 3/8"-16UNC flange nuts (91263) and 3/8"-16UNC x 1" flange screw (91263). (FIG. 2-20).




Closer Wheel Tank Guard Installation (Opt.) (continued)

7. Secure the top of the right-hand tank guard using two 1/2"-13UNC lock nuts (9003397) and two 1/2"-13UNC x 1" capscrews (9390-099). (FIG. 2-21)



8. Attach brace plate (415415G/R) between left-hand and right-hand tank guard using 5/16"-18UNC flange nuts (91257), 5/16" flat washers (9405-070) and 5/16"-18UNC x 1 button head screws (901563). (FIG. 2-22)

9. Tighten all hardware.



Tongue Adjustment

Units with Fixed Position Hitch (80' / 88' / 90' Units)

1. Pull applicator in a straight line for a few hundred feet and note how applicator is trailing behind the tractor.
2. If unit is trailing to the left, lengthen the RH tongue turnbuckle and shorten the LH tongue turnbuckle. Use 1/2 turn increments for both. (FIG. 2-23)
3. If unit is trailing to the right, lengthen the LH tongue turnbuckle and shorten the RH tongue turnbuckle. Use 1/2 turn increments for both. (FIG. 2-23)
4. Tighten both turnbuckle locking-nuts.
5. Re-check by repeating Step #1.




FIG. 2-23

Units Equipped with Steerable Hitch

Refer to your Steerable Hitch Manual.

Axle Tread Setting

Wheel Spacing Combinations



- **USE EXCEPTIONAL CARE WHEN OPERATING APPLICATOR EQUIPPED WITH SINGLE TIRES AND SET AT NARROW WHEEL SPACING. THE POSSIBILITY OF TIPPING OVER DURING TURNS OR TRAVEL ON ROUGH ROADS IS INCREASED UNDER THESE CONDITIONS.**

The axle spacing is infinitely adjustable between minimum and maximum settings. Through a combination of wheel offset, axle adjustment, and hub spacers, a wide variety of track, single wheel, and dual wheel combinations are possible. A summary of the available wheel spacings for each tire and wheel combination is as follows:

| WHEEL OFFSET TO INSIDE | | | | |
|---------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| TIRE & WHEEL | 1800 GALLON | | 2600 GALLON | |
| | MIN. SPACING (inches) | MAX. SPACING (inches) | MIN. SPACING (inches) | MAX. SPACING (inches) |
| 380/90 x 46 Single 5" Offset | 70 | 101* | - | - |
| 380/90 x 46 Duals | 60 Inner Dual | 101 Inner Dual | - | - |
| 320/90 x 50 Duals | 63 Inner Dual | 104 Inner Dual | - | - |
| 480/80 x 50 Single | 70 | 105* | - | - |
| 320/90 x 54 Duals | - | - | 62 Inner Dual | 103 Inner Dual |
| 380/90 x 54 Duals | - | - | 62 Inner Dual | 103 Inner Dual |

* 380/90 x 46 and 480/80 x 50 single tires need to be set at a tread width of 120"

| WHEEL OFFSET TO OUTSIDE | | | | |
|----------------------------------|-----------------------|-----------------------|--|--|
| TIRE & WHEEL | 1800 | | 2600 | |
| | MIN. SPACING (inches) | MAX. SPACING (inches) | MIN. SPACING (inches) | MAX. SPACING (inches) |
| 380/90 x 46 Single (30" Rows) | 84 | 132* | - | - |
| 380/90 x 46 Duals (30" Rows) | 120 Outer Dual | 160 Outer Dual | - | - |
| 480/80 x 50 Single (30" Rows) | 70 | 132* | - | - |
| 320/90 x 50 Duals (20" Rows) | 100 Outer Dual | 140 Outer Dual | - | - |
| 320/90 x 50 Duals (22" Rows) | 104 Outer Dual | 144 Outer Dual | 104 Outer Dual | 144 Outer Dual |
| 320/90 x 54 Duals (20" Rows) | - | - | 100 Outer Dual | 140 Outer Dual |
| 320/90 x 54 Duals (22" Rows) | - | - | 104 Outer Dual | 144 Outer Dual |
| 380/90 x 54 Duals (30" Rows) | - | - | 120 Outer Dual | 160 Outer Dual |
| Tracks | 80 | 144 | 80 (60'/66' Toolbars) 88 (80'/88'/90' Toolbars) | 144 (60'/66' Toolbars) 132 (80'/88'/90' Toolbars) |

* 380/90 x 46 and 480/80 x 50 single tires need to be set at a tread width of 120"

Axle Tread Setting (continued)

Adjustment

WARNING

- IMPROPER AXLE ADJUSTMENT CAN CAUSE AXLE TO SEPARATE FROM APPLICATOR, RESULTING IN PERSONAL INJURY OR DEATH DUE TO APPLICATOR OR AXLE FALLING.

- USE CARE THAT APPLICATOR DOES NOT FALL FROM SUPPORT STANDS DURING ADJUSTMENT. DO NOT ALLOW AXLE TO SLIDE OUT FROM APPLICATOR DURING ADJUSTMENT PROCEDURE.

- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

- KEEP HANDS CLEAR OF PINCH POINT AREAS.

CAUTION

- IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL, MACHINE DAMAGE, BODILY INJURY, AND DAMAGE TO EQUIPMENT / ENVIRONMENT. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Axle Tread Setting (continued)

IMPORTANT

- *Always adjust axles equally.*
1. Hitch applicator to tractor to help stabilize unit. Refer to “Hitching to the Tractor” in OPERATION section. Ensure tractor is in park and remove key.
 2. Using a safe lifting device and supports rated at 30,000 lbs., raise one side of the empty applicator and place on stands. Stands should be securely positioned under both frame rails, as far toward the rear of the applicator as practical. (FIG. 2-24)
 3. Units with tracks, skip to step 4.


Unit with wheels, if necessary for desired wheel spacing, change wheel dish direction by unbolting wheels and swap between left and right sides on applicator. Refer to information in wheel spacing chart to see if wheel dish needs to be reversed. Tighten 7/8” wheel lug bolts to 500 ft-lbs. torque. See Wheel Hardware Torque chart.

Note: If equipped with 480/80 x 50 singles, swap the tires between left and right sides on the applicator to have the wheel offset to the outside and achieve 120” tread width.

4. Loosen four 1” clamp bolts that hold one axle. Using a safe lifting device rated for 3,000 lbs., lift the axle slightly and slide it out until desired adjustment is reached.





Note: Do not extend axle beyond the clamps.

5. Verify the inner axle clamp fully contacts the axle.
6. After adjustment, tighten 1” clamp bolts to 500 ft-lbs.
7. Repeat steps 2 through 6 for other axle. Remove safe lifting devices and supports.



Axle Tread Setting (continued)

Track Tread Toolbar Widths



Axle Tread Setting (continued)

Tracks Toe In Adjustment

WARNING

- IMPROPER AXLE ADJUSTMENT CAN CAUSE AXLE TO SEPARATE FROM APPLICATOR, RESULTING IN PERSONAL INJURY OR DEATH DUE TO APPLICATOR OR AXLE FALLING.

- USE CARE THAT APPLICATOR DOES NOT FALL FROM SUPPORT STANDS DURING ADJUSTMENT. DO NOT ALLOW AXLE TO SEPARATE FROM APPLICATOR DURING ADJUSTMENT PROCEDURE.

- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.

- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

- KEEP HANDS CLEAR OF PINCH POINT AREAS.

CAUTION

- IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Axle Tread Setting (continued)

Tracks Toe In Adjustment (continued)

IMPORTANT

- *Always adjust axles equally.*
1. Hitch applicator to tractor to help stabilize unit. Refer to “Hitching to the Tractor” in OPERATION section. Ensure tractor is in park and remove key.
 2. Using a safe lifting device and supports rated at 30,000 lbs., raise one side of the empty applicator and place on stands. Stands should be securely positioned under both frame rails, as far toward the rear of the applicator as practical. (FIG. 2-25)

NOTE: Measure from one track to the other to determine if the track axle requires a shim.



3. Measure from front idler to front idler on opposite side and from rear idler to rear idler on opposite side.
4. Next, measure from front left idler to rear right idler and then the opposite dimension.

NOTE: For a toe in adjustment, the front idler measurement will be slightly less than the rear idler measurement. However, the “X” measurement from step 4 will be equal.

5. To establish toe in, install 14 gauge, 12 gauge or 10 gauge shim (411103B, 411098B or 411105B) on the upper rear side of the track diamond axle between the axle and applicator frame. (FIG. 2-26)
6. Using a safe lifting device rated for 3,000 lbs., loosen four 1” clamp bolts that hold one axle. Slide in shim for desired toe in adjustment.

NOTE: Do not extend axle beyond the clamps.

7. After adjustment, tighten 1” clamp bolts to a torque of 500 ft-lbs.
8. Repeat steps 2 through 6 for other axle. Remove safe lifting devices and supports.



Belt Conditioning

Condition Track Prior to Initial Usage

A new rubber track, fresh from the mold, will be slightly “tacky”. This is a standard consequence of the vulcanization (curing) process. The rubber track will perform better if this tackiness is removed, and thus it is recommended that all new rubber tracks be “conditioned” with talc, dirt, granular floor dry, or some other non-caustic particulate material. This is done by simply spreading a thin layer of the material over the undercarriage-engaging surface of the track, and then running the system for a brief period. This will serve to remove the tackiness of the rubber, and will promote optimum track-undercarriage engagement.

Belt Conditioning Procedures

IMPORTANT

- *Road transport weight, distance and speed will affect the belt life.*

Before loading the unit with product or solution, use the following recommendations to maximize the belt life:

1. Prior to transporting, apply generous amounts of clean dry dirt to the inside face, between the idler and bogie wheels, of the track.

NOTE: Clean dry dirt and dust are the most effective dry lubricants. For best results, it is recommended to perform the conditioning procedure for new belts in the field. Talc or floor dry are alternate dry lubricants when clean dry dirt is not an option.

2. Once in the field, reapply generous amounts of clean dry dirt to the inside of the track belt and operate for 20 minutes.
3. Using a temperature gun, measure the guide lug face including the radii between the guide lug and inside face of the track belt and record the highest temperature. Check multiple guide lugs. Repeat for the opposite side of track belt.
4. If the temperature difference of the sides of the guide lugs is greater than 30°, adjust the alignment. Refer to Alignment procedures in the Equalizer® Track manual.
5. Continue the alignment procedures until tracks are aligned applying clean dry dirt periodically.
6. Once the temperature difference between the sides of the guide lugs is below 30°, continue to run the track in the field stopping once every hour of run time to reapply clean dry dirt.
7. When 20 hours of total field run time has been achieved, then the guide lug temperatures should be checked after a couple miles of unloaded road transport. If guide lug temperatures are within the previous mentioned parameters, the unit is ready for use.
8. Check guide lug temperatures daily during road transport AND field operation to assure long track belt life. If the temperature difference of the sides of the guide lugs is greater than 30°, refer to Step 4.

Toolbar Functions

Refer to OPERATION section “Toolbar Operation”.

Controller Calibration Settings

Refer to the appropriate Raven manual or OEM rate controller manual if applicable.

| “BOOM CAL” Monitor Settings | | | | | | | |
|-----------------------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
| 40' | 20" | 90" | 100" | 100" | 100" | 90" | - |
| 40' | 30" | 75" | 120" | 90" | 120" | 75" | - |
| 40' Folded Down to 30' | 30" | - | 135" | 90" | 135" | - | - |
| 44' | 22" | 99" | 110" | 110" | 110" | 99" | - |
| 60' | 20" | 120" | 170" | 140" | 170" | 120" | - |
| 60' | 30" | 120" | 165" | 150" | 165" | 120" | - |
| 66' | 22" | 132" | 187" | 154" | 187" | 132" | - |
| 80' | 30" | 135" | 180" | 180" | 150" | 180" | 135" |
| 88' | 22" | 231" | 154" | 154" | 132" | 154" | 231" |
| 90' | 30" | 195" | 180" | 180" | 150" | 180" | 195" |

Pump Set Up

For set up of a PWM (Pulse Width Modulated) or non-PWM pump, refer to your Rate controller manual for details. For specific details related to your product pump, please refer to your pump manual.

NOTE: Foot switch must be installed and connected to ISO harness behind the ISO plug at the rear of the tractor for PWM pump to function properly. Extension harness (9503390) may also be required.

IMPORTANT

- Do not run pump for extended periods with outlet flow fully blocked. Overheating and pump damage can result.
- Liquid must be in the Solution Tank. Refer to Filling Applicator in the OPERATION section.
- Toolbar should be unfolded when setting the pump pressure. Refer to toolbar operation in the OPERATION section.
- The Pump Inlet valve should be open.



Setting the Pump Pressure (PWM Pump)

1. Rate controller must be calibrated.
2. Select manual control on the console and turn the master switch on. Press and hold the Inc. button for 5 seconds to verify cartridge valve is fully open.
3. Turn off section valves and agitation valve if equipped.
4. Turn the tractor's hydraulic flow dial to 100%. The PWM cartridge valve is sized to divert a maximum of 11 GPM to the pump. Decrease the tractor's hydraulic flow until Nutrimax system pressure starts to drop, approximately around 100 PSI.
5. Increase the agitation until the pump pressure drops by 5 PSI. The gauge should read 95 PSI.

RCM Set Up

Whenever the tractor is turned off or the ECU for the applicator loses power, the following steps will have to be performed in order for the RCM to function properly right away.




NOTE: Before programming the RCM, ensure the RCM monitor is connected to the battery.

1. Initial start-up screen. At “Profile Name” box, name as “Nutrimax”. Click “Machine Type” and select “Liquid Fert. Tool”. Next, enter 480 in., 720 in. or 1080 in. for “Application Width” depending on machine size and configuration. Click next arrow. (FIG 2-28)

NOTE: Highest value for “Application Width” is 1080 in.

2. Default for “ECU” box is 1. Click “Number of Products” box and enter 1. Click next. (FIG 2-29)

3. Under “Application Type”, select “Liquid”. Click next. (FIG 2-30)



RCM Set Up (continued)

NOTE: 40 FT. - 66 FT. units will have 5 sections.
80 FT. - 90 FT. units will have 6 sections.

- Under “Number of Sections”, select 5 for 40 FT. - 66 FT. units or 6 for 80 FT. - 90 FT. units. Default for “Section Valve Type” is 3-Wire. Uncheck “Equal Width Sections” box. Click next. (FIG 2-31)




FIG. 2-31

NOTE: Each section is listed in inches and will equal total application width.

NOTE: See Controller Calibration Settings in the SET UP section for specific toolbar lengths.

- Enter values for each section. Click next. (FIG 2-32).




FIG. 2-32


- Ensure all the appropriate boxes are selected as “None”. (FIG 2-33)




FIG. 2-33

RCM Set Up (continued)


7. No action required on this screen. Make sure this matches toolbar size and section widths. Continue to next page. (FIG 2-34)



8. Under “Pressure Sensor 1”, select “0-250 psi (1-5V)”. Under “Pressure Sensor 2”, select “None”. Click next. (FIG 2-35)




9. Under “Pressure 1”, set minimum and maximum pressures. Recommend starting at 10 psi and 150 psi. Check box if alarm is desired when above max or below min. Click next. (FIG 2-36)



RCM Set Up (continued)


10. For the auxiliary functions: uncheck both boxes. Click next page. (FIG. 2-37)



11. “Product 1” is the set up for the liquid. For “Control Valve Type”, always select “PWM”. (FIG. 2-38)

12. For “Valve Response Rate”, enter 40. This is how fast the valve responds.


13. Default for “Control Deadband %” box is 3 and “Valve Delay” box is 0.



14. For the PWM valve “Coil Frequency”, ensure the value is set at 122. (FIG. 2-39)

NOTE: Inputting “PWM Standby” at 20, for example, can resolve “Solution Pump Dry” error.


15. Set the “PWM High Limit” at 100, “PWM Low Limit” at 10 and “PWM Standby” at 0. Click next page. (FIG. 2-39)



RCM Set Up (continued)

16. For “Flowmeter Calibration”, check the tag on the flowmeter and enter the value. (FIG. 2-40)

17. Under “Flowmeter Pulse/Units” enter 10 gal. Click next page. (FIG. 2-40)




18. For “Tank Fill/Level Sensor”, select “None”. (FIG. 2-41)

19. Enter gallon capacity of unit for “Tank Capacity”.

20. Enter current gallons in unit for “Current Tank Level”.

21. “Low Tank Level” is the value an alarm is set off for a low bin level. Recommended setting is 250 and ensure the “Alarm” box is checked.




22. “Set Up Rates” page controls the application rates for speed and determines how much product is being applied for “Product 1”. Enter three “Preset Rate Values”, as desired, which can be clicked between on the homescreen. On the homescreen, target rates can be entered as well. (FIG. 2-42)

23. Enter “Rate Bump” value in an increment as desired.

24. For “Rate Selection”, manually input a selection or import an “Rx”.

25. “Display Smoothing” needs to be checked and “Decimal Shift” remains at 0.


26. “Standby Pressure” remains at 0. Standby PWM valve is used instead. Click next page. (FIG. 2-42)



RCM Set Up (continued)


27. Enter 20 for “Off Rate Alarm” and check box. Click next page. (FIG. 2-43)

NOTE: Alarm prompts when over 20% off target rate.



NOTE: “Number of Products” corresponds to liquid application. (FIG. 2-44)

28. No action required on this screen. Shows the set up summary. Make sure all values are correct. Continue to next page. (FIG. 2-44)



RCM Set Up (continued)

PWM Pump Start Up Procedure (Rate Control Module)

Whenever the tractor is turned off or the ECU for the PWM Pump loses power, the following steps will have to be performed in order for the PWM Pump to function properly right away.




1. Fill solution tank with desired product and reduce the flow on the SCV to lowest setting for the PWM pump before engaging.

Initial start-up screen (FIG. 2-45).

2. Switch the system from Auto to Manual (FIG. 2-45).

3. Cycle the system from Off to On. (FIG. 2-46)

4. Engage the SCV in continuous flow for the pump on the tractor.
5. Click the manual “+” button to increase the DC value to 100%. (FIG. 2-47)
6. Increase the hydraulic flow on the tractor until the pressure reaches 100 psi.
7. Switch the system from Manual back to Auto. The pump will go into Standby mode, and the pressure should drop.



Applicator Calibration

Determine Required Nozzle Size

Use the following procedure to assist with sizing the nozzle and calibrating the applicator. Additional information can be found in the rate controller owner’s manual and also obtained from nozzle manufacturers.

The following procedure assumes that an electronic rate controller is being used.

1. Determine the typical operating speed (in MPH) and coverage rate (in GPA) that will be used.
2. Calculate nozzle flow:

$$\text{Nozzle GPM} = \frac{\text{MPH} \times \text{GPA} \times \text{Nozzle Spacing} \times \text{DCF}^*}{5940}$$

*DCF = Density Conversion Factor

| Weight of Solution | Density Conversion Factor (DCF) |
|-------------------------------|---------------------------------|
| 8.34 lb./gal. (Water) | 1.00 |
| 10.65 lb./gal. (28% Nitrogen) | 1.13 |
| 11.05 lb./gal. (32% Nitrogen) | 1.15 |

Example:

Speed = 8 miles per hour
 Rate = 10 gallons per acre
 Nozzle Spacing = 20 inches
 Liquid = Water

$$\text{Nozzle GPM} = \frac{8 \times 10 \times 20 \times 1.00^*}{5940} = 0.27 \text{ GPM}$$





































3. Go to the PARTS section, “Injector Nozzles and Injector Knives” to select a nozzle tip.

Choose a nozzle that will provide the calculated GPM within the nozzle’s operating pressure range. Typically, 2 or 3 nozzle sizes will be found that meet the calculated GPM. However, it is usually a good practice to choose a flow size that lists this GPM in the mid-portion of the nozzle’s advertised ratings.

4. Go to the PARTS section, “Injector Nozzles and Injector Knives” to select a nozzle and knife orifice size. Choose a type of nozzle or orifice for the given application.

| INJECTOR NOZZLE & ORIFICE GUIDE | | | |
|---------------------------------|--------------------|-----------|---|
| Nozzle Size | Knife Orifice Size | P.S.I. | Approx. G.P.A. at 30” Rows at 10 M.P.H. |
| #0004 | #57 | 30 P.S.I. | 7 |
| #0006 | #70 | | 10 |
| #0008 | #80 | | 14 |
| #0010 | #89 | | 17 |
| #0015 | #107 | | 26 |
| #0020 | #125 | | 34 |
| #0030 | #151 | | 51 |
| #0040 | #177 | | 69 |


Overhead Layout - Legend

| | | | | | |
|--|---|--|---|---|--|
| <p>67931B - 60' - 90' Toolbar 415752B - 40' Toolbar Coulter Post Assembly (Straight Post)</p> <p>Overhead View</p>  <p>Front View</p>  | <p>68086B - 60' - 90' Toolbar 415754 - 40' Toolbar Coulter Post Assembly (Offset Post)</p> <p>Overhead View</p>  <p>Front View</p>  | <p>415753B - 40' Toolbar Center Coulter Post Assembly (Straight Post)</p> <p>Overhead View</p>  <p>Front View</p>  | <p>411173B - Coulter Post Assembly (Double Offset Left-Hand, Front)</p> <p>Overhead View</p>  <p>Front View</p>  | | |
| <p>410875B - Coulter Post Assembly (Double Offset Left-Hand, Rear)</p> <p>Overhead View</p>  <p>Front View</p>  | <p>411174B - Coulter Post Assembly (Double Offset Right-Hand, Front)</p> <p>Overhead View</p>  <p>Front View</p>  | <p>410876B - Coulter Post Assembly (Double Offset Right-Hand, Rear)</p> <p>Overhead View</p>  <p>Front View</p>  | <p>69290B - 60' - 90' Toolbar 415757B - Double Coulter Post Assembly RH 40' Toolbar 415763B - Center Double Coulter Post Assembly RH 40' Toolbar</p> <p>Front View</p>  <p>Overhead View</p>  | | |
| <p>414887B Coulter Mount Weldment</p> <p>Overhead View</p>  <p>Front View</p>  | <p>414898B Coulter Mount Offset RH</p> <p>Overhead View</p>  <p>Front View</p>  | <p>414899B Coulter Mount Offset LH</p> <p>Overhead View</p>  <p>Front View</p>  | <p>410014B - Gauge Wheel Assembly 60911 - Mounted Tire & Wheel (W815-6-08)</p> <p>Overhead View</p>  | <p>411261B - Gauge Wheel Assembly 95567 - Mounted Tire & Wheel (W6-610)</p> <p>Overhead View</p>  | <p>69275B - 60' - 90' Toolbar 415755B - 40' Toolbar Double Coulter Post Assembly LH</p> <p>Front View</p>  <p>Overhead View</p>  |
| <p>414894B Coulter Mount Offset LH</p> <p>Overhead View</p>  <p>Front View</p>  | <p>414895B Coulter Mount Offset RH</p> <p>Overhead View</p>  <p>Front View</p>  | <p>414902B Coulter Mount Weldment</p> <p>Overhead View</p>  <p>Front View</p>  | <p>414896B Coulter Mount Offset LH</p> <p>Overhead View</p>  <p>Front View</p>  | <p>414897B Coulter Mount Offset LH</p> <p>Overhead View</p>  <p>Front View</p>  | |

**Overhead Layout - 40' Toolbar - 20" Row Spacing
For 1800 NutriMax**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---|--------------------------------|---|
| 1, 2, 3, 5, 6, 7, 8, 10, 11, 13, 14, 16, 17, 18, 19, 21, 22, 23 | 415752B - Straight Post | 414887B - Coultter Mount Weldment |
| 12 | 415753B - Center Straight Post | 414887B - Coultter Mount Weldment |
| 4, 20 | 415754B - Offset Post | 414887B - Coultter Mount Weldment |
| 9 | | 414895B - Coultter Mount Weldment Offset Right-Hand |
| 15 | | 414894B - Coultter Mount Weldment Offset Left-Hand |

Direction of Travel →




| "BOOM CAL" Monitor Settings | | | | | | |
|-----------------------------|---------|-----------|-----------|-----------|-----------|-----------|
| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
| 40' | 20" | 90" | 100" | 100" | 100" | 90" |

**Overhead Layout - 44' Toolbar - 22" Row Spacing
For 1800 Nutrimax**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---|--------------------------------|---|
| 1, 2, 3, 4, 6, 7, 8, 9, 10, 14, 15, 16, 17, 18, 20, 21, 22, 23 | 415752B - Straight Post | 414887B - Coultter Mount Weldment |
| 11 | | 414899B - Coultter Mount Weldment Offset Right-Hand |
| 13 | 415753B - Center Straight Post | 414898B - Coultter Mount Weldment Offset Left-Hand |
| 12 | | 414887B - Coultter Mount Weldment |
| 5, 19 | 415754B - Offset Post | 414887B - Coultter Mount Weldment |


Direction of Travel →




| TOOLBAR SIZE | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|-----------|-----------|-----------|-----------|-----------|
| 44' | 22" | 99" | 110" | 110" | 99" |

**Overhead Layout - 40' Toolbar - 30" Row Spacing
For 1800 NutriMax**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|----------------------------------|--------------------------------|---|
| 1, 2, 4, 5, 7, 9, 11, 12, 14, 15 | 415752B - Straight Post | 414887B - Coultter Mount Weldment |
| 8 | 415753B - Center Straight Post | 414887B - Coultter Mount Weldment |
| 3, 13 | 415754B - Offset Post | 414887B - Coultter Mount Weldment |
| 6 | | 414895B - Coultter Mount Weldment Offset Right-Hand |
| 10 | | 414894B - Coultter Mount Weldment Offset Left-Hand |

Direction of Travel




“BOOM CAL” Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 40' | 30" | 75" | 120" | 90" | 120" | 75" |


**Overhead Layout - 40' Toolbar - Double Coulters - 30" Row Spacing
For 1800 NutriMax**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|-----------------------|--|---|
| 1, 17 | 415752B - Straight Post | 414887B - Coulters Mount Weldment |
| 9 | 415763B - Center Double Coulters Assembly RH | 414887B - Coulters Mount Weldment |
| 4, 10, 12, 13, 15, 16 | 415755B - Double Coulters Assembly LH | 414887B - Coulters Mount Weldment |
| 7 | | 414895B - Coulters Mount Weldment Offset Right-Hand |
| 2, 3, 5, 6, 8, 14 | 415757B - Double Coulters Assembly RH | 414887B - Coulters Mount Weldment |
| 11 | | 414894B - Coulters Mount Weldment Offset Left-Hand |


Direction of Travel



Overhead View



Front View




"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|-----------|-----------|-----------|-----------|-----------|
| 40' | 30" | 75" | 120" | 90" | 120" |
| | | | | | 75" |


**Overhead Layout - 40' Toolbar - 36" Row Spacing
For 1800 NutriMax**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---------------------------|--------------------------------|---|
| 1, 2, 4, 6, 8, 10, 12, 13 | 415752B - Straight Post | 414887B - Coultter Mount Weldment |
| 7 | 415753B - Center Straight Post | 414887B - Coultter Mount Weldment |
| 3, 11 | 415754B - Offset Post | 414887B - Coultter Mount Weldment |
| 9 | | 414895B - Coultter Mount Weldment Offset Right-Hand |
| 5 | | 414894B - Coultter Mount Weldment Offset Left-Hand |

Direction of Travel →



Overhead View



Front View

“BOOM CAL” Monitor Settings


| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 40' | 36" | 72" | 90" | 108" | 90" | 72" |

**Overhead Layout - 40' Toolbar - 38" Row Spacing
For 1800 NutriMax**


| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|--------------------|--------------------------------|---|
| 2, 4, 6, 8, 10, 12 | 415752B - Straight Post | 414887B - Coultter Mount Weldment |
| 1 | | 414896B - Coultter Mount Weldment Offset Left-Hand |
| 13 | | 414897B - Coultter Mount Weldment Offset Right-Hand |
| 7 | 415753B - Center Straight Post | 414887B - Coultter Mount Weldment |
| 3, 11 | 415754B - Offset Post | 414887B - Coultter Mount Weldment |
| 5 | | 414895B - Coultter Mount Weldment Offset Right-Hand |
| 9 | | 414894B - Coultter Mount Weldment Offset Left-Hand |

Direction of Travel →

Overhead View



Front View



"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 40' | 38" | 76" | 95" | 114" | 95" | 76" |


**Overhead Layout - 60' Toolbar - 20" Row Spacing
Offset Coulter Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|-------------|--|----------------------------------|
| 1, 35 | 68086B - Offset Post | 414887B - Coulter Mount Weldment |
| 6 | 410875B - Double Offset Left-Hand, Rear | |
| 30 | 410876B - Double Offset Right-Hand, Rear | |




Direction of Travel



Overhead View



Front View







“BOOM CAL” Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 60' | 20" | 120" | 170" | 140" | 170" | 120" |

**Overhead Layout - 60' Toolbar - 20" Row Spacing
Straight Coupler Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---|------------------------|---|
| 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 15, 17, 18, 19, 21, 24, 25, 26, 27, 28, 29, 31, 32, 33, 34 | 67931B - Straight Post | 414887B - Coultter Mount Weldment |
| 16 | | 414898B - Coultter Mount Weldment Offset Right-Hand |
| 20 | | 414899B - Coultter Mount Weldment Offset Left-Hand |
| 13, 23 | | 414902B - Coultter Mount Weldment |
| 14 | | 414895B - Coultter Mount Offset Right-Hand |
| 22 | | 414894B - Coultter Mount Offset Left-Hand |

Direction of Travel
↓



"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 60' | 20" | 120" | 170" | 140" | 170" | 120" |


**Overhead Layout - 66' Toolbar - 22" Row Spacing
Offset Coulter Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|-------------|--|----------------------------------|
| 3, 33 | 68086B - Offset Post | |
| 7 | 410875B - Double Offset Left-Hand, Rear | 414887B - Coulter Mount Weldment |
| 29 | 410876B - Double Offset Right-Hand, Rear | |




Direction of Travel



Overhead View





Front View



| "BOOM CAL" Monitor Settings | | | | | | |
|-----------------------------|---------|-----------|-----------|-----------|-----------|-----------|
| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
| 66' | 22" | 132" | 187" | 154" | 187" | 132" |

**Overhead Layout - 66' Toolbar - 22" Row Spacing
Straight Coulters Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---|------------------------|---|
| 1, 2, 4, 5, 8, 9, 10, 11, 12, 15, 16, 17, 18, 19, 20, 21, 24, 25, 26, 27, 28, 31, 32, 34, 35 | 67931B - Straight Post | 414887B - Coulters Mount Weldment |
| 6, 23 | | 414896B - Coulters Mount Offset Left-Hand |
| 14, 22 | | 414902B - Coulters Mount Weldment |
| 13, 30 | | 414897B - Coulters Mount Weldment Offset Right-Hand |





"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 66' | 22" | 132" | 187" | 154" | 187" | 132" |

**Overhead Layout - 60' Toolbar - 30" Row Spacing
Offset Coulter Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|-------------|--|----------------------------------|
| 1, 23 | 68086B - Offset Post | |
| 4 | 410875B - Double Offset Left-Hand, Rear | 414887B - Coulter Mount Weldment |
| 20 | 410876B - Double Offset Right-Hand, Rear | |

Direction of Travel
↓





"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 60' | 30" | 120" | 165" | 150" | 165" | 120" |

**Overhead Layout - 60' Toolbar - 30" Row Spacing
Straight Coulters Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|--|------------------------|-----------------------------------|
| 2, 3, 5, 6, 7, 8, 10, 11, 12, 13, 14, 16, 17, 18, 19, 21, 22 | 67931B - Straight Post | 414887B - Coulters Mount Weldment |
| 9, 15 | | 414902B - Coulters Mount Weldment |

Direction of Travel




| "BOOM CAL" Monitor Settings | | | | | | |
|-----------------------------|---------|-----------|-----------|-----------|-----------|-----------|
| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
| 60' | 30" | 120" | 165" | 150" | 165" | 120" |

**Overhead Layout - 60' Toolbar - 30" Row Spacing
Double Coulter Post**


| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|-----------------------------------|--|----------------------------------|
| 2, 14, 15, 17, 18, 19, 20, 22, 23 | 69275B - Double Coulter Post Left-Hand Lead | 414887B - Coulter Mount Weldment |
| 3, 4, 6, 7, 8, 9, 11, 12, 13, 24 | 69290B - Double Coulter Post Right-Hand Lead | |
| 10, 21 | 69275B - Double Coulter Post Left-Hand Lead | 414902B - Coulter Mount Weldment |
| 5, 16 | 69290B - Double Coulter Post Right-Hand Lead | |
| 1, 25 | 67931B - Straight Post | 414887B - Coulter Mount Weldment |

Direction of Travel →

Overhead View



Front View





“BOOM CAL” Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|
| 60' | 30" | 120" | 165" | 150" | 165" | 120" |

**Overhead Layout - 80' Toolbar - 20" Row Spacing
Straight Coulters Post**


| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---|------------------------------------|---|
| 2, 3, 4, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 23, 24, 25, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 44, 45, 46 | 67931B - Straight Post | 414887B - Coulters Mount Weldment |
| 22 | | 414898B - Coulters Mount Weldment Offset Right-Hand |
| 26 | | 414899B - Coulters Mount Weldment Offset Left-Hand |
| 1, 43 | | 414896B - Coulters Mount Offset Left-Hand |
| 5, 20, 47 | | 414897B - Coulters Mount Weldment Offset Right-Hand |
| 19, 21, 27, 29 | 414902B - Coulters Mount Weldment | 414902B - Coulters Mount Weldment |
| 28 | 414044B - Straight Post Right-Hand | 414896B - Coulters Mount Offset Left-Hand |

Direction of Travel



"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| 80' | 20" | 130" | 160" | 200" | 180" | 160" | 130" |




**Overhead Layout - 80' Toolbar - 30" Row Spacing
Offset Coulter Post**


| | | |
|-------------|-----------------------|----------------------------------|
| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
| 1, 31 | 68086B - Offset Post | 414887B - Coulter Mount Weldment |

Direction of Travel
↓

Overhead View



Front View




| "BOOM CAL" Monitor Settings | | | | | | | |
|-----------------------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
| 80' | 30" | 135" | 180" | 180" | 150" | 180" | 135" |

**Overhead Layout - 80' Toolbar - 30" Row Spacing
Straight Coulter Post**


| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|---|------------------------|----------------------------------|
| 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 15, 16, 17, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30 | 67931B - Straight Post | 414887B - Coulter Mount Weldment |
| 13, 14, 18, 19 | | 414902B - Coulter Mount Weldment |

Direction of Travel
↓

Overhead View



Front View





“BOOM CAL” Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| 80' | 30" | 135" | 180" | 180" | 150" | 180" | 135" |

**Overhead Layout - 88' Toolbar - 22" Row Spacing
Offset Coulter Post**

| | | |
|--------------------|------------------------------|----------------------------------|
| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
| 1, 47 | 68086B - Offset Post | 414887B - Coulter Mount Weldment |

Direction of Travel
↓



“BOOM CAL” Monitor Settings

| | | | | | | | |
|---------------------|----------------|------------------|------------------|------------------|------------------|------------------|------------------|
| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
| 88' | 22" | 231" | 154" | 154" | 132" | 154" | 231" |


**Overhead Layout - 88' Toolbar - 22" Row Spacing
Straight Coulter Post**

| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|--|------------------------|--|
| 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 22, 23, 24, 25, 26, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46 | 67931B - Straight Post | 414887B - Coulter Mount Weldment |
| 19 | | 414896B - Coulter Mount Offset Left-Hand |
| 20, 21, 27, 28 | | 414902B - Coulter Mount Weldment |
| 29 | | 414897B - Coulter Mount Weldment Offset Right-Hand |


Direction of Travel



Overhead View



Front View



“BOOM CAL” Monitor Settings


| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| 88' | 22" | 231" | 154" | 154" | 132" | 154" | 231" |

**Overhead Layout - 90' Toolbar - 30" Row Spacing
Offset Coulters Post**




| | | |
|--------------------|------------------------------|-----------------------------------|
| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
| 1, 35 | 68086B - Offset Post | 414887B - Coulters Mount Weldment |

Direction of Travel
→

Overhead View



Front View



“BOOM CAL” Monitor Settings


| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| 90' | 30" | 195" | 180" | 180" | 150" | 180" | 195" |

**Overhead Layout - 90' Toolbar - 30" Row Spacing
Straight Coulter Post**


| COULTER ROW | COULTER POST ASSEMBLY | COULTER MOUNT WELDMENT |
|--|------------------------|----------------------------------|
| 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 17, 18, 19, 22, 23, 24, 25, 26, 27, 28, 29, 30 | 67931B - Straight Post | 414887B - Coulter Mount Weldment |
| 15, 16, 20, 21 | | 414902B - Coulter Mount Weldment |

Direction of Travel →

Overhead View



Front View



"BOOM CAL" Monitor Settings

| TOOLBAR SIZE | SPACING | SECTION 1 | SECTION 2 | SECTION 3 | SECTION 4 | SECTION 5 | SECTION 6 |
|--------------|---------|-----------|-----------|-----------|-----------|-----------|-----------|
| 90' | 30" | 195" | 180" | 180" | 150" | 180" | 195" |

Section III Operation

| | |
|--|------|
| Preparing Tractor..... | 3-2 |
| Preparing Applicator..... | 3-2 |
| Hardware | 3-2 |
| Pivot Pins | 3-2 |
| Hitch | 3-2 |
| Hydraulic System..... | 3-2 |
| Tires/Wheels..... | 3-3 |
| Lubrication | 3-3 |
| Hitching to the Tractor | 3-4 |
| Drawbar Hitching (60'/66'/80'/88'/90' Toolbars) | 3-4 |
| Drawbar Hitching (1800 - 40'/44' Toolbars) | 3-5 |
| Transport Chain | 3-6 |
| Hydraulic Connections | 3-7 |
| Applicator Solution Pump Hydraulics..... | 3-7 |
| Toolbar Hydraulics..... | 3-9 |
| Electrical Connection..... | 3-9 |
| Steerable Hitch..... | 3-9 |
| Jack Usage | 3-10 |
| Parked Position (60'/66'/80'/88'/90' Toolbars) | 3-10 |
| Transport Position (60'/66'/80'/88'/90' Toolbars)..... | 3-10 |
| Parked Position (1800 - 40'/44' Toolbars) | 3-11 |
| Transport Position (1800 - 40'/44' Toolbars)..... | 3-11 |
| Transporting..... | 3-12 |
| Drawbar Connection | 3-12 |
| Toolbar Operation (60'/66'/80'/88'/90' Toolbars) | 3-13 |
| Unfolding..... | 3-13 |
| Folding | 3-13 |
| Raising/Lowering in the Field | 3-14 |
| Wing Fold Stops | 3-14 |
| Toolbar Operation (1800 - 40'/44' Toolbars) | 3-15 |
| Unfolding..... | 3-15 |
| Folding | 3-15 |
| Raising/Lowering in the Field | 3-16 |
| Depth Stop/Bushings | 3-16 |
| Dual Width Toolbar..... | 3-17 |
| Filling Applicator..... | 3-18 |
| Quick Fill | 3-18 |
| Inductor | 3-19 |
| Basic Operation | 3-19 |
| Tank Mixing..... | 3-19 |
| Jug and Inductor Tank Rinsing..... | 3-20 |
| Orifice and Nozzle Installation..... | 3-21 |
| Flow Ball Indicator..... | 3-22 |

Preparing Tractor

- Before operating applicator, read the tractor operator's manual and gain an understanding of its safe methods of operation.
- Check the tractor brakes and transport lights. Make sure they are in proper working order.
- Check the tractor hydraulic oil reservoir and add oil if needed.
- Verify that the tractor is adequately ballasted for drawbar operation at the anticipated draft and vertical tongue load. Vertical tongue load of a loaded applicator is approximately 8,500 lbs. unfolded (4,800 lbs. with toolbars folded to transport position). Ensure that the tractor's drawbar has sufficient strength to support this load.
- If possible, adjust the tractor drawbar vertically so the top side of the drawbar is at least 18 inches from the ground. Alternately, the applicator hitch may be adjusted vertically by choosing other mounting holes provided.
- Raise and secure all tractor 3-point hitch linkage to prevent interference with the implement tongue and hydraulic hoses during turning.

Preparing Applicator

Perform the service checks as outlined. Repair or replace any damaged or worn parts before operating.

Hardware

Check for loose bolts and nuts, and tighten as needed. Check again after the first half-day of operation.

Pivot Pins

Check that all pins are in place and in good condition. Replace any worn, damaged or missing pins.

Hitch

Check hitch and hitch retention hardware for damage and wear.

Hydraulic System

Check all hoses and cylinders for signs of leakage. Hoses should not be kinked, twisted or rubbing against sharp edges. Re-route or repair hoses as necessary. Refer to SAFETY section for additional information on safe repair and inspection of hydraulic components.

Preparing Applicator (continued)

Tires/Wheels

Check tire pressures and maintain at recommended values listed in the MAINTENANCE section.

CAUTION

- **IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGULARLY. SEE TORQUE PAGE IN THE “MAINTENANCE” SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.**

IMPORTANT

- *Installing wheels without the proper inset/offset could result in hub or spindle failure. This will cause substantial damage to the applicator and is not covered by warranty. Inset/offset will vary depending on tire size. Consult dealer for proper inset/offset.*

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Tire manufacturers' phone numbers and web sites are listed in the MAINTENANCE section for your convenience.

Lubrication

Lubricate the applicator as outlined in the MAINTENANCE section.

Hitching to the Tractor

Drawbar Hitching (60', 66', 80', 88', 90' Toolbars)

⚠ WARNING

- **DO NOT STAND BETWEEN THE APPLICATOR AND TRACTOR WHEN HITCHING. ALWAYS ENGAGE PARKING BRAKE AND STOP ENGINE BEFORE INSERTING HITCH PIN.**

Connect the hitch to the tractor drawbar. Do not attempt to hitch to any other location on the tractor. (FIG. 3-1)


NOTE: Only use the centered position on the hitch and tractor drawbar and lock in place.

The applicator is equipped with a single tang ball swivel hitch (JAP3228) with a 2" hitch ball which requires a 2" diameter drawbar pin.

The applicator must be relatively level in order for the tank volume indicator to read accurately.

The holes in the hitch and vertical holes in the tongue allow for adjustment so the tank sits level.

FIG. 3-1



IMPORTANT

- *The use of a smaller-diameter hitch pin will result in additional clearance between the implement hitch and pin. This additional clearance may cause accelerated pin and hitch wear, along with more pronounced jolting from the applicator during operation.*
- *Verify and/or adjust the applicator hitch height before coupling to the tractor. The applicator hitch is adjusted by unbolting the hitch and reinstalling in a different set of holes provided.*
- *After inserting drawbar pin, secure with a locking device to help prevent uncoupling during use.*

Hitching to the Tractor (continued)

Drawbar Hitching (1800 - 40'/44' Toolbars)

⚠ WARNING

- **DO NOT STAND BETWEEN THE APPLICATOR AND TRACTOR WHEN HITCHING. ALWAYS ENGAGE PARKING BRAKE AND STOP ENGINE BEFORE INSERTING HITCH PIN.**

IMPORTANT

- *Tractors with rear duals must use the bolt-on hitch extension (410887G or 410887R) and associated hardware (FIG. 3-2). When repositioning hitch, torque 1"-8UNC hardware to 525 ft-lbs. See "Dealer Set Up" in SET UP section.*

Connect the hitch only to the tractor drawbar. Do not attempt to hitch to any other location on the tractor. (FIG. 3-3)

Lock the tractor drawbar in the centered position.

The applicator is equipped with a single tang hitch (TA610050) that is recommended to be used with 1 1/2" drawbar pin.

NOTE: 1 1/2" pin is for a CAT III drawbar.

The applicator must be relatively level in order for the tank volume indicator to read accurately.

NOTE:

Empty/Transport Tongue Weight is 1,450 lbs.
Loaded/Operating Tongue Weight is 4,025 lbs.

FIG. 3-2





FIG. 3-3



IMPORTANT

- *The use of a smaller-diameter hitch pin will result in additional clearance between the implement hitch and pin. This additional clearance may cause accelerated pin and hitch wear, along with more pronounced jolting from the applicator during operation.*
- *Verify and/or adjust the applicator hitch height before coupling to the tractor. The applicator hitch is adjusted by unbolting the hitch and reinstalling in a different set of holes provided.*
- *After inserting drawbar pin, secure with a locking device to help prevent uncoupling during use.*

Hitching to the Tractor (continued)

Transport Chain

Always use a transport chain when connecting the applicator directly to a tractor. Make sure the intermediate chain support is in use. **DO NOT** use the intermediate chain support as the chain attaching point. FIG. 3-4 shows how the transport chain must be installed between the tractor and applicator.

Transport chain should have a minimum rating equal to the gross weight of the implement and all attachments. Use only ASABE approved chain. Allow no more slack in the chain than necessary to permit turning.

Transport chain connection shown for illustration purposes only. Refer to tractor manufacturer for proper attachment.



FIG. 3-4



CAUTION

- REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED OR DAMAGED. DO NOT WELD TRANSPORT CHAIN.

Hitching to the Tractor (continued)

Hydraulic Connections

After cleaning hydraulic hose couplers, connect to tractor hydraulic circuits as follows:

Applicator Solution Pump Hydraulics

IMPORTANT

- *The applicator pump is hydraulically driven, and needs to be configured correctly to match the type of hydraulic system on the tractor (closed center, open center, load-sensing, etc.). Failure to configure the pump correctly may permanently damage the pump through over-speeding and over-pressurizing. Refer to the SET UP section of this manual for guidelines on configuring the applicator pump.*

Connect hoses from the applicator pump to a tractor selective control valve (SCV) circuit (FIG. 3-5). The pump inlet (marked PUMP PRESSURE) should be connected to the RETRACT port and the pump outlet (marked PUMP RETURN) to a low-pressure return port at the tractor (recommended) or to the EXTEND port. If connected to the EXTEND port, it is recommended to shut the pump down in float to preserve pump life.

NOTE: It is recommended to pressurize all hydraulic circuits using the retract outlets on the SCVs. This allows all circuits to be shut-off by engaging the hydraulic float feature of the tractor hydraulic system.



Hitching to the Tractor (continued)

Applicator Solution Pump Hydraulics (continued)

| Hose Connections | | | | Function Settings For Tractors | |
|---|-----|--------|----------|--------------------------------|---|
| Hose Identification | SCV | Extend | Retract | Flow | Detent (Time) |
| Main Lift Up / Down | 1 | Up | Down | 30 GPM Maximum | Constant |
| Wing Fold In / Out | 2 | In | Out | 5 GPM Maximum | 60 seconds or as required for full extend and retract |
| Outer Wing Fold In / Out | 3 | In | Out | 5 GPM | Constant |
| Pump Pressure / Return | | | | | |
| ACE 205/HYPRO 930C PWM | 4 | Return | Pressure | 11 GPM | Constant |
| or ACE HYD 750 | 4 | Return | Pressure | 17 GPM | Constant |
| Steerable Hitch Pressure / Return (If Equipped) | 5 | Return | Pressure | 5 GPM | Constant |

To protect the applicator pump from damage due to excessive speed, adjust circuit flow to minimum setting prior to operating circuit for the first time.

IMPORTANT

- *Never operate applicator pump dry, or with pump inlet selector valve closed. Pump damage may result.*

Hitching to the Tractor (continued)

Toolbar Hydraulics

CAUTION

- **DO NOT UNFOLD OR FOLD TOOLBAR WITHOUT HITCHING TO THE TRACTOR.**

The applicator has 4 sets of hydraulic hoses (5 if equipped with steerable hitch).

NOTE: It is recommended to pressurize all hydraulic circuits using the retract outlets on the SCV's. This allows all circuits to be shut-off by engaging the hydraulic float feature of the tractor hydraulic system.

IMPORTANT

- *If the SCV control lever kicks out, the most likely reason is excessive hydraulic pressure. Try reducing the tractor's flow control setting.*

Refer to the MAINTENANCE section for diverter valve and sequence valve setup information.

Before disconnecting hoses from the tractor, relieve pressure from the lines. See tractor's operators manual for proper procedure to relieve pressure.

WARNING

- **AFTER INITIAL SET-UP OR REPLACEMENT OF ANY HYDRAULIC COMPONENT ON THE APPLICATOR, AIR MUST BE REMOVED FROM THE WING-FOLD HYDRAULIC SYSTEM PRIOR TO ITS FIRST USE. FAILURE TO DO SO MAY RESULT IN DAMAGE TO TOOLBAR COMPONENTS DUE TO RAPID MOVEMENT. SEE AIR PURGING INSTRUCTIONS IN MAINTENANCE SECTION.**

Electrical Connection

The main harness has a 7-pin (round) plug conforming to SAE standards that connects to tractor. If your tractor does not have the mating socket connector, contact your tractor dealer. (FIG. 3-6)

The wiring schematic for this applicator, as shown in the MAINTENANCE section, complies with current ASABE standards. Always verify correct electrical function before using this applicator.




FIG. 3-6

Steerable Hitch

Refer to Steerable Hitch Operations Manual.

Jack Usage

WARNING


- **UNHITCHING A LOADED APPLICATOR CAN CAUSE SERIOUS INJURY OR DEATH DUE TO TONGUE RISING OR FALLING. ALWAYS HAVE A LOADED APPLICATOR ATTACHED TO A TRACTOR.**

Use jack to support an empty applicator, never a loaded applicator. Always have a loaded applicator hooked to tractor.

Parked Position (60', 66', 80', 88', 90' Toolbars)

Remove keeper and pin while supporting bottom of jack. Move the jack to vertical position and reinstall hitch pin and keeper. Lower drop leg to contact the ground. Crank jack leg downward to completely remove the hitch weight from tractor drawbar. (FIG. 3-7)


FIG. 3-7



Transport Position (60', 66', 80', 88', 90' Toolbars)

After tractor connection is established, raise jack leg of the jack to highest position to maximize ground clearance. Remove keeper and pin. Pivot bottom of jack to toward the applicator tongue so generally parallel to the slanted portion of the applicator tongue. Reinstall the pin and keeper. (FIG. 3-8)


FIG. 3-8



Jack Usage (continued)


Parked Position (1800 - 40'/44' Toolbars)

Remove jack retaining pin while supporting bottom of jack. Move the jack from storage bushing to lower jack bushing and reinstall pin. Crank jack leg downward to completely remove the hitch weight from tractor drawbar. (FIG. 3-9)



Transport Position (1800 - 40'/44' Toolbars)

After tractor connection is established, raise jack leg of the jack to highest position to maximize ground clearance. Remove jack pin. Remove jack and move to transport mount location on the side of the tongue. Reinstall the jack pin. (FIG. 3-10)



Transporting

Drawbar Connection

WARNING

- USE EXCEPTIONAL CARE WHEN OPERATING APPLICATOR EQUIPPED WITH SINGLE TIRES AND SET AT NARROW WHEEL SPACING. THE POSSIBILITY OF TIPPING OVER DURING TURNS OR TRAVEL ON ROUGH ROADS IS INCREASED UNDER THESE CONDITIONS.

CAUTION

- THIS IMPLEMENT IS NOT EQUIPPED WITH BRAKES. ENSURE THAT THE TOWING VEHICLE HAS ADEQUATE WEIGHT AND BRAKING CAPACITY TO TOW THIS IMPLEMENT.
- IMMEDIATELY PRIOR TO ROAD TRANSPORT, RUN THE FULL FOLD SEQUENCE FOR PROPER SYSTEM PRESSURES AND TO AVOID INADVERTENT MOVEMENT.



See towing vehicle manual for towing and braking capacity. Regulate speed to road conditions. Maximum speed of applicator with wheels should never exceed 20 m.p.h. Maximum speed of applicator with tracks should never exceed 15 m.p.h.

Secure drawbar pin with a locking device and lock tractor drawbar in centered position.

Secure transport chain to tractor before transporting, see FIG. 3-11. Use good judgment when transporting equipment on highways. Regulate speed to road conditions and maintain complete control.

It is probable that this implement is taller, wider, and longer than the towing tractor. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.

Toolbar Operation (60', 66', 80', 88', 90' Toolbars)

DANGER

- PERFORM TOOLBAR UNFOLDING AND FOLDING OPERATIONS ONLY IN AREAS WITH ADEQUATE HEIGHT, WIDTH AND LENGTH CLEARANCES. IN PARTICULAR, BE MINDFUL OF LOCATION OF OVERHEAD POWER LINES. FAILURE TO DO SO CAN RESULT IN PERSONAL INJURY AND PROPERTY DAMAGE.

WARNING

- KEEP ALL PERSONNEL A SAFE DISTANCE AWAY FROM THE APPLICATOR WHEN UNFOLDING OR FOLDING THE TOOLBAR. PERSONAL INJURY CAN RESULT FROM IMPACT WITH TOOLBAR.
- DO NOT EXCEED 10 MPH DURING OFF-HIGHWAY TRAVEL.

Unfolding (60', 66', 80', 88', 90' Toolbars)

IMPORTANT

- *Never fold or unfold the unit without attaching to tractor first. Refer to “Hitching to the Tractor” and “Jack Usage” in this section.*
1. Engage the toolbar lift circuit to fully raise the toolbar up out of the main wing rests.
 2. Engage the main wing unfold circuit to unfold the main wings. The toolbar transport latch will unlatch and the main wing will swing out, then the pivoting coulter tube will rotate down and the main wing masts will lower. If the wings do not sequence properly, the unfold sequence valve on the hydraulic manifold will need to be adjusted. (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Sequence Valve Adjustments”.)
 3. Engage the outer wing unfold circuit to unfold the outer wing. (With the wing stops removed, the wings can flex down 8 degrees horizontal—there is no limit for the flex upwards.)
 4. Engage the toolbar lift and lower circuit to lower toolbar to desired working depth. Once the toolbar is in the ground, the lower circuit should be locked in continuous detent to engage the hydraulic down pressure feature of the toolbar. (The outer wings also have a down pressure function and the outer wing extend can be locked in detent to engage the outer wing down pressure feature.) (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Down Pressure”.)

Folding (60', 66', 80', 88', 90' Toolbars)

1. Engage the toolbar lift circuit to raise the toolbar and fully tilt the wings up.
2. Engage the outer wing fold circuit to fold the outer wings.
3. Engage the main wing fold circuit to fold the main wings. The pivoting coulter tube will rotate up and main wing masts will raise first, then the main wings will swing in. If the wings do not sequence properly, the fold sequence valve on the hydraulic manifold will need to be adjusted. (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Sequence Valve Adjustments”.)
4. Engage the toolbar lower circuit to lower the wings into the main wing rests and to lower the toolbar into the transport latch.

Toolbar Operation (60', 66', 80', 88', 90' Toolbars) (continued)


Raising/Lowering Toolbar In The Field

IMPORTANT

- If unit is equipped with injection knives, the tractor must be moving forward when lowering toolbar into the ground.
1. Engage the toolbar lift and lower circuit to raise the toolbar and fully tilt the wings up.
 2. When you are ready to lower the toolbar, engage the toolbar lower circuit to lower toolbar to desired working depth. Once the toolbar is in the ground, the lower circuit should be locked in continuous detent to engage the active hydraulic down pressure feature of the toolbar. (The outer wings also have a down pressure function and the outer wing extend can be locked in detent to engage the outer wing down pressure feature.) (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Down Pressure”.)

Wing Fold Stops

Cylinder stops can be added, before operating, to the wing tilt cylinders. This limits how far the wing pivots up when turning on the headlands reducing amount of time it takes to fully raise the toolbar. Cylinder stops **MUST** be removed from the wing tilt cylinders before transporting. See FIG. 3-12.



Toolbar Operation (1800 - 40'/44' Toolbars)

DANGER

- **PERFORM TOOLBAR UNFOLDING AND FOLDING OPERATIONS ONLY IN AREAS WITH ADEQUATE HEIGHT, WIDTH AND LENGTH CLEARANCES. IN PARTICULAR, BE MINDFUL OF LOCATION OF OVERHEAD POWER LINES. FAILURE TO DO SO CAN RESULT IN PERSONAL INJURY AND PROPERTY DAMAGE.**

WARNING

- **KEEP ALL PERSONNEL A SAFE DISTANCE AWAY FROM THE APPLICATOR WHEN UNFOLDING OR FOLDING THE TOOLBAR. PERSONAL INJURY CAN RESULT FROM IMPACT WITH TOOLBAR.**

Unfolding

IMPORTANT

- *Never fold or unfold the unit without attaching to tractor first. Refer to “Hitching to the Tractor” and “Jack Usage” in this section.*
1. Engage the main wing fold/unfold circuit to unfold the main wings. The toolbar transport latch will unlatch and the main wing unfold.

NOTE: If the wings do not sequence properly, the unfold sequence valve on the hydraulic manifold will need to be adjusted. (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Sequence Valve Adjustments”.)
 2. Engage the toolbar lift/lower circuit to lower toolbar to desired working depth. Once the toolbar is in the ground, the lower circuit should be locked in continuous detent to engage the hydraulic down pressure feature of the toolbar. (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Down Pressure”.)

Folding

1. Engage the toolbar lift and lower circuit to raise the toolbar and fully tilt the wings up.
2. Engage the main wing fold and unfold circuit to fold the main wings. The transport latch will engage and then the main wings will fold back. If the wings do not sequence properly, the fold sequence valve on the hydraulic manifold will need to be adjusted. (Refer to MAINTENANCE section “Toolbar & Wing Adjustments - Sequence Valve Adjustments”.)

Toolbar Operation (1800 - 40'/44' Toolbars) (continued)

Raise/Lower Toolbar In The Field

NOTE: The tractor SCV 2 main wing fold/unfold circuit must be running in float at all times.

NOTE: If unit is equipped with injection knives, the tractor must be moving forward when lowering toolbar into the ground.

1. Engage the toolbar lift and lower circuit to raise the toolbar and fully tilt the wings up.
2. When you are ready to lower the toolbar, engage the toolbar lift and lower circuit to lower toolbar to desired working depth. Once the toolbar is in the ground, the lower circuit should be locked in detent to engage the hydraulic down pressure feature of the toolbar. (Refer to MAINTENANCE section "Toolbar & Wing Adjustments - Down Pressure".)

Depth Stop/Bushings

NOTE: The depth stop/bushing is to adjust the depth of the center section and partially the main wings. The depth stop/bushing contacts the bottom of the center section toolbar main tubes when it is lowered down. To adjust the depth, remove the lynch pin on the depth stop and switch out the bushing.

IMPORTANT

- *Toolbar needs to be raised and secured in latch before changing the depth stop bushings. See SET UP section for bushing location.*
1. Depths can be changed in 1" increments by using the next size larger/smaller bushing.
 2. To get additional depth control, the depth stop weldment can be flipped over by removing the pins shown in the image below, this gives an additional 3" of adjustment.
 3. Repeat steps 1 and 2 adjusting each gauge wheel position on all of the wing sections. (FIG. 3-13)




FIG. 3-13

Toolbar Operation (1800 - 40'/44' Toolbars) (continued)

Dual Width Toolbar

1. Fold the toolbar to 30' for the dual width application. (FIG. 3-14)
2. Turn off sections 1 and 5 on the flow controller, and turn on the chemsaver valves to the outside coulters on each main wing. (FIG. 3-14)
3. In the controller calibration settings, change each section widths for sections 2 and 4 from 110" to 135". Refer to "Controller Calibration Settings" in the SET UP section on page 2-19.




FIG. 3-14

Filling Applicator

Quick Fill



CAUTION

- NEVER LEAVE APPLICATOR UNATTENDED WHILE FILLING. TANK CONTENTS MAY SPILL OUT OF AIR VENTS IF OVERFILLED.

IMPORTANT

- *The tank is designed with additional air expansion space in excess of the rated capacity. The full capacity can be reached with the level approximately 6"- 8" below the top surface of the tank access hatch (lid opened).*

The QUICK-FILL VALVE and indicator level are shown in FIG. 3-15 for reference.

1. Assure that QUICK-FILL VALVE is <OFF>.
2. To fill the tank, remove the cap and attach the hose to the 3" quick fill coupler. Turn quick-fill valve on the tank <ON>.
3. Fill applicator solution tank to desired level.
4. Return valve to <OFF> when desired fill level is reached.
5. Reinstall the cap when finished.




FIG. 3-15

Inductor

Basic Operation

IMPORTANT

- The main solution tank should contain at least 50 gallons of liquid.

The INDUCTION VALVE, INDUCTOR MIX VALVE, and tank are shown in FIG. 3-16 and 3-17 for reference.



- Assure INDUCTION VALVE on the bottom of the inductor tank is in the <OFF> position.
- Push the tank lever and lower it to the “fill” position.

- Set valves: **VALVE SETTINGS**

| | |
|-----------------------------|--------------------|
| PUMP INLET VALVE | OPEN |
| INDUCTOR MIX VALVE (OPT.) | OFF |
| AGITATION CONTROL (100 PSI) | PARTIALLY OPEN 1/4 |
| INDUCTION VALVE | OFF |

- Start pump.
- Open lid and pour chemical into inductor tank. (If using dry chemical, open INDUCTOR MIX valve to mix chemical, using care not to overfill inductor tank.)
- Close the lid.
- Open INDUCTION VALVE on the bottom of the inductor tank to evacuate the inductor tank.
- Close INDUCTION VALVE when the inductor tank is empty and rinse.
- Raise the tank to storage position.

WARNING

- WHEN USING JUG RINSER, BE CAREFUL NOT TO SPRAY SOLUTION INTO EYES OR FACE.



Tank Mixing

Fertilizer additives can be added to the solution tank through the use of the optional inductor. Before adding fertilizer additives, ensure the main tank contains at least 50 gallons of liquid.

WARNING

- ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.

Inductor (continued)

Jug and Inductor Tank Rinsing

⚠ WARNING

- ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.

IMPORTANT

- Do not allow pump to run dry. Pump damage will result.
- Rinse the jug, nozzle, or tank with the product in the main solution tank.

The INDUCTION VALVE, INDUCTOR MIX VALVE, and tank are shown in FIG. 3-18 and 3-19 for reference.

1. To rinse a chemical container, place container upside down on rinse nozzle and squeeze handle on rinse wand.
2. To rinse inductor tank, close lid, open INDUCTOR MIX valve and squeeze rinse wand handle for approximately 10 seconds.
3. To rinse out container nozzle, close lid, and activate jug rinser for approximately 10 seconds.
4. Repeat steps 2 and 3 for additional rinsing, if desired.
5. Close INDUCTOR MIX valve and release rinse wand when rinsing is complete.
6. When inductor tank is empty, close INDUCTOR DRAIN valve.
7. Close INDUCTOR FLOW valve then set AGITATION CONTROL to proper settings.
8. Raise tank to storage position.

⚠ WARNING

- WHEN USING JUG RINSER, BE CAREFUL NOT TO SPRAY SOLUTION INTO EYES OR FACE.



FIG. 3-18




FIG. 3-19


Orifice and Nozzle Installation

WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.

1. Attach the nozzle body to the nozzle mount plates at the top of the coulters post using two 1/4" flange nuts (9004720) and two 1/4" x 3/4" capscrews (900900-003) (FIG. 3-20)
2. Install the desired orifice plate into each hose quick connect cap prior to attaching the hose to the nozzle body tee.
3. Route the 3/8" EPDM hose along the front of the vertical coulters post and attach each hose to the nozzle body tee (FIG. 3-20). Secure with hose clamps.

NOTE: Rotate the coulters assembly clockwise and counterclockwise on the vertical shaft to assure proper hose slack in the hose below the nozzle body to allow for oscillation of the coulters assembly.




Flow Ball Indicator

⚠ WARNING

- ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.
- WASH HANDS AND EXPOSED SKIN IMMEDIATELY AFTER CONTACT WITH SPRAY/FERTILIZER SOLUTION AND APPLICATION EQUIPMENT.
- REMOVE CLOTHING IMMEDIATELY IF CHEMICALS PENETRATE CLOTHING AND CONTACT SKIN. WASH THOROUGHLY AND PUT ON CLEAN CLOTHING.

The Flow Ball Indicator plumbing kit allows the operator to easily determine changes occurring in the hoses. It operates by utilizing hoses of equal length and size allowing for the ball to float at equal levels.

1. When liquid is flowing evenly all balls hover at the same level.
2. A ball that is lower than the others indicates the flow is too low due to a restriction or blockage.
3. A ball that is higher than the others indicates the flow is too high due to a leaking fitting or hose.



Selecting the Correct Flow Ball

1. Calculate the flow rate required per flow indicator with the following formula:

$$\text{Flow Rate} = \frac{\text{MPH} \times \text{GPA} \times \text{Nozzle Spacing (in)} \times \text{DCF}^*}{5940}$$

*DCF = Density Conversion Factor

| Weight of Solution | Density Conversion Factor (DCF) |
|-------------------------------|---------------------------------|
| 8.34 lb./gal. (Water) | 1.00 |
| 10.65 lb./gal. (28% Nitrogen) | 1.13 |
| 11.05 lb./gal. (32% Nitrogen) | 1.15 |

Example:

Speed = 8 miles per hour
 Rate = 10 gallons per acre
 Nozzle Spacing = 20 inches
 Liquid = 28% Nitrogen

$$\text{Flow Rate } 0.304 = \frac{8 \text{ MPH} \times 10 \text{ GPA} \times 20'' \text{ Nozzle Spacing (in)} \times 1.13 \text{ DCF}^*}{5940}$$

Flow Ball Indicator (continued)

2. Select the flow indicator ball required for you application using the calculated flow rate and the guide below.

| Flow Indicator Ball Selector Guide | | |
|------------------------------------|-----------------------|----------------------------|
| Part Number | Color | Flow Rate - U.S. GPM Range |
| 9007782 | Green Polypropylene | 0.05 - 0.18 |
| 9007781 | Red Celcon | 0.09 - 0.30 |
| 9007780 | Maroon Glass | 0.31 - 0.72 |
| 9007779 | 1/2" Stainless Steel | 0.40 - 1.33 |
| 9007883 | 7/16" Stainless Steel | 1.00 - 2.70 |

Flow Ball for Half Rate Nozzles

NOTE: With the applicator unfolded, the end rows use the half rate nozzles. If applicator is running folded, internal rows use half rate nozzles.

1. Half rate nozzles require a different size ball than than full rate nozzles. Once the ball has been sized for the full rate nozzles, pick the ball that corresponds to half the full rate. The half rate hoses have been factory marked with a gray sleeve (Fig. 3-22).



FIG. 3-22

Ball Removal/Replacement

NOTE: Flush the system with clean water before servicing.

1. Remove the fittings from the top of the flow ball manifold by removing the retaining clip (Fig. 3-23)



FIG. 3-23

NOTE: During operation in the event of a blockage, each hose has been connected in order, beginning with the left most coultter nozzle representing the left most flow ball indicator. It is recommended the fittings, be removed to access the ball, be reinstalled in the same location to maintain similar visual troubleshooting capabilities.


2. Remove the rear capscrews from the flow ball manifold mounting brackets. This will allow the flow ball manifold assembly to be rotated (Fig 3-24).



FIG. 3-24

Flow Ball Indicator (continued)

3. Rotate the manifold assembly down carefully to avoid any residual liquid that may be in the manifold to avoid coming in contact with exposed skin, eyes, or other sensitive areas. (Fig. 3-25)



4. Fully tilt manifold bracket down and remove plastic ball stop. This will allow indicator balls to roll out of flow monitors. (Fig. 3-26)




5. Rotate bracket up completely, align capscrew holes, reinsert hardware removed in Step 2, and insert indicator balls into the flow monitors.
6. Reinsert the fittings removed in step 1 ensuring that the hoses marked with the gray sleeves are inserted on the flow monitors that have the balls selected for the half rate nozzles. Reinsert retaining clips.

Section IV Maintenance

| | |
|---|------|
| Lubrication (60'/66'/80'/88'/90' Toolbars)..... | 4-2 |
| Lubrication (1800 - 40'/44' Toolbars)..... | 4-4 |
| Applicator Maintenance..... | 4-5 |
| Seasonal Storage..... | 4-5 |
| Purging A Hydraulic System | 4-6 |
| Hydraulically Driven Centrifugal Pump..... | 4-7 |
| Tracks..... | 4-8 |
| Toolbar & Wing Adjustments | 4-8 |
| Main Wing & Wing Mast Adjustment..... | 4-9 |
| Stop Bolts | 4-9 |
| Slider Adjustment..... | 4-9 |
| Diverter Valve (60'/66'/80'/88'/90' Toolbars) | 4-10 |
| Diverter Valve (40' Toolbar / 1800 Model) | 4-10 |
| Center Toolbar & Main Wing Down Pressure | 4-11 |
| Pivoting Coulter Tube Adjustment | 4-12 |
| Shim Adjustment..... | 4-12 |
| Stop Bolt Adjustment..... | 4-12 |
| Outer Wing Adjustment..... | 4-12 |
| Wing Stop & Shim Adjustment..... | 4-12 |
| Outer Wing Down Pressure | 4-13 |
| Sequence Valve Adjustment (40' Toolbar / 1800 Model)..... | 4-14 |
| Unfolding to Working Position..... | 4-14 |
| Folding to Transport Position | 4-14 |
| Sequence Valve Adjustment (60'/66'/80'/88'/90' Toolbars)..... | 4-15 |
| Unfolding to Working Position..... | 4-15 |
| Folding to Transport Position | 4-15 |
| Center Toolbar & Wing Mast Cylinder End Replacement (80'/88'/90' Toolbars)..... | 4-16 |
| Coulter Hub Adjustment and Replacement | 4-19 |
| Coulter Spring Replacement..... | 4-21 |
| Coulter Post Mount Bracket Adjustment | 4-22 |
| Closer Wheel Adjustment & Replacement (Optional) | 4-23 |
| Filters (1800 - 40'/44' Toolbars)..... | 4-25 |
| Primary Filter..... | 4-25 |
| Secondary Filter..... | 4-26 |
| Filters (60'/66'/80'/88'/90' Toolbars)..... | 4-27 |
| Primary Filter | 4-27 |
| Secondary Filter..... | 4-28 |
| Winterizing..... | 4-29 |
| Schematics | 4-30 |
| Troubleshooting..... | 4-42 |
| Wheel, Hub and Spindle Disassembly and Assembly | 4-43 |
| Wheels and Tires | 4-45 |
| Wheel Nut Torque Requirements..... | 4-45 |
| Tire Pressure | 4-46 |
| Tire Warranty | 4-47 |
| Tracks..... | 4-47 |
| Equalizer Track System | 4-47 |
| Track Warranty..... | 4-47 |
| Complete Torque Chart | 4-48 |
| Hydraulic Fittings - Torque and Installation | 4-49 |

Lubrication (For 60', 66', 80', 88', 90' Toolbars)



Lubrication (For 60', 66', 80', 88', 90' Toolbars) (continued)


To keep your applicator in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.

Use EP-2 lubricant at the locations described in the chart.

The lubrication locations and recommended schedule are as follows:

| ITEM | DESCRIPTION | POINT | QTY. | HOURS |
|------|---|-------|----------|-------------------|
| A | Hitch Pivot - 80' / 88' / 90' Units Only | 1 | 10 Shots | Weekly |
| B | Latch Pivot Pin | 1 | 5 Shots | Weekly |
| C | Tongue Brace Assembly/Turnbuckle - 80' / 88' / 90' Units Only | 4 | 1 Shot | Once Every Season |
| D | Coulter Swivel | 2 | 2 Shots | Weekly |
| E | Coulter Hub | - | 10 Shots | Once Every Season |
| F | Main Wing Gauge Wheel Hub | 2 | Repack | Once Every Season |
| G | Outer Wing Gauge Wheel Hub | 2 | Repack | Once Every Season |
| H | Parallel Lift Arm Pivot Pin | 8 | 5 Shots | Weekly |
| I | Wing Mast Hinge Pivot Pin | 4 | 5 Shots | Weekly |
| J | Wing Mast Roller Pin | 4 | 3 Shots | Weekly |
| K | Wing Mast Adjustment Roller Pin | 4 | 3 Shots | Weekly |
| L | Wing Mast/Main Wing Hinge Area | 2 | 10 Shots | Weekly |
| M | Wing Mast/Cylinder Pin Weldment - 80' / 88' / 90' Units Only | 2 | 3 Shots | Weekly |
| N | Outer Wing Hinge Area | 2 | 10 Shots | Weekly |
| O | Applicator Frame Hub (NOT SHOWN) | 2 | Repack | Once Every Season |
| P | Hitch | 2 | 2 Shots | Weekly |
| Q | Track Lubrication (Refer to your 14" Wide x 80" Long Equalizer™ track manual.) | - | - | - |

Lubrication (For 1800 40'/44' Toolbars)



To keep your applicator in top operating condition and to assure its proper performance and reliability for a long period of time, periodic inspection and lubrication is a must.

The lubrication locations and recommended schedule are as follows:

| ITEM | DESCRIPTION | POINT | LUBRICANT | QTY. | HOURS |
|------|----------------------------------|-------|-----------|----------|-------------------|
| A | Latch Pivot Pin | 1 | EP-2 | 5 Shots | Weekly |
| B | Main Toolbar Pivot Hinge | 1 | EP-2 | 5 Shots | Weekly |
| C | Main Wing Linkage Pins | 6 | EP-2 | 3 Shots | Weekly |
| D | Coulter Swivel | 2 | EP-2 | 2 Shots | Weekly |
| E | Coulter Hub | - | EP-2 | 10 Shots | Once Every Season |
| F | Main Wing Gauge Wheel Hub | 2 | EP-2 | Repack | Once Every Season |
| G | Main Wing/Outer Wing Hinge Area | 2 | EP-2 | 10 Shots | Weekly |
| H | Applicator Frame Hub (NOT SHOWN) | 2 | EP-2 | Repack | Once Every Season |

Applicator Maintenance

DANGER

- ELECTROCUTION WILL CAUSE SERIOUS INJURY OR DEATH. THE APPLICATOR IS NOT INSULATED. KEEP AWAY FROM ALL ELECTRICAL LINES AND DEVICES. ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT.



WARNING

- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.
- ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.
- AVOID BREATHING SPRAY MIST OR VAPOR.
- WASH HANDS BEFORE EATING, DRINKING, CHEWING GUM, OR USING TOILET.
- NEW HYDRAULIC SYSTEMS OR SYSTEMS THAT HAVE BEEN MAINTAINED MUST BE PURGED OF AIR BEFORE OPERATING OR MOVING MACHINE TO PREVENT SERIOUS INJURY OR DEATH.

CAUTION

- SHARP EDGES ON COULTER BLADES AND KNIVES CAN CAUSE SERIOUS INJURY. BE CAREFUL WHEN WORKING AROUND COULTER BLADES AND KNIVES.

Seasonal Storage

Check coulters swivel limit spiral and roll pins for wear. Replace as needed. See FIG. 4-1 on next page.

Always open all valves to remove any fluids and to allow moisture to dry.

Immediately after season is finished, completely wash machine to remove corrosive fertilizer inside and out before storing. When using pressure washers maintain an adequate distance so not to force water into bearings, hydraulic seals, or electrical connections.

Repaint all areas where paint has been removed to keep rust from developing. Coat areas of coulters blades and knives, if equipped, and coulters posts with rust preventative material.

For 60' toolbars, lower the toolbar to working position and check for a gap between the slide and the mainframe cross it rests on. If a shim can be placed between the slide and the cross piece, add the shim. This check should be done once after 10 hours of use and then seasonally.

Applicator Maintenance (continued)

Coat exposed cylinder piston rods with rust preventative material.


Inspect machine for parts that may need to be replaced so they may be ordered in the off season.

Lubricate machine at all points outlined.

Check coulters hubs for free rotation. If blade hubs do not rotate, replace and/or pack bearings with grease. Replace coulters arm if spindle is damaged. (FIG. 4-1)

Check coulters post swivel for free movement. If post swivel does not move, free the swivels and grease. Grease the coulters post swivel until fresh grease purges top or bottom of swivel casting to prevent the coulters pivot seizing on post. (FIG. 4-1) Refer to "Lubrication" in this section.

After period of unused time, unit should be unfolded and refolded to check function of hydraulic system.



Purging A Hydraulic System

WARNING

- RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE TRACTOR OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.

1. Purge air from system as follows:

- A. Disconnect the rod end of all cylinders in a circuit. Block up all rod end of each hydraulic cylinders in each circuit so the rod can completely extend and retract without contacting any other component.
- B. Pressurize the system and maintain system at full pressure for at least 5 seconds after cylinder rods stop moving. Check that all cylinders have fully extended or retracted.
- C. Check oil reservoir in hydraulic power source and re-fill as needed.
- D. Pressurize system again to reverse the motion of step B. Maintain pressure on system for at least 5 seconds after cylinder rods stop moving. Check that cylinders have fully extended or retracted.
- E. Check for hydraulic leaks using cardboard or wood. Tighten connections according to directions in Torque Specifications in MAINTENANCE section.
- F. Repeat steps B, C, D, and E 10-12 times.
- G. De-pressurize hydraulic system and connect cylinder rods clevises to their mating lugs.

Hydraulically Driven Centrifugal Pump

ACE HYD 750 Barrier Fluid Charge

IMPORTANT

- Inflation valve must be assembled in the “IN” port of the regulating valve.

1. Turn regulating valve adjusting knob counterclockwise until it is at the minimum pressure setting. (FIG. 4-2)
2. Attach air chuck to air valve.
3. Turn adjusting knob on regulating valve clockwise until gauge reads 30 psi. (FIG. 4-2)
4. Remove the air pressure before disconnecting the hose. To add barrier fluid to the fluid chamber, disconnect the hose from the fitting on top of the hydraulically driven centrifugal pump. Remove the fitting on top of the pump. (FIG. 4-3)
5. Fill the fluid chamber by attaching a 1/8” hose to the barrier fluid and using the hose to fill the fluid chamber where the fitting was removed. (FIG. 4-4)
6. Add fluid until level is half-way up the sight gauge on the side of the pump.

NOTE: Any 1/8” hose will attach to the nipple of the barrier fluid bottle (9005518) to ease filling of the sight gauge. (FIG. 4-4)

At the end of each season, it is recommended to change/check the barrier fluid and seal. Follow the guidelines below.

- The pump requires pressure and/or fluid more frequently. Change barrier fluid and seal.
- The barrier fluid becomes cloudy, discolored, or water mixes with barrier fluid. Change barrier fluid and seal.
- The barrier fluid is clear. No service needed. Refill and store for the winter.

Refer to ACE pump manual and operating instructions.



FIG. 4-2




FIG. 4-3



FIG. 4-4

Tracks

Refer to the Equalizer® Track System manual 411200 for proper procedures.

Toolbar & Wing Adjustments

Several areas of adjustment have been designed into the toolbar to maintain proper wing folding operation throughout the life of the toolbar.

WARNING

- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.**
- **EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.**
- **KEEP HANDS CLEAR OF PINCH POINT AREAS.**
- **FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.**
- **MOVING WINGS CAN CAUSE SERIOUS INJURY OR DEATH. KEEP AWAY FROM FOLDING AND UNFOLDING WINGS.**
- **KEEP AWAY FROM OVERHEAD POWER LINES. ELECTRICAL SHOCK CAN CAUSE SERIOUS INJURY OR DEATH.**
- **TIPPING OR MOVEMENT OF APPLICATOR CAN CAUSE SERIOUS INJURY OR DEATH. APPLICATOR MUST BE HITCHED TO THE TRACTOR BEFORE OPERATING BOOM.**
- **ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.**
- **RESIDUAL PRESSURE MAY EXIST IN APPLICATOR PLUMBING EVEN WHEN UNIT IS NOT IN USE. RELIEVE PRESSURE BEFORE SERVICING ANY PLUMBING.**

Toolbar & Wing Adjustments (continued)

Main Wing & Wing Mast Adjustment

Stop Bolts


The stop bolts on the upper, front side of the center toolbar align wing mast assemblies so they can lower into the saddle area on the toolbar. (FIG. 4-5)

If the toolbar will not slide down into the saddle, the stop bolt on the side that does not lower properly needs to be adjusted.

The stop bolts on the upper back side of the center toolbar align the wing mast assemblies for transporting. (FIG. 4-5)


Adjusting Stop Bolts

1. Place the wings in transport position. (FIG. 4-5)
2. Adjust stop bolts 1/2 turn.
3. Unfold the wings and lower the toolbar into the saddle area. If the toolbar will not slide down into the saddle, repeat steps 1 and 2.



Slider Adjustment

Tighten the roller adjustment pin hardware to maintain the toolbar alignment. (FIG. 4-6)




Toolbar & Wing Adjustments (continued)

Diverter Valve (60', 66', 80', 88', 90' Toolbars)

The diverter valve relieves the down pressure on the main wing tilt cylinders so that full pressure is not applied to the wing tilt cylinders when the wings are lowered in to the wing rests.


If the valve does not engage, adjust the handle. (FIG. 4-7)



Diverter Valve (40' Toolbars / 1800 Models)

The diverter valve relieves the down pressure on the outer wing fold cylinders so that full pressure is not applied to the outer wing fold cylinders when the wings are lowered in to the wing rests.

If the valve does not engage, adjust the diverter valve forward to be activated when the wings are in the transport position. (FIG. 4-8)



Toolbar & Wing Adjustments (continued)

Center Toolbar & Main Wing Down Pressure (60', 66', 80', 88', 90' Toolbars)

Proper down pressure is achieved when the gauge wheels contact the ground and maintain the coulter depth. Excessive down pressure can cause unnecessary stress on the toolbar gauge wheel components.

Note: There is an external relief valve installed on the unit. The main wing down pressure is changed using the adjustment screw on the external valve block instead of Port 7A on the main valve block. (FIG. 4-9)

Cartridge adjustment requires the following tools: (FIG. 4-9)

- The jam nut needs an 11/16" wrench
- The set knob for the cartridge uses a 3/16" hex


1. Turn the adjustment screw all the way in (clockwise) on the existing relief valve on the main valve block at Port 7A.

Note: Adjusting the existing relief valve is critical. The center toolbar and main wing hydraulics will not function properly if not performed.

2. Loosen the jam nut on the external relief valve.
3. Turn set knob clockwise to increase pressure/counter clockwise to decrease pressure.

Note: Down pressure setting should be between 750 and 1500 PSI. DO NOT EXCEED 1500 PSI.

4. Tighten the jam nut.



Toolbar & Wing Adjustments (continued)

Pivoting Coultter Tube Adjustment

The pivoting coultter tubes and main wings are parallel to each other when in the working position. The pivoting coultter tubes can be adjusted if the pivoting coultter tubes and main wings are not parallel by adding or removing the shims. (FIG. 4-10)


The pivoting coultter tubes and main wings are straight up and down when in the transport position. The pivoting coultter tubes can be adjusted if the pivoting coultter tubes and main wings are not straight up and down by adjusting the stop bolts.

Shim Adjustment

1. Place pivoting coultter tube in the transport position.
2. Add or remove shims accordingly.
3. Lower the pivoting coultter tubes in the working position. If the pivoting coultter tubes and main wings are not parallel, repeat steps 1 and 2.

Stop Bolt Adjustment

1. Place pivoting coultter tubes in the working position.
2. Adjust stop bolts 1/2 turn.
3. Raise the pivoting coultter tube in the transport position. If the pivoting coultter tubes and main wings are not straight up and down, repeat steps 1 and 2.



Outer Wing Adjustment


Rigid Setting - no adjustment.

Float Setting - The outer wings can be adjusted to allow the wings to flex down 8 degrees and no limit for the flex up.

NOTE: When wings are in the float setting, wings will not be parallel with the center toolbar.

Wing Stop & Shim Adjustment

1. Place the wings in transport position.
2. Remove shim plates or shim plates and wing stop weldment to allow the wings to flex. (FIG. 4-11)
3. Unfold the wings. If additional adjustment is required, repeat steps 1 and 2.



Toolbar & Wing Adjustments (continued)

Outer Wing Adjustment (continued)

Outer Wing Down Pressure

Outer wing down pressure is determined by how much pressure it takes to fold the outer wings into the operating position.

Cartridge adjustment requires the following tools:

(FIG. 4-12)

- The jam nut needs an 11/16" wrench
- The set knob for the cartridge uses a 3/16" hex

1. Loosen the jam nut.
2. Turn set knob clockwise to increase pressure/counter clockwise to decrease pressure. **DO NOT EXCEED 2000 PSI.**

NOTE: Outer wing down pressure will be higher than 1500 PSI due to folding pressure requirements. Alleviate potential issues during operation by reducing outer wing fold flow to a minimum.

3. Tighten the jam nut.




FIG. 4-12

Toolbar & Wing Adjustments (continued)

Sequence Valve Adjustments (40' Toolbars / 1800 Models)


During sequence valve adjustment, disengage hydraulics, use $\frac{1}{4}$ turn adjustment, and then engage to check. Smaller increments may be used for fine tuning if needed.

Cartridge adjustment requires the following tools (FIG. 4-13 and 4-14):

- The jam nut needs an 11/16" wrench
- The set knob for the cartridge uses a 3/16" hex


Unfolding to Working Position

If the main wings are fully unfolded and the toolbar latch is not disengaged, adjust sequence valve SEQ2. Turn the adjustment screw counterclockwise until the toolbar latch actuates. (FIG. 4-13)



Folding to Transport Position

If the main wings begin to fold before the latch engages adjust sequence valve SEQ1. Rotate the adjustment screw clockwise $\frac{1}{4}$ of a turn and then cycle the fold circuit. (FIG. 4-14)



Toolbar & Wing Adjustments (continued)

Sequence Valve Adjustments (60', 66', 80', 88', 90' Toolbars)

During sequence valve adjustment, disengage hydraulics, use ¼ turn adjustment, and then engage to check. Smaller increments may be used for fine tuning if needed.

Cartridge adjustment requires the following tools (FIG. 4-15 and 4-16):


- The jam nut needs an 11/16" wrench
- The set knob for the cartridge uses a 3/16" hex

Unfolding to Working Position

The transport latch will unlatch and the wings will swing out. If the mast lift cylinder or pivoting coultter tube cylinder begin to move before the wings have completely swung outward, the sequence valve needs to be adjusted. Turn the cartridge clockwise 1/4 of a revolution at a time until no movement of these cylinders can be seen until the wings are fully outward.

If the mast and pivoting coultter tube cylinders do not move at all, the sequence valve is set too high. Turn counter-clockwise until these cylinders start to move.

FIG. 4-15



Sequence Valve Adjustment
Unfolding to Working Position
Port 3B

Folding to Transport Position

The pivoting coultter tube will rotate up and the mast lift will raise. If the main wing starts to fold back before this action is complete, the sequence valve needs to be adjusted. Turn the cartridge clockwise 1/4 of a revolution at a time until no movement of the main fold cylinders can be seen until the mast and pivoting coultter tube are fully raised.

If the main wing does not fold at all, the sequence valve is set too high. Turn counter-clockwise until the cylinder starts to move.

Sequence Valve Adjustment
Folding to Transport Position
Port 3A




FIG. 4-16

Center Toolbar & Wing Mast Cylinder End Replacement (80', 88', 90' Toolbars)

The following instructions are for replacing the center toolbar cylinder end weldments and cylinder pins.

WARNING

- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.**

 - **EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.**

 - **KEEP HANDS CLEAR OF PINCH POINT AREAS.**

 - **FALLING OR LOWERING EQUIPMENT CAN CAUSE SERIOUS INJURY OR DEATH. KEEP EVERYONE AWAY FROM EQUIPMENT WHEN SUSPENDED, RAISING, OR LOWERING.**

 - **MOVING WINGS CAN CAUSE SERIOUS INJURY OR DEATH. KEEP AWAY FROM FOLDING AND UNFOLDING WINGS.**

 - **KEEP AWAY FROM OVERHEAD POWER LINES. ELECTRICAL SHOCK CAN CAUSE SERIOUS INJURY OR DEATH.**

 - **TIPPING OR MOVEMENT OF APPLICATOR CAN CAUSE SERIOUS INJURY OR DEATH. APPLICATOR MUST BE HITCHED TO THE TRACTOR BEFORE OPERATING BOOM.**

 - **ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.**


 - **RESIDUAL PRESSURE MAY EXIST IN APPLICATOR PLUMBING EVEN WHEN UNIT IS NOT IN USE. RELIEVE PRESSURE BEFORE SERVICING ANY PLUMBING.**

1. Park the empty unit on a firm, level surface. Block the tires or tracks to keep the machine from moving. Unfold the wings into the field working position, and lower the machine to the ground. Set the vehicle parking brake. Relieve hydraulic system pressure, see “Purging A Hydraulic System” in this section. Shut off the engine and remove the ignition key. Completely disconnect the unit from the towing vehicle.




Center Toolbar & Wing Mast Cylinder End Replacement (80', 88', 90' Toolbars) (Continued)

2. Unscrew the 3/8-16UNC lock nut (9928) and remove hose holder (9006039), 3/8 flat washer (9006212) and 3/8-16UNC x 3 capscrew (9390-063). Keep hose holder and hardware. (FIG. 4-17)




3. Remove original cylinder pin (415228) and discard. (FIG. 4-18)




NOTE: Hydraulic cylinder is removed for clarity. (FIG. 4-19)

4. Loosen set screw on original cylinder end weldment (413967B).
5. Unscrew from hydraulic cylinder the original cylinder end weldment and remove two split tension bushings (9003894) and grease zerk (9501603). Discard original cylinder end weldment and parts, as shown. (FIG. 4-19)




Center Toolbar & Wing Mast Cylinder End Replacement
(80', 88', 90' Toolbars) (Continued)

NOTE: Ensure the clevis is removed from hydraulic cylinder rod end. (FIG. 4-20)




NOTE: Ensure cylinder end weldment grease zerk hole is rearward and split tension bushings slots face the hydraulic cylinder. (FIG. 4-21)



6. Completely tighten new cylinder end weldment to hydraulic cylinder rod end.
7. Insert two split tension bushings and grease zerk into cylinder end weldment. (FIG. 4-21)
8. Tighten set screw to new cylinder end weldment.

9. Insert new cylinder pin into wing mast and cylinder end weldment. (FIG. 4-22)



10. Reusing hose holder and hardware from step 2, reattach parts to the unit.
11. Tighten hardware.
12. Repeat steps 2 through 11 for left-hand side.
13. Grease the cylinder end weldments to prevent seizing. Refer to "Lubrication" in this section.
14. Fold wings to transport position. Check for smooth wing operation.

Coulter Hub Adjustment and Replacement

The following instructions are for adjusting and lubricating the hub and replacing the “O”-ring and seal.

After the first 100 acres, the hubs should be checked for tightness and wear.

CAUTION

- SHARP EDGES ON COULTER BLADES CAN CAUSE SERIOUS INJURY. BE CAREFUL WHEN WORKING AROUND COULTER BLADES.

IMPORTANT

- Do not allow dirt and debris to contaminate the hub and its internal components. Neglecting to do so could result in failure of the hub and its components due to excessive wear.
1. Check the coultter hub and bearing for looseness or wobble by pushing/pulling the ends of the blade. Rotate and laterally push and pull on the coultter blade. A tight hub will have no wobble and will rotate smoothly with a slight resistance.
 2. If there is wobble in the hub, the hub must be tightened. To do this, remove retaining ring and the hub cap. Remove the nut retainer and tighten the slotted nut. The nut should be torqued to 40-45 foot-pounds. Increase the tightness to reinsert the c-ring.
 3. After tightening, retest the hub for wobble by repeating Step #1. If wobble still exists, continue with the following guidelines.

IMPORTANT

- When tightening slotted nut onto spindle, rotate hub back and forth so that flats do not form on bearings.
4. Turn the blade and feel for any roughness in the rotation. Also, check the base of the hub to see if the seal is intact and in position. If either problem exists, the hub must be dismantled, cleaned, inspected for damage, and repacked with grease. Refer to the following guidelines for this procedure.
 - A. Remove the blade and hub cap. Remove the C-ring securing the slotted nut.

IMPORTANT

- Removal of C-ring is best accomplished by using two screwdrivers or similar tools and prying on the outside ends to spread ring. If ring is damaged discard and replace.
 - When removing the hub and its components, be sure to keep them free of debris and dirt. Failure to do so will result in contamination of hub and bearing failure.
- B. Unscrew the nut and carefully remove the hub from the spindle.
 - C. Remove the components, clean, and inspect for any damage or wear. If even the slightest imperfection exists, replace the component(s). Once the hub is dismantled, always check the bearing and seal assembly, o-ring, and triple lip seal.

Coulter Hub Adjustment and Replacement (continued)

IMPORTANT

- Always replace the “O”-ring and seal if dismantling the hub. Failure to do so could result in premature failure of hub and its components.

- D. Replace any damaged parts before reassembling the components. Be sure to remove any debris or dirt and repack bearings with an SAE approved hub grease.

- E. Assemble “O”-ring onto spindle first. Assemble seal and bearings into hub and position onto spindle.

- F. After reassembling the hub, position the slotted nut back onto the spindle and torque to 40-45 foot-pounds. Slightly tighten the nut to align slot (in nut) with the closest cotter pin hole and install C-ring and O-ring (902158) (FIG. 4-23).

IMPORTANT

- Rotate coulter hub when torquing slotted nut. Doing this will prevent flats from forming on bearings.

- Assembly of C-ring is best accomplished by the use of a hog ring type pliers or similar tool. After installation be sure C-ring will lay flat against the spindle retaining nut to allow for proper installation of hub cap.

- G. Reinstall the hub cap and blade.

NOTE: Be sure to re-pack bearings with an SAE approved grease and keep it and its components free of dust and debris.




FIG. 4-23

Coulter Spring Replacement

The following guidelines are for replacing the spring on the coulters.

⚠ WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.


⚠ CAUTION

- SHARP EDGES ON COULTER BLADES CAN CAUSE SERIOUS INJURY. BE CAREFUL WHEN WORKING AROUND COULTER BLADES.

IMPORTANT

- *The spring should only be adjusted when repairs are being made. The springs have been preset before leaving the factory.*

1. Loosen the set screw retaining the spring bolt on the coulters arm (FIG. 4-24).
2. Slowly unscrew the spring bolt which will relieve spring pressure (FIG. 4-24).
3. Once the bolt is removed, inspect bolt for wear and replace bolt if necessary. Replace with new spring and re-insert bolt.




4. Tighten bolt until a compression of 1" is obtained on spring (FIG. 4-25).

The coulters springs are preset at the factory to 9 3/8". This measurement is the total amount of exposed spring.

NOTE: Adjusting the spring below 9 3/8" could cause premature part failure and void any warranty considerations.

5. Tighten set screw to secure bolt.



Coulter Post Mount Bracket Adjustment

IMPORTANT

- The following instructions are for installing a bolt-on coultter post shim kit (414905B) for original style coultter post mounts. This kit is not for current style coultter post mounts.


WARNING

- KEEP HANDS CLEAR OF PINCH POINT AREAS.

CAUTION

- SHARP EDGES ON COULTER BLADES CAN CAUSE SERIOUS INJURY. BE CAREFUL WHEN WORKING AROUND COULTER BLADES.

1. Slide the shim plate (413991B) between the coultter post and the bottom of the original coultter post mount as shown. (FIG. 4-26)
2. Using 3/8"-16UNC x 3 15/16" U-bolt (9004679) and two 3/8"-16 THD serrated flange nuts (9005640), attach the shim plate to the coultter post. (FIG. 4-26)
3. Tighten the serrated flange nuts.



Closer Wheel Adjustment and Replacement (Opt.)

The following guidelines are for adjusting and replacing the closer wheel on the coulter.

WARNING


- KEEP HANDS CLEAR OF PINCH POINT AREAS.

CAUTION


- SHARP EDGES ON COULTER BLADES CAN CAUSE SERIOUS INJURY. BE CAREFUL WHEN WORKING AROUND COULTER BLADES.

1. Remove 5/8"-18UNF lock nut (9501439-007) and 5/8" flat washer retaining the closer wheel and hub assembly. Keep hardware. (FIG. 4-27).

FIG. 4-27



2. Unattach the closer wheel and hub assembly from adjustable hub mount (69152B). (FIG. 4-28).



Closer Wheel Adjustment and Replacement (Opt.) (continued)

3. Remove four 1/2"-13UNC x 1 1/2" carriage bolts (9501993-104) and four 1/2"-13UNC lock nuts (9501443-034) retaining the hub assembly (69161B) on the closer wheel (69142B), and hub strap (68315) on the hub. Keep hardware. (FIG. 4-29).
4. Replace closer wheel. (FIG. 4-29).
5. Once closer wheel is replaced, inspect 1/2"-13UNC x 1 1/2" carriage bolts, 1/2"-13UNC lock nuts, 5/8"-18UNF lock nut, and 5/8" flat washer for wear and replace, if necessary.
6. Re-install and loosely tighten 1/2" hardware to closer wheel and hub strap.
7. Reattach and loosely tighten 5/8" hardware to adjustable hub mount.
8. Tighten all hardware.
9. Grease hub assembly zerk before operation.
10. Check closer wheel for smooth rotation.

NOTE: Adjustable hub mount has two toe settings. The right-hand setting positions the closer wheel to toe out and left-hand setting to toe in. (FIG. 4-30)

11. Remove kilk pin (9093) from closer wheel retainer pin (415156). (FIG. 4-30).
12. Insert closer wheel retainer pin in desired position and lock with kilk pin. (FIG. 4-30).
13. Tighten screw to secure adjustable hub mount to the closer assembly (69217B).

FIG. 4-29





FIG. 4-30



Filters (For 1800 - 40' & 44' Toolbars)

This applicator uses two filters to help ensure proper operation. These filters will need to be cleaned periodically during use and prior to applicator storage.


WARNING

- ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.
- RESIDUAL PRESSURE MAY EXIST IN APPLICATOR PLUMBING EVEN WHEN UNIT IS NOT IN USE. RELIEVE PRESSURE BEFORE SERVICING ANY PLUMBING.

Primary Filter

To clean the filter located towards the front of the frame underneath the tongue, (FIG. 4-31):


1. Rotate the pump inlet valve to <OFF>.
2. Drain the strainer.
3. Unscrew the filter housing by turning counter-clockwise and remove the filter screen.
4. Clean filter by flushing strainer element with water.
5. Reassemble filter, open pump inlet valve, and check for leaks.



Filters (For 1800 - 40' & 44' Toolbars) (continued)

Secondary Filter

A secondary filter is located on the tongue near the toolbar electric valves. This filter, similar in construction to the primary filter, is used to eliminate the need for strainers at the tips. To clean this filter, first drain the filter housing. Then unscrew the filter housing and remove the screen. Flush the strainer element with water. After cleaning, reassemble filter and check for leaks. (FIG. 4-32)



Filters (60', 66', 80', 88', 90' Toolbars)

This applicator uses two filters to help ensure proper operation. These filters will need to be cleaned periodically during use and prior to applicator storage.


⚠ WARNING

- **ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.**
- **RESIDUAL PRESSURE MAY EXIST IN APPLICATOR PLUMBING EVEN WHEN UNIT IS NOT IN USE. RELIEVE PRESSURE BEFORE SERVICING ANY PLUMBING.**

Primary Filter

To clean the filter located at the rear of the toolbar parallel lift on the right side of the applicator (FIG 4-33):

1. Rotate the pump inlet valve to <OFF>.
2. Unscrew the filter housing by turning counter-clockwise and remove the filter screen.
3. Clean filter by flushing strainer element with water.
4. Reassemble filter, open pump inlet valve, and check for leaks.



Filters (60', 66', 80', 88', 90' Toolbars) (continued)

Secondary Filter

A secondary filter is located on the toolbar center section, just in front of the toolbar electric valves (FIG. 4-34). This filter, similar in construction to the primary filter, is used to eliminate the need for strainers at the tips. To clean this filter, unscrew the filter housing and remove the screen. Flush the strainer element with water. After cleaning, reassemble filter and check for leaks.




FIG. 4-34

Winterizing

WARNING

- ALWAYS WEAR PERSONAL PROTECTIVE EQUIPMENT WHEN WORKING WITH OR NEAR CHEMICALS. THIS EQUIPMENT INCLUDES, BUT IS NOT LIMITED TO: PROTECTIVE EYE WEAR, GLOVES, SHOES, SOCKS, LONG-SLEEVED SHIRT, AND LONG PANTS. ADDITIONAL PROTECTION MAY BE REQUIRED FOR MANY TYPES OF CHEMICALS.

IMPORTANT

- *Do not allow pump to run dry. Pump damage will result.*


Before storing the applicator in freezing climates, perform the following winterizing procedure:

1. Perform a complete system rinse using procedure in the “OPERATION SECTION, INDUCTOR - Chemical Container and Inductor Tank Rinsing” of this manual.
2. Wash the applicator thoroughly inside and out with a high-pressure washer.
3. Remove as much water from the main tank as possible. Close drain valve on main tank after draining.
4. Pour approximately 50 gallons of R.V. antifreeze into main tank.


NOTE: If equipped with an inductor, the applicator can circulate the R.V. antifreeze.

5. Loosen diaphragm caps on nozzle bodies to relieve pressure and allow excess antifreeze to drain from wings.


Schematics - Plumbing




Schematics - Hydraulic (40' Toolbars)




Schematics - Hydraulic (60', 66', 80', 88', 90' Toolbars)




Schematic — Electrical — Main Light Harness (9007224)




Schematic — Electrical — Amber LED Lamp (9005142)




Schematic — Electrical — Red LED Tail/Turn Light (9006282)




Schematic — Wiring Harness (9007310)




Schematic — Electrical — Work Light (9500801)




Schematics - Rate Control Module (RCM)




Schematics - SCS 450 Console




40' Toolbar Plumbing for 20" Spacing and Orifice Options




40' Toolbar Plumbing for 30" Spacing and Orifice Options



44' Toolbar Plumbing for 22" Spacing and Orifice Options




40' Toolbar Plumbing for 36" & 38" Spacing and Orifice Options




60' Toolbar Plumbing for 20" Spacing and Orifice Options

Section 5 Routing is Identical to Section 1




60' Toolbar Plumbing for 30" Spacing and Orifice Options




66' Toolbar Plumbing for 22" Spacing and Orifice Options


Section 4 Routing is Identical to Section 2




80' Toolbar Plumbing for 30" Spacing and Orifice Options



88' Toolbar Plumbing for 22" Spacing and Orifice Options



90' Toolbar Plumbing for 30" Spacing and Orifice Options



Troubleshooting

| Problem | Possible Cause | Corrective Action |
|---|---|---|
| No toolbar functions work | Inadequate oil flow | Check tractor SCV flow setting. Check hydraulic oil level in tractor. |
| | Valve sticking | Remove the valves from the block. Lubricate the valve and re-check for easy movement. If still not getting any movement, replace the valve. |
| | Debris in block | Remove debris from block. |
| | Debris in SCV hose tips | Remove hose tips and clean. |
| Toolbar is slow or some functions work and others do not. | Valve sticking | Remove the valves from the block. Lubricate the valve and re-check for easy movement. If still not getting any movement, replace the valve. |
| | Defective or missing o-ring on valve | Inspect valve for missing or damaged o-rings. Replace any suspect o-rings. |
| | Debris in block | Remove debris from block. |
| Pressure too Low | Valve has an obstruction | Open all valves to pump and check for obstruction. |
| | Air lock in water tank | Check for air lock in tank. |
| | Hydraulic flow on tractor set too low | Increase hydraulic flow on tractor. |
| | Agitation is not set properly | Close agitation completely and slightly open the valve so the pump pressure decreases by 5 psi. |
| | Impeller has obstruction | Separate pump housing. Remove and clean the impeller. |
| | Impeller is not turning | Separate pump housing. Verify that shaft and impeller turn together. |
| Pressure too High | Hydraulic flow on tractor set too high | Decrease hydraulic flow on tractor. |
| | Improper nozzle size | Verify Nozzle Size. |
| Rate control console will not turn on | No power coming to the console | Check power source connections. |
| | Bad console | Check for 12 volts of power on Pin #16 with Pin #1 being ground on the cable coming into the console if equipped with 450 controller. |
| Do not have a rate | Not getting a speed | Press the speed button on the console to see if there is a speed. |
| | Not getting a flow | Press the vol/min button on the console to see if there is a flow. |
| Do not have a speed | Orange wire is unplugged | Verify the orange wire is plugged in to the speed sensor. |
| | Defective cable or sensor | Program a self test into the console and then check for a rate. |
| Speed is inaccurate | Loosen cable connection | Wiggle the connections for the speed cable. If accurate speed is displayed tighten connection. |
| | Cut in cable | Check speed cable for cuts in the cable. Fix the cable or replace the cable. |
| Do not have a flow | Regulating valve is not operating or PWM cartridge is not functioning | Check and remove debris from valve or PWM cartridge. |
| | Defective cable | Unplug the flow meter. With the plug keyway at the 12 o'clock position, check voltage between pins at the 2 o'clock and 6 o'clock positions (2 o'clock is ground). Should have 5 volts. Also check voltage between pins at the 2 o'clock and 10 o'clock positions (2 o'clock is ground). Should have 5 volts. |
| | Defective flow meter | Unplug the flow meter. Check for 5 volts across the 2 wires and getting voltage. |
| Rate is Unstable | Console is in manual | Put console into either rate 1 or rate 2 and check to see if rate becomes stable. |
| | Speed is inaccurate | Refer to "Speed is Inaccurate Section". |
| | Console is not programmed | Verify all numbers programmed into console are correct. |
| Cannot adjust pressure when console is in manual | Defective cable or console | Unplug regulating valve or PWM cartridge. Check for 12 volts across the two wires. |
| | Defective Valve | Unplug regulating valve or PWM cartridge. Check for 12 volts across the two wires. |

Wheel, Hub and Spindle Disassembly and Assembly


WARNING

- TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE MACHINE IS SECURELY BLOCKED.
- FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 30,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.
- EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING IMPLEMENT.
- KEEP HANDS CLEAR OF PINCH POINT AREAS.

CAUTION

- IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

IMPORTANT

- *Remove only one wheel and tire from a side at any given time in the following procedure.*
1. Hitch applicator to tractor. Park the empty applicator on a firm, level surface. Set the tractor's parking brake, shut off engine and remove key.
 2. With applicator empty, use a safe lifting device rated at 30,000 lbs. to support the weight of your applicator. Place the safe lifting device under the axle closest to the tire.
 3. Use a 3,000 lbs. safe lifting device to support the wheel and tire during removal.

NOTE: For straddle duals, first remove the outer wheel and tire.

WARNING

- INNER WHEEL AND TIRE MAY FALL FROM HUB CAUSING SERIOUS INJURY OR DEATH. ALWAYS SUPPORT INNER WHEEL WHEN REMOVING OUTER WHEEL AND/OR THE WHEEL EXTENSION.
4. If only removing wheel and tire, skip to Step 8; otherwise continue with Step 4.

Remove the hardware retaining the hubcap. Next, remove the hubcap, gasket, cotter pin, castle nut and spindle washer. Remove hub with bearings from old spindle using a 200 lbs. lifting device.

Wheel, Hub and Spindle Disassembly and Assembly (continued)

5. Inspect the spindle and replace if necessary. If spindle does not need to be replaced, skip to Step 6; otherwise continue with Step 5.

Remove the bolt and lock nut that retain the spindle to the axle. Using a lifting device rated for 150 lbs., remove the old spindle. Coat spindle shaft with anti-seize lubricant prior to installation. Reuse bolt and lock nut to retain spindle to axle. Torque as outlined in Maintenance Section.

6. Remove seal and inspect bearings, spindle washer, castle nut and cotter pin. Replace if necessary. Pack both bearings with Extreme Pressure NLGI #2 grease and reinstall inner bearing. Install new seal in hub with garter spring facing inward to the hub by tapping on flat plate that completely covers seal while driving it square to hub. Install until flush with back face of hub. Using a 200 lb. rated lifting device, install hub assembly onto spindle. Install outer bearing, spindle washer and castle nut.

IMPORTANT

- *Do not use an impact wrench!*
7. Slowly tighten castle nut while spinning the hub until drag causes the hub to stop freely spinning. Turn castle nut counterclockwise until the hole in the spindle aligns with the next notch in castle nut. Hub should spin smoothly with minimal drag and no end play. If play exists, tighten to next notch of castle nut. If drag exists, then back castle nut to next notch. Spin and check again. Install cotter pin. Clean face for hub cap gasket and install gasket, grease- filled hub cap and retain hubcap with hardware removed. Tighten hubcap hardware in alternating pattern.
 8. Attach the wheel(s) and tire(s) to the hub using the same rated safe lifting device for removal. Tighten wheel nuts to appropriate requirements and recheck as outlined in the Wheels and Tires section of this manual.
 9. Raise applicator, remove lifting device attached to wheel(s) and tire(s) and lower tire to the ground.
 10. Remove safe lifting device from applicator.

Wheels and Tires

Wheel Nut Torque Requirements

CAUTION

- IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THEREAFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagrams 1 and 2.

| WHEEL HARDWARE | |
|----------------|--------------|
| SIZE | FOOT-POUNDS |
| 1/2-20 (UNF) | 75 Ft.-Lbs. |
| 7/8-14 (UNF) | 440 Ft.-Lbs. |




DIAGRAM 1




DIAGRAM 2

Wheels and Tires (continued)

Tire Pressure

The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. It is important that tires are inspected after unit is loaded. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. Do not exceed maximum recommended tire pressure.

| Tire Pressure for Top Air Sprayers | | | |
|---|------------------|--------------------------------|----------------|
| Tire Make | Tire Size | Load Index / Ply Rating | Max PSI |
| Firestone | 480/80R42 R-1 | 151 A8 | 36 |
| Goodyear | 320/105R54 R-1W | 166 A8 | 75 |
| Mitas | 320/95R46 R-1W | 152 A8 | 58 |
| | 320/90R50 R-1W | 150 A8 | 52 |
| | 320/105R54 R-1W | 169 D | 58 |
| | 380/90R46 R-1W | 159 A8 | 58 |
| | 380/90R54 R-1W | 152 A8 | 35 |
| | 480/80R50 R-1W | 159 A8 | 35 |
| | 650/65R42 R-1W | 168 A8 | 44 |

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Following are phone numbers and Websites for your convenience:

Firestone www.firestoneag.com
Phone 800-847-3364

Titan www.titan-intl.com
or Phone 800-USA-BEAR
Goodyear Fax 515-265-9301

Trelleborg www.trelleborg.com
Phone 866-633-8473

Continental/Mitas www.mitas-tires.com
Phone 704-542-3422
Fax 704-542-3474

Carlstar Group LLC www.carlstargroup.com
Phone 800-260-7959
Fax 800-352-0075

Tracks

Equalizer® Track System

Refer to the Equalizer® Track System manual 411200 for information regarding the tracks.

Track Warranty


For questions regarding new track warranty, please contact your local original equipment track dealer. Used tracks carry no warranty. Following is the phone number and website for your convenience:

Contitech www.contitech.us
Phone USA: 888-899-6354
Canada: 888-275-4397

Complete Torque Chart

Capscrews - Grade 5

NOTE:

- Grade 5 capscrews can be identified by three radial dashes on the head. 
- For wheel torque requirements, refer to Wheels and Tires.
- Tighten U-bolts evenly and equally to have the same number of threads exposed on each end.

| SIZE | FOOT POUNDS | NEWTON METERS |
|---------------------|------------------------|------------------------|
| 1/4-20 1/4-28 | 8-10 9-11 | 11-13 12-15 |
| 5/16-18 5/16-24 | 15-17 17-19 | 20-23 23-26 |
| 3/8-16 3/8-24 | 25-28 28-31 | 34-38 38-42 |
| 7/16-14 7/16-20 | 40-45 45-50 | 54-61 61-68 |
| 1/2-13 1/2-20 | 62-68 68-75 | 84-92 92-102 |
| 9/16-12 9/16-18 | 90-98 100-110 | 122-133 134-148 |
| 5/8-11 5/8-18 | 120-135 124-137 | 162-183 168-186 |
| 3/4-10 3/4-16 | 200-220 210-230 | 270-300 285-310 |
| 7/8-9 7/8-14 | 330-350 360-380 | 425-475 460-515 |
| 1-8 1-14 | 500-525 540-560 | 675-710 730-760 |
| 1 1/8-7 1 1/8-12 | 600-635 665-700 | 815-860 920-950 |
| 1 1/4-7 1 1/4-12 | 850-895 940-990 | 1150-1215 1275-1340 |
| 1 3/8-6 1 3/8-12 | 1125-1175 1280-1335 | 1525-1590 1735-1810 |
| 1 1/2-6 1 1/2-12 | 1500-1560 1685-1755 | 2035-2115 2285-2380 |


IMPORTANT

- Follow these torque recommendations except when specified in text.

Hydraulic Fittings - Torque and Installation


SAE Flare Connection (J. I. C.)

1. Tighten nut with finger until it bottoms the seat.
2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



SAE Straight Thread O-Ring Seal

1. Back off jam nut and washer to expose smooth surface for O-ring seal.
2. Lubricate o-ring.
3. Thread into port until washer bottoms onto spot face.
4. Position elbows by backing up adapter.
5. Tighten jam nut.





Unverferth[®]

Manufacturing Company, Inc. www.unverferth.com