




Bulk Seed Handling

SEED PRO® BULK BOX CARRIER MODEL 210

Beginning With Serial Number D64320100 & Up

Part No. 2008047

Foreword

 This symbol identifies important safety messages. When you see it, read the message that follows and be alert to the possibility of personal injury.

Remember, safety instructions stated in this manual are for your protection. Read them carefully and follow them closely when working around or using this machine.

Read and study this manual completely before attempting to operate this implement. Take this manual to the field for handy reference when operating, adjusting, or servicing your machine.

When referenced, “Right-Hand” (RH) and “Left-Hand” (LH) side of the machine are determined by standing behind the machine and facing in the direction of travel.



Product Information

All products manufactured by Unverferth Mfg. Co., Inc. are warranted to be free from material and workmanship defects for one full year from time of consumer delivery. Your local dealer will gladly assist you with any warranty questions.

Please fill out and retain this portion for your records. The serial number plate is located on the frame as shown below.

Purchase Date _____ Model _____ Serial No. _____

Dealer _____ City _____

Dealer Contact _____ Phone _____



IMPORTANT

The information, specifications, and illustrations in the manual are on the basis of information available at the time it was written. Due to continuing improvements in the design and manufacture of Unverferth products, all specifications and information contained herein are subject to change without notice.

Table Of Contents

Foreword2
Product Information.....3

SECTION I
Safety

General Hazard Information 1-2
Safety Decals 1-3
Following Safety Instructions 1-4
Before Servicing..... 1-4
Before Operating 1-5
During Operation..... 1-5
Before Transporting 1-6
During Transport..... 1-6
Pressurized Oil 1-7
Prepare for Emergencies 1-8
Wearing Protective Equipment 1-8

SECTION II
Set Up

Pre-Delivery Checklist..... 2-2
General Set Up 2-2
Assemble Hitch to Undercarriage 2-4
Optional UM2520 Scale Package (#2009426TS)..... 2-5
Optional Hopper Cover (#901472) 2-7
Optional 6” Conveyor 3- State Telescopic Downspout (#22578)..... 2-8
Optional 4’ Flex Spout for 6” Conveyor (#TAAU14170)..... 2-8
Optional 2-Function Wireless Remote Control Package (#2008026)..... 2-9
Optional Hitches, Pintle Hitch (#24948B) & Clevis Hitch (28475B)..... 2-10
Optional AG Decal Package Placement..... 2-11

**FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR WORK LIGHT INFORMATION, REFER TO YOUR WORK LIGHT MANUAL.**

Table Of Contents

SECTION III

Operation

Preparing Towing Vehicle	3-2
Preparing Implement	3-3
Hydraulic System	3-3
Lubrication	3-3
Tires/Wheels	3-3
Connecting to Towing Vehicle	3-4
Transport Chains	3-4
Transporting	3-5
Hydraulic Power Unit Operation	3-7
Before Starting Engine	3-8
Starting Engine	3-9
Adjusting Hydraulic Relief Valve	3-9
Conveyor Belt Electronic Speed Control if Equipped	3-11
Conveyor Belt Manual Speed Control Valve	3-11
Pivoting Conveyor Side-to-Side	3-12
Raising and Lowering Conveyor	3-13
Manual Control of Conveyor	3-14
Pull Start Engine	3-14
Loading Boxes Onto Seed Pro Box Carrier	3-15
Filling Planter or Drill	3-17
Rotating Conveyor Out For Transferring Grain	3-18
Work Light Kit #2004450 (Optional)	3-20

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR WIRELESS REMOTE INFORMATION, PLEASE REFER TO YOUR WIRELESS REMOTE MANUAL.

Table Of Contents

SECTION IV
Maintenance

Lubrication..... 4-2
 Conveyor Bearings..... 4-2
 Pivot Points..... 4-2
 Wheel Bearings..... 4-2
 Hydraulic Power Unit..... 4-2
 Hydraulic System 4-3
 Purge Hydraulic System 4-3
 Relieving Hydraulic Pressure 4-4
 Conveyor Belt..... 4-5
 Belt Tension..... 4-5
 Belt Tracking..... 4-6
 Brake Cleaning and Inspection..... 4-8
 Brake Lubrication 4-8
 Magnets 4-8
 Shoes and Linings..... 4-9
 How To Measure Voltage..... 4-9
 How To Measure Amperage 4-10
 Brake Drum Inspection 4-11
 Bearing Inspection..... 4-11
 Bearing Lubrication 4-11
 Troubleshooting Brakes 4-12
 Power Pak..... 4-12
 Battery Warranty 4-15
 Wheels and Tires..... 4-16
 Wheel Nut Torque Requirements..... 4-16
 Tire Pressure 4-16
 Tire Warranty 4-17
 Complete Torque Chart
 Capscrews 4-18
 Hydraulic Fittings 4-18
 Storage..... 4-19
 Optional Belt Stretcher 4-20
 Troubleshooting..... 4-22
 Smooth-Start Module with Speed Control Troubleshooting 4-26
 Scale Troubleshooting..... 4-27
 Scale “Short Form” Set Up & Calibration For UM2520 Indicator..... 4-28
 Electrical Schematics 4-30
 Stackable Valve Manual Override Schematic 4-40

Table Of Contents

SECTION V

Parts

Door Components & Frame Decals.....	5-2
Pivot Arm & Conveyor Decals.....	5-4
Stationary Bracket Components.....	5-6
Scale Components.....	5-8
Pivot Arm Components.....	5-10
Pivot Arm Mounting Components to Platform.....	5-12
Platform Components.....	5-14
Hydraulic Components.....	5-16
Control Valve - 2 Function (Stackable Valve).....	5-18
Undercarriage Components.....	5-20
Touch-Up Paint.....	5-23
Axle & Wheel Components.....	5-24
Spare Tire Kit Components.....	5-25
Pivot Arm Mounting Components to Conveyor.....	5-26
Conveyor Controller Components.....	5-27
Hopper Components.....	5-28
Idler End Components.....	5-30
Discharge Spout Components.....	5-32
Power Pak Components.....	5-34
Power Pak Mounting Components.....	5-36
Platform for Units Less Undercarriage.....	5-37
Enclosure Components.....	5-38
Telescopic Spout Components (Optional).....	5-40
Conveyor Spout Light Kit (Optional).....	5-41
Hopper Cover (Optional).....	5-42
Electric Breakaway Components.....	5-42
2-Function Wireless Remote Control (Optional).....	5-43
Hydraulic Jack for Bumper Hitch Kit #2005116TS (Optional).....	5-44
License Plate/Lamp Holder Assembly (Optional).....	5-46
AG Decal Package (Optional) - SMV, SIS Decals, & Reflectors.....	5-47

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.

Notes

SECTION I

Safety

General Hazard Information	1-2
Safety Decals	1-3
Following Safety Instructions	1-4
Before Servicing.....	1-4
Before Operating.....	1-5
During Operation.....	1-5
Before Transporting	1-6
During Transport.....	1-6
Pressurized Oil.....	1-7
Prepare for Emergencies	1-8
Wearing Protective Equipment.....	1-8

General Hazard Information

No accident-prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

A large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the field, or in the industrial plant, can be safer than the person who is at the controls. If accidents are to be prevented--and they can be prevented--it will be done by the operators who accept the full measure of their responsibility.

It is true that the designer, the manufacturer, and the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that, "the best kind of a safety device is a careful operator." We, at Unverferth Mfg. Co., Inc. ask that you be that kind of operator.



REMEMBER:
THINK SAFETY
A CAREFUL OPERATOR IS THE
BEST INSURANCE AGAINST AN
ACCIDENT!

SIGNAL WORDS



INDICATES AN EXTREMELY HAZARDOUS SITUATION OR ACTION THAT WILL RESULT IN SERIOUS INJURY OR DEATH.



INDICATES A HAZARDOUS SITUATION OR ACTION THAT COULD RESULT IN SERIOUS INJURY OR DEATH.



INDICATES AN UNSAFE SITUATION OR ACTION THAT MAY RESULT IN PERSONAL INJURY.




Is used for instruction on operating, adjusting, or servicing a machine.

Safety Decals

⚠ WARNING

REPLACE LOST, DAMAGED, PAINTED, OR UNREADABLE DECALS IMMEDIATELY. IF PARTS THAT HAVE DECALS ARE REPLACED, ALSO MAKE SURE TO INSTALL NEW DECALS. THESE DECALS INFORM AND REMIND THE OPERATOR WITH OPERATIONAL INFORMATION AND SAFETY MESSAGES.



Part No. 95445



Part No. 97961



Part No. 901580



Part No. 95839



Part No. 98350



Part No. 901478




Part No. 9500710



Part No. 97961



Part No. 235161




Part No. 9500345



Part No. 95445



Part No. 98229



Part No. TA1-906109-0



Part No. 95445



Part No. 97048






Part No. 902026




Part No. 95839



Following Safety Instructions

- Read and understand this operator's manual before operating. 
- All machinery should be operated only by trained and authorized personnel.
- To prevent machine damage, use only attachments and service parts approved by the manufacturer.
- Always shut towing vehicle engine and hydraulic power unit engine off and remove key before servicing the implement. 
- Avoid personal attire such as loose fitting clothing, shoestrings, drawstrings, pants cuffs, long hair, etc., that may become entangled in moving parts.
- Do not allow anyone to ride on the implement. Make sure everyone is clear before operating machine or towing vehicle. 
- Never enter a seed tender containing seed or grain. Flowing grain traps and suffocates victims in seconds.

Before Servicing

- Avoid working under the unit; however, if it becomes absolutely unavoidable, make sure the implement is safely blocked. 
- Ensure that all applicable safety decals are installed and legible.
- To prevent personal injury or death, always ensure that there are people who remain outside the seed tender to assist the person working inside, and that all safe work place practices are followed. There is restricted mobility and limited exit paths when working inside the implement.
- Explosive separation of a tire and rim can cause serious injury or death. Only properly trained personnel should attempt to service a tire and wheel assembly.

Before Operating

- Do not stand between the towing vehicle and implement during hitching.

- Always make certain everyone and everything is clear of the machine before beginning operation.

- Verify that all safety shields are in place and properly secured.

- Ensure that all applicable safety decals are installed and legible.

During Operation

- Regulate speed to field conditions. Maintain complete control at all times.

- Never service or lubricate equipment when in operation.

- Keep away from overhead power lines. Electrical shock can cause serious injury or death.

- Use extreme care when operating close to ditches, fences, or on hillsides.

- Do not leave towing vehicle or implement unattended with engine running.

- Carbon monoxide can cause severe nausea, fainting or death. Do not operate engine in closed or confined area.

- Explosive fuel can cause fires and severe burns. Stop engine before filling fuel tank.

- Hot parts can cause severe burns. Do not touch engine while operating or just after stopping.

- Explosive gas from battery can cause fires and severe acid burns. Charge battery only in a well ventilated area. Keep sources of ignition away.

- Seed being transported may contain seed treatment. Read and follow all requirements for personal protective equipment and first aid as outlined on seed tags.

Before Transporting

- Secure transport chains to the towing vehicle before transporting. **DO NOT** transport without chains.

- Install transport locks before transporting.

- Check for proper functioning of all available transport lights. Make sure that all reflectors are clean and in place on machine.

During Transport

- Comply with all laws governing highway safety when moving machinery.

- Use transport lights as required by all laws to adequately warn operators of other vehicles.

- Use good judgment when transporting equipment on highways. Regulate speed to road conditions and maintain complete control.


- Maximum speed of implement should never exceed 20 mph. Do not exceed 10 mph during off-highway travel.

- Slow down before making sharp turns to avoid tipping. Drive slowly over rough ground and side slopes.

- It is probable that this implement is taller, wider and longer than the towing vehicle. Become aware of and avoid all obstacles and hazards in the travel path of the equipment, such as power lines, ditches, etc.

Pressurized Oil

- Relieve the hydraulic system of all pressure before adjusting or servicing. See MAINTENANCE section of this manual for procedure to relieve pressure.

- High-pressure fluids can penetrate the skin and cause serious injury or death. Use cardboard or wood to detect leaks in the hydraulic system. Seek medical treatment immediately if injured by high-pressure fluids. 

- Hydraulic system must be purged of air before operating to prevent serious injury or death.

- Do not bend or strike high-pressure lines. Do not install bent or damaged tubes or hoses.

- Repair all oil leaks. Leaks can cause fires, personal injury, and environmental damage.

- Route hoses and lines carefully to prevent premature failure due to kinking and rubbing against other parts. Make sure that all clamps, guards and shields are installed correctly.

- Check hydraulic hoses and tubes carefully. Replace components as necessary if any of the following conditions are found:
 - End fittings damaged, displaced, or leaking.
 - Outer covering chafed/cut or wire reinforcing exposed.
 - Outer covering ballooning locally.
 - Evidence of kinking or crushing of the flexible part of a hose.

Preparing for Emergencies

- Keep a first aid kit and properly rated fire extinguisher nearby.



- Keep emergency numbers for fire, rescue, and poison control personnel near the phone.



Wearing Protective Equipment

- Wear clothing and personal protective equipment appropriate for the job.



- Wear steel-toed shoes when operating.



- Wear hearing protection when exposed to loud noises.



- Do not wear additional hearing impairing devices such as radio headphones, etc.



SECTION II

Set Up

Pre-Delivery Checklist.....	2-2
General Set Up.....	2-2
Assemble Hitch to Undercarriage.....	2-4
Optional UM2520 Scale Package (#2009426TS).....	2-5
Optional Hopper Cover (#901472).....	2-7
Optional 6” Conveyor 3- State Telescopic Downspout (#22578).....	2-8
Optional 4’ Flex Spout for 6” Conveyor (#TAAU14170).....	2-8
Optional 2-Function Wireless Remote Control Package (#2008026).....	2-9
Optional Hitches, Pintle Hitch (#24948B) & Clevis Hitch (28475B).....	2-10
Optional AG Decal Package Placement.....	2-11

FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR WORK LIGHT INFORMATION, REFER TO YOUR WORK LIGHT MANUAL.

Pre-Delivery Checklist

After the Seed Pro tender has been completely assembled, use the following checklist and inspect the seed tender. Check off each item as it is found satisfactory or after proper adjustment is made.

- Torque wheel nuts as specified in Maintenance section.
- Torque all axle mounting hardware to 120 ft.-lbs.
- Tires are inflated to specified air pressure.
- All grease fittings have been lubricated.
- Check to be sure all safety decals are correctly located and legible. Replace if damaged.
- Check to be sure all reflective decals are correctly located.
- Check belt alignment and tension.
- Check to be sure transport lights are working properly.
- Transport chains are properly installed and hardware is torqued to specification.
- Paint all parts scratched in shipment.
- For Seed Pro tenders equipped with a wireless remote option, cycle each function 10 times to ensure no air is present in hydraulic lines.

General Set Up

WARNING

- **READ AND UNDERSTAND THE SAFETY RULES BEFORE OPERATING OR SERVICING THIS MACHINE. REVIEW THE SAFETY SECTION IN THIS MANUAL, IF NECESSARY.**
- **TIPPING OR MOVEMENT OF THE MACHINE CAN CAUSE SERIOUS INJURY OR DEATH. BE SURE THE MACHINE IS SECURELY BLOCKED.**
- **ENTANGLEMENT WITH MOVING PARTS CAN CAUSE SERIOUS INJURY OR DEATH. USE EXTREME CARE WHEN INSPECTING AND ADJUSTING BELT TRACKING. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOESTRINGS, DRAWSTRINGS, PANTS CUFF, LONG HAIR, ETC., THAT MAY BECOME ENTANGLED IN MOVING PARTS.**
- **MOVING PARTS CAN CRUSH AND CUT. KEEP AWAY FROM MOVING PARTS.**
- **KEEP HANDS CLEAR OF PINCH POINT AREAS.**
- **FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 7,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.**
- **EYE PROTECTION AND OTHER APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN WHILE SERVICING THE IMPLEMENT.**

General Set Up (continued)

IMPORTANT

- *The procedures for assembling this Seed Pro tender are intended for two or more people.*

NOTE: Unverferth Manufacturing has designed the transport lighting and marking kit to meet United States federal law and ASABE standards at the time of manufacture. Machine modifications, including additional features or changes to the intended configurations, may require updates to the lighting and marking as well.

Compliance with all lighting and marking laws is the responsibility of the operator at the time of travel.

See federal regulation 49 CFR 562; available at www.govinfo.gov for US federal law requirements.

See your Unverferth dealer for additional brackets, reflectors, or lights to meet your requirements.

This section contains instructions required for assembly of the Seed Pro tender.


For your safety, and the safety of others, use proper tools and equipment and always use safe working procedures. Refer to these instructions before starting any work on the machine.

For ease of assembly, install all hardware loosely until assembly is complete and then tighten according to Torque Chart in the MAINTENANCE Section of this manual.

Assemble Hitch to Undercarriage

1. If the Seed Pro tender was shipped with a hitch installed, torque 5/8"-11UNC retaining hardware to 120-135 ft.-lbs. If the Seed Pro tender was shipped without a hitch installed, proceed with the following. Place supports rated for minimum 1,000 lbs. capacity under front of undercarriage frame. Raise hitch using a safe lifting device with a minimum 1,000 lbs. capacity, and place the hitch in line with the undercarriage.
2. Connect the electrical connections, and push extra wire harness into tubes. Move hitch against undercarriage frame being careful not to pinch the wiring harness.
3. Bolt the hitch to undercarriage using 5/8"-11UNC x 2 1/4" (9390-125), 5/8" stainless steel flat washers (903108), and 5/8"-11UNC locknuts (9801). Torque 5/8"-11UNC hardware to 120-135 ft.-lbs.

FIG. 2-1



Optional UM2520 Scale Package (#2009426TS)



⚠ WARNING

- **FALLING OBJECTS CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT WORK UNDER THE MACHINE AT ANY TIME WHILE BEING HOISTED. BE SURE ALL LIFTING DEVICES AND SUPPORTS ARE RATED FOR THE LOADS BEING HOISTED. THESE ASSEMBLY INSTRUCTIONS WILL REQUIRE SAFE LIFTING DEVICES UP TO 1,000 LBS. SPECIFIC LOAD RATINGS FOR INDIVIDUAL LOADS WILL BE GIVEN AT THE APPROPRIATE TIME IN THE INSTRUCTIONS.**

1. Support one side of the upper platform using a safe lifting device rated at a minimum of 1,000 lbs.
2. Remove the 5/8" bolts holding the stationary bracket in place.
3. Remove the stationary bracket.
4. Create four scale sub-assemblies by assembling two left-hand scale brackets (29065TS) and two right-hand scale brackets (29065TS) with weigh bars (901173), 3/8"-16UNC x 3 1/2" capscrews (9390-065), and 3/8"-16UNC locknuts (9928).

IMPORTANT

- *The weigh bars must be assembled so the bending direction arrow on the backside of the weigh bar is pointing up. The serial number decal on the spindle should be positioned on the top side of the weigh bar.*
5. Install all four weigh bars onto the unit making sure the arrow is pointing up. Reinstall the 5/8" bolts and locknuts, and tighten the bolts.
 6. Remove the safe lifting device from the center plates on the upper platform.
 7. Route the weigh bar cables along the inside edge of the box and fasten using the cable ties (9000106). Be certain cables will not get pinched or worn.




Optional UM2520 Scale Package (#2009426TS) (continued)

8. Route cables from weigh bars into opening at bottom of enclosure and connect to the scale indicator (9500374) ports. Fasten indicator into enclosure using two 1/4"-20UNC x 3/4" capscrews (9390-003) and locknuts (9928). Remove harness (2002130) from enclosure and replace with harness (2002132).

FIG. 2-4



Optional UM2520 Scale Package (#2009426TS) (continued)



Optional Hopper Cover (#901472)




**Optional 6" Conveyor 10'x5" Dia.
3-Stage Telescopic Downspout (#22578)**

1. Lower the conveyor to approximately 4-5 feet off the ground.
2. Remove the 2-stage telescopic downspout (27629) from the conveyor.
3. Slip the optional 3-stage telescopic downspout (22578) with T-bolt clamp ring (98060) over the conveyor tube end and tighten.


NOTE: The 2-stage 4' to 6' telescoping downspout, as well as the optional 4' flex spout are intended for bulk seed loading into large central-fill planter seed hoppers (35 to 100 bushels). They both have the full 8" diameter flex hose attachment at the discharge end of the conveyor and require no manual holding or maneuvering of the spout during operation.

The optional 3-stage 6' to 10' telescoping downspout is intended for manual filling of smaller individual planter seed hoppers, requiring increased operator holding, lifting, maneuvering of the long spout assembly while filling. The spout therefore is downsized with a metal adapter for the smaller 6" flex hose and smaller diameter spout for more manageable handling of the spout. The operator is encouraged to slow the engine and conveyor speed for proper operation.



4' Flex Spout for 6" Conveyor (#TAAU14170)

1. Park the empty Seed Pro on a firm, level surface. Block the wheels on the machine to keep it from moving. Set the towing vehicle's parking brake. Lower the conveyor to approximately 4-5 feet off the ground, shut off the engine and remove the ignition key.
2. Remove the T-bolt clamp ring (98060) and spout from the conveyor.
3. Slip the 4' flex spout over the conveyor tube end and tighten with T-bolt clamp ring (98060).



Optional 2-Function Wireless Remote Control Pkg (#2008026)


IMPORTANT

- See manual #2008027 for complete set up instructions.




**Optional Hitches,
Pintle Hitch (#24948B) & Clevis Hitch (#28475B)**

1. Remove the hardware, shims, and hitch.
2. Attach optional hitch using the hardware and shims removed in step #1.
3. Torque hardware according to “Torque Chart” in MAINTENANCE section.




Optional AG Decal Package Placement

1. Center and attach the SMV Emblem (95730) to the rear of the unit 1" from the frame. (FIG. 2-20)
2. Attach the SIS decal (9008714) to the rear of the unit 9 3/4" from the bottom of the SMV Emblem (95730). (FIG. 2-20)
3. Attach the red reflector (9003126) 13" from the right-hand side of the bumper. (FIG. 2-20)




4. Attach the SIS decal (9008714) to the front of the unit 31 3/4" from the frame and 5 3/4" from the side of the panel as shown in FIG. 2-21.




Optional AG Decal Package Placement (continued)

5. Place the amber reflector (9003127) 2" down on the frame on the right-hand side of the unit. (FIG. 2-22)



6. Place the amber reflector (9003127) 2" down on the frame on the left-hand side of the unit. (FIG. 2-23)



SECTION III

Operation

Preparing Towing Vehicle	3-2
Preparing Implement	3-3
Hydraulic System	3-3
Lubrication	3-3
Tires/Wheels	3-3
Connecting to Towing Vehicle	3-4
Transport Chains	3-4
Transporting	3-5
Hydraulic Power Unit Operation	3-7
Before Starting Engine	3-8
Starting Engine	3-9
Adjusting Hydraulic Relief Valve	3-9
Conveyor Belt Electronic Speed Control if Equipped	3-11
Conveyor Belt Manual Speed Control Valve	3-11
Pivoting Conveyor Side-to-Side	3-12
Raising and Lowering Conveyor	3-13
Manual Control of Conveyor	3-14
Pull Start Engine	3-14
Loading Boxes Onto Seed Pro Box Carrier	3-15
Filling Planter or Drill	3-17
Rotating Conveyor Out For Transferring Grain	3-18
Work Light Kit #2004450 (Optional)	3-20

**FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.
FOR WIRELESS REMOTE INFORMATION, PLEASE REFER TO YOUR WIRELESS REMOTE MANUAL.**

Preparing Towing Vehicle

Before operating implement, refer to towing vehicle's operator's manual for information concerning safe methods of operation, hitch capacities, hitch adjustments, tire inflation, and undercarriage braking operation.

Vehicle must be equipped with proper electric undercarriage braking components. Check vehicle brakes and transport lights. Make sure they are in proper working order.

Compliance with all lighting and marking laws is the responsibility of the operator at the time of travel.

See federal regulation 49 CFR 562; available at www.govinfo.gov for US federal law requirements.

See your Unverferth dealer for additional brackets, reflectors, or lights to meet your requirements.

IMPORTANT

- *This implement is equipped with LED lights. The towing vehicle may require a flasher upgrade for lights to function properly. For flasher upgrade, please see towing vehicle manufacturer for assistance.*

Do not exceed towing vehicle's GVWR (Gross Vehicle Weight Rating) or GCWR (Gross Combination Weight Rating), or the maximum hitch load.

Estimated weights of the fully loaded Seed Pro tender are:

Model 210

- Gross Vehicle Weight Rating is 8,500 lbs.
- Loaded tongue weight is 700 lbs.

These are estimates. The loaded tongue weight will vary greatly based on the height of the hitch, and the variation in terrain that implement is being pulled across.

Towing vehicle hitch – ball or pintle hook, must be heavy enough to carry the load of the Seed Pro tender.

Preparing Implement

Hydraulic System

Check routing of all hydraulic hoses. Hoses should not be kinked, twisted, or rubbing against sharp edges.

Check hoses and fittings for hydraulic leaks. Tighten and/or repair or replace as required. Refer to “Torque Chart” in MAINTENANCE section.

Lubrication

Lubricate the implement as outlined in the MAINTENANCE SECTION of this manual.

Refer to this operator’s manual for proper fluid levels in engine.

Tires/Wheels

CAUTION

- **IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. WHEEL NUTS/BOLTS MUST BE CHECKED REGULARLY. SEE TORQUE PAGE IN MAINTENANCE SECTION FOR PROPER WHEEL NUT/BOLT SPECIFICATIONS. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS.**

Check tire pressures and maintain at recommended values listed in the MAINTENANCE section of this manual. Check wheel nuts/bolts torque as specified in the MAINTENANCE section.

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Tire manufacturers’ phone numbers and web sites are listed in the MAINTENANCE Section of this manual for your convenience.

Connecting to Towing Vehicle

WARNING

- **CRUSHING CAN CAUSE SERIOUS INJURY OR DEATH. DO NOT STAND BETWEEN THE TOWING VEHICLE AND IMPLEMENT WHEN HITCHING. ALWAYS ENGAGE THE PARKING BRAKE AND STOP THE ENGINE BEFORE INSERTING THE HITCH PINS OR SECURING THE LATCHES.**

The Seed Pro undercarriage is designed to be connected to a towing vehicle utilizing either the pintle hitch, clevis hitch or a 2 5/16" ball hitch.

Back the towing vehicle up to the undercarriage and align the vehicle's ball or pintle hook with the coupler or ring on the undercarriage. Lower jack to set undercarriage down on ball or pintle hook. Latch coupler so the connection is secure. Pivot jack to transport position and pin in place.

Connect electrical plug from undercarriage to towing vehicle. Check routing of the electrical cord to be certain it is long enough to pivot when turning, but not too long to touch or rub the ground during transport.

Connect undercarriage brake breakaway cable to towing vehicle. Do not connect this directly to hitch. It needs to be connected in a place that will still be attached, even if the ball or pintle coupler fails.

Transport Chains

CAUTION

- **ALWAYS USE TRANSPORT CHAINS WHEN TRANSPORTING IMPLEMENTS. FAILURE TO USE A TRANSPORT CHAIN COULD CAUSE PERSONAL INJURY OR DAMAGE IF IMPLEMENTS BECOMES DISENGAGED.**
- **REPLACE TRANSPORT CHAIN IF ANY LINK OR END FITTING IS BROKEN, STRETCHED OR DAMAGED. DO NOT WELD THE TRANSPORT CHAIN.**

Transport chains should have a minimum rating equal to the gross weight of implement and all attachments. Allow no more slack in chains than necessary to permit turning.

Cross chains when connecting as shown in photo.



Transporting

DANGER

- ELECTROCUTION WILL CAUSE SERIOUS INJURY OR DEATH. ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT. KEEP AWAY FROM ALL UTILITY LINES AND DEVICES.



WARNING


- ALWAYS TRAVEL AT A SPEED THAT PERMITS COMPLETE CONTROL OF TOWING VEHICLE AND IMPLEMENT.

CAUTION

- USE APPROVED ACCESSORY LIGHTS AND REFLECTORS WHEN TRANSPORTING AT NIGHT, DURING PERIODS OF POOR VISIBILITY, AND AS REQUIRED BY ALL LAWS.

IMPORTANT

- Before seed tender is transported, be sure the jack stand is in the 'Transport Position'.
- Conveyor must be latched in the unloading position. The pivoting arm must be latched in the transport position with klik pin installed before moving Seed Pro tender. Refer to photo on following page.
- This implement is equipped with LED lights. The towing vehicle may require a flasher upgrade for lights to function properly. For flasher upgrade, please see towing vehicle manufacturer for assistance.




Transporting (continued)

When transporting on public roads, the conveyor needs to be latched in the forward position, extending over the tongue of the undercarriage. Transporting implement with conveyor latched in the rearward position does not comply with lighting and conspicuity marking requirements.

The center of gravity on the seed tender is higher than a typical undercarriage. Use extreme caution when making turns and entering/exiting fields.

Comply with all state and local laws governing highway safety and regulation when moving machinery on public roads.

Be sure reflectors and lights are in place and clearly visible to approaching traffic.



Hydraulic Power Unit Operation

WARNING

- **EXPLOSIVE FUEL CAN CAUSE FIRES AND SEVERE BURNS. STOP ENGINE BEFORE FILLING FUEL TANK.**

- **CARBON MONOXIDE CAN CAUSE SEVERE NAUSEA, FAINTING OR DEATH. DO NOT OPERATE ENGINE IN A CLOSED OR CONFINED AREA.**

- **HOT PARTS CAN CAUSE SEVERE BURNS. DO NOT TOUCH ENGINE WHILE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.**

- **EXPLOSIVE GAS FROM BATTERY CAN CAUSE FIRES AND SEVERE ACID BURNS. CHARGE BATTERY ONLY IN A WELL VENTILATED AREA. KEEP SOURCES OF IGNITION AWAY.**

- **HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.**

- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**

- **RELIEVE THE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.**

- **OPERATION OF THIS EQUIPMENT MAY CREATE SPARKS THAT CAN START FIRES AROUND DRY VEGETATION. A SPARK ARRESTOR MAY BE REQUIRED. THE OPERATOR SHOULD CONTACT LOCAL FIRE AGENCIES FOR LAWS OR REGULATIONS RELATING TO FIRE PREVENTION REQUIREMENTS. THE SPARK ARRESTOR MUST BE PURCHASED SEPARATELY AND CAN BE FOUND IN THE PARTS SECTION NEAR THE END OF THIS MANUAL.**



Hydraulic Power Unit Operation (continued)

IMPORTANT

- Make certain hoses are all connected, and everyone is clear of conveyor before starting engine.
- Conveyor must be turned off before starting engine. Starting engine with conveyor turned on will result in hard starting, or failure to start.
- When engine is not in use, turn fuel lever to the <OFF> position. Leaving the fuel valve on could cause carburetor flooding, fuel in crankcase, or fuel leakage. See photo above.



NOTE: Installation instructions for the spark arrestor can be found in the Honda engine manual.

Before Starting Engine

Inspect that all fittings and hardware are in place and secure. Check for any potential hydraulic leaks. Check fluid levels in engine and sight gauge on reservoir. Be sure all valves are switched to neutral position.

Hydraulic Power Unit Operation (continued)

Starting Engine


1. Turn fuel shut-off valve to <ON> position.
2. Apply choke.

3. **Wired Two-Function Switch:**

Turn key to start engine.

- Remote Two-Function Switch:**

Turn key to start the engine. Pull the red emergency stop button out on the 2-Function remote to enable remote functions.



4. Once running, turn choke off and increase throttle speed.

In extremely cold weather, it is best to allow engine and hydraulics to warm up before operating at full throttle speed.

NOTE: If hydraulic leaks become apparent, turn engine <OFF> immediately and take appropriate actions.

See Engine operator's manual for more detailed information on engine operation.

Adjusting Hydraulic Pressure Relief Valve

⚠ WARNING

- FAILURE TO REPLACE THE CAP ON THE RELIEF VALVE BEFORE STARTING THE ENGINE WILL CAUSE OIL TO ESCAPE FROM THE RELIEF VALVE CARTRIDGE.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.



IMPORTANT

- *It will be necessary to install a pressure gauge into the hydraulic system to accurately adjust the relief valve.*


Hydraulic Power Unit Operation (continued)

- A. The Seed Pro box carrier has an adjustable relief valve on the direction control valve which can be adjusted for optimum operation. It is pre-set at the factory to by-pass the system once the hydraulic fluid pressure exceeds 1800 psi. This is the optimum setting. Adjusting the relief to higher settings may give unsatisfactory results.


IMPORTANT

- *This Seed Pro can be adjusted to provide system pressures from 1,000 PSI up to 2,500 PSI. When adjusting the relief to allow the system to exceed 1,800 PSI, the engine will tend to bog down due to the load and in high load applications, may cause the engine to stall.*


- B. Remove the cap from the relief valve on the directional control valve with an allen wrench.



- C. To increase the pressure, turn the wrench clockwise.
To decrease the pressure, turn the wrench counter-clockwise.



- D. Replace the cap on the relief valve and tighten.



Conveyor Belt Electronic Speed Control

The smooth-start module speed control is simply two push buttons one to increase the conveyor speed and one to decrease the conveyor speed. Each time a button is pressed the conveyor speed changes by 10%. The speed can be varied from 20% to 100%. The speed is shown by a series of LEDs, the LEDs indicate 10% steps by flashing and 20% increments by being on continuous.




Pivoting Conveyor Side-To-Side

Unlatch the conveyor arm by pressing down and sliding the latch into the unlocked position. Turn the pivot latch handle down and pull the conveyor out away from the box to pivot.

IMPORTANT

- Do not raise the conveyor arm until it has been moved out of the latch position.



Conveyor pivot can be left to swing freely, or it can be latched in place at various points along the track.



CAUTION

- WHEN THE SEED TENDER IS PARKED ON AN INCLINE, THE CONVEYOR MAY PIVOT AS SOON AS THE LATCH IS RELEASED. INADVERTENT MOVEMENT OF THE CONVEYOR MAY CAUSE PERSONAL INJURY.

Raising and Lowering Conveyor

Conveyor height is adjusted by a switch either on the wired pendant, or the remote control. This switch activates the solenoid on the spool valve to raise or lower the conveyor.

IMPORTANT

- *Always swing the conveyor out from the transport position before raising the conveyor.*


Activate switch to raise or lower conveyor to desired height. A check valve in the system requires hydraulic pressure for both raising and lowering the conveyor.

Manual Control Of Conveyor

Should the wired switch or remote control not work to operate the conveyor, use the override buttons on the valve for operation. These are the knurled buttons located on top of the solenoids. The operations are performed by either pushing in the button and holding in place or pulling the button up and holding in place.

Valve 1 = By pushing this button in and holding in position, it will raise the conveyor. Pull this button up and hold in position, to lower the conveyor.

Valve 2 = To override, turn screw clockwise to turn conveyor on. To return to normal valve function, turn screw counterclockwise until it stops.



NOTE: To pull-out on Valve 1, push in on the button and pull up on the knurled sleeve.

Pull Start Engine

Should the engine fail to start due to a weak battery, it is possible to pull start the engine. If the battery voltage is extremely low the ignition system will need to be bypassed to be able to pull start the engine. This procedure includes:

1. Flip the override switch to the “pull start” position.
2. Pull the choke and then pull start the engine, open the choke as the engine warms.
3. Once the engine is running, move the keyswitch to the on position and flip the override switch back to “key switch” position.



Loading Boxes Onto Seed Pro Box Carrier

1. Remove covers from the chute.




2. Locate covers in storage position in front of the front standard, securing with provided bungee cord.




Loading Boxes Onto Seed Pro Box Carrier (continued)

3. Push and turn handle to the side to unlock all box hold downs.
4. Lift boxes into position on platform.



5. With boxes in position, push and turn handle down to lock all box hold downs.



Filling Planter or Drill

Position the seed tender next to planter so conveyor discharge will be over planter box. Start engine on hydraulic power unit and increase throttle speed. Raise conveyor to desired discharge height, and pivot to location over planter. Place spout over planter box. Open door(s) on seed tender box to begin flow of seed. Turn on conveyor by pressing conveyor on/off switch.

Fill box to desired level and turn conveyor off. Repeat process until each box/hopper is filled by pressing conveyor on/off button again. Adjusting engine speed on the hydraulic power unit will regulate conveyor speed. Shut the doors so that the conveyor is empty when filling the last box.

IMPORTANT

- *Do not let telescoping spout rest in bottom of seed box. Seed will rapidly build up and plug conveyor, resulting in potential damage to belt.*

It is recommended that the conveyor be emptied once planter is filled. Do this by closing door(s) on seed tender box shortly before last planter box is full, and let conveyor empty out.

NOTE: When using seed tender to fill individual planter boxes, the cover plate must be installed over grate. This will slow grain flow to an acceptable level for ease of use. Failure to do so will result in over-filling conveyor and potential damage to seed or conveyor.

Leaving seed in the conveyor for short periods of time will not damage conveyor, nor will it hinder starting/stopping conveyor when it is full, but over time seed could begin to settle resulting in hard starting of the conveyor.




Standard Two-Function Wired Switch

Rotating Conveyor Out For Transferring Grain


WARNING

- THE SEED PRO MUST BE HOOKED TO THE TOWING VEHICLE WHEN BEING FILLED AND THE BRAKES ON THE TOWING VEHICLE MUST BE SET.

Pivot conveyor out of transport position and lower completely. Remove upper spout from conveyor by releasing latch and sliding spout off of conveyor. Loosen the two knobs on the side of the deflector, pivot deflector up, and tighten knobs to hold deflector in place.



Raise conveyor about half way up. Unlatch conveyor from lower cradle, lower flexible hopper by sliding lever back, and pull hopper end of conveyor out from under the Seed Pro box.



Position conveyor so that the discharge end is located over the Seed Pro box and the hopper is on the ground or on the stand away from the box.



Rotating Conveyor Out For Transferring Grain (continued)

IMPORTANT

- *Whenever possible, use the stand on the bottom of the conveyor to keep the hopper off the ground. Maximum conveyor performance and easier access to discharge point on bulk seed containers will result.*

Raise flexible hopper by sliding lever to the upright position. Locate wagon or bulk seed container over conveyor hopper and operate conveyor to fill Seed Pro.

When finished loading seed into the Seed Pro tender, move wagon or bulk seed container away from conveyor. Pivot conveyor hopper back under the Seed Pro box, and latch in place. Conveyor should be placed back in the transport position and secured with the latch pin.

IMPORTANT

- *When pivoting conveyor, be certain to pivot back in the direction it originally came from. Do not pivot conveyor round and around. Doing so will twist hydraulic hoses at pivot point resulting in damage to hoses and potential hydraulic failure.*
- *Conveyor must always be latched in cradle except when self-filling seed tender box.*




Work Light Kit #2004450 (Optional)

Turning light on/off:

1. Turn light on/off using the button on the light or by turning the key on or off. Aim light to best illuminate work area.

IMPORTANT

- *When not using light for long periods of time, make sure light is turned off. If left on battery may be drained.*



SECTION IV

Maintenance

Lubrication.....	4-2
Conveyor Bearings.....	4-2
Pivot Points.....	4-2
Wheel Bearings.....	4-2
Hydraulic Power Unit.....	4-2
Hydraulic System	4-3
Purge Hydraulic System	4-3
Relieving Hydraulic Pressure	4-4
Conveyor Belt.....	4-5
Belt Tension.....	4-5
Belt Tracking.....	4-6
Brake Cleaning and Inspection.....	4-8
Brake Lubrication	4-8
Magnets	4-8
Shoes and Linings.....	4-9
How To Measure Voltage.....	4-9
How To Measure Amperage	4-10
Brake Drum Inspection.....	4-11
Bearing Inspection.....	4-11
Bearing Lubrication	4-11
Troubleshooting Brakes	4-12
Power Pak.....	4-12
Battery Warranty	4-15
Wheels and Tires.....	4-16
Wheel Nut Torque Requirements.....	4-16
Tire Pressure	4-16
Tire Warranty.....	4-17
Complete Torque Chart	
Capscrews	4-18
Hydraulic Fittings	4-18
Storage.....	4-19
Optional Belt Stretcher	4-20
Troubleshooting.....	4-22
Smooth-Start Module with Speed Control Troubleshooting	4-26
Scale Troubleshooting.....	4-27
Scale “Short Form” Set Up & Calibration For UM2520 Indicator.....	4-28
Electrical Schematics	4-30
Stackable Valve Manual Override Schematic	4-40

Lubrication

Lubricate with an SAE multi-purpose grease. All fittings must be free from dirt and paint to insure entry of lubricant inside bearing.

Conveyor Bearings

Lubricate these bearings every 100 hours of operation and at the end of each season before storage. Use only one stroke of grease per bearing.



CAUTION

- DO NOT USE A HIGH-PRESSURE GREASE GUN TO LUBRICATE CONVEYOR BEARINGS, AS DAMAGE TO BEARING SEAL COULD OCCUR.

NOTE: Excessive lubrication of these bearings will result in premature failure.



Pivot Points

Lubricate pivot points on pivoting arm every 50 hours of operation and at the end of each season.

Wheel Bearings

The wheel bearings should be cleaned, repacked and adjusted every 12 months or 12,000 miles, whichever comes first. Use a number 2 wheel bearing grease to repack the bearings and adjust the bearing to a free-rolling fit with no end play.

Hydraulic Power Unit

Inspect hydraulic oil level in reservoir daily. Level should be 1 to 1 1/2" from the top. Add appropriate hydraulic oil as needed. Most farm tractor type hydraulic oils are acceptable. **DO NOT** use Automatic Transmission Fluid! **DO NOT** mix different oils when topping off the tank.

Check motor oil level in engine daily. See Engine operator's manual for details on oil levels, oil types, and service intervals.

Hydraulic System

Refer to parts section for hydraulic component detail listing.

When properly assembled and maintained, the hydraulic system of the seed tender requires little maintenance.

Replacing Hoses/Fittings/Cylinders:

1. Use replacement hoses, fittings, and cylinders from your Unverferth Manufacturing dealer which are rated for 3000 psi.
2. Do not use hoses, fittings and cylinders that have pipe threads.
3. Do not use Teflon tape or thread sealant on JIC or O-ring fittings. Tighten fittings according to "Torque Chart" in this section.
4. When replacing hoses, always allow sufficient slack to permit hoses to move through the full range of motion of the cylinders.
5. Always purge the hydraulic system after servicing.

Purge Hydraulic System

WARNING

- **HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.**

- **RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE "RELIEVING HYDRAULIC PRESSURE".**

- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**

- **KEEP CLEAR OF PINCH POINTS WHEN ADJUSTING OR MOVING CONVEYOR.**



Purge air from system as follows:

- A. Disconnect the rod end of all cylinders in a circuit and block up cylinders so the rod can completely extend and retract without contacting any other component.
- B. Pressurize the system and maintain system at full pressure for at least 5 seconds after cylinder rods stop moving. Check that all cylinders have fully extended or retracted.
- C. Check oil reservoir in hydraulic power source and refill as needed.
- D. Pressurize system again to reverse the motion of step B. Maintain pressure on system for at least 5 seconds after cylinder rods stop moving. Check that cylinders have fully extended or retracted.
- E. Check for hydraulic leaks using cardboard or wood. Tighten connections according to directions in Torque Chart.
- F. Repeat steps B, C, D, and E 3-4 times.
- G. Depressurize hydraulic system and connect cylinder rod clevises to their mating lugs.

IMPORTANT

- *Machine damage will occur if the cylinder is incorrectly installed.*

Check for and correct any leaks. Make sure hoses are not kinked, stretched, or twisted. Secure hoses to prevent cuts or chafing during operation.

Hydraulic System (continued)

Relieving Hydraulic Pressure

To relieve hydraulic pressure in the system, be sure hydraulic motor is disengaged and/or hydraulic cylinder is not exerting force on the system. Next, turn off engine and actuate valve in hydraulic system to all positions of actuation and to the neutral position. This should relieve all pressure in the system. If there is a need to remove hydraulic fittings or hoses, slowly loosen the appropriate connections. If there appears to be pressure in the system, begin at the top of this section and perform all procedures again until pressure is relieved.

Conveyor Belt

Proper tensioning and tracking of the belt are critical to maintaining the belt for years of worry-free use. Belt tension and belt tracking should be checked after the very first initial use then after the first 2 hours of initial use. Thereafter, belt tracking and tension should be checked at the beginning of each season and every eight hours of use. Belt tracking will also need to be checked anytime the belt tension is adjusted.

⚠ WARNING

- **ENTANGLEMENT WITH MOVING PARTS CAN CAUSE SERIOUS INJURY OR DEATH. USE EXTREME CARE WHEN INSPECTING AND ADJUSTING BELT TRACKING. AVOID PERSONAL ATTIRE SUCH AS LOOSE FITTING CLOTHING, SHOESTRINGS, DRAWSTRINGS, PANTS CUFFS, LONG HAIR, ETC., THAT MAY BECOME ENTANGLED IN MOVING PARTS.**

Belt Tension



Belt tension is inspected by removing lower cover panel from conveyor, and gently pulling on the conveyor belt. The belt should have approximately 1/2" of slack at the center.

Belt tension is adjusted at the discharge end of the conveyor. Loosen, **DO NOT REMOVE**, the four 3/8" bolts on each side of the conveyor. Use the two adjusting bolts to adjust the belt to the proper tension.

It is important to move both sides the same distance. Too much tension on the belt will stretch the splice link and greatly reduce belt life. Too little tension on the belt could result in belt slipping on drive pulley. Replace the bottom cover panel and continue to check belt tracking before re-tightening the four bolts on each side of the conveyor.

IMPORTANT

- *Belt tracking must be done every time tension is adjusted.*




Conveyor Belt (continued)

Belt Tracking


Conveyor belt must always run at the center of the pulley on both the intake and discharge end. Improper tracking of the belt will result in excessive wear to the edge of the belt, and will greatly reduce belt life. Check belt tracking every 8 hours of use, and every time belt tension is adjusted.

Inspect tracking of belt at discharge end by removing lower spout, pivoting deflector up, and looking up at the belt and pulley. Belt should be in center of pulley.



Adjust by loosening, DO NOT REMOVE, the four bolts on the side of the conveyor. Operate conveyor at slow speed, and tighten or loosen the adjustment bolt until belt is running in the center of the pulley.

Tighten all bolts on side of conveyor, and lock adjustment bolts into place.




Conveyor Belt (continued)

Belt Tracking (continued)

Adjust by loosening (Do Not Remove) the four bolts (two on each side) on the adjusting plate.

Inspect tracking of belt at intake end by opening bottom inspection door on conveyor. Belt should be in the center of the pulley.



Operate conveyor at slow speed, and tighten or loosen adjustment bolt until belt is running in the center of the pulley.

Tighten the two bolts on the adjustment plate, and lock the adjustment bolt into place.

Brake Cleaning and Inspection

Your undercarriage brakes must be inspected and serviced immediately if a loss of performance is experienced. With normal use, servicing at one year intervals is usually adequate. With increased usage, this work should be performed more frequently as required. Magnets and shoes must be changed when they become excessively worn or scored, a condition which can reduce vehicle braking. Clean the backing plate, magnet arm, magnet, and brake shoes. Make certain that all the parts removed are replaced in the same brake and drum assembly. Inspect for any loose or worn parts, stretched or deformed springs and replace as necessary.

WARNING

- **POTENTIAL ASBESTOS DUST HAZARD - SOME BRAKE LININGS MAY CONTAIN ASBESTOS DUST, WHICH HAS BEEN LINKED TO SERIOUS OR FATAL ILLNESSES. CERTAIN PRECAUTIONS NEED TO BE TAKEN WHEN SERVICING BRAKES:**

1. Avoid creating or breathing dust.
2. Avoid machining, filing or grinding the brake linings.
3. Do not use compressed air or dry brushing for cleaning (dust can be removed with a damp brush).


Brake Lubrication

Before reassembling, apply a light film of grease or anti-seize compound on the brake anchor pin, the actuating arm bushing and pin, and the areas on the backing plate that are in contact with the brake shoes and magnet lever arm. Apply a light film of grease on the actuating block mounted on the actuating arm.

NOTE: Do not get grease or oil on the brake linings, drums or magnets.

Magnets

Your electric brakes are equipped with high quality electromagnets that are designed to provide the proper input force and friction characteristics. Your magnets should be inspected and replaced if worn unevenly or abnormally. Use a straightedge to check magnet condition. For best results, the magnet should be flat. Even if wear is normal as indicated by your straightedge, the magnets should be replaced if any part of the magnet coil has become visible through the friction material facing of the magnet. It is also recommended that the drum armature surface be refaced when replacing magnets. Magnets should also be replaced in pairs - both sides of an axle.




Brake Cleaning and Inspection (continued)**Shoes and Linings**

A simple visual inspection of your brake linings will tell if they are usable. Replacement is necessary if the lining is worn (to within 1/16" or less), contaminated with grease or oil, or abnormally scored or gouged. Hairline heat cracks are normal in bonded linings and should not be cause for concern. When replacement is necessary, it is important to replace both shoes on each brake and both brakes of the same axle. This will help retain the "balance" of your brakes.

After replacement of brake shoes and linings, the brakes must be re-burnished to seat in the new components. This should be done by applying the brakes 20 to 30 times from an initial speed of 40 m.p.h., slowing the vehicle to 20 m.p.h. Allow ample time for brakes to cool between applications. This procedure allows the brake shoes to seat in to the drum surface.


**How to Measure Voltage**

System voltage is measured at the magnets by connecting the voltmeter to the two magnet lead wires at any brake. This may be accomplished by using a pin probe inserted through the insulation of the wires. The engine of the towing vehicle should be running when checking the voltage so that a low battery will not affect the readings. Voltage in the system should begin at 0 volts and, as the controller bar is slowly actuated, should gradually increase to about 12 volts. If the controller does not produce this voltage control, consult your controller manual. The threshold voltage of a controller is the voltage applied to the brakes when the controller first turns on. Lower threshold voltage will provide for smoother braking. If the threshold voltage is too high, the brakes may feel grabby and harsh.



How to Measure Amperage

System amperage is the current flowing in the system when all the magnets are energized. The amperage will vary in proportion to the voltage. The engine of the tow vehicle should be running with the undercarriage connected when checking the undercarriage braking system. One place to measure system amperage is at the BLUE wire of the controller which is the output to the brakes. The BLUE wire must be disconnected and the ammeter put in series into the line. System amperage draw should be as noted in the following table.



Brake Size	Amps/Magnet	Two Brakes	Four Brakes	Six Brakes	Magnet Ohms
7 x 1¼	2.5	5.0	10.0	15.0	3.9
10 x 1½	3.0	6.0	12.0	18.0	3.2
10 x 2¼	3.0	6.0	12.0	18.0	3.2
12 x 2	3.0	6.0	12.0	18.0	3.2
12¼ x 2½	3.0	6.0	12.0	18.0	3.2

Make sure your ammeter has sufficient capacity and note polarity to prevent damaging your ammeter. If a resistor is used in the brake system, it must be set at zero or bypassed completely to obtain the maximum amperage reading. Individual amperage draw can be measured by inserting the ammeter in the line at the magnet you want to check. Disconnect one of the magnet lead wire connectors and attach the ammeter between the two wires. Make sure that the wires are properly reconnected and sealed after testing is completed. The most common electrical problem is low or no voltage and amperage at the brakes. Common causes of this condition are:

1. Poor electrical connections
2. Open circuits
3. Insufficient wire size
4. Broken wires
5. Blown fuses (fusing of brakes is not recommended)
6. Improperly functioning controllers or resistors

Another common electrical problem is shorted or partially shorted circuits (indicated by abnormally high system amperage). Possible causes are:

1. Shorted magnet coils
2. Defective controllers
3. Bare wires contacting a grounded object

Finding the cause of a short circuit in the system is done by isolating one section at a time. If the high amperage reading drops to zero by unplugging the undercarriage, then the short is in the undercarriage. If the amperage reading remains high with all the brake magnets disconnected, the short is in the undercarriage wiring. All electrical troubleshooting procedures should start at the controller. Most complaints regarding brake harshness or malfunction are traceable to improperly adjusted or nonfunctional controllers. See your controller manufacturer's data for proper adjustment and testing procedures. For best results, all the connection points in the brake wiring should be sealed to prevent corrosion. Loose or corroded connectors will cause an increase in resistance which reduces the voltage available for the brake magnets.

Brake Drum Inspection

There are two areas of the brake drum that are subject to wear and require periodic inspection. These two areas are the drum surface where the brake shoes make contact during stopping and the armature surface where the magnet contacts (only in electric brakes).

The drum surface should be inspected for excessive wear or heavy scoring. If worn more than .020" oversized, or the drum has worn out of round by more than .015", then the drum surface should be re-machined. If scoring or other wear is greater than .090" on the diameter, the drum must be replaced. When turning the drum surface, the maximum re-bore diameter is as follows:

The machined inner surface of the brake drum that contacts the brake magnet is called the armature surface. If the armature surface is scored or worn unevenly, it should be re-faced to a 120 micro inch finish by removing not more than .030" of material. To insure proper contact between the armature face and the magnet face, the magnets should be replaced whenever the armature surface is re-faced and the armature surface should be re-faced whenever the magnets are replaced.

IMPORTANT

- *It is important to protect the wheel bearing bores from metallic chips and contamination which result from drum turning or armature re-facing operations. Make certain that the wheel bearing cavities are clean and free of contamination before reinstalling bearing and seals. The presence of these contaminants will cause premature wheel bearing failure.*


Bearing Inspection

Wash all grease and oil from the bearing cone using a suitable solvent. Dry the bearing with a clean, lint-free cloth and inspect each roller completely.

Bearing Lubrication

Along with bearing adjustment, proper lubrication is essential to the proper function and reliability of your undercarriage axle. Bearings should be lubricated every 12 months or 12,000 miles. The method to repack bearing cones is as follows:

1. Place a quantity of grease into the palm of your hand.
2. Press a section of the widest end of the bearing into the outer edge of the grease pile closest to the thumb forcing grease into the interior of the bearing.
3. Repeat this while rotating the bearing from roller to roller.
4. Continue this process until you have the entire bearing completely filled with grease.
5. Before reinstalling, apply a light coat of grease on the bearing cup.



Troubleshooting Brakes

Most electric brake malfunctions, that cannot be corrected by either brake adjustments or synchronization adjustments, can generally be traced to electrical system failure. Voltmeters and ammeters are essential tools for proper troubleshooting of electric brakes. Mechanical causes are ordinarily obvious, i.e. bent or broken parts, worn out linings or magnets, seized lever arms or shoes, scored drums, loose parts, etc. Please consult the following troubleshooting charts in this section of the manual to determine the causes and solutions for common problems found in undercarriage braking systems.

CAUTION

- **BEST BRAKING PERFORMANCE IS ACHIEVED WITH A CONTROLLER SETTING THAT IS JUST SHORT OF WHEEL LOCK UP OR SLIDE. OVERLY AGGRESSIVE BRAKING WHICH RESULTS IN WHEEL LOCK UP AND SLIDING, CAN CAUSE A DANGEROUS LOSS OF CONTROL AND RESULT IN PERSONAL INJURY OR DEATH.**

Power Pak

For general maintenance and servicing of power pak unit.

NOTE: Honda engines are warranted for 3 years. For maintenance of engine and warranty information, refer to Operator's Manual provided with engine. Following are Websites to locate local Honda engine dealers and service centers:

US www.engines.honda.com

Canada www.honda.ca

Please provide Honda with the following engine information:
11.7 HP GX390 UT2QNE2

The hydraulic filter and fluid should be replaced after every 100 hours of engine run or once the filter gauge indicates a restriction in the red area. Be sure to filter the fluid when filling tank, especially from a bulk container. Any foreign materials in fluid will dramatically reduce the life of the pump. Follow steps below to change hydraulic fluid:

WARNING

- **RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR THE PROPER PROCEDURES.**
- **HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.**
- **HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.**




Power Pak (continued)

Replace the initial filter after 3 hours of use with the additional oil filter provided. It is not necessary to replace the hydraulic fluid at this time. When the filter is replaced after the initial filter replacement, it is important that the hydraulic fluid be replaced too. It takes approximately 4.5 gallons to fill the system.

IMPORTANT

- When checking the filter by using a gauge, check the filter gauge after conveyor is ran for 2 minutes to allow oil to warm up.



- When replacing filter be sure that it is replaced with an Unverferth service part. This filter has an ultra-fine mesh which filter out microscopic particles. Failure to replace with an Unverferth filter could result in system malfunction and/or shortened life of components. The hydraulic filter and fluid should be replaced after every 100 hours of engine run time. Be sure to filter the fluid when filling the tank, especially from a bulk container. Any foreign fluid will dramatically reduce the life of the pump.
- Use a premium hydraulic fluid. This fluid not only will provide pressure to operate your equipment, but also lubricates all components. This unit was designed to use **Chevron 1000 THF hydraulic fluid**. Use the same or equivalent-type hydraulic fluid to provide a long service life of your Power Pak.

NOTE: The filter gauge may take several seasons for the gauge to approach the red (replace) portion of the gauge. Once the gauge is close to the red (replace) portion, the gauge will spike.

1. Turn off engine and remove spark plug to prevent engine from starting. Be sure all hydraulic fittings and hoses are relieved of pressure, Fig. 1.






FIG. 1

Power Pak (continued)

2. Make sure a proper container is available to drain hydraulic oil. Remove hydraulic fluid o-ring drain plug (99692) and drain hydraulic oil into container, Fig. 2.



3. Using a 1 7/8" wrench, remove intake strainer from tank. Clean strainer of all debris and check for any damage. Replace if necessary, Fig. 3.



4. Before reinstalling intake strainer to tank, apply teflon paste or tape on threads to help seal threads, Fig. 3.

5. On return line filter, remove filter cap and pull out filter using pull tabs on filter, Fig. 4. Properly dispose of filter and replace with a new filter of exact specifications. **DO NOT** substitute filter specifications.


6. Once all components have been reassembled and secured, new hydraulic fluid may be added to the hydraulic fluid tank. Fill fluid to the top of the level gauge on the front of the unit, Fig. 4. There must be 1 to 1 1/2 inches of space at the top of the tank. **DO NOT** over fill. Once the tank is full, secure cap to top of tank.

NOTE: When topping off hydraulic fluid tank, always use the same fluid as what is already in the tank. **DO NOT** mix different brands or types of hydraulic fluid.

NOTE: Use Chevron 1000 THF hydraulic fluid.

7. With the spark plug removed, the pump must be primed. To prime pump, rotate engine by pulling on the pull cord to make pump cycle. Do this approximately 10 times to fill the intake line.

8. Reinstall spark plug and start engine.





Power Pak (continued)

Also to maintain POWER PAK, inspect the battery. Remove battery cover and inspect the battery itself, along with any components, wires and connections for any wear or damage, Fig. 5. Replace as required.

Be sure battery strap is secure preventing battery from shifting inside compartment.

IMPORTANT

- *When storing Seed Pro tender for long periods of time be sure battery has a full charge and then turn the battery disconnect switch to the off position.*



Battery Warranty

Interstate Battery:
www.interstatebatteries.com
800-CRANKIT

Wheels and Tires


Wheel Nut Torque Requirements

CAUTION

- **IMPROPERLY TORQUED WHEEL NUTS/BOLTS CAN CAUSE A LOSS OF IMPLEMENT CONTROL AND MACHINE DAMAGE. TORQUE WHEEL NUTS/BOLTS TO VALUES IN TABLE. CHECK TORQUE BEFORE USE, AFTER ONE HOUR OF UNLOADED USE OR AFTER FIRST LOAD, AND EACH LOAD UNTIL WHEEL NUTS/BOLTS MAINTAIN TORQUE VALUE. CHECK TORQUE EVERY 10 HOURS OF USE THERE-AFTER. AFTER EACH WHEEL REMOVAL START TORQUE PROCESS FROM BEGINNING. WARRANTY DOES NOT COVER FAILURES CAUSED BY IMPROPERLY TORQUED WHEEL NUTS/BOLTS..**

Failure to check torque before first load may damage wheel nut/bolt seats. Once seats are damaged, it will become impossible to keep nuts/bolts tight. Tighten nuts/bolts to applicable torque value shown in table. Start all nuts/bolts by hand to prevent cross threading. Torque nuts/bolts in the recommended sequence as shown in Diagram 1.

WHEEL HARDWARE	
SIZE	FOOT-POUNDS
1/2-20 (UNF)	75 ft.-lbs.



Tire Pressure

- The following is to be used as a general guide for tire inflation and figures can vary depending on specific brand of tire used. It is important that tires are inspected after Seed Pro Tender is loaded. Start with minimum pressure indicated. The tire should stand up with no side-wall buckling or distress as tire rolls. Record the pressure needed to support the full load and maintain this pressure to achieve proper tire life. Do not exceed maximum recommended tire pressure.

TIRE SIZE	PSI
225/75R15	65

(All tire pressures in psi)

Wheels and Tires (continued)

Tire Warranty

For questions regarding new tire warranty, please contact your local original equipment tire dealer. Used tires carry no warranty. Following is a phone number and Website for your convenience:

***Carlisle** www.carlisletire.com
Phone 800-260-7959
Fax 800-352-0075

***NOTE:** Gladiator and Ironman tire brands are being sold by Carlisle as well.

Complete Torque Chart - Capscrews - Grade 5

IMPORTANT


- Grade 5 capscrews can be identified by three radial dashes on head.
- For wheel torque requirements, refer to *Wheels and Tires*.
- Tighten U-bolts to have the same number of threads exposed on each end.

SIZE	FOOT POUNDS	NEWTON METERS	SIZE	FOOT POUNDS	NEWTON METERS
1/4-20	8-10	11-13	3/4-10	200-220	270-300
1/4-28	9-11	12-15	3/4-16	210-230	285-310
5/16-18	15-17	20-23	7/8-9	330-350	425-475
5/16-24	17-19	23-26	7/8-14	360-380	460-515
3/8-16	25-28	34-38	1-8	500-525	675-710
3/8-24	28-31	38-42	1-14	540-560	730-760
7/16-14	40-45	54-61	1 1/8-7	600-635	815-860
7/16-20	45-50	61-68	1 1/8-12	665-700	920-950
1/2-13	62-68	84-92	1 1/4-7	850-895	1150-1215
1/2-20	68-75	92-102	1 1/4-12	940-990	1275-1340
9/16-12	90-98	22-133	1 3/8-6	1125-1175	1525-1590
9/16-18	100-110	134-148	1 3/8-12	1280-1335	1735-1810
5/8-11	120-135	162-183	1 1/2-6	1500-1560	2035-2115
5/8-18	124-137	168-186	1 1/2-12	1685-1755	2285-2380

Hydraulic Fittings - Torque and Installation


SAE FLARE CONNECTION (J.I.C.)

1. Tighten nut with finger until it bottoms the seat.
2. Using a wrench, rotate nut to tighten. Turn nut 1/3 turn to apply proper torque.



SAE STRAIGHT THREAD O-RING SEAL

1. Insure jam nut and washer are backed up to the back side of smooth portion of elbow adapter.
2. Lubricate o-ring -- VERY IMPORTANT!
3. Thread into port until washer bottoms onto spot face.
4. Position elbows by backing up adapter.
5. Tighten jam nut.



Storage

Your Seed Tender is an important investment. Spend a little time to protect it from destructive rust and corrosion. You will be repaid in longer service life and better performance.

After use, clean out box, conveyor, and hopper. Remove all seed, and pressure wash to remove road dirt, seed treatment, etc.

Prepare engine on hydraulic power unit for storage. Refer to engine operator's manual for details.

Inspect hydraulic oil level in reservoir. Level should be 1 to 1 1/2" from the top. Add appropriate hydraulic oil as needed. Most farm tractor type hydraulic oils are acceptable. **DO NOT** use Automatic Transmission Fluid! **DO NOT** mix different oils when topping off the tank.


Check bolts for tightness. Inspect for damaged or worn parts. Check valves, motor, hoses, and fittings for leaks. Check hoses for wear. Replace or repair items as needed.

Repaint any chipped or scraped areas, and store inside away from livestock.

Charge battery before storage if applicable. Lack of charge may result in the battery to freeze over the winter.

Replace all worn, torn or faded decals and reflectors.

Belt Stretcher (Optional)






Install Bottom Bars Across Underside Of Belt, And Secure With Four 5/8"-11UNC x 1 1/2" Capscrews Through Top Bars As Shown.

ITEM	PART NO.	QTY	DESCRIPTION
	TA4-114400-0	1	BELT INSTALLATION TOOL
1	9390-122	4	CAPSCREW, 5/8-11UNC x 1 1/2 LG. GRADE 5
2	TA0-903118-0	2	BEARING, BALL THRUST, 5/8" I.D.
3	TA1-114401-0	2	BOTTOM BAR
4	TA2-114404-0	1	PLAIN TOP BAR WELDMENT
5	TA2-114406-0	1	THREADED TOP BAR WELDMENT
6	TA2-114408-0	2	THREAD ROD WELDMENT

Belt Stretcher (Optional) (Continued)

Stretcher Assembled to Belt

FOR ILLUSTRATION ONLY



Troubleshooting

PROBABLE CAUSE

CORRECTION

Undercarriage Swaying, Tire Wear, Lights

Unit sways during travel

Check tire pressure

Check tongue and steering hardware, tighten appropriately

Tires show excessive wear

Check tire pressure

Wheel makes grinding or squeaking noise

Service wheel bearings

Tail lights are not functioning

Check wires and connections

Replace lamps

Conveyor Will Not Turn Over or Develop Proper Speed/Torque

Pump does not deliver sufficient pressure or volume

Check output and delivery, change if necessary

Conveyor jammed

Shut-off and lock-out power, open clean-out door and remove excess material (make sure swivel spout is clear)

Oil level too low

Fill to proper level

Conveyor Runs Too Slow

Engine running too slow

Increase engine speed

Pump not producing minimum required flow and pressure

Check pump fluid capacity and correct

Pump is worn

Repair or replace pump

Internal leak in controls or motor

Replace seals; repair or replace valves or motor

Air in system

Purge system and tighten connections

Improper hydraulic oil viscosity

If conveyor starts slowly and speed increases after oil heats up, oil is too heavy weight. If conveyor slows down after oil heats up, oil is too light weight

Troubleshooting (continued)

PROBABLE CAUSE	CORRECTION
Oil Heats Excessively	
Oil viscosity incorrect	Drain and refill with proper weight oil
Dirty oil	Drain, flush, and refill with a clean oil and filter
Oil level too low	Fill to proper level
Oil slipping through worn pump	Repair or replace pump
Restricted line or piping	Reroute lines to eliminate restrictions
Reservoir too small to provide adequate cooling	Replace with larger reservoir or install oil cooler
Belt Edges Showing Excessive Wear	
Belt tracking incorrect	Adjust tracking as detailed in service section page 2-3.
Poly seals on intake and/or discharge end worn.	Replace poly seals
Pivoting Arm Will Not Raise or Lower	
Engine running too slow	Increase engine speed
Conveyor Will Not Pivot	
Pivot lock in place	Unlatch conveyor or check pivot lock operating mechanism.
Dirt or debris on pivot track	Clean dirt from track
Bearing worn out	Replace bearing
Power Pak	
Pump Squeals: A. Oil level too low in reservoir B. Oil is cold C. Intake strainer is plugged D. Return-line filter is plugged E. Hoses are kinked or leaking	A. Check sight gauge on reservoir B. Run engine at low idle until hydraulic fluid warms C. Drain reservoir and clean strainer D. Remove and replace filter E. Inspect, adjust or replace hose if necessary
Unit is lacking power: A. Oil level too low in reservoir B. Oil is cold C. Intake strainer is plugged D. Return-line filter is plugged E. Hoses are kinked or leaking F. Pressure relief valve is set too low or is plugged	A. Check sight gauge on reservoir B. Run engine at low idle until hydraulic fluid warms C. Drain reservoir and clean strainer D. Remove and replace filter E. Inspect, adjust or replace hoses if necessary F. Remove cover and adjust with "L" wrench or remove valve and inspect for contamination

Troubleshooting (continued)

Conveyor Raise/Lower Cylinder Not Working Properly


⚠ WARNING

- HYDRAULIC SYSTEM MUST BE PURGED OF AIR BEFORE OPERATING TO PREVENT SERIOUS INJURY OR DEATH.
- RELIEVE HYDRAULIC SYSTEM OF ALL PRESSURE BEFORE ADJUSTING OR SERVICING. SEE THE HYDRAULIC POWER UNIT OPERATOR'S MANUAL FOR PROPER PROCEDURES.
- HIGH-PRESSURE FLUIDS CAN PENETRATE THE SKIN AND CAUSE SERIOUS INJURY OR DEATH. USE CARDBOARD OR WOOD TO DETECT LEAKS IN THE HYDRAULIC SYSTEM. SEEK MEDICAL TREATMENT IMMEDIATELY IF INJURED BY HIGH-PRESSURE FLUIDS.
- DO NOT BEND OR STRIKE HIGH-PRESSURE LINES. DO NOT INSTALL BENT OR DAMAGED TUBES OR HOSES.
- REPAIR ALL OIL LEAKS. LEAKS CAN CAUSE FIRES, PERSONAL INJURY, AND ENVIRONMENTAL DAMAGE. ROUTE HOSES AND LINES CAREFULLY TO PREVENT PREMATURE FAILURE DUE TO KINKING AND RUBBING AGAINST OTHER PARTS. MAKE SURE THAT ALL CLAMPS, GUARDS AND SHIELDS ARE INSTALLED CORRECTLY.

The parts list would include:

- 99515 Ball Check Valve
- 99516 Check Valve Seal Kit
- 9003744 0.030 Orifice fitting (2) required
- 92295 Union Fitting




1. If the conveyor is in the raised position, use an appropriate lifting device rated for at least 1,000 lbs and support the conveyor. If the conveyor is in the transport position proceed as follows. Make sure that all the load is off the lift cylinder (902361) and that cylinder pin will freely rotate.
2. Remove the two hoses (9500425) from the cylinder (902361) and connect the two hoses (9500425) together using union fitting (92295). Tighten the connections as directed by the "Hydraulic Fittings - Torque and Installation" in the MAINTENANCE section of the Seed Pro operator's manual.



Troubleshooting (continued)

Conveyor Raise/Lower Cylinder Not Working Properly (continued)

3. To flush the two hoses (9500425), operate the Seed Pro for a minimum of ten minutes while actuating the control to raise and lower the conveyor. Make sure to actuate the control in both directions (raise and lower).




Smooth-Start Module With Speed Control Troubleshooting

This module, located inside the common enclosure at the front of the machine, is used to control the conveyor belt speed by gradually bringing the speed up, reducing the wear on the conveyor components.

If the system is not operating as expected, the LED can be used to determine what is occurring.

LED State / Blink Rate	System Status
Steady Off	The module is not powered or has failed.
Slow On/Off Flash (1 Hz)	The input signal is inactive and the output is off. (CONVEYOR OFF)
Steady On	The input signal is detected as active and the output is on. (CONVEYOR ON)
Rapid On/Off Flash (5 Hz)	The input signal is active and the output is active. The module is detecting an error condition with the output. Check the output wiring for open or short circuits.



**Scale “Short Form” Set Up & Calibration
For UM2520 Indicator**

***IMPORTANT!** This indicator was calibrated at the factory to weigh accurately with your system. Additional calibration is not necessary under NORMAL conditions.*

The Short Form Set Up & Calibration procedure allows you to change the “SETUP” and “CAL” numbers of the indicator. You may want to perform this procedure if;

- 1) The indicator is being connected to different load cells.
or
- 2) You want to adjust the calibration to match another scale system.

PLEASE NOTE: Do not attempt to calibrate the scale if the indicator is not reading stable weights. The calibration procedure will not fix instability, inconsistencies, or flashing “RANGE” messages.

Before continuing, first write down the current “SETUP” and “CAL” numbers of your UM indicator. These numbers are displayed during the “Self Test”. To run the Self Test:

With the indicator already ON, press the [FIELD] key and then [ON/OFF] key to start the Self Test. Press the [ON/OFF] key to “pause” the Self Test while numbers are displayed. Press [ON/OFF] key again to resume.

Verify the SETUP & CAL numbers with the Example table below and record the numbers on your UM indicator.

Example Table:

SETTING	SEED PRO
SETUP#	127060
CAL#	24080

SETUP# _____ CAL# _____

Keep this information for future reference. See next page for more SETUP#'s & CAL#'s.

1. Adjust UM2520 Indicator to Match Another Scale:

Sometimes two different scales are used to weigh the same load. When this is done, the weight measured by each scale may not be the same. This can be caused by one or both of the two scales being slightly out of calibration. This indicator has the ability to match any other scale, even if that scale is uncalibrated.

To match your UM2520 scale (Scale A) to another scale (Scale B) you must determine the Calibration Multiplier. To do this, place a load on Scale A (feed wagon, etc...) and write down the weight displayed. Repeat several times to determine the average weight. Next, place the same load on Scale B and again write down the weight displayed. Again, repeat several times to determine the average weight. Then, use this formula to determine the Calibration Multiplier for the UM2520's "CAL" number:

**Scale “Short Form” Set Up & Calibration
For UM2520 Indicator (continued)**

It is important to use an average of several weights before calibrating the scale.

Scale Matching Example:
Original
 SETUP# 127060
 CAL# 24080

	1 Trail	2 Trail	3 Trail
Scale B	30,000	30,580	28,000
Scale A	29,440	29,800	27,500
Scale B ÷ A	1,020	1,026	1,018

1.020 + 1.026 + 1.018 = 3.064
 3.064 ÷ 3 Trails = 1.021 CAL Multiplier

Orig. UM CAL# X CAL Multiplier = NEW UM CAL#
 24080 X 1.021 = 24586

You should not modify your "SETUP" number. Only your "CAL" number.

Scale Matching Example:
Original
 SETUP# _____
 CAL# _____

	1 Trail	2 Trail	3 Trail
Scale B			
Scale A			
Scale B ÷ A			



(Trail 1) + (Trail 2) + (Trail 3) = "X"

"X" ÷ 3 Trails = _____ CAL Multiplier




Orig. UM CAL# X CAL Multiplier = NEW UM CAL#
 _____ X _____ = _____

Follow the instructions "To change the Set Up / Calibration Numbers" shown in the indicator operator's manual.









Undercarriage Hitch #25045 Electrical Schematic




Looking at Insertion End of Connector




Undercarriage Lighting & Brake Electrical Schematic — # 25046




Engine Harness #2009998 Schematic



Standard Corded Control Harness Schematic (#2002519)




Switch Assembly Schematic (#27627)




Wireless Remote Harness Schematic (#2002520)

2 Function Wireless Remote Harness




Wireless Remote Harness Schematic (#2002520) (continued)


2 Function Wireless Remote Harness



Work Light Harness #2002125 — Electrical Schematic




Non-Scale Electrical Schematic (Harness #2002130)



Scale Electrical Schematic (Harness #2002132) (Option)

When equipped with a 2520 scales, connectors circled should be connected together. Remaining connector should be covered using the attached cap.




Stackable Valve Manual Override Operation & Wire Schematic


*Push the inner button down, and either push in or pull up on the outer collar to activate the function.

Bumper Hitch Hydraulic Jack Valve

Pull Out/Push In to manually operate the jack.



2 Function



Conveyor Raise/Lower

- * Pull out to lower conveyor.
- ORANGE Wire Labeled: Conveyor Lower - Top Solenoid
- * Push in to raise conveyor.
- YELLOW Wire Labeled: Conveyor Raise - Bottom Solenoid

Conveyor On/Off

- Screw In to override and operate the conveyor.
- PURPLE Wire Labeled: Conveyor On/Off

2003034 Rev. 4

SECTION V

Parts


Please visit www.unverferth.com/parts/ for the most current parts listing.

Door Components & Frame Decals.....	5-2
Pivot Arm & Conveyor Decals.....	5-4
Stationary Bracket Components.....	5-6
Scale Components.....	5-8
Pivot Arm Components.....	5-10
Pivot Arm Mounting Components to Platform.....	5-12
Platform Components.....	5-14
Hydraulic Components.....	5-16
Control Valve - 2 Function (Stackable Valve).....	5-18
Undercarriage Components.....	5-20
Touch-Up Paint.....	5-23
Axle & Wheel Components.....	5-24
Spare Tire Kit Components.....	5-25
Pivot Arm Mounting Components to Conveyor.....	5-26
Conveyor Controller Components.....	5-27
Hopper Components.....	5-28
Idler End Components.....	5-30
Discharge Spout Components.....	5-32
Power Pak Components.....	5-34
Power Pak Mounting Components.....	5-36
Platform for Units Less Undercarriage.....	5-37
Enclosure Components.....	5-38
Telescopic Spout Components (Optional).....	5-40
Conveyor Spout Light Kit (Optional).....	5-41
Hopper Cover (Optional).....	5-42
Electric Breakaway Components.....	5-42
2-Function Wireless Remote Control (Optional).....	5-43
Hydraulic Jack for Bumper Hitch Kit #2005116TS (Optional).....	5-44
License Plate/Lamp Holder Assembly (Optional).....	5-46
AG Decal Package (Optional) - SMV, SIS Decals, & Reflectors.....	5-47


FOR SCALE INFORMATION, PLEASE REFER TO YOUR SCALE MANUAL.

Door Components & Frame Decals


Please visit www.unverferth.com/parts/ for the most current parts listing.



Front, Left-Hand View



Rear, Left-Hand View



Front, Right-Hand View


Door Components & Frame Decals

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9388-052	Carriage Bolt 3/8-16UNC x 1 1/4	4	Grade 5
2	91263	Large Flange Nut 3/8-16UNC	4	
3	29261TS	Spacer Bar	2	
4	25977B	Latch	1	
5	9390-003	Capscrew 1/4-20UNC x 3/4	1	Grade 5
6	29078TS	Door Weldment	1	
7	9936	Locknut 1/4-20UNC	1	
8	2000959TS	Chute Weldment	1	
9	27741B	Tool Box Strap	1	
10	902456	Tool Box	1	
11	9390-028	Capscrew 5/16-18UNC x 3/4	2	Grade 5
12	9807	Locknut 5/16-18UNC	2	
13	901833	Decal UM	2	
14	235161	Decal, DANGER "Flammable"	1	
15	95445	Decal, WARNING "High-Pressure Fluid"	1	
16	98350	Decal, WARNING "No Riders"	1	
17	97961	Decal, WARNING "Read and Understand"	1	
18	91605	Decal, FEMA	1	
19	2001622IV	Talc Applicator Hole Cover	1	
20	9473	Self Drilling Screw 1/4-14 x 3/4	3	

Pivot Arm & Conveyor Decals

Please visit www.unverferth.com/parts/ for the most current parts listing.




Pivot Arm & Conveyor Decals

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	95445	Decal, WARNING (High Pressure)	1	
2	TA1-906109-0	Decal, WARNING (Moving Parts)	2	
3	95839	Decal, WARNING (Pinch Point)	2	
4	9501790	Decal, IMPORTANT	1	
5	901607	Decal, UM Oval	2	
6	901705	Unverferth Logo	2	
7	902685	Decal "Lock/Unlock"	1	
8	98229	Decal, WARNING (Lower Equipment)	2	
9	95839	Decal, WARNING (Pinch Point)	2	
10	95445	Decal, WARNING (High Pressure)	2	
11	901478	Decal, DANGER (Electrocution Hazard)	2	

Stationary Bracket Components

Please visit www.unverferth.com/parts/ for the most current parts listing.





Stationary Bracket Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	29070TS	Stationary Bracket	4	
2	9390-138	Capscrew 5/8-11UNC x 7	8	Grade 5
3	9801	Locknut 5/8-11UNC	8	

Scale Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Scale Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	29065TS	Scale Bracket Weldment	4	
2	900513	Grommet/Rubber 2" Dia.	2	
3	901173	Weigh Bar	4	
4	903108	Flat Washer 5/8" (Stainless Steel)	16	
5	9390-065	Capscrew 3/8-16UNC x 3 1/2	8	Grade 5
6	9390-138	Capscrew 5/8-11UNC x 7	8	Grade 5
7	9801	Locknut 5/8-11UNC	8	
8	9928	Locknut 3/8-16UNC	8	
9	2002132	Common Scale Wiring Harness	1	
10	9500374	2520 Scale Indicator	1	
11	9390-003	Capscrew 1/4-20UNC x 3/4	2	Grade 5
12	9936	Locknut 1/4-20UNC	2	
13	9000106	Cable Tie 6"	16	
	9000107	Cable Tie 15 1/2"	6	
	94038	Cable Tie 32"	2	
14	21903	Connector	1	
15	26554	Heat Shrink Tube	2	
16	91023	Butt Connector	2	
17	9007102	Roll Printer Kit	1	NOT SHOWN

Pivot Arm Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Pivot Arm Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	29248	Pin 3/4" Dia.	2	
2	9349	Bearing Cup LM501310	2	
3	29974TS	Cam Weldment	1	
4	9390-007	Capscrew 1/4-20UNC x 1 1/2	2	
5	9936	Locknut 1/4-20UNC	4	
6	24023TS	Handle	2	
7	92928	Hand Grip 3/4" ID	2	
8	27750TS	Latch Weldment	1	
9	27755	Pin 3/8" Dia.	1	
10	9392-056	Roll Pin 1/8" Dia. x 3/4"	2	
11	9928	Locknut 3/8-16UNC	1	
12	9390-061	Capscrew 3/8-16UNC x 2 1/2	1	
13	99860	Spring 2 1/4" Long	1	
14	9247	Bearing Cone LM501349	2	
15	9355	Seal 2 1/4"	2	
16	9003869	Hand Grip 3/8" ID	1	
17	91160	Grease Zerk	2	
18	903145-018	Retaining Ring 3/4" Nom.	4	
19	82044	U-Channel	1	
20	9388-052	Carriage Bolt 3/8-16UNC x 1 1/4	6	
21	91263	Flange Nut 3/8-16UNC	6	
22A	29220CG	Latch Assembly LH (SHOWN)	1	Includes Items 23A though 31
22B	29221CG	Latch Assembly RH	1	Includes Items 23B though 31
23A	29200CG	Latch Plate LH	1	
23B	29201CG	Latch Plate RH	1	
24A	29217CG	Inside Plate LH	1	
24B	29218CG	Inside Plate RH	1	
25	29209	Double Threaded Pin	2	
26	29219	Latch Pin	2	
27	91263	Flange Nut 3/8-16UNC	2	
28	9800	Locknut 1/2-13UNC	2	
29	903141	Extension Spring	2	
30	9928	Locknut 3/8-16UNC	4	
31	902603	Hand Grip	2	

Pivot Arm Mounting Components to Platform

Please visit www.unverferth.com/parts/ for the most current parts listing.




Pivot Arm Mounting Components to Platform

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2000189	Bearing Assembly	2	
2	2001301	Plate/Segment	1	
3	22018	Bushing 3/8" OD	2	
4	23951	Bushing	2	
5	24863	Plate/Segment	2	
6	27512	Pin Weldment 1 1/4" Dia. x 9 7/8"	1	
7	27922	Pin Weldment 1" Dia. x 7 3/4"	1	
8	28453TS	Latch Weldment	1	
9	29032TS	Pivot Weldment	1	
10	29414TS	Stop Bracket	2	
11	29970TS	Pivot/Hub Weldment Splined Shaft 2" Dia.	1	
12	29973TS	Push Rod	1	
13	9005639	Flange Nut 5/16"-18UNC	6	Stainless Steel
14	9007908-025	Carriage Bolt 5/16"-18UNC x 1"	6	Stainless Steel
15	901169	Rubber Bumper	2	
16	901186	Poly Washer	1	
17	902361	Cylinder 2 1/2 x 4	1	
	2004322	Seal Kit		
18	902602	Spring 1" Long	1	
19	902616	Spring 5" Long	1	
20	91263	Flange Nut 3/8"-16UNC	14	
21	9388-052	Carriage Bolt 3/8"-16UNC x 1 1/4" G5	14	
22	9390-006	Capscrew 1/4"-20UNC x 1 1/4" G5	2	
23	9390-034	Capscrew 5/16"-18UNC x 2" G5	1	
24	9390-037	Capscrew 5/16"-18UNC x 2 3/4" G5	1	
25	9390-062	Capscrew 3/8"-16UNC x 2 3/4" G5	1	
26	9390-187	Capscrew 1"-8UNC x 3" G5	2	
27	9391-046	Cotter Pin 3/16" Dia. x 2"	1	
28	9392-159	Roll Pin 5/16" Dia. x 2"	1	
29	9393-020	Slotted Nut 1"-14UNS	1	
30	9405-064	Flat Washer 1/4" USS	2	
31	9405-086	Flat Washer 1/2" SAE	1	
32	9405-116	Flat Washer 1" SAE	2	
33	9405-118	Flat Washer 1" USS	2	
34	9500091	Nylon Washer	1	
35	9500423	Pin 1" Dia. x 5 1/8"	1	
36	9663	Lock Nut/Top 1-8"UNC	2	
37	96976-040	Thin Locknut 1-14UNS	1	
38	9800	Lock Nut/Top 1/2-13UNC	1	
39	9807	Lock Nut/Top 5/16"-18UNC	2	
40	98580	Flange Screw 5/16"-18UNC x 1 1/4" G5	2	
41	9928	Lock Nut/Top 3/8"-16UNC	1	
42	9936	Lock Nut/Top 1/4"-20UNC	3	

Platform Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Platform Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2010229IV	Cover Panel Weldment =Ivory White=	2	
2	27825IV	Hopper Weldment =Ivory White=	2	
3	27827TS	Hopper Cover =Tan Speckle=	2	
4	9388-025	Carriage Bolt 5/16"-18UNC x 1"	24	Grade 5
5	91257	Large Flange Hex Nut 5/16"-18UNC	24	
6	27826	Rubber Hopper	2	
7	902346	Elevator Bolt 1/4"-20UNC x 1"	4	
8	902006	Elevator Bolt 1/4"-20UNC x 3/4"	14	
9	97189	Large Flange Hex Nut 1/4"-20UNC	18	
10	9093	Klik Pin 3/16" Dia.	2	
11	29030IV	Side Panel Weldment =Ivory White=	2	
12	9405-088	Flat Washer 1/2" USS	8	
13	9390-101	Capscrew 1/2"-13UNC x 1 1/2"	8	Grade 5
14	24550	Bushing 1/2" Long	8	
15	9800	Locknut 1/2"-13UNC	8	
16	91144-186	Spiral Pin 5/16" Dia. x 2"	2	
17	902642	Decal, Unverferth Seed Pro	2	
18	9502348	Decal, Model Seed Pro 210	2	
19	2001336	Pin Weldment	2	
20	900152	Foam Rubber	2	
21	29020IV	Platform Weldment =Ivory White=	1	
22	903108	Flat Washer 5/8" (Stainless Steel)	8	
23	9500091	Nylon Washer 3/4"	2	

Hydraulic Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Hydraulic Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	9500806	Hydraulic Motor w/Keyed Shaft	1	
	901649	Woodruff Key 1/4" x 1"	-	
	91687	Seal Kit for Hydraulic Motor	-	
2	93607	Adapter 3/4-16 JIC Male x 7/8-14 O-Ring Male	2	
3	902837	Hose 1/2" x 310"	2	
4	2003034	Decal, Valve Manual Override Operation	1	
5	9500855	Stackable Control Valve - 2 Section	1	
6	902361	Cylinder 2 1/2" x 4" (3000 PSI)	1	
	99515	Ball Valve 3/4-16UNF-2A Threaded x 1 7/8 W/3 O-Rings	-	
	2004322	Seal Kit For Ball Valve	-	
7	9003744	90° Elbow 9/16-18 JIC Male x 9/16-18 O-Ring Male w/ .030 Restrictor	2	
8	9500425	Hose 1/4" x 72"	2	
9	9001495	Adapter 9/16-18 JIC Male x 9/16-18 O-Ring Male	2	
10	9864	Adapter 3/4-16 JIC Male x 3/4-16 O-Ring Male	2	
11	93607	Adapter 3/4-16 JIC Male x 7/8-14 O-Ring Male	1	
12	93683	90° Elbow 3/4-16 JIC Male x 3/4-16 JIC Female Swivel Nut	1	
13	93599	90° Elbow 3/4-16 JIC Male x 7/8-14 O-Ring ADJ Male Boss	1	
14	902836	Hose 1/2" x 24"	2	
15	9405-070	Flat Washer 5/16" USS	3	
16	2002553TS	Mounting Plate	1	
17	9390-044	Capscrew 5/16"-18UNC x 5"	3	
18	9807	Locknut 5/16"-18UNC	8	
19	9390-030	Capscrew 5/16"-18UNC x 1" G5	4	
20	9004075	Spiral Hose Wrap	3	
21	97189	Large Flange Hex Nut 1/4"-20UNC	4	
22	9500067	Isolator	2	
23	2005069TS	Relay Mount Weldment	1	
24	9390-055	Capscrew 3/8"-16UNC x 1" G5	2	
25	9928	Lock Nut/Top 3/8"-16UNC	2	

Control Valve - 2 Function Components (Stackable Valve)

Please visit www.unverferth.com/parts/ for the most current parts listing.




Control Valve - 2 Function Components (Stackable Valve)

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	9500855	Valve Assembly w/End Cover Assembly	1	Includes items 2 through 18
2	9500879	Valve Body Only	1	
3	902347	Orifice Plug 0.025, 5/16-24UNF Thread, 0.125 Allen Hex Socket	1	
4	902825	Port Plug 7/16-20UNF Hex Head	1	
5	9003423	Plug 9/16-18 O-Ring Male w/Hollow Hex Socket	4	
6	902821	Check Valve	1	
	902853	Seal Kit	-	
7	9501428	Flow Regulator	1	
	9500116	Seal Kit	-	
8	902918	Relief Cartridge	1	
	903032	Seal Kit	-	
9	902842	Cartridge Valve 3/4-16UNF (3 Position, 4 Way)	3	
	902849	Seal Kit for 3 Position, 4 Way Cartridge Valve	-	
	902813	Coil Nut 1/2-20UNF	-	
10	9500131	Cartridge - Proportional 1 1/16-8UNC Thread	1	
	9500132	Seal Kit	-	
11	9500136	Proportional Coil	1	
12	902811	Coil - Electromagnetic	6	
13	902812	Coil Spacer	3	
14	9500600	Seal Kit - Valve Assembly O-Rings	-	
15	9500306	Valve End Cover Assembly without Power Beyond	1	Includes Item #17
16	98048	Hex Plug 3/4-16 O-Ring Male	1	
17	9390-059	Capscrew 3/8-16UNC x 2	3	
18	9405-074	Flat Washer 3/8" SAE	3	

Undercarriage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



Undercarriage Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	29237TS	Fender Step/Mount LH	1	
2	29238TS	Fender Step/Mount RH	1	
3	29240TS	Fender Weldment	2	
4	900956	Grommet	8	
5	900954	Light/Amber (Round)	2	
6	9405-086	Flat Washer 1/2" SAE	22	
7	9390-100	Capscrew 1/2-13UNC x 1 1/4	14	Grade 5
8	9800	Locknut 1/2-13UNC	16	
9	9390-113	Capscrew 1/2-13UNC x 5	8	
10	9000106	Cable Tie 6" Long	A/R	
11	25788TS	Hitch Weldment 10' Undercarriage w/Decals	1	SHOWN
	2009899TS	Hitch Assembly 10'	-	Includes Items 12, 13, 15-23, 30-32, 34-37, 43-45, 48
12	9405-098	Flat Washer 5/8" SAE	6	
13	9801	Locknut 5/8-11UNC	27	
14	25347B	Shim	2	
15	98792	Chain w/Hook & C-Link Asy	2	
16	9405-116	Flat Washer 1" SAE	2	
17	9663	Locknut 1-8UNC	2	
18	91299-184	Capscrew 1"-8UNC x 2 1/4"	2	Grade 8
19	902326	Jack Stand Weldment 8000#	1	
20	84979	Bent Pin 5/8" Dia.	1	
21	9805	Clevis Pin 5/8" Dia. x 4	1	
22	9806	Hairpin Cotter .148" Dia. x 2.687	1	
23	98487	Grommet 1 3/4" Dia.	8	
24	900956	Grommet	2	
25	900955	Light/Red (Round)	2	
26	97180	Light/Red (Oval)	2	
27	97182	Grommet	2	
28	99599	Cable Tie 8.39" Long	A/R	
29	94038	Cable Ties 32" Long	A/R	
30	902238	Flange Bolt 1/4-20UNC x 3 (Grade 5)	4	
31	9512	Screw/Self Drill 1/4-14 x 1	2	
32	25045	Front Wiring Harness 165"	1	
33	25046	Rear Wiring Harness 352"	1	

(Continued on next page)

Undercarriage Components (continued)

Please visit www.unverferth.com/parts/ for the most current parts listing.


ITEM	PART NO.	DESCRIPTION	QTY	NOTES
34	25003	Conspicuity Marking 18"	10	
35	97961	Decal WARNING (Read & Understand Manual)	1	
36	900786	Breakaway Electric Switch Complete	1	
37	902764	Battery w/Charger & Box	1	
38	29230TS	Light Bar Weldment	1	
39	9390-125	Capscrew 5/8-11UNC x 2 1/4	16	Grade 5
40	903108	Flat Washer 5/8" (Stainless Steel)	40	
41	9388-102	Capscrew 1/2-13UNC x 1	4	Grade 5
42	91267	Flange Nut 1/2-13UNC	4	
43	2000357TS	Ball Hitch Kit with Mounting Hardware	1	
44	9390-134	Capscrew 5/8-11UNC x 5	3	Grade 5
45	9500710	Decal CAUTION (Transport Chains)	1	
46	2000264B	Optional Clevis Hitch Kit	-	
47	2000265B	Optional Pintle Hitch Kit	-	
48	9500345	Decal, CAUTION (Towing...)	1	

Touch-Up Paint

PAINT	PART NO.
Ivory White - Spray Paint (12oz)	901210
Tan Base Coat - Spray Paint (12oz)	9500474
Radiant Brass/Tan Speckle - Finishing Paint (12oz)	901297

Axle & Wheel Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	NOTES	
1	9390-123	Capscrew 5/8-11UNC x 1 3/4	Grade 5	
2	9801	Locknut 5/8-11UNC		
3	98115	Wheel/Tire Assembly 6 x 15	TL225/75D15	
	98395	Wheel Only		
4	903052B	Torsion Axle Assembly w/Brakes	Includes Items 5 through 21	
5	32651	Hub 6 Bolt Sub Assy with Cups & Studs	Includes Items 6 through 8	
	6	91812	Bearing Cup (25520)	
	7	91813	Bearing Cup (15245)	
	8	97346	Stud Bolt 1/2-20UNF x 2 (Grade 8)	
9	91822	Bearing Cone (25580)		
10	97342	Seal 2 1/4 ID x 3.376 OD		
11	91823	Bearing Cone (15123)		
12	97343	Washer/Key 1.032 ID		
13	97344	Slotted Jam Nut 1-14UNS		
14	97345	Hub Cap		
15	9390-055	Capscrew 3/8-16UNC x 1	Grade 5	
16	9404-021	Lock Washer 3/8"		
17	9394-006	Hex Nut 3/8-16UNC		
18	91875	Tapered Nut 1/2-20UNF		
19	9391-035	Cotter pin 5/32" Dia x 1 1/2		
20	97348	Electric Brake Cluster, LH		
21	97349	Electric Brake Cluster, RH		
22	903108	Flat Washer 5/8" (Stainless Steel)		
23	9746	Flat Washer 5/8"		

Spare Tire Kit Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	NOTES
	2000622TS	Spare Tire Kit	Includes Items 1 through 10
1	29736TS	Mounting Plate	
2	29744TS	Washer	
3	29751	Pin Weldment 1/2" Dia. x 6 5/8	
4	91323	U-Bolt 1/2-13UNC x 7 1/8	
5	9390-028	Capscrew 5/16-18UNC x 3/4	Grade 5
6	9500475	Handle Wing Nut 1/2-13UNC	
7	9800	Locknut 1/2-13UNC	
8	9807	Locknut 5/16-18UNC	
9	98115	Tire & Wheel Assembly (6 x 15)	TL225/75D15
10	TA500470	Lock Washer - External Tooth 1/2" I.D.	

Pivot Arm Mounting Components to Conveyor


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	28581TS	Retainer Cap	1	
2	9162	Hub Cap	1	
3	9393-015	Slotted Nut 3/4"-10UNC G2	1	
4	9391-027	Cotter Pin 1/8" Dia. x 2"	1	
5	2001804TS	Upper Pivot Weldment	1	
6	91160	Grease Zerk	2	
7	28496TS	Spring	1	
8	9002131	Capscrew 5/8"-11UNC x 5" Full Threaded	1	
9	9395-014	Hex Jam Nut 5/8"-11UNC	1	
10	2001834	Pin Weldment 1" Dia. x 9 3/4"	2	
11	9390-055	Capscrew 3/8"-16UNC x 1" G5	2	
12	9928	Lock Nut/Top 3/8"-16UNC	2	

Conveyor Controller Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	27627	Switch Assembly	1	
2	2002519	Wire Harness	1	
3	26505	Switch Retainer	1	
4	9473	Self-Drilling Screw 1/4-14 x 3/4	2	

Hopper Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Hopper Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
1	N/A	Plate	1	
2	2003191	Shoulder Bolt with 1/2"-13UNC Threaded	8	
3	901169	Rubber Bumper 1.7" Dia.	1	
4	9512	Screw/Self Drilling 1/4-14 x 1	6	
5	9501011	Nylon Washer	2	
6	2007602TS	Handle Weldment	1	
7	9405-086	Flat Washer 1/2" SAE	4	
8	9800	Locknut 1/2-13UNC	8	
9	92928	Grip/Handle Bar	2	
10	2003821TS	Pivot Weldment	1	
11	2007603TS	Bent Tube	1	
12	9390-032	Capscrew 5/16-18UNC x 1 1/2	2	
13	9807	Locknut 5/16-18UNC	4	
14	24964	Brush Holder	1	
15	901111	Nylon Brush	1	
16	2001058TS	Strap	2	
17	24986	Poly Strip	2	
18	91257	Flange Nut 5/16-18UNC	23	
19	24943TS	Stand Weldment	1	
20	24946	Pin	1	
21	91144-121	Spiral Pin 3/16" Dia. x 1 1/8"	2	
22	901044	Flange Screw 5/16"-18UNC x 1" G5	3	
23	9000117	Plug	2	
24	27110TS	Latch Weldment	1	
25	9390-035	Capscrew 5/16"-18UNC x 2 1/4" G5	1	
26	9390-042	Capscrew 5/16"-18UNC x 4" G5	1	
27	9405-070	Flat Washer 5/16"	1	
28	TA510035	Spring, Stop Pin	1	
29	9003869	Hand Grip	1	
30	2003862	Wear Guard	1	
31	2007952TS	Grate	1	
32	28486TS	Plate/Strap 3/4" x 7 1/2"	1	
33	26865	Seal	1	
34	97604	Large Flange Screw 5/16"-18UNC x 1" G5	6	
35	2003176TS	Link Plate 1 3/8" x 7 1/4"	2	
36	9500701	Vinyl Hopper	1	

Idler End Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Idler End Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	900608	Idler Pulley	1	
2	TA0-903088-0	Bearing w/ Flange	4	
3	23912TS	Adjustment Plate	1	
4	9388-024	Carriage Bolt 5/16-18UNC x 3/4	4	
5	9394-004	Hex Nut 5/16-18UNC	4	
6	9404-019	Lock Washer 5/16	4	
7	9394-006	Hex Nut 3/8-16UNC	10	
8	24756	Poly Strip	2	
9	97420	Flange Screw 1/4-20UNC x 3/4	14	
10	97189	Hex Nut / Large Flange 1/4-20UNC	20	
11	TA0-907104-0	Capscrew 3/8-16UNC x 1 3/4	1	
12	22018	Bushing	8	
13	9390-003	Capscrew 1/4"-20UNC x 3/4" G5	4	
14	9405-064	Flat Washer 1/4"	4	
15	9936	Locknut 1/4"-20UNC	8	
16	91257	Flange Nut 5/16-18UNC	23	
17	9500341	Carriage 5/16-18UNC x 1 3/4	6	
18	9500310	Idler Cover	3	
19	9405-052	Flat Washer 3/16" USS	4	
20	2003793TS	Shield	1	
21	TA0-902596-0	Latch/Draw Blade	1	
22	9500175	Rivet 3/16"	2	
23	2003807TS	Cleanout Door	1	
24	9501224	Conveyor Belt	1	
	9501506	Belt Splice Kit	-	
	9500087	Belt Splice Pin	-	
25	9003829	Button Head Socket 1/4"-20UNC x 3/4"	4	

Discharge Spout Components

Please visit www.unverferth.com/parts/ for the most current parts listing.



Discharge Spout Components

 Please visit www.unverferth.com/parts/ for the most current parts listing.


ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	93607	Adapter 3/4-16 JIC Male x 7/8-14 O-Ring Male	2	
2	2003772TS	Spout Weldment	1	
3	TA0-903088-0	Bearing w/Flange	4	
4	9390-102	Capscrew 1/2"-13UNC x 1 3/4" G5	2	
5	9394-006	Hex Nut 3/8"-16UNC	10	
6	97420	Flange Screw 1/4"-20UNC x 3/4"	14	
7	97189	Hex Nut/Large Flange 1/4"-20UNC	20	
8	9388-051	Carriage Bolt 3/8"-16UNC x 1"	8	
9	9404-021	Lock Washer 3/8"	8	
10	9405-076	Flat Washer 3/8"	10	
11	2003742TS	Adjustment Plate Weldment	1	
12	2003765TS	Adjustment Plate Weldment	1	
13	93400	Capscrew 1/2"-13UNC x 4 1/2"	2	
14	9394-010	Hex Nut 1/2"-13UNC	2	
15	901077	Drive Pulley	1	
16	2003762	Poly Strip	2	
17	24260	Seal	2	
18	901101	Flange Screw 1/4"-20UNC x 1"	4	
19	2003730TS	Cover/Top Shield	1	
20	91256	Screw/Large Flange 5/16"-18UNC x 3/4"	4	
21	22018	Bushing	8	
22	9390-003	Capscrew 1/4"-20UNC x 3/4" G5	4	
23	9405-064	Flat Washer 1/4"	4	
24	9936	Locknut 1/4"-20UNC	8	
25	901046	Knob	2	
26	2003487TS	Shield	2	
27	91257	Flange Nut 5/16"-18UNC	23	
28	9501220	Fenner Coupler	1	
29	9500341	Carriage Bolt 5/16"-18UNC x 1 3/4" G5	6	
30	9405-086	Flat Washer 1/2" SAE	4	
31	9388-027	Carriage Bolt 5/16"-18UNC x 1 1/2" G5	2	
32	9501256	Neoprene Deflector	1	
33	9500155	Spring Snap Hook	1	
34	902006	Elevator Bolt 1/4"-20UNC x 3/4"	6	
35	9500806	Hydraulic Motor w/Keyed Shaft	1	
	901649	Woodruff Key 1/4" x 1"	-	
	91687	Seal Kit for Hydraulic Motor	-	
36	9500310	Idler Cover	3	
37	24550	Bushing	2	
38	9800	Lock Nut/Top 1/2"-13UNC	8	
39	2003745TS	Deflector Weldment	1	

SEED PRO® BULK BOX CARRIER — Parts

Power Pak Components

Please visit www.unverferth.com/parts/ for the most current parts listing.

Honda nearest location:
USA: www.engines.honda.com
phone: 1-800-426-7701
Canada: www.honda.ca
phone: 1-888-9HONDA9



Power Pak Components


 Please visit www.unverferth.com/parts/ for the most current parts listing.

ITEM	PART NO.	QTY	DESCRIPTION
1	25508IV	1	Battery Cover
2	25515	1	Pump/Motor Mount Weldment
3	25519	1	Hydraulic Hose 3/4"
4	2007491B	1	Throttle Vertical Support
5	26823	1	Decal, IMPORTANT (Battery)
6	27163B	1	Strap
7	28664IV	1	Pan Weldment
8	28668IV	1	Pump Shroud
9	28670	1	Flap Seal Trim
10	28671IV	1	Battery Hold Down Strap
11	901370	1	Jaw Coupling 5/8" Bore
12	901371	1	Jaw Coupling 1" Bore
13	901372	1	Coupler Insert/Spider
14	-	1	Battery 12-Volt Top Post (Purchase Battery Locally)
15	901379	1	Straight 3/4" Hose ID Insert x 3/4-14 NPTF Male
16	901380	1	90° Elbow 3/4" Hose Insert x 1 1/16-12 O-ring Male
17	901404	1	Battery Cable 14" (Black)
18	9502625	1	Battery Cable 14 13/16" (Red)
19	901507	1	Decal, IMPORTANT (Close Fuel Valve)
20	901567	2	Internal Lock Washer
21	901694	1	Pump 10 CU (2000RPM)
	903056	-	Key
22	901771	1	Site Gauge Assembly
23	902026	1	Decal, WARNING (Sparks)
24	902275	1	Choke Stay Control
25	902368	1	Ball Joint Quick Disconnect 10-32UNF Threaded Both Ends
26	902927	1	Honda 11.7 Net HP
	903057	-	Key on Output Shaft
27	902892	1	Clamp Body (2-Halves)
28	902893	1	Cover Plate - Clamp
29	902898	1	Hydraulic Steel Line 1/2" OD
30	902910	1	Suction Strainer w/Magnet
31	902915	1	In-Tank Return Filter 9.2GPM
	A 902123	-	Cover
	B 902124	-	Bowl
	C 902905	-	Gasket
	D 902906	-	O-Ring 2 5/16" Dia.
	E 902907	-	O-Ring 1 31/32" Dia.
	F 902911	-	Filter Gauge
		-	Adapter Street 90° Elbow
	G 902912	-	Filter Replacement
	H 902125	-	Compression Spring
32	91263	4	Large Flange Nut 3/8-16UNC

ITEM	PART NO.	QTY	DESCRIPTION
33	93599	1	90° Elbow 3/4-16 JIC Male x 7/8-14 O-ring Adj. Male
34	9388-053	4	Carriage Bolt 3/8-16UNC x 1 1/2 (Grade 5)
35	9390-005	2	Capscrew 1/4-20UNC x 1 (Grade 5)
36	9390-007	2	Capscrew 1/4-20UNC x 1 1/2 (Grade 5)
37	903161-014	2	Large Flange Screw 5/16-18UNC x 1/2
38	9390-055	2	Capscrew 3/8-16UNC x 1 G5
39	9390-056	4	Capscrew 3/8-16UNC x 1 1/4
40	9394-004	1	Hex Nut 5/16-18UNC
41	9404-017	2	Lock Washer 1/4"
42	9404-019	1	Lock Washer 5/16"
43	9404-021	6	Lock Washer 3/8"
44	9405-070	1	Flat Washer 5/16" USS
45	9405-074	2	Flat Washer 3/8" SAE
46	97189	2	Large Flange Hex Nut 1/4-20UNC
47	97420	2	Flange Screw 1/4-20UNC x 3/4
48	9501669	1	Fluted Knob
49	98048	1	Plug 3/4-16 O-ring Male w/Hollow Hex Socket
50	9830-016	3	Hex Nut #10-32 (Grade 2)
51	9864	1	Adapter 3/4-16JIC Male x 3/4-16 O-ring Male
52	98830	1	Grommet/Rubber 1 1/4" Dia.
53	9936	2	Locknut 1/4-20UNC
54	99692	1	O-Ring Plug
55	99888-065	2	Socket Head 3/8-16UNC x 1 1/2 (Grade 8)
56	TA800912	2	Hose Clamp SAE#16
57	2009998	1	Engine Harness
58	94917-038	1	Capscrew M6x16
59	2007490B	1	Throttle Bracket
60	9502619	1	Battery Disconnect Switch
	9502620	-	Service Key
61	9405-062	2	Flat Washer 1/4" SAE
62	9390-004	2	Capscrew 1/4"-20UNC x 7/8"
63	9502623	1	Decal, On/Off Switch
64	9502626	1	Batter Cable 14 13/16" (Red)
	901405		Non-Disconnect Cable 18" (Red)
65	9502661	1	Nylon Lanyard 8"
66	97489	1	Split Ring 1"
67	9500076	1	Rectifier
68	9502847	1	Facenut 0.570" Dia.
69	9502848	1	Locking Ring

Power Pak Mounting Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	--	Power Pak Assembly	-	
2	901044	Serrated Flange Bolt 5/16-18UNC x 1	1	Grade 5
3	901169	Rubber Bumper 1.7" Dia.	4	
4	91257	Large Flange Hex Nut 5/16-18UNC	1	
5	9390-059	Capscrew 3/8-16UNC x 2	3	Grade 5
6	9405-076	Flat Washer 3/8" USS	3	
7	9928	Locknut 3/8-16UNC	3	

Platform for Units Less Undercarriage


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2003078TS	Adapter Bracket Weldment =Tan Speckle=	2	
2	2003079TS	Stand Weldment =Tan Speckle=	2	
3	2003126TS	S-Bracket =Tan Speckle=	2	
4	901710	Cavity Plug (Green)	2	
5	9390-101	Capscrew 1/2-13UNC x 1 1/2 (Grade 5)	4	
6	9390-112	Capscrew 1/2-13UNC x 4 1/2 (Grade 5)	16	
7	98004	Connector Assembly Shroud 2-Male Contacts	1	
8	9405-086	Flat Washer 1/2" SAE	40	
9	9501151	Round Plug	12	
10	9800	Locknut 1/2-13UNC	20	
11	9000106	Cable Tie 7 1/2" Long	1	
12	2003075B	Backer Plate	4	

Enclosure Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




Enclosure Components

Please visit www.unverferth.com/parts/ for the most current parts listing.


ITEM	PART NO.	DESCRIPTION	QTY	NOTES
	2008492TS	Common Enclosure Assembly =Tan Speckle=	1	Includes Items 1 through 35
1	2002538TS	Keyswitch/Throttle/Choke Plate =Tan Speckle=	1	
2	27134TS	Lever =Tan Speckle=	1	
3	2002539TS	Cover =Tan Speckle=	1	
4	22018	Bushing	2	
5	9405-064	Flat Washer, 1/4"	2	
6	9936	Lock Nut, 1/4"-20UNC G5	4	
7	9390-003	Capscrew, 1/4"-20UNC x 3/4" G5	4	
8	901718	Key	2	
9	901719	Keyswitch Nut	1	
10	901720	Ignition Starter	1	
11	95236	Flat Washer, 7/16"	2	
12	99913	Belleville Washer, 1/2"	1	
13	9405-088	Flat Washer, 1/2"	1	
14	9390-102	Capscrew, 1/2"-13UNC x 1 3/4" (Grade 5)	1	
15	9800	Lock Nut, 1/2"-13UNC (Grade 5)	7	
16	901811	Decal, "Power Keyswitch"	1	
17	9220	Draw Latch	1	
18	902321	Decal, "Throttle"	1	
19	902322	Decal, "Choke"	1	
20	9500339	Control Cable with Ball Joint	1	
21	9500340	Control Cable with Handle	1	
22	9830-016	Hex Nut, #10-32UNF G2	8	
23	97489	Split-Ring	1	
24	9404-013	Lock Washer #10	3	
25	2002540TS	Remote Enclosure Weldment =Tan Speckle=	1	
26	2002630TS	Cable Mount Bracket =Tan Speckle=	1	
27	29612	Spacer 1 3/8" OD	1	
28	900152	Tape/Black Foam Rubber with Adhesive Back	3	
29	9003503	Rivet	2	
30	901334	Grommet 2 1/4" ID	1	
31	903172-343	Pan Head #10-32UNF x 1/2" Phillips, Machine Screw	2	
32	9388-002	Carriage Bolt 1/4"-20UNC x 3/4" G5	2	
33	9501811	Conveyor Speed Module with Smooth Start	1	
34	97189	Hex Nut/Large Flange 1/4"-20UNC	2	
35	97961	Decal, WARNING "Read and Understand Manual"	1	
36	2008018TS	Enclosure Mounting Bracket =Tan Speckle=	1	
37	2003162TS	Side Mounting Bracket =Tan Speckle=	1	
38	9390-100	Capscrew 1/2"-13UNC x 1 1/4" G5	2	
39	9390-099	Capscrew 1/2"-13UNC x 1" G5	1	
40	9388-102	Carriage Bolt 1/2"-13UNC x 1" G5	1	
41	9390-113	Capscrew 1/2"-13UNC x 5" G5	2	

Telescopic Spout Components


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART	DESCRIPTION	QTY
	2005066	Standard Spout Bundle 6" x 48"	-
1	TAAU14170	4' Flex Spout	1
2	98060	Clamp 6" Dia.	1
3	94038	Cable Tie 32" Long	2




ITEM	PART	DESCRIPTION	QTY
	27629	2-Stage Telescopic Spout	-
1	22577	Canvas Sock	1
2	9003378	Rivet 3/16"	6
3	98060	Clamp 6" Dia.	1
4	94038	Cable Tie 32" Long	2



ITEM	PART	DESCRIPTION	QTY
	22578	3-Stage Telescopic Spout (Option)	-
1	21759	18" Flex Spout	1
2	98060	Clamp 6" Dia.	1
3	22577	Canvas Sock	1
4	94038	Cable Tie 32" Long	2

Optional Conveyor Spout Light Kit (2004450)

Please visit www.unverferth.com/parts/ for the most current parts listing.




ITEM	PART NUMBER	DESCRIPTION	QTY	NOTES
1	2002125	Harness - Lights	1	
2	2002489	Light Harness	1	
3	9000106	Cable Tie 7 1/2"	20	
4	301213	Work Light W/Switch	3	
5	9500977	Contura III Switch	1	
6	9500978	Switch Actuator	1	

Optional Hopper Cover #901472



Electric Breakaway Components

Please visit www.unverferth.com/parts/ for the most current parts listing.




ITEM	PART NO.	DESCRIPTION	NOTES
1	900786	Breakaway Electric Switch w/Pull Pin	
2	900787	Battery 12V Charger	
3	902179	Battery Box w/Decals	
4	900789	Battery 12V Rechargeable	5.0 AMP-HR
5	901950	Pull Cord Breakaway Switch	
6	902764	Battery with Charger & Box (NOT SHOWN)	Includes Items 2, 3, & 4

Optional 2-Function Wireless Remote Control Pkg #2008026

Please visit www.unverferth.com/parts/ for the most current parts listing.



Hydraulic Jack for Bumper Hitch Kit #2005116TS (Option)




Hydraulic Jack for Bumper Hitch Kit #2005116TS (Option)

ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	2005100TS	Hydraulic Jack Assembly	1	
2	93419	U-Bolt 5/8"-11UNC	4	
3	9500058	Clamp Set	3	
4	9500059	Cover Plate	3	
5	9404-019	Lock Washer 5/16"	3	
6	9390-033	Capscrew 5/16"-18UNC x 1 3/4"	3	Grade 5
7	97445	90° Elbow 9/16"-18 JIC Male x 9/16"-18 O-Ring Male	1	
8	9801	Locknut 5/8"-11UNC	8	
9	9501021	Valve Assembly	1	
	9500600	Seal Kit for Stackable Valves	-	
10	900016	Adapter 9/16"-18 JIC Male x 9/16"-18 O-Ring Male with 0.060 Restrictor	2	
11	9500602	Hydraulic Hose 1/4" x 240" 90° Elbow 9/16"-18 JIC Female x 9/16"-18 JIC Female	2	
12	2002811	Wire Harness 370"	1	
13	94037	Cable Tie .35 x 15 1/2"	10	
14	2005833	Loop Connector	1	
15	9001495	Adapter 9/16-18 JIC Male x 9/16-18 O-Ring Male	1	
16	9876	90° Elbow 9/16-18 JIC Male x 9/16-18 JIC Female Swivel Nut	1	
17	9390-067	Capscrew 3/8-16UNC x 4	3	Grade 5 NOT SHOWN
	9390-075	Capscrew 3/8-16UNC x 8		
	9390-9500625	Capscrew 3/8-16UNC x 10		
	9390-752	Capscrew 3/8-16UNC x 14		

Optional License Plate/Lamp Holder Assembly Kit #25481


Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY	NOTES
1	900368	Sealed Splice Connector	1	
2	93769	License Plate/Lamp Holder	1	
3	9388-002	Carriage Bolt 1/4-20UNC x 3/4	2	
4	9473	Screw/Self 1/4-14 X 3/4	2	
5	97189	Hex Nut/Large Flange 1/4-20UNC	2	

AG Decal Package (Optional) - SMV, SIS Decals, & Reflectors

Please visit www.unverferth.com/parts/ for the most current parts listing.



ITEM	PART NO.	DESCRIPTION	QTY.	NOTES
	2010513	AG Decal Package Option		
1	9003126	Reflector, RED	1	
2	9003127	Reflector, AMBER	2	
3	9008714	Decal, Rear SIS 20MPH	2	
4	97530	Decal, SMV Emblem	1	



Unverferth[®]
Manufacturing Company, Inc.

www.unverferth.com