

FREQUENTLY ASKED QUESTIONS

Q Why is my toolbar is not running level?

A Verify the toolbar leveled when the unit is in the ground and follow the leveling procedures as described in the manual.

Q How to correct anhydrous leaking out the cooler vapor tubes?

A Check to make sure all the bleeders are closed, Bleed the system down, and check plumbing for leaks. Next try rebuilding the cooler with a seal kit and inspect the internals for rusting/pitting if it is an old cooler.

Q I am under applying, how can I hit rate?

A Check correct orifice sizing on the cooling line to the cooler, then check tank pressure. Verify configuration of the unit and weather as these two combinations affect rate output.

Q How do I know my flow meter calibration is correct?

A Read the tag on flow meter for lbs of N and make sure the rate controller shows the correct number. Also, verify the rate is set to per 10lbs of N.