Unverferth®
Manufacturing Company, Inc.

# FREQUENTLY ASKED QUESTIONS

**Q** Do I need anything special to carry my head?

**A** This depends on the head. Have your dealer refer to the Header Transport Selection Guide, reference the "Fitments" section on umequip.com or call Unverferth Manufacturing.

**Q** My combine cannot reach high enough to mount the head. What can I do?

**A** To reduce ground height, we are limited to the rest pad height adjustment pins and utilizing smaller tires. If needed, the rest pad backstop can be flipped down while loading or unloading.

**Q** What do I need to carry an FD2 head?

**A** We require our support arm extension kit 34603B to carry FD2 heads. This is only available on AWS/6WS units.